


27,000 SIZES • 2,000 MATERIALS • ENDLESS POSSIBILITIES

# WASHERS

## 2013 CATALOG

**FAST  
DELIVERY**

**ISO  
9001:2008  
REGISTERED**



**BOKER'S, INC.**

WASHERS, SPACERS & SHIMS

SINCE 1919



# Washers, Spacers and Shims Made to Order

Choose from a wide variety of sizes and materials with no tooling charges when you order non-standard washers and spacers from Boker's 2013 Catalog. With outside diameters of 0.080" to 5.140" and a wide variety of inside diameters and thicknesses as well as material variations, you have endless possibilities. In the .500" OD size alone, there are over 200 options available.



## Superalloys Available

Boker's offers wrought cobalt, iron and nickel-base superalloys together with the company's industry-best selection of over 2,000 washer and spacer materials. Superalloys provide superior mechanical strength, good surface stability, corrosion resistance, and can withstand high temperatures without oxidizing or losing mechanical properties. The new materials include 3 varieties of wrought cobalt-base, 7 varieties of wrought iron-base, and 11 varieties of wrought nickel-base superalloys. Boker's features the capabilities to produce short, medium or long run washer and spacer orders in over 27,000 non-standard sizes with no tooling charges.



## Special Shapes and Sizes

As the photo above shows, Boker's can make special washer shapes and sizes, up to 12" in outside diameter. These custom items are made with very low tooling costs. They can be easily quoted by sending, faxing or emailing us your print. Tell us what you need and we'll make it to your exact specifications.

## Metric Sizes No Problem!

All Boker's washer sizes are also available in metric measurements and searchable at [bokers.com](http://bokers.com). To specify a specific metric size simply send us your prints or call toll-free at (800) 927-4377.



## Fast Delivery

At Boker's, fast delivery is the standard practice. Boker's can also meet your delivery and stocking requirements with flexible "Just-In-Time" (J.I.T.) and "Dock-to-Stock" programs. In case of an urgent requirement, your order can also be expedited for even faster delivery.

## Minimum Quantity

Orders require a minimum production run of 100 pieces, though deliveries of lesser quantities can be arranged. Per-unit costs rapidly decrease as the quantity increases.

## High Volume Orders

Increased washer production capacity and enhanced technology allow Boker's quality non-standard washers to be manufactured quickly well into the millions.

## Quality Assurance & Certification

-  C OF C
-  PPAP
-  DFARS
-  RoHS
-  S.P.C.
-  F.A.I.
-  AS9102
-  DOCK-TO-STOCK
-  REACH
-  ITAR

**ISO  
9001:2008  
REGISTERED**



### ISO 9001:2008 Registered

Boker's takes their manufacturing practices very seriously and maintains an ISO 9001:2008 registered status. This means when you purchase your products from Boker's you will have the confidence our processes are efficient and effective.

### Secondary Operations

Boker's provides the secondary operations you require including deburring, tapping, reaming, counterboring, and spofacing to name a few. Boker's also has approved vendors for heat treating and plating. See page 4 for a full list of equipment and capabilities.

### Non-Metallic Washers & Spacers

The thickness ranges stated in this catalog are minimum and maximum values for metallic washers and spacers but may be suitable for non-metallic pieces as well. When the thickness stated for a particular tool is .005"-.010", that tool can be considered for non-metallic items from .005" to .125" thick. These washer tools are in bold type within the catalog for easy reference.

When determining the proper sized tool for your washer or spacer, the outside diameter (O.D.) listed in the catalog typically remains the same for both the metallic and non-metallic part. The inside diameter (I.D.), however, may shrink by as much as ten percent of the material thickness depending on the material used and its thickness.

Boker's estimates of these shrinkage factors are as follows:

MATERIAL	FACTOR (%)
Polycarbonate	10-12
Nylon	10
Polyethylene	10
Acetal	10
PVC	10
A.B.S.	10
MD Nylon	10
Polypropylene	5-10
PTFE	5
Polyester	5
Linen Phenolic	5
Vulcanized Fiber	0-5
FR-4	0-5
G-10	0-5

For assistance in determining the actual tool to be used, please contact one of our estimators at (800) 927-4377.



**Owner Operated Since 1919**



### Over 2,000 Materials

To expedite your order and shorten delivery time, Boker's has immediate access to over 2,000 commonly specified and hard-to-find materials including low carbon, cold rolled strip and sheet steel; SAE 1050, 1075, and 1095 spring steel; blue and black temper spring steel; low alloy steel sheets; brass; copper; nickel silver; beryllium copper; phosphor bronze; stainless steel; aluminum; and several non-metallic materials such as acetal, PTFE, polyester, nylon, fiber, polyethylene, and NEMA grade laminates. Plus varieties of wrought cobalt, iron and nickel-base superalloys for demanding, high-performance applications. Certificates of Compliance or chemical/physical analysis are available upon request. Whatever your needs, if it can be stamped, Boker's can turn it into your washer or spacer.

### Precision Fabrication

It's important for you to know that the washers and spacers you get from Boker's are going to meet your specifications. From the first part to the last... Those aren't just words at Boker's, but the goal of the quality-conscious personnel who produce your precision parts with tolerances as close as the specifications demand, and sometimes even closer. Metallic washers and spacers are flat, tumble deburred, and can be heat treated or plated. As a final check, your parts are sent to the inspection department before your order is shipped.

# Equipment and Capabilities List

Housed in over 90,000 square feet of buildings, the equipment listed below, as well as all tooling, are protected by a central station security and fire system.



## Tool & Engineering Department

- CAD CAM Drawing System
- Kitamura Vertical Machine Center
- Mori Seiki Vertical Machine Center (20" x 40")
- Mori Seiki High Precision C.N.C. Lathes
- Digital Optical Comparator
- Cylindrical & Automatic Surface Grinders
- (3) Charmilles Wire E.D.M.s (14" x 21" x 8")
- Charmilles E.D.M. Drill

## Washer Department

- 18 Punch Presses (10 to 60 tons)
- Digital Servo Feeders
- Electric Coil Reels (1,200 lb. capacity)
- Coil Straighteners
- Tonnage Monitors

## Stamping Department

- 46 Punch Presses (10 to 200 tons)
- 2 High Speed Minster Progressive Die Presses (60 to 150 tons)
- Digital Servo Feeders
- Electric Coil Reels (1,200 lb. capacity)
- 48" Press Brake
- Optical Part Detection Systems
- Tonnage Monitors

## Raw Stock & Shear Department

- 2-10' Shears (.25" thick maximum)
- Stanat Model Rolling Mill
- Cooper Weymouth Roller Levelers
- Coil Set Straightener
- Wilder Coil Slitter
- Computer Inventory & Control System

## Heat Treating Department

- Electric High Temperature Hardening Furnace
- Electric Tempering Furnaces (all furnaces calibrated)

## Cleaning & Deburring Department

- Agitated Chemical Washing System
- Rotary Deburring Machines
- Vibratory Deburring Machines
- Centrifugal Tumblers
- Heated Centrifugal Dryers
- Lewis Ultrasonic Cleaner
- High Energy Deburring Machine

## Secondary Operations Department

- Trimming Lathes
- Production Milling Machines
- Pneumatic Presses
- Tapping Machines
- 6 Spindle Machine Centers (multiple head drilling, tapping, and reaming)
- 4 Straight-liners up to 18"
- Parts Washing System

## Shipping Department

- Toledo Electronic Scales & Printer
- Precision Mettler Electronic Scale
- Sartorius Precision Electronic Scale & Printer
- Automated Protective Packaging Bagger
- Polychem Automatic Plastic Strapping System
- Hercules Ergo Container Handling System
- Wulftec Pallet Wrapper



## Inspection Department

- Numerex Coordinate Measuring Machine
- Digital Optical Comparator
- Hardness Testers
- Surface Finish Indicator
- Ceramic Gauge Block Sets
- Plug Gauge Sets
- Height Gauges
- Thread Gauges

*\*Statistical Process Control & Capability Studies Available.*



## Material Capabilities

- Material Thickness: .005" to .134"
- Blank Size: 12" x 12" maximum (flat)
- Draws: 8" diameter, 3" deep maximum



## Credit Cards Accepted



**Call Toll Free:**  
**1-800-927-4377**

**BOKER'S, INC.**

3104 Snelling Avenue  
Minneapolis, MN 55406-1937  
(612) 729-9365 • Fax (800) 321-3462  
Call 1-800-WASHERS  
www.bokers.com • sales@bokers.com

# Boker's Non-Standard Washers and Spacers

This is our list of stock tools from which our washers are made to your order in any quantity without a tooling charge. We do NOT carry any washers in stock. You can choose an exact thickness for metal washers within the tool range indicated. Tools with thickness from .005" to .010" can be used for non-metallic materials from .005" to .125" thick, and are indicated in **BOLD**. For the most up-to-date list of sizes, please visit [bokers.com](http://bokers.com)

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.080	.049	.005 - .010	.107	.055	.005 - .012	<b>.123</b>	<b>.058</b>	<b>.005 - .010</b>	.135	.072	.005 - .015	.149	.097	.015 - .025	<b>.156</b>	<b>.071</b>	<b>.005 - .010</b>
<b>.081</b>	<b>.033</b>	<b>.005 - .010</b>	<b>.108</b>	<b>.055</b>	<b>.005 - .010</b>	.123	.080	.010 - .020	<b>.135</b>	<b>.085</b>	<b>.005 - .010</b>	<b>.150</b>	<b>.033</b>	<b>.005 - .010</b>	.156	.071	.010 - .020
<b>.084</b>	<b>.043</b>	<b>.005 - .010</b>	.108	.055	.010 - .020	.123	.082	.010 - .020	.136	.064	.015 - .030	.150	.035	.010 - .020	.156	.077	.015 - .035
.084	.048	.012 - .020	.109	.047	.012 - .020	<b>.124</b>	<b>.063</b>	<b>.005 - .010</b>	<b>.136</b>	<b>.073</b>	<b>.005 - .010</b>	.150	.041	.005 - .012	<b>.156</b>	<b>.078</b>	<b>.005 - .010</b>
<b>.085</b>	<b>.040</b>	<b>.005 - .010</b>	.109	.058	.010 - .020	.124	.065	.015 - .025	<b>.136</b>	<b>.090</b>	<b>.005 - .010</b>	.150	.041	.016 - .030	.156	.080	.025 - .035
.085	.048	.010 - .015	.109	.067	.008 - .018	.124	.066	.015 - .030	.136	.095	.012 - .020	<b>.150</b>	<b>.044</b>	<b>.005 - .010</b>	.156	.088	.006 - .015
.086	.027	.010 - .020	.110	.032	.010 - .015	<b>.124</b>	<b>.073</b>	<b>.005 - .010</b>	<b>.137</b>	<b>.049</b>	<b>.005 - .010</b>	<b>.150</b>	<b>.046</b>	<b>.005 - .010</b>	.156	.094	.010 - .015
.086	.036	.005 - .008	<b>.110</b>	<b>.054</b>	<b>.005 - .010</b>	<b>.125</b>	<b>.049</b>	<b>.005 - .010</b>	.137	.066	.012 - .025	.150	.056	.015 - .020	<b>.156</b>	<b>.095</b>	<b>.005 - .010</b>
<b>.086</b>	<b>.045</b>	<b>.005 - .010</b>	.110	.055	.010 - .020	.125	.052	.005 - .012	.137	.077	.020 - .030	.150	.057	.010 - .020	.156	.098	.010 - .020
.086	.048	.010 - .015	<b>.110</b>	<b>.073</b>	<b>.005 - .010</b>	.125	.054	.015 - .025	.137	.091	.008 - .016	.150	.057	.015 - .020	.156	.100	.016 - .025
.087	.043	.015 - .030	.111	.061	.010 - .020	.125	.055	.020 - .030	.138	.049	.010 - .020	<b>.150</b>	<b>.059</b>	<b>.005 - .010</b>	.156	.103	.015 - .030
.088	.066	.005 - .015	.111	.067	.015 - .025	.125	.060	.015 - .030	<b>.138</b>	<b>.070</b>	<b>.005 - .010</b>	<b>.150</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.156</b>	<b>.106</b>	<b>.005 - .010</b>
<b>.089</b>	<b>.044</b>	<b>.005 - .010</b>	<b>.112</b>	<b>.039</b>	<b>.005 - .010</b>	.125	.062	.010 - .020	<b>.138</b>	<b>.073</b>	<b>.005 - .010</b>	.150	.066	.006 - .010	<b>.156</b>	<b>.115</b>	<b>.005 - .010</b>
.089	.065	.005 - .015	.112	.044	.012 - .020	<b>.125</b>	<b>.063</b>	<b>.005 - .010</b>	.138	.075	.015 - .030	<b>.150</b>	<b>.073</b>	<b>.005 - .010</b>	.157	.043	.020 - .030
.090	.030	.010 - .015	.112	.059	.015 - .025	.125	.063	.010 - .020	<b>.138</b>	<b>.088</b>	<b>.005 - .010</b>	.150	.077	.010 - .020	<b>.157</b>	<b>.057</b>	<b>.005 - .010</b>
.090	.050	.010 - .015	<b>.112</b>	<b>.061</b>	<b>.005 - .010</b>	.125	.064	.010 - .020	<b>.138</b>	<b>.102</b>	<b>.005 - .010</b>	.150	.087	.010 - .015	.157	.057	.015 - .025
.090	.054	.010 - .015	.112	.062	.015 - .025	<b>.125</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.139</b>	<b>.047</b>	<b>.005 - .010</b>	<b>.150</b>	<b>.088</b>	<b>.005 - .010</b>	.157	.061	.010 - .020
.090	.064	.008 - .012	.112	.067	.015 - .025	.125	.065	.010 - .018	.139	.053	.005 - .012	.150	.089	.015 - .025	<b>.157</b>	<b>.064</b>	<b>.005 - .010</b>
<b>.091</b>	<b>.031</b>	<b>.005 - .010</b>	<b>.112</b>	<b>.073</b>	<b>.005 - .010</b>	.125	.065	.018 - .030	.139	.056	.010 - .020	.150	.090	.015 - .030	.157	.066	.010 - .020
<b>.091</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.113</b>	<b>.052</b>	<b>.005 - .010</b>	<b>.125</b>	<b>.066</b>	<b>.005 - .010</b>	.139	.057	.005 - .012	.150	.091	.005 - .012	<b>.157</b>	<b>.086</b>	<b>.005 - .010</b>
.092	.027	.010 - .015	<b>.113</b>	<b>.074</b>	<b>.005 - .010</b>	.125	.066	.015 - .030	<b>.139</b>	<b>.063</b>	<b>.005 - .010</b>	.150	.099	.020 - .025	<b>.157</b>	<b>.088</b>	<b>.005 - .010</b>
.092	.041	.008 - .012	<b>.114</b>	<b>.044</b>	<b>.005 - .010</b>	.125	.067	.015 - .025	.139	.066	.015 - .030	.150	.116	.016 - .020	.157	.091	.010 - .020
.092	.043	.010 - .020	<b>.114</b>	<b>.066</b>	<b>.005 - .010</b>	.125	.068	.010 - .018	.139	.095	.010 - .020	.151	.056	.015 - .025	.157	.092	.010 - .020
<b>.092</b>	<b>.044</b>	<b>.005 - .010</b>	<b>.114</b>	<b>.073</b>	<b>.005 - .010</b>	.125	.068	.018 - .032	<b>.139</b>	<b>.097</b>	<b>.005 - .010</b>	<b>.151</b>	<b>.069</b>	<b>.005 - .010</b>	.157	.094	.020 - .030
<b>.092</b>	<b>.047</b>	<b>.005 - .010</b>	.115	.031	.010 - .020	<b>.125</b>	<b>.069</b>	<b>.005 - .010</b>	<b>.140</b>	<b>.062</b>	<b>.005 - .010</b>	<b>.151</b>	<b>.073</b>	<b>.005 - .010</b>	<b>.157</b>	<b>.096</b>	<b>.005 - .010</b>
<b>.092</b>	<b>.060</b>	<b>.005 - .010</b>	<b>.115</b>	<b>.033</b>	<b>.005 - .010</b>	.125	.072	.012 - .020	<b>.140</b>	<b>.073</b>	<b>.005 - .010</b>	.151	.077	.015 - .020	.157	.096	.025 - .030
.093	.036	.010 - .020	<b>.115</b>	<b>.061</b>	<b>.005 - .010</b>	.125	.076	.020 - .025	<b>.140</b>	<b>.082</b>	<b>.005 - .010</b>	.151	.078	.010 - .020	<b>.157</b>	<b>.120</b>	<b>.005 - .010</b>
.093	.049	.010 - .020	.115	.079	.005 - .015	<b>.125</b>	<b>.078</b>	<b>.005 - .010</b>	.140	.082	.010 - .025	.151	.083	.025 - .030	<b>.157</b>	<b>.127</b>	<b>.005 - .010</b>
<b>.093</b>	<b>.051</b>	<b>.005 - .010</b>	<b>.116</b>	<b>.037</b>	<b>.005 - .010</b>	.126	.042	.008 - .015	.140	.082	.025 - .032	.152	.094	.020 - .025	.158	.040	.010 - .020
.093	.051	.008 - .012	.116	.055	.010 - .020	.126	.042	.016 - .032	<b>.140</b>	<b>.090</b>	<b>.005 - .010</b>	.152	.095	.015 - .025	.158	.046	.012 - .025
.093	.051	.015 - .020	.116	.066	.015 - .025	.126	.050	.005 - .012	<b>.140</b>	<b>.095</b>	<b>.005 - .010</b>	<b>.152</b>	<b>.098</b>	<b>.005 - .010</b>	.158	.050	.020 - .035
.094	.062	.010 - .015	<b>.116</b>	<b>.067</b>	<b>.005 - .010</b>	.126	.052	.008 - .025	.140	.109	.010 - .015	<b>.152</b>	<b>.100</b>	<b>.005 - .010</b>	.158	.057	.010 - .020
.095	.024	.010 - .015	<b>.116</b>	<b>.073</b>	<b>.005 - .010</b>	.126	.057	.025 - .032	<b>.141</b>	<b>.061</b>	<b>.005 - .010</b>	.153	.056	.010 - .020	.158	.060	.020 - .030
<b>.095</b>	<b>.043</b>	<b>.005 - .010</b>	<b>.117</b>	<b>.032</b>	<b>.005 - .010</b>	.126	.062	.008 - .020	.141	.065	.015 - .025	<b>.153</b>	<b>.061</b>	<b>.005 - .010</b>	.158	.089	.020 - .032
<b>.095</b>	<b>.049</b>	<b>.005 - .010</b>	.117	.035	.005 - .012	<b>.126</b>	<b>.064</b>	<b>.005 - .010</b>	.141	.067	.010 - .016	<b>.153</b>	<b>.062</b>	<b>.005 - .010</b>	.158	.094	.025 - .035
<b>.095</b>	<b>.052</b>	<b>.005 - .010</b>	.117	.056	.010 - .015	<b>.126</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.141</b>	<b>.076</b>	<b>.005 - .010</b>	.153	.073	.015 - .025	<b>.158</b>	<b>.095</b>	<b>.005 - .010</b>
.095	.056	.015 - .020	.118	.058	.010 - .020	.126	.065	.010 - .015	.141	.079	.015 - .025	.153	.077	.025 - .035	.158	.098	.005 - .015
<b>.097</b>	<b>.060</b>	<b>.005 - .010</b>	<b>.118</b>	<b>.073</b>	<b>.005 - .010</b>	<b>.126</b>	<b>.068</b>	<b>.005 - .010</b>	.141	.092	.015 - .025	.153	.078	.005 - .015	.158	.100	.015 - .020
<b>.097</b>	<b>.074</b>	<b>.005 - .010</b>	.118	.073	.010 - .020	<b>.126</b>	<b>.073</b>	<b>.005 - .010</b>	.142	.038	.015 - .030	.153	.081	.020 - .030	<b>.158</b>	<b>.101</b>	<b>.005 - .010</b>
<b>.098</b>	<b>.040</b>	<b>.005 - .010</b>	.118	.075	.005 - .015	.126	.095	.005 - .012	<b>.142</b>	<b>.073</b>	<b>.005 - .010</b>	.153	.081	.020 - .035	.158	.119	.015 - .025
.098	.064	.010 - .020	.118	.080	.005 - .012	.126	.095	.007 - .015	<b>.142</b>	<b>.076</b>	<b>.005 - .010</b>	.153	.095	.020 - .030	<b>.159</b>	<b>.077</b>	<b>.005 - .010</b>
<b>.098</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.118</b>	<b>.091</b>	<b>.005 - .010</b>	.127	.039	.020 - .032	<b>.142</b>	<b>.078</b>	<b>.005 - .010</b>	.153	.100	.010 - .025	<b>.159</b>	<b>.081</b>	<b>.005 - .010</b>
<b>.099</b>	<b>.050</b>	<b>.005 - .010</b>	.120	.039	.010 - .020	.127	.042	.010 - .020	<b>.142</b>	<b>.083</b>	<b>.005 - .010</b>	.154	.073	.020 - .040	<b>.159</b>	<b>.095</b>	<b>.005 - .010</b>
.100	.026	.010 - .015	.120	.040	.010 - .020	.127	.047	.015 - .030	.142	.089	.020 - .030	<b>.154</b>	<b>.095</b>	<b>.005 - .010</b>	.159	.100	.010 - .025
<b>.100</b>	<b>.035</b>	<b>.005 - .010</b>	<b>.120</b>	<b>.041</b>	<b>.005 - .010</b>	.127	.065	.012 - .020	.142	.098	.010 - .015	<b>.154</b>	<b>.101</b>	<b>.005 - .010</b>	.159	.110	.005 - .012
<b>.100</b>	<b>.040</b>	<b>.005 - .010</b>	<b>.120</b>	<b>.050</b>	<b>.005 - .010</b>	.127	.067	.010 - .020	<b>.143</b>	<b>.052</b>	<b>.005 - .010</b>	.154	.110	.020 - .030	.160	.060	.005 - .015
<b>.100</b>	<b>.055</b>	<b>.020 - .030</b>	.120	.062	.010 - .020	.127	.077	.015 - .025	.143	.083	.015 - .025	.155	.064	.015 - .030	.160	.088	.010 - .020
<b>.100</b>	<b>.062</b>	<b>.005 - .010</b>	.120	.063	.015 - .030	.127	.083	.015 - .030	.143	.095	.010 - .020	<b>.155</b>	<b>.066</b>	<b>.005 - .010</b>	<b>.160</b>	<b>.090</b>	<b>.005 - .010</b>
<b>.100</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.120</b>	<b>.065</b>	<b>.005 - .010</b>	.127	.093	.010 - .015	.143	.097	.005 - .015	.155	.069	.005 - .015	.160	.095	.025 - .040
.100	.065	.010 - .020	.120	.070	.015 - .030	.127	.094	.008 - .015	<b>.144</b>	<b>.065</b>	<b>.005 - .010</b>	.155	.072	.020 - .040	.161	.063	.015 - .030
.100	.067	.015 - .025	<b>.120</b>	<b>.073</b>	<b>.005 - .010</b>	.128	.056	.015 - .025	<b>.144</b>	<b>.073</b>	<b>.005 - .010</b>	.155	.076	.010 - .020	.161	.069	.010 - .020
.101	.036	.015 - .025	.120	.080	.010 - .016	<b>.128</b>	<b>.073</b>	<b>.005 - .010</b>	.144	.076	.010 - .020	.155	.078	.008 - .012	.161	.076	.015 - .030
<b>.101</b>	<b>.045</b>	<b>.005 - .010</b>	.121	.043	.005 - .012	.128	.076	.015 - .030	<b>.145</b>	<b>.056</b>	<b>.005 - .010</b>	<b>.155</b>	<b>.081</b>	<b>.005 - .010</b>	<b>.162</b>	<b>.061</b>	<b>.005 - .010</b>
.101	.045	.020 - .030	<b>.121</b>	<b>.047</b>	<b>.005 - .010</b>	<b>.128</b>	<b>.089</b>	<b>.005 - .010</b>	.145	.068	.005 - .012	<b>.155</b>	<b>.084</b>	<b>.005 - .010</b>	.162	.061	.010 - .020
.101	.049	.015 - .020	.121	.054	.010 - .025	<b>.128</b>	<b>.103</b>	<b>.005 - .010</b>	<b>.145</b>	<b>.090</b>	<b>.005 - .010</b>	.155	.094	.015 - .025	.162	.077	.012 - .020
<b>.101</b>	<b>.050</b>	<b>.005 - .010</b>	.121	.062	.010 - .020	.129	.083	.010 - .020	<b>.145</b>	<b>.097</b>	<b>.005 - .010</b>	<b>.155</b>	<b>.111</b>	<b>.005 - .010</b>	.162	.086	.020 - .032
.102	.040	.020 - .030	<b>.121</b>	<b>.072</b>	<b>.005 - .010</b>	<b>.130</b>	<b>.073</b>	<b>.005 - .010</b>	<b>.145</b>	<b>.116</b>	<b>.005 - .010</b>	.155	.124	.010 - .020	.162	.097	.010 - .020
.102	.053	.020 - .030	<b>.121</b>	<b>.092</b>	<b>.005 - .010</b>	.131	.059	.005 - .012	.146	.046	.010 - .020	.156	.044				

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.165	.080	.015 - .025	<b>.177</b>	<b>.081</b>	<b>.005 - .010</b>	.185	.119	.015 - .030	.188	.094	.010 - .020	<b>.196</b>	<b>.104</b>	<b>.005 - .010</b>	.202	.120	.015 - .032
<b>.165</b>	<b>.083</b>	<b>.005 - .010</b>	.177	.094	.007 - .015	.185	.126	.020 - .030	<b>.188</b>	<b>.095</b>	<b>.005 - .010</b>	.196	.105	.015 - .030	<b>.202</b>	<b>.126</b>	<b>.005 - .010</b>
<b>.165</b>	<b>.090</b>	<b>.005 - .010</b>	.177	.099	.005 - .015	<b>.185</b>	<b>.127</b>	<b>.005 - .010</b>	.188	.102	.005 - .015	.196	.117	.008 - .010	<b>.202</b>	<b>.128</b>	<b>.005 - .010</b>
.165	.096	.015 - .030	.177	.113	.005 - .015	.185	.128	.010 - .020	.188	.103	.020 - .030	.196	.117	.010 - .015	<b>.202</b>	<b>.134</b>	<b>.005 - .010</b>
.165	.100	.015 - .025	.177	.119	.030 - .042	.185	.129	.005 - .015	.188	.106	.010 - .020	.196	.122	.010 - .020	.202	.136	.020 - .032
<b>.165</b>	<b>.125</b>	<b>.005 - .010</b>	.177	.122	.015 - .020	<b>.185</b>	<b>.131</b>	<b>.005 - .010</b>	.188	.113	.020 - .040	<b>.196</b>	<b>.128</b>	<b>.005 - .010</b>	<b>.203</b>	<b>.063</b>	<b>.005 - .010</b>
.165	.126	.015 - .025	<b>.177</b>	<b>.127</b>	<b>.005 - .010</b>	<b>.185</b>	<b>.134</b>	<b>.005 - .010</b>	.188	.118	.015 - .025	<b>.196</b>	<b>.129</b>	<b>.005 - .010</b>	.203	.063	.020 - .032
.166	.073	.010 - .020	.178	.050	.030 - .040	.185	.136	.015 - .025	.188	.119	.005 - .012	.196	.129	.015 - .025	.203	.072	.015 - .020
<b>.166</b>	<b>.075</b>	<b>.005 - .010</b>	.178	.077	.015 - .030	.186	.028	.006 - .010	.188	.121	.010 - .025	.196	.130	.010 - .020	.203	.072	.020 - .040
<b>.166</b>	<b>.081</b>	<b>.005 - .010</b>	.178	.113	.005 - .015	<b>.186</b>	<b>.035</b>	<b>.005 - .010</b>	<b>.188</b>	<b>.122</b>	<b>.005 - .010</b>	.196	.140	.010 - .020	.203	.091	.010 - .020
.166	.108	.010 - .020	.178	.119	.030 - .042	<b>.186</b>	<b>.038</b>	<b>.005 - .010</b>	<b>.188</b>	<b>.128</b>	<b>.005 - .010</b>	.196	.145	.005 - .012	.203	.091	.030 - .040
<b>.166</b>	<b>.129</b>	<b>.005 - .010</b>	.178	.137	.010 - .020	.186	.046	.010 - .020	.188	.128	.007 - .015	.197	.055	.015 - .025	.203	.092	.030 - .040
<b>.167</b>	<b>.031</b>	<b>.005 - .010</b>	<b>.178</b>	<b>.139</b>	<b>.005 - .010</b>	.186	.064	.008 - .020	.188	.128	.020 - .036	<b>.197</b>	<b>.077</b>	<b>.005 - .010</b>	.203	.093	.040 - .060
.167	.065	.010 - .020	<b>.179</b>	<b>.039</b>	<b>.005 - .010</b>	.186	.075	.015 - .025	.188	.129	.020 - .030	.197	.091	.020 - .040	.203	.114	.015 - .020
<b>.167</b>	<b>.078</b>	<b>.005 - .010</b>	.179	.101	.010 - .020	.186	.079	.015 - .030	.188	.131	.020 - .030	<b>.197</b>	<b>.099</b>	<b>.005 - .010</b>	.203	.114	.020 - .040
.167	.085	.010 - .020	<b>.179</b>	<b>.103</b>	<b>.005 - .010</b>	.186	.079	.020 - .040	.189	.043	.025 - .040	<b>.197</b>	<b>.103</b>	<b>.005 - .010</b>	<b>.203</b>	<b>.123</b>	<b>.005 - .010</b>
.167	.108	.010 - .020	<b>.179</b>	<b>.113</b>	<b>.005 - .010</b>	<b>.186</b>	<b>.086</b>	<b>.005 - .010</b>	.189	.053	.030 - .040	<b>.197</b>	<b>.116</b>	<b>.005 - .010</b>	.203	.124	.010 - .020
<b>.168</b>	<b>.082</b>	<b>.005 - .010</b>	.179	.115	.025 - .030	.186	.088	.015 - .025	.189	.064	.010 - .025	<b>.197</b>	<b>.121</b>	<b>.005 - .010</b>	.203	.128	.015 - .025
.168	.096	.025 - .040	.180	.081	.020 - .035	.186	.093	.015 - .030	.189	.064	.030 - .050	.197	.122	.020 - .040	.203	.137	.020 - .040
<b>.168</b>	<b>.130</b>	<b>.005 - .010</b>	<b>.180</b>	<b>.089</b>	<b>.005 - .010</b>	.186	.094	.025 - .035	.189	.094	.040 - .060	<b>.197</b>	<b>.129</b>	<b>.005 - .010</b>	.203	.170	.005 - .020
.169	.115	.015 - .025	.180	.089	.020 - .032	<b>.186</b>	<b>.096</b>	<b>.005 - .010</b>	.189	.095	.025 - .045	.197	.139	.030 - .040	<b>.203</b>	<b>.175</b>	<b>.005 - .010</b>
.170	.064	.015 - .032	.180	.090	.010 - .020	.186	.098	.012 - .025	<b>.189</b>	<b>.102</b>	<b>.005 - .010</b>	.197	.147	.015 - .025	<b>.203</b>	<b>.176</b>	<b>.005 - .010</b>
.170	.067	.010 - .020	.180	.094	.010 - .025	<b>.186</b>	<b>.099</b>	<b>.005 - .010</b>	<b>.189</b>	<b>.109</b>	<b>.005 - .010</b>	.198	.088	.010 - .020	<b>.204</b>	<b>.044</b>	<b>.005 - .010</b>
.170	.070	.020 - .030	<b>.180</b>	<b>.096</b>	<b>.005 - .010</b>	<b>.186</b>	<b>.103</b>	<b>.005 - .010</b>	<b>.189</b>	<b>.119</b>	<b>.005 - .010</b>	.198	.092	.010 - .020	.204	.075	.025 - .040
.170	.089	.015 - .025	.180	.100	.025 - .040	.186	.108	.010 - .020	.189	.136	.010 - .020	.198	.092	.020 - .030	<b>.204</b>	<b>.100</b>	<b>.005 - .010</b>
<b>.170</b>	<b>.097</b>	<b>.005 - .010</b>	.180	.114	.020 - .040	<b>.186</b>	<b>.119</b>	<b>.005 - .010</b>	<b>.190</b>	<b>.048</b>	<b>.005 - .010</b>	<b>.198</b>	<b>.097</b>	<b>.005 - .010</b>	.204	.105	.030 - .040
.170	.109	.025 - .035	<b>.180</b>	<b>.118</b>	<b>.005 - .010</b>	.186	.124	.020 - .030	<b>.190</b>	<b>.091</b>	<b>.005 - .010</b>	.198	.126	.020 - .030	.204	.125	.025 - .040
<b>.170</b>	<b>.121</b>	<b>.005 - .010</b>	<b>.180</b>	<b>.128</b>	<b>.005 - .010</b>	.186	.125	.010 - .020	.190	.095	.040 - .060	.198	.131	.020 - .040	.204	.143	.020 - .030
<b>.171</b>	<b>.065</b>	<b>.005 - .010</b>	<b>.180</b>	<b>.141</b>	<b>.005 - .010</b>	.186	.125	.020 - .030	.190	.113	.010 - .020	<b>.198</b>	<b>.147</b>	<b>.005 - .010</b>	.204	.157	.010 - .020
.171	.086	.030 - .050	<b>.181</b>	<b>.071</b>	<b>.005 - .010</b>	<b>.186</b>	<b>.126</b>	<b>.005 - .010</b>	.190	.128	.010 - .015	<b>.199</b>	<b>.050</b>	<b>.005 - .010</b>	.205	.038	.015 - .025
<b>.171</b>	<b>.090</b>	<b>.005 - .010</b>	.181	.078	.007 - .016	.186	.127	.010 - .015	.190	.130	.015 - .030	.199	.088	.030 - .050	.205	.050	.030 - .040
.171	.090	.015 - .030	<b>.181</b>	<b>.087</b>	<b>.005 - .010</b>	.186	.129	.020 - .040	<b>.190</b>	<b>.132</b>	<b>.005 - .010</b>	.199	.105	.030 - .050	.205	.079	.020 - .030
.171	.098	.007 - .015	<b>.181</b>	<b>.093</b>	<b>.005 - .010</b>	.186	.136	.010 - .020	<b>.191</b>	<b>.038</b>	<b>.005 - .010</b>	.199	.122	.010 - .020	.205	.094	.010 - .020
.171	.101	.010 - .020	.181	.095	.010 - .016	<b>.186</b>	<b>.155</b>	<b>.005 - .010</b>	.191	.039	.010 - .020	.199	.154	.005 - .015	.205	.097	.010 - .020
.171	.128	.010 - .020	.181	.116	.015 - .030	.187	.042	.015 - .030	.191	.063	.010 - .016	.199	.158	.015 - .020	.205	.112	.010 - .020
.171	.129	.010 - .020	.181	.127	.015 - .025	.187	.074	.015 - .030	.191	.065	.025 - .050	<b>.200</b>	<b>.026</b>	<b>.005 - .010</b>	.205	.115	.015 - .025
<b>.171</b>	<b>.130</b>	<b>.005 - .010</b>	<b>.181</b>	<b>.128</b>	<b>.005 - .010</b>	.187	.077	.020 - .040	.191	.069	.025 - .040	<b>.200</b>	<b>.053</b>	<b>.005 - .010</b>	.205	.131	.010 - .020
<b>.172</b>	<b>.074</b>	<b>.005 - .010</b>	.181	.128	.015 - .025	.187	.078	.025 - .050	.191	.075	.040 - .060	<b>.200</b>	<b>.066</b>	<b>.005 - .010</b>	.205	.137	.025 - .040
.172	.074	.010 - .020	.182	.052	.010 - .020	<b>.187</b>	<b>.080</b>	<b>.005 - .010</b>	<b>.191</b>	<b>.077</b>	<b>.005 - .010</b>	.200	.072	.020 - .030	.205	.147	.025 - .030
.172	.080	.015 - .025	.182	.057	.012 - .020	<b>.187</b>	<b>.081</b>	<b>.005 - .010</b>	.191	.077	.020 - .030	.200	.078	.020 - .030	.206	.051	.005 - .015
.172	.081	.020 - .030	.182	.068	.010 - .020	.187	.082	.005 - .015	.191	.092	.032 - .050	.200	.079	.010 - .020	<b>.206</b>	<b>.094</b>	<b>.005 - .010</b>
.172	.096	.020 - .032	.182	.083	.040 - .050	.187	.082	.032 - .042	.191	.104	.020 - .030	.200	.086	.025 - .040	<b>.206</b>	<b>.154</b>	<b>.005 - .010</b>
.172	.103	.010 - .020	.182	.094	.015 - .030	<b>.187</b>	<b>.084</b>	<b>.005 - .010</b>	.191	.119	.010 - .020	.200	.087	.025 - .040	<b>.206</b>	<b>.161</b>	<b>.005 - .010</b>
.172	.109	.020 - .040	.182	.110	.010 - .020	.187	.086	.030 - .050	<b>.191</b>	<b>.142</b>	<b>.005 - .010</b>	.200	.090	.010 - .020	<b>.207</b>	<b>.112</b>	<b>.005 - .010</b>
<b>.172</b>	<b>.128</b>	<b>.005 - .010</b>	<b>.182</b>	<b>.130</b>	<b>.005 - .010</b>	.187	.089	.010 - .020	.191	.162	.015 - .020	<b>.200</b>	<b>.092</b>	<b>.005 - .010</b>	.207	.127	.015 - .025
.173	.065	.015 - .030	.182	.130	.010 - .016	.187	.089	.015 - .030	.192	.091	.020 - .040	.200	.095	.015 - .025	.207	.132	.020 - .030
<b>.173</b>	<b>.088</b>	<b>.005 - .010</b>	<b>.182</b>	<b>.134</b>	<b>.005 - .010</b>	.187	.090	.025 - .040	<b>.192</b>	<b>.118</b>	<b>.005 - .010</b>	<b>.200</b>	<b>.096</b>	<b>.005 - .010</b>	.207	.133	.020 - .030
.173	.092	.020 - .035	.183	.067	.012 - .025	.187	.091	.015 - .025	.192	.120	.020 - .040	.200	.097	.015 - .030	<b>.207</b>	<b>.147</b>	<b>.005 - .010</b>
.173	.096	.020 - .040	.183	.090	.010 - .020	<b>.187</b>	<b>.095</b>	<b>.005 - .010</b>	<b>.192</b>	<b>.125</b>	<b>.005 - .010</b>	.200	.098	.015 - .025	.208	.099	.010 - .020
.173	.100	.010 - .020	.183	.096	.020 - .030	.187	.096	.010 - .025	<b>.192</b>	<b>.133</b>	<b>.005 - .010</b>	.200	.100	.040 - .050	<b>.208</b>	<b>.120</b>	<b>.005 - .010</b>
.173	.102	.010 - .020	<b>.183</b>	<b>.097</b>	<b>.005 - .010</b>	.187	.098	.015 - .025	.192	.149	.015 - .025	<b>.200</b>	<b>.101</b>	<b>.005 - .010</b>	.208	.120	.030 - .040
.173	.104	.016 - .025	.183	.101	.020 - .036	<b>.187</b>	<b>.100</b>	<b>.005 - .010</b>	.193	.075	.015 - .030	.200	.101	.020 - .040	.208	.120	.040 - .060
.173	.114	.010 - .020	<b>.183</b>	<b>.105</b>	<b>.005 - .010</b>	.187	.104	.032 - .042	.193	.095	.020 - .040	<b>.200</b>	<b>.102</b>	<b>.005 - .010</b>	.208	.127	.015 - .025
<b>.173</b>	<b>.117</b>	<b>.005 - .010</b>	.183	.106	.010 - .020	.187	.106	.015 - .025	.193	.103	.010 - .020	.200	.102	.015 - .030	.208	.128	.040 - .050
.173	.117	.015 - .025	.183	.118	.015 - .030	.187	.106	.025 - .040	<b>.193</b>	<b>.111</b>							

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.211	.133	.020 - .035	.218	.106	.020 - .032	.223	.059	.015 - .025	.232	.120	.015 - .025	<b>.237</b>	<b>.162</b>	<b>.005 - .010</b>	.245	.127	.010 - .018
.211	.142	.025 - .035	.218	.108	.008 - .020	.223	.059	.025 - .040	<b>.232</b>	<b>.133</b>	<b>.005 - .010</b>	.237	.164	.008 - .012	.245	.127	.018 - .030
<b>.211</b>	<b>.158</b>	<b>.005 - .010</b>	.218	.113	.025 - .040	<b>.223</b>	<b>.100</b>	<b>.005 - .010</b>	.232	.134	.010 - .020	.237	.164	.025 - .035	.245	.136	.025 - .040
.211	.163	.020 - .032	.218	.116	.005 - .020	.223	.102	.025 - .035	<b>.232</b>	<b>.136</b>	<b>.005 - .010</b>	.237	.193	.010 - .020	<b>.245</b>	<b>.141</b>	<b>.005 - .010</b>
<b>.211</b>	<b>.167</b>	<b>.005 - .010</b>	.218	.119	.005 - .008	.223	.118	.005 - .015	.232	.159	.006 - .016	.237	.194	.010 - .020	<b>.245</b>	<b>.185</b>	<b>.005 - .010</b>
<b>.212</b>	<b>.084</b>	<b>.005 - .010</b>	<b>.218</b>	<b>.127</b>	<b>.005 - .010</b>	.223	.127	.025 - .042	<b>.233</b>	<b>.040</b>	<b>.005 - .010</b>	.238	.071	.015 - .030	.245	.204	.010 - .020
.212	.093	.015 - .030	<b>.218</b>	<b>.128</b>	<b>.005 - .010</b>	<b>.223</b>	<b>.130</b>	<b>.005 - .010</b>	.233	.060	.010 - .025	.238	.126	.030 - .050	.246	.055	.005 - .012
.212	.120	.010 - .020	.218	.128	.010 - .020	.223	.132	.025 - .035	<b>.233</b>	<b>.110</b>	<b>.005 - .010</b>	<b>.238</b>	<b>.143</b>	<b>.005 - .010</b>	<b>.246</b>	<b>.080</b>	<b>.005 - .010</b>
<b>.212</b>	<b>.124</b>	<b>.005 - .010</b>	.218	.132	.008 - .015	.223	.135	.010 - .020	.233	.118	.020 - .040	.238	.146	.030 - .040	.246	.094	.010 - .020
<b>.212</b>	<b>.131</b>	<b>.005 - .010</b>	.218	.138	.020 - .040	.223	.139	.015 - .025	.233	.124	.010 - .020	.238	.181	.020 - .030	.246	.122	.025 - .040
.212	.135	.005 - .015	.218	.140	.015 - .025	<b>.223</b>	<b>.155</b>	<b>.005 - .010</b>	<b>.233</b>	<b>.127</b>	<b>.005 - .010</b>	.239	.068	.008 - .016	<b>.246</b>	<b>.128</b>	<b>.005 - .010</b>
.212	.137	.015 - .025	.218	.141	.025 - .036	<b>.223</b>	<b>.191</b>	<b>.005 - .010</b>	.233	.130	.005 - .015	<b>.239</b>	<b>.094</b>	<b>.005 - .010</b>	<b>.246</b>	<b>.131</b>	<b>.005 - .010</b>
.212	.138	.005 - .012	.218	.143	.015 - .030	.224	.075	.025 - .040	<b>.233</b>	<b>.155</b>	<b>.005 - .010</b>	.239	.131	.032 - .050	<b>.246</b>	<b>.134</b>	<b>.005 - .010</b>
.212	.158	.015 - .025	.218	.169	.015 - .025	.224	.139	.005 - .012	.233	.163	.010 - .015	.239	.141	.015 - .030	.246	.142	.015 - .030
.213	.043	.005 - .012	.219	.070	.020 - .030	<b>.224</b>	<b>.141</b>	<b>.005 - .010</b>	.233	.170	.020 - .030	.239	.142	.015 - .030	<b>.246</b>	<b>.170</b>	<b>.005 - .010</b>
.213	.066	.025 - .040	<b>.219</b>	<b>.085</b>	<b>.005 - .010</b>	<b>.225</b>	<b>.063</b>	<b>.005 - .010</b>	<b>.233</b>	<b>.173</b>	<b>.005 - .010</b>	<b>.239</b>	<b>.148</b>	<b>.005 - .010</b>	.246	.180	.010 - .020
.213	.077	.015 - .030	<b>.219</b>	<b>.090</b>	<b>.005 - .010</b>	.225	.090	.015 - .030	<b>.233</b>	<b>.191</b>	<b>.005 - .010</b>	.239	.161	.030 - .050	.246	.182	.020 - .030
<b>.213</b>	<b>.100</b>	<b>.005 - .010</b>	.219	.103	.010 - .020	<b>.225</b>	<b>.092</b>	<b>.005 - .010</b>	<b>.234</b>	<b>.039</b>	<b>.005 - .010</b>	.239	.163	.030 - .040	.246	.197	.015 - .025
<b>.213</b>	<b>.108</b>	<b>.005 - .010</b>	<b>.219</b>	<b>.106</b>	<b>.005 - .010</b>	.225	.101	.015 - .030	.234	.066	.042 - .062	<b>.239</b>	<b>.181</b>	<b>.005 - .010</b>	.247	.051	.010 - .020
.213	.110	.010 - .020	.219	.106	.010 - .020	.225	.111	.015 - .030	.234	.096	.042 - .060	.239	.190	.005 - .015	.247	.063	.030 - .050
.213	.130	.025 - .040	.219	.124	.020 - .040	.225	.125	.015 - .032	<b>.234</b>	<b>.121</b>	<b>.005 - .010</b>	<b>.240</b>	<b>.024</b>	<b>.005 - .010</b>	.247	.080	.010 - .030
<b>.213</b>	<b>.154</b>	<b>.005 - .010</b>	.219	.126	.010 - .020	.225	.129	.030 - .050	.234	.121	.010 - .020	<b>.240</b>	<b>.072</b>	<b>.005 - .010</b>	.247	.080	.030 - .040
.213	.162	.020 - .030	.219	.126	.020 - .030	.225	.135	.005 - .015	.234	.126	.015 - .025	.240	.090	.020 - .030	.247	.090	.020 - .030
<b>.214</b>	<b>.050</b>	<b>.005 - .010</b>	.219	.127	.030 - .040	.225	.141	.005 - .015	.234	.128	.015 - .030	.240	.102	.010 - .020	.247	.091	.030 - .050
.214	.062	.015 - .030	.219	.129	.010 - .015	.225	.144	.015 - .030	<b>.234</b>	<b>.129</b>	<b>.005 - .010</b>	.240	.105	.010 - .020	.247	.095	.040 - .060
.214	.089	.010 - .020	.219	.130	.015 - .030	.225	.147	.025 - .040	.234	.134	.020 - .030	.240	.108	.025 - .040	<b>.247</b>	<b>.097</b>	<b>.005 - .010</b>
.214	.098	.010 - .020	<b>.219</b>	<b>.142</b>	<b>.005 - .010</b>	<b>.225</b>	<b>.150</b>	<b>.005 - .010</b>	.234	.135	.030 - .050	<b>.240</b>	<b>.109</b>	<b>.005 - .010</b>	.247	.097	.008 - .020
.214	.100	.015 - .025	.219	.147	.025 - .040	<b>.226</b>	<b>.087</b>	<b>.005 - .010</b>	.234	.138	.010 - .020	.240	.125	.025 - .040	<b>.247</b>	<b>.100</b>	<b>.005 - .010</b>
.214	.109	.020 - .030	.219	.156	.010 - .020	.226	.098	.015 - .030	.234	.142	.035 - .050	.240	.125	.040 - .060	<b>.247</b>	<b>.118</b>	<b>.005 - .010</b>
<b>.214</b>	<b>.126</b>	<b>.005 - .010</b>	<b>.219</b>	<b>.161</b>	<b>.005 - .010</b>	.226	.098	.030 - .050	.234	.192	.010 - .020	<b>.240</b>	<b>.131</b>	<b>.005 - .010</b>	.247	.118	.008 - .020
.214	.163	.010 - .020	.219	.161	.020 - .035	.226	.108	.020 - .030	<b>.235</b>	<b>.048</b>	<b>.005 - .010</b>	<b>.240</b>	<b>.135</b>	<b>.005 - .010</b>	.247	.119	.025 - .040
<b>.214</b>	<b>.166</b>	<b>.005 - .010</b>	<b>.219</b>	<b>.171</b>	<b>.005 - .010</b>	.226	.114	.025 - .040	.235	.068	.010 - .025	.240	.135	.015 - .030	.247	.125	.020 - .032
.214	.169	.010 - .015	<b>.219</b>	<b>.173</b>	<b>.005 - .010</b>	<b>.226</b>	<b>.129</b>	<b>.005 - .010</b>	.235	.068	.030 - .050	<b>.240</b>	<b>.136</b>	<b>.005 - .010</b>	.247	.126	.023 - .032
<b>.214</b>	<b>.180</b>	<b>.005 - .010</b>	<b>.220</b>	<b>.040</b>	<b>.005 - .010</b>	.226	.129	.020 - .030	.235	.086	.020 - .030	<b>.240</b>	<b>.139</b>	<b>.005 - .010</b>	.247	.127	.025 - .042
.215	.034	.020 - .030	.220	.051	.025 - .035	<b>.226</b>	<b>.175</b>	<b>.005 - .010</b>	.235	.088	.020 - .030	.240	.160	.015 - .025	.247	.132	.020 - .030
.215	.034	.020 - .030	.220	.063	.010 - .020	<b>.226</b>	<b>.193</b>	<b>.005 - .010</b>	<b>.235</b>	<b>.090</b>	<b>.005 - .010</b>	.240	.160	.025 - .040	<b>.247</b>	<b>.138</b>	<b>.005 - .010</b>
.215	.088	.010 - .015	.220	.065	.020 - .032	.227	.050	.010 - .020	<b>.235</b>	<b>.099</b>	<b>.005 - .010</b>	<b>.240</b>	<b>.188</b>	<b>.005 - .010</b>	<b>.247</b>	<b>.140</b>	<b>.005 - .010</b>
.215	.090	.042 - .062	.220	.070	.020 - .030	<b>.227</b>	<b>.127</b>	<b>.005 - .010</b>	.235	.102	.015 - .030	<b>.241</b>	<b>.103</b>	<b>.005 - .010</b>	.247	.141	.020 - .032
.215	.091	.010 - .025	<b>.220</b>	<b>.090</b>	<b>.005 - .010</b>	.227	.153	.020 - .032	.235	.108	.030 - .050	.241	.119	.020 - .035	<b>.247</b>	<b>.144</b>	<b>.005 - .010</b>
.215	.100	.010 - .020	<b>.220</b>	<b>.091</b>	<b>.005 - .010</b>	.228	.051	.020 - .030	.235	.114	.010 - .020	<b>.241</b>	<b>.148</b>	<b>.005 - .010</b>	<b>.247</b>	<b>.147</b>	<b>.005 - .010</b>
.215	.100	.040 - .050	.220	.091	.020 - .040	<b>.228</b>	<b>.091</b>	<b>.005 - .010</b>	.235	.114	.020 - .030	<b>.241</b>	<b>.162</b>	<b>.005 - .010</b>	.247	.158	.030 - .040
.215	.104	.010 - .020	<b>.220</b>	<b>.099</b>	<b>.005 - .010</b>	.228	.096	.010 - .020	.235	.126	.030 - .050	<b>.241</b>	<b>.180</b>	<b>.005 - .010</b>	.247	.159	.010 - .020
.215	.106	.005 - .015	.220	.106	.005 - .015	.228	.106	.020 - .035	.235	.130	.015 - .030	<b>.242</b>	<b>.072</b>	<b>.005 - .010</b>	<b>.247</b>	<b>.164</b>	<b>.005 - .010</b>
.215	.112	.020 - .040	.220	.108	.010 - .020	.228	.118	.010 - .020	.235	.131	.025 - .040	.242	.118	.010 - .020	.247	.169	.020 - .030
.215	.123	.015 - .035	<b>.220</b>	<b>.109</b>	<b>.005 - .010</b>	.228	.118	.040 - .050	.235	.134	.020 - .035	<b>.242</b>	<b>.128</b>	<b>.005 - .010</b>	<b>.247</b>	<b>.185</b>	<b>.005 - .010</b>
.215	.127	.005 - .012	.220	.113	.032 - .048	.228	.121	.010 - .020	.235	.138	.015 - .025	.242	.129	.015 - .025	<b>.247</b>	<b>.205</b>	<b>.005 - .010</b>
.215	.137	.010 - .015	.220	.114	.010 - .020	.228	.129	.020 - .030	.235	.139	.025 - .040	.242	.145	.010 - .015	<b>.247</b>	<b>.206</b>	<b>.005 - .010</b>
.215	.138	.020 - .030	.220	.117	.025 - .042	.228	.131	.015 - .030	.235	.152	.020 - .032	<b>.242</b>	<b>.146</b>	<b>.005 - .010</b>	.248	.052	.035 - .050
.215	.144	.030 - .050	.220	.122	.025 - .040	<b>.228</b>	<b>.148</b>	<b>.005 - .010</b>	.235	.156	.010 - .020	.242	.147	.010 - .020	.248	.063	.015 - .025
<b>.215</b>	<b>.162</b>	<b>.005 - .010</b>	.220	.125	.020 - .030	<b>.228</b>	<b>.167</b>	<b>.005 - .010</b>	<b>.235</b>	<b>.161</b>	<b>.005 - .010</b>	<b>.242</b>	<b>.163</b>	<b>.025 - .035</b>	.248	.067	.015 - .030
<b>.215</b>	<b>.164</b>	<b>.005 - .010</b>	.220	.127	.025 - .048	.229	.096	.010 - .020	.235	.164	.010 - .020	.242	.172	.025 - .040	.248	.078	.015 - .030
<b>.215</b>	<b>.166</b>	<b>.005 - .010</b>	.220	.128	.040 - .050	.229	.139	.015 - .025	.235	.167	.020 - .036	.242	.192	.012 - .020	.248	.087	.005 - .015
.215	.168	.010 - .020	.220	.129	.020 - .035	<b>.229</b>	<b>.149</b>	<b>.005 - .010</b>	<b>.235</b>	<b>.202</b>	<b>.005 - .010</b>	<b>.242</b>	<b>.194</b>	<b>.005 - .010</b>	.248	.089	.020 - .035
<b>.215</b>	<b>.170</b>	<b>.005 - .010</b>	.220	.140	.010 - .020	.229	.166	.010 - .020	<b>.236</b>	<b>.061</b>	<b>.005 - .010</b>	.243	.095	.015 - .025	.248	.091	.030 - .040
.216	.054	.015 - .032	.220	.144	.025 - .035	.230	.038	.020 - .030	.236	.070	.010 - .020	.243	.130	.010 - .020	.248	.092	.005 - .015
<b>.216</b>	<b>.055</b>	<b>.005 - .010</b>	.220	.147	.015 - .025	.230	.050	.020 - .030	<b>.236</b>	<b>.078</b>	<b>.005 - .010</b>	.243	.130	.040 - .050	<b>.248</b>	<b>.093</b>	<b>.005 - .010</b>
.216	.057	.020 - .030	<b>.220</b>	<b>.159</b>	<b>.005 - .010</b>	.230	.073	.015 - .030	.236	.080	.020 - .030	<b>.243</b>	<b>.133</b>	<b>.005 - .010</b>	.248	.093	.015 - .030
.216	.110	.010 - .020	.220	.166	.015 - .020	.230	.094	.042 - .062	.236	.082	.015 - .030	<b>.243</b>	<b>.136</b>	<b>.005 - .010</b>	.248	.094	.040 - .060
.216	.120	.010 - .020	.220	.177	.015 - .020	.230	.097	.010 - .020	.236	.091	.020 - .030	.243	.145	.010 - .020	<b>.248</b>	<b>.098</b>	<b>.005 - .010</b>
<b>.216</b>	<b>.126</b>	<b>.005 - .010</b>	<b>.220</b>	<b>.179</b>	<b>.005 - .010</b>	<b>.230</b>	<b>.108</b>	<b>.005 - .010</b>	.236	.094	.015 - .030	.243	.146	.010 - .020	.248	.100	.015 - .030
<b>.216</b>	<b>.148</b>																

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.249	.116	.020 - .040	.250	.129	.010 - .020	.252	.120	.010 - .020	<b>.261</b>	<b>.206</b>	<b>.005 - .010</b>	.270	.132	.025 - .035	.276	.159	.030 - .050
.249	.121	.015 - .025	.250	.129	.015 - .032	.252	.127	.030 - .050	.262	.062	.020 - .030	.270	.135	.031 - .042	.276	.161	.005 - .015
.249	.123	.015 - .030	.250	.129	.030 - .050	<b>.252</b>	<b>.128</b>	<b>.005 - .010</b>	.262	.117	.015 - .030	.270	.148	.010 - .020	.276	.162	.010 - .020
<b>.249</b>	<b>.124</b>	<b>.005 - .010</b>	<b>.250</b>	<b>.130</b>	<b>.005 - .010</b>	.252	.141	.020 - .040	<b>.262</b>	<b>.129</b>	<b>.005 - .010</b>	<b>.270</b>	<b>.160</b>	<b>.005 - .010</b>	.276	.192	.030 - .040
.249	.127	.010 - .020	.250	.130	.010 - .020	.252	.146	.008 - .016	.262	.156	.015 - .030	<b>.270</b>	<b>.207</b>	<b>.005 - .010</b>	<b>.276</b>	<b>.196</b>	<b>.005 - .010</b>
.249	.127	.025 - .050	.250	.130	.025 - .042	.252	.159	.025 - .040	.262	.188	.025 - .040	.270	.210	.020 - .040	.276	.209	.010 - .020
.249	.128	.020 - .035	<b>.250</b>	<b>.131</b>	<b>.005 - .010</b>	.252	.191	.010 - .020	.262	.192	.020 - .030	.271	.127	.015 - .025	<b>.277</b>	<b>.088</b>	<b>.005 - .010</b>
<b>.249</b>	<b>.135</b>	<b>.005 - .010</b>	.250	.131	.040 - .060	.252	.191	.020 - .040	.262	.199	.020 - .040	.271	.130	.008 - .015	.277	.092	.010 - .020
.249	.137	.025 - .050	.250	.132	.032 - .052	.252	.195	.012 - .020	.263	.091	.025 - .040	<b>.271</b>	<b>.138</b>	<b>.005 - .010</b>	<b>.277</b>	<b>.108</b>	<b>.005 - .010</b>
<b>.249</b>	<b>.139</b>	<b>.005 - .010</b>	<b>.250</b>	<b>.134</b>	<b>.005 - .010</b>	.252	.197	.020 - .030	.263	.129	.010 - .020	.271	.138	.025 - .040	<b>.277</b>	<b>.126</b>	<b>.005 - .010</b>
.249	.139	.020 - .040	.250	.135	.030 - .048	<b>.252</b>	<b>.205</b>	<b>.005 - .010</b>	.263	.158	.030 - .050	<b>.271</b>	<b>.146</b>	<b>.005 - .010</b>	.277	.127	.005 - .008
.249	.143	.015 - .030	<b>.250</b>	<b>.136</b>	<b>.005 - .010</b>	.253	.048	.040 - .050	<b>.263</b>	<b>.191</b>	<b>.005 - .010</b>	.271	.175	.030 - .050	.277	.129	.050 - .070
.249	.144	.030 - .050	<b>.250</b>	<b>.140</b>	<b>.005 - .010</b>	.253	.056	.025 - .040	<b>.263</b>	<b>.193</b>	<b>.005 - .010</b>	.271	.190	.015 - .025	.277	.132	.015 - .025
<b>.249</b>	<b>.152</b>	<b>.005 - .010</b>	.250	.140	.010 - .020	.253	.096	.025 - .040	<b>.263</b>	<b>.195</b>	<b>.005 - .010</b>	.271	.199	.015 - .025	.277	.140	.020 - .030
.249	.158	.020 - .030	.250	.140	.040 - .060	.253	.115	.005 - .012	.263	.199	.010 - .025	.271	.221	.020 - .030	<b>.277</b>	<b>.143</b>	<b>.005 - .010</b>
.249	.160	.020 - .040	.250	.146	.010 - .020	.253	.116	.005 - .012	.264	.108	.025 - .040	.272	.093	.025 - .042	.277	.146	.050 - .070
.249	.170	.025 - .040	.250	.147	.005 - .015	.253	.125	.040 - .060	.264	.139	.015 - .025	.272	.095	.015 - .030	.277	.161	.015 - .030
.249	.172	.010 - .020	.250	.147	.030 - .050	.253	.127	.020 - .030	<b>.264</b>	<b>.147</b>	<b>.005 - .010</b>	.272	.121	.020 - .040	.277	.163	.015 - .025
<b>.249</b>	<b>.186</b>	<b>.005 - .010</b>	.250	.150	.005 - .015	.253	.132	.025 - .040	.264	.162	.025 - .040	.272	.132	.015 - .030	.277	.166	.005 - .008
.249	.189	.015 - .032	.250	.153	.010 - .020	.253	.145	.025 - .040	.264	.168	.015 - .025	.272	.156	.030 - .048	.277	.170	.015 - .030
.249	.190	.005 - .008	.250	.154	.015 - .025	.253	.166	.020 - .040	<b>.264</b>	<b>.240</b>	<b>.005 - .010</b>	.272	.169	.032 - .042	<b>.277</b>	<b>.195</b>	<b>.005 - .010</b>
.249	.193	.008 - .012	.250	.157	.025 - .040	.253	.190	.020 - .040	.265	.101	.020 - .040	.272	.192	.015 - .032	.277	.201	.010 - .020
			.250	.158	.015 - .030	.253	.191	.020 - .040	.265	.115	.040 - .050	.272	.194	.010 - .020	<b>.278</b>	<b>.087</b>	<b>.005 - .010</b>
			.250	.159	.020 - .036	<b>.253</b>	<b>.192</b>	<b>.005 - .010</b>	.265	.122	.020 - .040	<b>.272</b>	<b>.220</b>	<b>.005 - .010</b>	.278	.135	.040 - .062
			<b>.250</b>	<b>.161</b>	<b>.005 - .010</b>	<b>.253</b>	<b>.197</b>	<b>.005 - .010</b>	<b>.265</b>	<b>.125</b>	<b>.005 - .010</b>	<b>.273</b>	<b>.104</b>	<b>.005 - .010</b>	.278	.141	.010 - .020
			.250	.162	.032 - .042	.254	.051	.030 - .050	.265	.126	.020 - .040	.273	.108	.015 - .030	.278	.142	.025 - .040
			.250	.164	.010 - .020	.254	.117	.010 - .020	<b>.265</b>	<b>.129</b>	<b>.005 - .010</b>	.273	.118	.015 - .030	.278	.151	.015 - .030
			.250	.165	.010 - .020	.254	.127	.025 - .040	<b>.265</b>	<b>.141</b>	<b>.005 - .010</b>	.273	.141	.015 - .025	<b>.278</b>	<b>.155</b>	<b>.005 - .010</b>
			<b>.250</b>	<b>.166</b>	<b>.005 - .010</b>	<b>.254</b>	<b>.159</b>	<b>.005 - .010</b>	.265	.143	.040 - .062	<b>.273</b>	<b>.148</b>	<b>.005 - .010</b>	<b>.278</b>	<b>.190</b>	<b>.005 - .010</b>
			.250	.166	.008 - .012	.254	.160	.025 - .042	<b>.265</b>	<b>.153</b>	<b>.005 - .010</b>	.273	.149	.020 - .030	.278	.191	.015 - .032
<b>.250</b>	<b>.027</b>	<b>.005 - .010</b>	.250	.167	.010 - .015	.254	.194	.025 - .035	<b>.265</b>	<b>.160</b>	<b>.005 - .010</b>	.273	.163	.020 - .040	.278	.224	.010 - .020
<b>.250</b>	<b>.039</b>	<b>.005 - .010</b>	.250	.167	.020 - .035	.254	.194	.035 - .042	.265	.161	.010 - .030	<b>.273</b>	<b>.173</b>	<b>.005 - .010</b>	.279	.045	.005 - .015
.250	.039	.015 - .025	.250	.167	.035 - .045	<b>.254</b>	<b>.201</b>	<b>.005 - .010</b>	.265	.166	.010 - .015	.273	.203	.020 - .030	.279	.116	.010 - .020
.250	.044	.005 - .015	<b>.250</b>	<b>.172</b>	<b>.005 - .010</b>	<b>.254</b>	<b>.205</b>	<b>.005 - .010</b>	.265	.183	.025 - .040	<b>.274</b>	<b>.032</b>	<b>.005 - .010</b>	.279	.129	.010 - .015
.250	.052	.005 - .012	.250	.173	.025 - .040	<b>.255</b>	<b>.097</b>	<b>.005 - .010</b>	<b>.265</b>	<b>.189</b>	<b>.005 - .010</b>	<b>.274</b>	<b>.052</b>	<b>.005 - .010</b>	.279	.139	.032 - .048
<b>.250</b>	<b>.063</b>	<b>.005 - .010</b>	.250	.176	.025 - .040	.255	.101	.030 - .050	.266	.082	.015 - .030	<b>.274</b>	<b>.093</b>	<b>.005 - .010</b>	.279	.140	.030 - .040
.250	.072	.005 - .012	.250	.186	.010 - .020	.255	.105	.025 - .040	<b>.266</b>	<b>.090</b>	<b>.005 - .010</b>	.274	.093	.025 - .040	.279	.144	.025 - .040
.250	.077	.012 - .025	.250	.189	.010 - .020	.255	.109	.010 - .020	<b>.266</b>	<b>.106</b>	<b>.005 - .010</b>	<b>.274</b>	<b>.095</b>	<b>.005 - .010</b>	.279	.156	.020 - .030
<b>.250</b>	<b>.082</b>	<b>.005 - .010</b>	.250	.190	.010 - .020	.255	.135	.015 - .030	.266	.110	.010 - .020	<b>.274</b>	<b>.121</b>	<b>.005 - .010</b>	.279	.170	.015 - .025
.250	.083	.015 - .020	.250	.191	.010 - .020	.255	.149	.040 - .050	.266	.123	.031 - .048	.274	.127	.030 - .060	<b>.279</b>	<b>.195</b>	<b>.005 - .010</b>
<b>.250</b>	<b>.085</b>	<b>.005 - .010</b>	.250	.192	.025 - .030	.255	.164	.035 - .050	.266	.131	.036 - .060	.274	.132	.025 - .035	.279	.195	.025 - .040
.250	.085	.010 - .030	.251	.036	.010 - .020	<b>.255</b>	<b>.167</b>	<b>.005 - .010</b>	.266	.134	.025 - .040	.274	.170	.030 - .050	.279	.197	.015 - .030
.250	.091	.020 - .030	.251	.057	.005 - .012	.255	.195	.040 - .060	.266	.168	.025 - .040	.274	.172	.040 - .060	.279	.217	.015 - .030
.250	.093	.062 - .083	<b>.251</b>	<b>.059</b>	<b>.005 - .010</b>	.256	.119	.040 - .060	.266	.171	.020 - .035	.274	.174	.035 - .050	<b>.279</b>	<b>.232</b>	<b>.005 - .010</b>
<b>.250</b>	<b>.094</b>	<b>.005 - .010</b>	.251	.063	.025 - .040	.256	.164	.025 - .042	.266	.179	.020 - .030	.274	.191	.005 - .020	.279	.247	.010 - .015
.250	.094	.010 - .025	.251	.074	.025 - .050	.257	.067	.015 - .030	.266	.185	.015 - .025	<b>.274</b>	<b>.211</b>	<b>.005 - .010</b>	.280	.067	.005 - .015
.250	.095	.007 - .015	<b>.251</b>	<b>.076</b>	<b>.005 - .010</b>	.257	.078	.025 - .040	<b>.266</b>	<b>.218</b>	<b>.005 - .010</b>	<b>.274</b>	<b>.237</b>	<b>.005 - .010</b>	.280	.079	.030 - .050
.250	.095	.020 - .040	<b>.251</b>	<b>.093</b>	<b>.005 - .010</b>	.257	.191	.010 - .020	.267	.059	.010 - .020	.275	.079	.010 - .020	.280	.105	.015 - .032
.250	.097	.030 - .050	.251	.101	.025 - .040	<b>.257</b>	<b>.213</b>	<b>.005 - .010</b>	.267	.100	.030 - .050	.275	.081	.020 - .040	.280	.115	.015 - .030
.250	.097	.060 - .080	.251	.108	.020 - .040	.258	.067	.015 - .030	<b>.267</b>	<b>.125</b>	<b>.005 - .010</b>	.275	.091	.020 - .040	.280	.118	.010 - .020
.250	.098	.010 - .025	.251	.113	.030 - .050	.258	.163	.015 - .030	.267	.140	.015 - .030	<b>.275</b>	<b>.096</b>	<b>.005 - .010</b>	.280	.122	.025 - .048
.250	.099	.032 - .050	.251	.115	.040 - .060	.258	.169	.020 - .030	.267	.143	.010 - .025	.275	.098	.030 - .050	.280	.126	.020 - .030
.250	.100	.025 - .040	.251	.122	.035 - .050	.258	.177	.005 - .015	.267	.144	.020 - .030	.275	.118	.020 - .040	<b>.280</b>	<b>.127</b>	<b>.005 - .010</b>
.250	.102	.015 - .025	.251	.125	.010 - .020	<b>.259</b>	<b>.116</b>	<b>.005 - .010</b>	<b>.267</b>	<b>.168</b>	<b>.005 - .010</b>	.275	.122	.020 - .040	.280	.128	.010 - .020
.250	.102	.040 - .060	.251	.127	.010 - .025	<b>.259</b>	<b>.160</b>	<b>.005 - .010</b>	.267	.170	.030 - .050	.275	.135	.005 - .012	.280	.128	.020 - .032
.250	.103	.015 - .025	.251	.130	.015 - .030	<b>.259</b>	<b>.213</b>	<b>.005 - .010</b>	.267	.178	.025 - .040	.275	.143	.010 - .020	.280	.133	.020 - .040
.250	.103	.040 - .060	<b>.251</b>	<b>.131</b>	<b>.005 - .010</b>	.260	.089	.010 - .020	.267	.190	.005 - .008						

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
<b>.281</b>	<b>.143</b>	<b>.005 - .010</b>	.288	.197	.015 - .030	<b>.296</b>	<b>.173</b>	<b>.005 - .010</b>	.301	.190	.010 - .020	<b>.308</b>	<b>.043</b>	<b>.005 - .012</b>	<b>.310</b>	<b>.250</b>	<b>.005 - .010</b>
<b>.281</b>	<b>.156</b>	<b>.005 - .010</b>	.289	.037	.020 - .030	.296	.188	.015 - .030	.301	.203	.015 - .030	<b>.308</b>	<b>.108</b>	<b>.005 - .015</b>	<b>.310</b>	<b>.250</b>	<b>.010 - .020</b>
.281	.159	.015 - .030	<b>.289</b>	<b>.046</b>	<b>.005 - .010</b>	.296	.189	.015 - .030	<b>.301</b>	<b>.215</b>	<b>.005 - .010</b>	<b>.308</b>	<b>.121</b>	<b>.015 - .030</b>	<b>.310</b>	<b>.254</b>	<b>.015 - .030</b>
.281	.162	.010 - .020	<b>.289</b>	<b>.084</b>	<b>.005 - .010</b>	.296	.190	.015 - .025	<b>.301</b>	<b>.225</b>	<b>.005 - .010</b>	<b>.308</b>	<b>.131</b>	<b>.005 - .010</b>	<b>.310</b>	<b>.255</b>	<b>.005 - .010</b>
.281	.162	.030 - .050	.289	.090	.075 - .090	.296	.198	.025 - .042	<b>.301</b>	<b>.245</b>	<b>.005 - .010</b>	<b>.308</b>	<b>.136</b>	<b>.005 - .010</b>	<b>.310</b>	<b>.255</b>	<b>.010 - .020</b>
.281	.170	.016 - .032	.289	.091	.060 - .075	.296	.258	.005 - .015	.301	.255	.010 - .016	<b>.308</b>	<b>.140</b>	<b>.005 - .015</b>	<b>.310</b>	<b>.256</b>	<b>.010 - .020</b>
<b>.281</b>	<b>.173</b>	<b>.005 - .010</b>	<b>.289</b>	<b>.123</b>	<b>.005 - .010</b>	.297	.062	.010 - .025	.302	.125	.070 - .090	<b>.308</b>	<b>.143</b>	<b>.015 - .030</b>	<b>.310</b>	<b>.257</b>	<b>.005 - .010</b>
.281	.185	.015 - .030	<b>.289</b>	<b>.126</b>	<b>.005 - .010</b>	<b>.297</b>	<b>.086</b>	<b>.005 - .010</b>	.302	.130	.050 - .070	<b>.308</b>	<b>.145</b>	<b>.020 - .030</b>	<b>.310</b>	<b>.257</b>	<b>.020 - .030</b>
<b>.281</b>	<b>.186</b>	<b>.005 - .010</b>	.289	.126	.010 - .030	.297	.120	.050 - .070	.302	.131	.040 - .060	<b>.308</b>	<b>.148</b>	<b>.030 - .050</b>	<b>.310</b>	<b>.258</b>	<b>.005 - .010</b>
.281	.187	.015 - .030	.289	.175	.025 - .040	.297	.135	.020 - .035	<b>.302</b>	<b>.141</b>	<b>.005 - .010</b>	<b>.308</b>	<b>.175</b>	<b>.040 - .060</b>	<b>.310</b>	<b>.260</b>	<b>.005 - .010</b>
.282	.082	.030 - .040	.289	.189	.040 - .050	.297	.159	.030 - .050	<b>.302</b>	<b>.151</b>	<b>.005 - .010</b>	<b>.308</b>	<b>.188</b>	<b>.040 - .060</b>	<b>.311</b>	<b>.118</b>	<b>.050 - .075</b>
.282	.089	.075 - .093	.289	.192	.010 - .020	.297	.190	.010 - .020	.302	.167	.035 - .050	<b>.308</b>	<b>.199</b>	<b>.005 - .010</b>	<b>.311</b>	<b>.125</b>	<b>.005 - .010</b>
.282	.096	.015 - .025	<b>.290</b>	<b>.103</b>	<b>.005 - .010</b>	.297	.203	.020 - .040	.302	.168	.015 - .025	<b>.308</b>	<b>.204</b>	<b>.020 - .040</b>	<b>.311</b>	<b>.126</b>	<b>.030 - .050</b>
.282	.123	.005 - .015	<b>.290</b>	<b>.126</b>	<b>.005 - .010</b>	<b>.297</b>	<b>.209</b>	<b>.005 - .010</b>	.302	.172	.015 - .025	<b>.308</b>	<b>.205</b>	<b>.005 - .010</b>	<b>.311</b>	<b>.127</b>	<b>.012 - .025</b>
.282	.126	.015 - .025	.290	.126	.010 - .030	<b>.297</b>	<b>.255</b>	<b>.005 - .010</b>	<b>.302</b>	<b>.190</b>	<b>.005 - .010</b>	<b>.308</b>	<b>.205</b>	<b>.016 - .025</b>	<b>.311</b>	<b>.128</b>	<b>.060 - .080</b>
.282	.127	.040 - .060	.290	.128	.015 - .030	.298	.062	.010 - .020	.302	.190	.020 - .032	<b>.308</b>	<b>.209</b>	<b>.015 - .025</b>	<b>.311</b>	<b>.129</b>	<b>.025 - .048</b>
<b>.282</b>	<b>.130</b>	<b>.005 - .010</b>	.290	.137	.010 - .020	<b>.298</b>	<b>.139</b>	<b>.005 - .010</b>	.302	.190	.025 - .040	<b>.308</b>	<b>.210</b>	<b>.015 - .025</b>	<b>.311</b>	<b>.130</b>	<b>.005 - .010</b>
.282	.173	.025 - .040	<b>.290</b>	<b>.139</b>	<b>.005 - .010</b>	<b>.298</b>	<b>.155</b>	<b>.005 - .010</b>	.302	.198	.015 - .030	<b>.308</b>	<b>.254</b>	<b>.005 - .010</b>	<b>.311</b>	<b>.130</b>	<b>.012 - .025</b>
<b>.282</b>	<b>.176</b>	<b>.005 - .010</b>	.290	.151	.032 - .042	.298	.158	.008 - .016	.302	.205	.030 - .050	<b>.309</b>	<b>.031</b>	<b>.010 - .020</b>	<b>.311</b>	<b>.137</b>	<b>.030 - .050</b>
.282	.180	.025 - .040	.290	.199	.015 - .030	.298	.161	.025 - .040	.302	.252	.005 - .015	<b>.309</b>	<b>.070</b>	<b>.015 - .025</b>	<b>.311</b>	<b>.142</b>	<b>.040 - .050</b>
.282	.184	.006 - .016	.290	.201	.030 - .040	.298	.164	.030 - .050	<b>.303</b>	<b>.114</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.094</b>	<b>.010 - .020</b>	<b>.311</b>	<b>.142</b>	<b>.050 - .070</b>
.282	.187	.040 - .050	.290	.209	.025 - .040	.298	.180	.015 - .030	<b>.303</b>	<b>.128</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.109</b>	<b>.025 - .040</b>	<b>.311</b>	<b>.147</b>	<b>.080 - .090</b>
.282	.191	.025 - .040	.291	.078	.015 - .030	.298	.181	.030 - .050	.303	.171	.020 - .040	<b>.309</b>	<b>.147</b>	<b>.010 - .020</b>	<b>.311</b>	<b>.155</b>	<b>.015 - .030</b>
.282	.197	.010 - .020	.291	.159	.040 - .060	.298	.193	.015 - .025	.303	.181	.030 - .050	<b>.309</b>	<b>.159</b>	<b>.020 - .030</b>	<b>.311</b>	<b>.155</b>	<b>.030 - .050</b>
.282	.223	.007 - .015	.291	.176	.020 - .040	<b>.298</b>	<b>.200</b>	<b>.005 - .010</b>	<b>.303</b>	<b>.191</b>	<b>.025 - .040</b>	<b>.309</b>	<b>.161</b>	<b>.040 - .062</b>	<b>.311</b>	<b>.159</b>	<b>.005 - .010</b>
<b>.283</b>	<b>.095</b>	<b>.005 - .010</b>	.291	.184	.008 - .015	<b>.298</b>	<b>.205</b>	<b>.005 - .010</b>	.303	.197	.030 - .050	<b>.309</b>	<b>.172</b>	<b>.020 - .035</b>	<b>.311</b>	<b>.159</b>	<b>.012 - .025</b>
.283	.096	.015 - .030	.291	.190	.025 - .050	<b>.298</b>	<b>.241</b>	<b>.005 - .010</b>	<b>.303</b>	<b>.198</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.176</b>	<b>.020 - .030</b>	<b>.311</b>	<b>.160</b>	<b>.010 - .020</b>
.283	.098	.032 - .062	<b>.291</b>	<b>.195</b>	<b>.005 - .010</b>	.299	.105	.030 - .040	<b>.303</b>	<b>.200</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.191</b>	<b>.030 - .050</b>	<b>.311</b>	<b>.166</b>	<b>.040 - .062</b>
.283	.111	.010 - .020	.291	.244	.015 - .025	.299	.116	.010 - .020	.303	.220	.030 - .050	<b>.309</b>	<b>.194</b>	<b>.025 - .040</b>	<b>.311</b>	<b>.167</b>	<b>.005 - .015</b>
.283	.140	.025 - .042	<b>.291</b>	<b>.250</b>	<b>.005 - .010</b>	.299	.145	.010 - .030	<b>.303</b>	<b>.225</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.195</b>	<b>.050 - .070</b>	<b>.311</b>	<b>.177</b>	<b>.005 - .010</b>
.283	.143	.010 - .015	.292	.114	.040 - .060	<b>.299</b>	<b>.202</b>	<b>.005 - .010</b>	<b>.303</b>	<b>.234</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.202</b>	<b>.030 - .050</b>	<b>.311</b>	<b>.183</b>	<b>.042 - .062</b>
.283	.165	.008 - .015	.292	.145	.025 - .040	.300	.045	.025 - .040	.303	.240	.020 - .030	<b>.309</b>	<b>.210</b>	<b>.010 - .020</b>	<b>.311</b>	<b>.187</b>	<b>.025 - .042</b>
<b>.283</b>	<b>.166</b>	<b>.005 - .010</b>	<b>.292</b>	<b>.146</b>	<b>.005 - .010</b>	.300	.065	.008 - .020	.303	.251	.010 - .020	<b>.309</b>	<b>.247</b>	<b>.005 - .010</b>	<b>.311</b>	<b>.188</b>	<b>.005 - .010</b>
.283	.168	.025 - .040	.292	.148	.020 - .040	.300	.065	.025 - .040	.304	.083	.025 - .040	<b>.309</b>	<b>.251</b>	<b>.015 - .030</b>	<b>.311</b>	<b>.188</b>	<b>.020 - .030</b>
.283	.173	.030 - .040	.292	.149	.030 - .040	<b>.300</b>	<b>.081</b>	<b>.005 - .010</b>	.304	.163	.010 - .020	<b>.309</b>	<b>.254</b>	<b>.010 - .030</b>	<b>.311</b>	<b>.188</b>	<b>.030 - .050</b>
<b>.283</b>	<b>.184</b>	<b>.005 - .010</b>	<b>.292</b>	<b>.171</b>	<b>.005 - .010</b>	.300	.095	.010 - .020	<b>.304</b>	<b>.174</b>	<b>.005 - .010</b>	<b>.309</b>	<b>.255</b>	<b>.015 - .030</b>	<b>.311</b>	<b>.190</b>	<b>.015 - .030</b>
.283	.190	.008 - .015	.292	.192	.010 - .015	.300	.097	.016 - .025	.304	.217	.030 - .050	<b>.310</b>	<b>.047</b>	<b>.025 - .035</b>	<b>.311</b>	<b>.191</b>	<b>.008 - .020</b>
.283	.200	.010 - .020	.292	.193	.020 - .030	.300	.097	.060 - .090	.304	.241	.010 - .020	<b>.310</b>	<b>.060</b>	<b>.010 - .025</b>	<b>.311</b>	<b>.191</b>	<b>.020 - .040</b>
<b>.283</b>	<b>.216</b>	<b>.005 - .010</b>	.292	.197	.040 - .050	.300	.100	.005 - .015	.304	.245	.015 - .020	<b>.310</b>	<b>.071</b>	<b>.005 - .010</b>	<b>.311</b>	<b>.195</b>	<b>.005 - .010</b>
.283	.216	.015 - .030	<b>.292</b>	<b>.236</b>	<b>.005 - .010</b>	.300	.116	.020 - .040	.304	.250	.020 - .030	<b>.310</b>	<b>.076</b>	<b>.020 - .040</b>	<b>.311</b>	<b>.204</b>	<b>.005 - .010</b>
<b>.283</b>	<b>.218</b>	<b>.005 - .010</b>	.293	.034	.015 - .025	.300	.117	.025 - .040	.305	.087	.025 - .040	<b>.310</b>	<b>.088</b>	<b>.015 - .025</b>	<b>.311</b>	<b>.204</b>	<b>.010 - .020</b>
.283	.218	.015 - .025	.293	.124	.010 - .020	<b>.300</b>	<b>.119</b>	<b>.005 - .010</b>	<b>.305</b>	<b>.125</b>	<b>.005 - .010</b>	<b>.310</b>	<b>.090</b>	<b>.012 - .025</b>	<b>.311</b>	<b>.215</b>	<b>.005 - .010</b>
<b>.283</b>	<b>.250</b>	<b>.005 - .010</b>	<b>.293</b>	<b>.129</b>	<b>.005 - .010</b>	<b>.300</b>	<b>.128</b>	<b>.005 - .010</b>	.305	.140	.032 - .060	<b>.310</b>	<b>.093</b>	<b>.025 - .040</b>	<b>.311</b>	<b>.217</b>	<b>.020 - .040</b>
.284	.095	.015 - .025	<b>.293</b>	<b>.147</b>	<b>.005 - .010</b>	.300	.128	.040 - .060	.305	.153	.015 - .025	<b>.310</b>	<b>.095</b>	<b>.025 - .035</b>	<b>.311</b>	<b>.219</b>	<b>.020 - .035</b>
.284	.119	.025 - .040	.293	.188	.030 - .050	.300	.130	.030 - .050	.305	.156	.010 - .020	<b>.310</b>	<b>.096</b>	<b>.005 - .010</b>	<b>.311</b>	<b>.231</b>	<b>.025 - .040</b>
.284	.125	.005 - .015	.293	.192	.040 - .050	.300	.138	.040 - .060	.305	.160	.025 - .040	<b>.310</b>	<b>.102</b>	<b>.015 - .030</b>	<b>.311</b>	<b>.238</b>	<b>.005 - .010</b>
.284	.191	.010 - .018	<b>.293</b>	<b>.219</b>	<b>.005 - .010</b>	.300	.144	.015 - .030	.305	.162	.015 - .030	<b>.310</b>	<b>.104</b>	<b>.020 - .040</b>	<b>.312</b>	<b>.039</b>	<b>.005 - .012</b>
.284	.200	.010 - .020	.294	.086	.015 - .030	.300	.145	.005 - .012	.305	.169	.025 - .040	<b>.310</b>	<b>.106</b>	<b>.025 - .050</b>	<b>.312</b>	<b>.054</b>	<b>.005 - .010</b>
<b>.284</b>	<b>.212</b>	<b>.005 - .010</b>	.294	.089	.015 - .030	.300	.157	.020 - .030	.305	.188	.010 - .020	<b>.310</b>	<b>.119</b>	<b>.025 - .050</b>	<b>.312</b>	<b>.062</b>	<b>.015 - .030</b>
<b>.285</b>	<b>.079</b>	<b>.005 - .010</b>	.294	.122	.015 - .030	.300	.162	.025 - .040	<b>.305</b>	<b>.197</b>	<b>.005 - .010</b>	<b>.310</b>	<b>.120</b>	<b>.030 - .060</b>	<b>.312</b>	<b>.066</b>	<b>.010 - .020</b>
<b>.285</b>	<b>.088</b>	<b>.005 - .010</b>	.294	.126	.015 - .030	<b>.300</b>	<b>.166</b>	<b>.005 - .010</b>	.305	.204	.025 - .048	<b>.310</b>	<b>.122</b>	<b>.025 - .035</b>	<b>.312</b>	<b>.072</b>	<b>.005 - .010</b>
.285	.107	.020 - .032	.294	.177	.040 - .060	.300	.167	.030 - .042	.305	.205	.025 - .042	<b>.310</b>	<b>.124</b>	<b>.005 - .010</b>	<b>.312</b>	<b>.073</b>	<b>.015 - .025</b>
.285	.115	.015 - .030	.294	.187	.030 - .050	.300	.169	.015 - .030	<b>.305</b>	<b>.221</b>	<b>.005 - .010</b>	<b>.310</b>	<b>.127</b>	<b>.020 - .030</b>	<b>.312</b>	<b>.090</b>	<b>.025 - .050</b>
.285	.127	.010 - .020	.294	.192	.005 - .012	.300	.175	.025 - .040	.305	.225	.010 - .020	<b>.310</b>	<b>.127</b>	<b>.042 - .062</b>	<b>.312</b>	<b>.093</b>	<b>.005 - .010</b>
.285	.127	.025 - .035	<b>.294</b>	<b>.224</b>	<b>.005 - .010</b>	<b>.300</b>	<b>.176</b>	<b>.005 - .010</b>	.306	.045	.010 - .025	<b>.310</b>	<b>.127</b>	<b>.062 - .075</b>	<b>.312</b>	<b>.093</b>	<b>.042 - .062</b>
.285	.128	.010 - .020	.295	.106	.008 - .016	.300	.177	.010 - .020	.306	.127	.025 - .040	<b>.310</b>	<b>.130</b>	<b>.030 - .050</b>	<b>.312</b>	<b>.094</b>	<b>.020 - .030</b>
.285																	

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.312	.146	.008 - .016	.313	.207	.020 - .040	.318	.132	.010 - .020	.325	.236	.025 - .040	.333	.173	.032 - .048	.340	.257	.010 - .020
.312	.148	.040 - .060	<b>.313</b>	<b>.208</b>	<b>.005 - .010</b>	.318	.143	.008 - .020	.325	.244	.015 - .025	.333	.175	.020 - .030	.340	.283	.015 - .025
<b>.312</b>	<b>.154</b>	<b>.005 - .010</b>	.313	.224	.020 - .040	.318	.191	.010 - .020	.325	.254	.015 - .025	.333	.175	.030 - .050	.341	.052	.025 - .040
.312	.154	.040 - .060	.313	.230	.005 - .015	.318	.198	.030 - .060	<b>.326</b>	<b>.138</b>	<b>.005 - .010</b>	.333	.212	.020 - .036	<b>.341</b>	<b>.061</b>	<b>.005 - .010</b>
.312	.156	.016 - .032	.313	.232	.005 - .015	.318	.228	.008 - .016	.326	.150	.030 - .050	.333	.225	.010 - .020	.341	.090	.060 - .080
.312	.156	.032 - .040	<b>.313</b>	<b>.242</b>	<b>.005 - .010</b>	<b>.318</b>	<b>.237</b>	<b>.005 - .010</b>	<b>.326</b>	<b>.180</b>	<b>.005 - .010</b>	.333	.257	.015 - .025	.341	.093	.020 - .040
.312	.156	.050 - .080	.313	.253	.020 - .030	.319	.140	.015 - .030	<b>.326</b>	<b>.181</b>	<b>.005 - .010</b>	.334	.039	.015 - .025	<b>.341</b>	<b>.120</b>	<b>.005 - .010</b>
<b>.312</b>	<b>.157</b>	<b>.005 - .010</b>	.313	.255	.015 - .025	.319	.146	.020 - .030	.326	.189	.050 - .070	<b>.334</b>	<b>.122</b>	<b>.005 - .010</b>	.341	.131	.070 - .090
.312	.157	.025 - .035	.314	.039	.010 - .020	<b>.319</b>	<b>.178</b>	<b>.005 - .010</b>	<b>.326</b>	<b>.196</b>	<b>.005 - .010</b>	<b>.334</b>	<b>.127</b>	<b>.005 - .010</b>	.341	.141	.080 - .090
.312	.158	.010 - .020	<b>.314</b>	<b>.043</b>	<b>.010 - .010</b>	.319	.228	.010 - .020	<b>.326</b>	<b>.256</b>	<b>.005 - .010</b>	.334	.160	.015 - .030	.341	.158	.025 - .040
.312	.160	.040 - .060	.314	.088	.015 - .035	<b>.320</b>	<b>.061</b>	<b>.005 - .010</b>	.327	.113	.025 - .042	<b>.334</b>	<b>.196</b>	<b>.005 - .010</b>	.341	.161	.015 - .035
.312	.165	.020 - .040	.314	.103	.025 - .045	.320	.067	.030 - .042	.327	.120	.025 - .040	.334	.197	.032 - .048	.341	.164	.010 - .025
.312	.167	.015 - .025	.314	.111	.010 - .025	<b>.320</b>	<b>.078</b>	<b>.005 - .010</b>	.327	.130	.030 - .050	<b>.334</b>	<b>.220</b>	<b>.005 - .010</b>	.341	.202	.015 - .030
.312	.171	.040 - .060	.314	.114	.032 - .050	.320	.084	.030 - .040	.327	.190	.030 - .050	.334	.220	.035 - .050	.341	.281	.025 - .035
.312	.172	.020 - .030	.314	.122	.025 - .048	.320	.093	.042 - .060	.327	.194	.010 - .020	.334	.226	.025 - .040	<b>.342</b>	<b>.092</b>	<b>.005 - .010</b>
<b>.312</b>	<b>.173</b>	<b>.005 - .010</b>	.314	.128	.005 - .015	<b>.320</b>	<b>.113</b>	<b>.005 - .010</b>	.327	.217	.030 - .050	.334	.242	.010 - .020	.342	.092	.010 - .020
.312	.182	.010 - .020	.314	.139	.040 - .060	.320	.122	.015 - .030	.327	.258	.010 - .025	.334	.258	.020 - .030	.342	.118	.032 - .048
.312	.188	.020 - .040	.314	.148	.025 - .042	<b>.320</b>	<b>.124</b>	<b>.005 - .010</b>	<b>.327</b>	<b>.262</b>	<b>.005 - .010</b>	<b>.334</b>	<b>.260</b>	<b>.005 - .010</b>	.342	.145	.005 - .008
<b>.312</b>	<b>.189</b>	<b>.005 - .010</b>	.314	.148	.042 - .062	<b>.320</b>	<b>.131</b>	<b>.005 - .010</b>	<b>.328</b>	<b>.105</b>	<b>.005 - .010</b>	<b>.334</b>	<b>.275</b>	<b>.005 - .010</b>	.342	.162	.030 - .050
.312	.189	.040 - .062	.314	.152	.035 - .050	.320	.145	.025 - .042	.328	.162	.040 - .060	.334	.295	.010 - .015	.342	.164	.015 - .030
<b>.312</b>	<b>.190</b>	<b>.005 - .010</b>	.314	.158	.060 - .080	.320	.146	.015 - .030	.328	.175	.030 - .050	.335	.034	.010 - .020	.342	.193	.005 - .015
.312	.190	.015 - .030	.314	.161	.040 - .060	<b>.320</b>	<b>.149</b>	<b>.005 - .010</b>	<b>.328</b>	<b>.177</b>	<b>.005 - .010</b>	.335	.129	.015 - .025	.342	.193	.030 - .050
.312	.191	.008 - .015	.314	.162	.040 - .060	.320	.170	.015 - .025	.328	.179	.015 - .030	.335	.159	.060 - .075	.342	.198	.015 - .030
.312	.191	.012 - .020	.314	.176	.030 - .050	.320	.178	.010 - .020	.328	.192	.030 - .050	.335	.169	.015 - .030	.342	.201	.025 - .040
<b>.312</b>	<b>.192</b>	<b>.005 - .010</b>	.314	.189	.015 - .032	.320	.182	.050 - .070	.328	.197	.025 - .040	.335	.172	.010 - .020	.342	.206	.015 - .030
.312	.192	.010 - .020	.314	.219	.030 - .050	.320	.221	.050 - .062	.328	.200	.005 - .015	.335	.196	.025 - .040	.342	.212	.015 - .025
.312	.192	.020 - .035	.314	.220	.015 - .030	<b>.321</b>	<b>.062</b>	<b>.005 - .010</b>	.328	.214	.010 - .020	.335	.200	.020 - .040	.342	.255	.020 - .030
<b>.312</b>	<b>.193</b>	<b>.005 - .010</b>	.314	.225	.015 - .025	.321	.077	.020 - .030	.328	.214	.020 - .032	<b>.335</b>	<b>.204</b>	<b>.005 - .010</b>	.343	.087	.030 - .050
.312	.194	.025 - .040	<b>.314</b>	<b>.236</b>	<b>.005 - .010</b>	.321	.135	.020 - .035	.328	.219	.030 - .050	.335	.215	.030 - .050	.343	.088	.060 - .075
.312	.195	.020 - .035	.314	.242	.010 - .020	.321	.147	.010 - .020	.328	.222	.010 - .025	.335	.235	.010 - .020	<b>.343</b>	<b>.092</b>	<b>.005 - .010</b>
<b>.312</b>	<b>.199</b>	<b>.005 - .010</b>	.314	.256	.010 - .020	<b>.321</b>	<b>.203</b>	<b>.005 - .010</b>	<b>.328</b>	<b>.225</b>	<b>.005 - .010</b>	.335	.257	.010 - .016	.343	.094	.025 - .040
.312	.199	.008 - .020	.315	.025	.006 - .010	.321	.226	.010 - .020	.328	.225	.020 - .040	.335	.257	.020 - .030	.343	.097	.010 - .020
.312	.200	.040 - .060	<b>.315</b>	<b>.030</b>	<b>.005 - .010</b>	.321	.253	.020 - .030	.328	.245	.007 - .016	<b>.335</b>	<b>.258</b>	<b>.005 - .010</b>	.343	.110	.025 - .040
<b>.312</b>	<b>.204</b>	<b>.005 - .010</b>	.315	.030	.010 - .015	<b>.322</b>	<b>.050</b>	<b>.005 - .010</b>	.328	.252	.020 - .031	.335	.259	.005 - .015	.343	.116	.015 - .030
.312	.206	.010 - .020	.315	.068	.010 - .020	<b>.322</b>	<b>.128</b>	<b>.010 - .020</b>	<b>.328</b>	<b>.253</b>	<b>.005 - .010</b>	.336	.117	.040 - .060	.343	.134	.007 - .016
<b>.312</b>	<b>.208</b>	<b>.005 - .010</b>	.315	.087	.020 - .040	.322	.145	.015 - .030	.328	.256	.010 - .020	.336	.118	.040 - .060	.343	.138	.040 - .060
.312	.216	.010 - .020	.315	.092	.045 - .065	<b>.322</b>	<b>.206</b>	<b>.005 - .010</b>	.328	.260	.020 - .040	.336	.138	.032 - .048	.343	.161	.005 - .008
.312	.219	.015 - .030	.315	.095	.032 - .062	.322	.224	.010 - .020	<b>.328</b>	<b>.273</b>	<b>.005 - .010</b>	.336	.191	.030 - .050	.343	.167	.010 - .020
<b>.312</b>	<b>.221</b>	<b>.005 - .010</b>	<b>.315</b>	<b>.097</b>	<b>.005 - .010</b>	.322	.228	.025 - .040	.329	.030	.010 - .020	<b>.336</b>	<b>.197</b>	<b>.005 - .010</b>	.343	.193	.005 - .008
<b>.312</b>	<b>.223</b>	<b>.005 - .010</b>	.315	.097	.015 - .030	.322	.241	.010 - .020	.329	.100	.025 - .040	<b>.336</b>	<b>.218</b>	<b>.005 - .010</b>	.343	.193	.010 - .020
.312	.223	.020 - .030	.315	.124	.050 - .060	.322	.242	.025 - .040	<b>.329</b>	<b>.108</b>	<b>.005 - .010</b>	.336	.230	.010 - .020	.343	.193	.030 - .040
.312	.223	.030 - .042	.315	.127	.050 - .070	.322	.287	.010 - .020	.329	.111	.010 - .020	.336	.257	.020 - .040	.343	.193	.040 - .060
.312	.227	.030 - .042	.315	.129	.030 - .050	.323	.094	.010 - .020	<b>.329</b>	<b>.206</b>	<b>.005 - .010</b>	<b>.336</b>	<b>.270</b>	<b>.005 - .010</b>	.343	.194	.060 - .078
.312	.228	.030 - .050	.315	.138	.060 - .080	.323	.099	.020 - .040	.329	.209	.030 - .050	<b>.336</b>	<b>.275</b>	<b>.005 - .010</b>	.343	.195	.006 - .016
.312	.231	.025 - .040	.315	.147	.020 - .030	.323	.130	.025 - .042	<b>.329</b>	<b>.221</b>	<b>.005 - .010</b>	<b>.336</b>	<b>.306</b>	<b>.005 - .010</b>	.343	.195	.050 - .070
<b>.312</b>	<b>.251</b>	<b>.005 - .010</b>	.315	.157	.005 - .015	<b>.323</b>	<b>.160</b>	<b>.005 - .010</b>	.329	.245	.020 - .040	.337	.129	.005 - .012	.343	.196	.010 - .020
.312	.252	.025 - .042	<b>.315</b>	<b>.160</b>	<b>.005 - .010</b>	.323	.160	.015 - .025	<b>.329</b>	<b>.253</b>	<b>.005 - .010</b>	.337	.165	.015 - .025	.343	.197	.025 - .040
.312	.254	.015 - .030	.315	.162	.020 - .030	.323	.166	.020 - .030	<b>.329</b>	<b>.288</b>	<b>.005 - .010</b>	.337	.252	.020 - .030	.343	.217	.040 - .050
<b>.313</b>	<b>.082</b>	<b>.005 - .010</b>	<b>.315</b>	<b>.163</b>	<b>.005 - .010</b>	.323	.171	.015 - .030	<b>.330</b>	<b>.093</b>	<b>.005 - .010</b>	.337	.277	.015 - .030	.343	.219	.032 - .050
.313	.096	.075 - .090	.315	.170	.020 - .040	.323	.180	.042 - .062	.330	.124	.020 - .032	.337	.285	.015 - .030	<b>.343</b>	<b>.229</b>	<b>.005 - .010</b>
.313	.100	.008 - .020	.315	.223	.030 - .050	.323	.180	.062 - .090	.330	.140	.042 - .062	<b>.338</b>	<b>.115</b>	<b>.005 - .010</b>	.343	.230	.025 - .035
.313	.100	.020 - .042	.315	.238	.010 - .020	<b>.323</b>	<b>.196</b>	<b>.005 - .010</b>	.330	.143	.020 - .040	.338	.168	.072 - .090	<b>.343</b>	<b>.245</b>	<b>.005 - .010</b>
.313	.101	.040 - .060	<b>.315</b>	<b>.250</b>	<b>.005 - .010</b>	.323	.200	.020 - .032	<b>.330</b>	<b>.193</b>	<b>.005 - .010</b>	.338	.170	.010 - .020	.343	.261	.010 - .020
.313	.105	.008 - .020	.315	.250	.010 - .020	.323	.211	.020 - .030	.330	.206	.005 - .015	.338	.201	.050 - .060	.343	.274	.020 - .040
.313	.110	.008 - .015	.316	.098	.030 - .050	<b>.323</b>	<b>.213</b>	<b>.005 - .010</b>	<b>.330</b>	<b>.217</b>	<b>.005 - .010</b>	<b>.338</b>	<b>.238</b>	<b>.005 - .010</b>	<b>.344</b>	<b>.102</b>	<b>.005 - .010</b>
<b>.313</b>	<b>.120</b>	<b>.005 - .010</b>	.316	.105	.025 - .048	<b>.323</b>	<b>.223</b>	<b>.005 - .010</b>	.330	.229	.025 - .040	.338	.251	.015 - .030	.344	.152	.025 - .045
.313	.123	.050 - .070	.316	.124	.060 - .075	<b>.324</b>	<b>.035</b>	<b>.005 - .010</b>	<b>.330</b>	<b>.250</b>	<b>.005 - .010</b>	.338	.253	.010 - .020	.344	.165	.015 - .030
.313	.126	.020 - .040	<b>.316</b>	<b>.134</b>	<b>.005 - .010</b>	<b>.324</b>	<b>.099</b>	<b>.005 - .010</b>	<b>.330</b>	<b>.251</b>	<b>.005 - .010</b>	.339	.150	.010 - .020	.344	.167	.015 - .025
<b>.313</b>	<b>.129</b>	<b>.005 - .010</b>	<b>.316</b>	<b>.140</b>	<b>.005 - .010</b>	.324	.126	.020 - .040	.330	.251	.010 - .020	<b>.339</b>	<b>.151</b>	<b>.005 - .010</b>	.344	.172	.035 - .050
.313	.130	.025 - .040	<b>.316</b>	<b>.153</b>	<b>.005 - .010</b>	.324	.145	.010 - .020	.330	.253	.020 - .040	<b>.339</b>	<b>.157</b>	<b>.005 - .010</b>	.344	.184	.025 - .040
.313	.133	.015 - .030	<b>.316</b>	<b>.157</b>	<b>.005 - .010</b>	.324	.162	.060 - .080	.330	.257	.020 - .036	.339	.176	.020 - .040	.344	.189	.015 - .025
.313	.138	.025 - .040	<b>.316</b>	<b>.167</b>	<b>.005 - .010</b>	.324	.165	.060 - .080	<b>.3</b>								

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
<b>.345</b>	<b>.205</b>	<b>.005 - .010</b>	.351	.200	.025 - .050	<b>.357</b>	.150	.030 - .050	.365	.046	.010 - .020	<b>.369</b>	<b>.205</b>	<b>.005 - .010</b>	<b>.372</b>	<b>.199</b>	<b>.005 - .010</b>
<b>.345</b>	<b>.216</b>	<b>.005 - .010</b>	.351	.201	.020 - .030	.357	.173	.070 - .090	<b>.365</b>	<b>.062</b>	<b>.005 - .010</b>	.369	.208	.025 - .040	.372	.199	.010 - .016
.345	.223	.030 - .050	.351	.208	.030 - .060	.357	.191	.060 - .080	.365	.098	.020 - .040	<b>.369</b>	<b>.215</b>	<b>.005 - .010</b>	.372	.202	.015 - .030
.345	.228	.015 - .030	.351	.230	.040 - .060	.357	.195	.060 - .080	<b>.365</b>	<b>.178</b>	<b>.005 - .010</b>	<b>.369</b>	<b>.224</b>	<b>.005 - .010</b>	.372	.204	.030 - .050
.345	.252	.010 - .020	.351	.241	.020 - .040	.357	.260	.040 - .050	.365	.189	.007 - .015	.369	.257	.050 - .070	.372	.208	.015 - .030
.345	.276	.015 - .030	.351	.252	.010 - .020	.357	.303	.010 - .020	<b>.365</b>	<b>.200</b>	<b>.005 - .010</b>	<b>.369</b>	<b>.313</b>	<b>.005 - .010</b>	.372	.221	.050 - .075
<b>.345</b>	<b>.277</b>	<b>.005 - .010</b>	.351	.268	.020 - .030	<b>.357</b>	<b>.318</b>	<b>.005 - .010</b>	.365	.208	.020 - .040	<b>.369</b>	<b>.324</b>	<b>.005 - .010</b>	.372	.230	.015 - .030
.346	.046	.025 - .040	.351	.309	.010 - .020	.358	.126	.025 - .040	.365	.212	.050 - .070	.370	.034	.020 - .025	.372	.253	.010 - .020
.346	.084	.030 - .050	.352	.031	.010 - .020	.358	.127	.015 - .025	<b>.365</b>	<b>.226</b>	<b>.005 - .010</b>	.370	.088	.010 - .025	.372	.254	.010 - .020
<b>.346</b>	<b>.116</b>	<b>.005 - .010</b>	.352	.090	.010 - .015	.358	.170	.006 - .010	.365	.247	.050 - .070	.370	.101	.010 - .020	.372	.254	.040 - .060
.346	.128	.050 - .070	.352	.129	.020 - .030	.358	.178	.030 - .050	<b>.365</b>	<b>.250</b>	<b>.005 - .010</b>	.370	.110	.025 - .040	<b>.372</b>	<b>.255</b>	<b>.005 - .010</b>
.346	.143	.040 - .060	.352	.167	.030 - .050	<b>.358</b>	<b>.203</b>	<b>.005 - .010</b>	.365	.250	.010 - .020	<b>.370</b>	<b>.119</b>	<b>.005 - .010</b>	.372	.256	.005 - .015
.346	.149	.075 - .090	.352	.168	.008 - .020	.358	.204	.020 - .030	.365	.253	.025 - .040	<b>.370</b>	<b>.125</b>	<b>.005 - .010</b>	.372	.257	.020 - .030
<b>.346</b>	<b>.152</b>	<b>.005 - .010</b>	.352	.184	.015 - .030	.358	.238	.025 - .040	<b>.365</b>	<b>.254</b>	<b>.005 - .010</b>	.370	.125	.030 - .060	.372	.258	.040 - .050
.346	.158	.005 - .015	.352	.191	.035 - .050	<b>.358</b>	<b>.252</b>	<b>.005 - .010</b>	.365	.255	.015 - .025	<b>.370</b>	<b>.126</b>	<b>.005 - .010</b>	<b>.372</b>	<b>.272</b>	<b>.005 - .010</b>
.346	.158	.015 - .025	.352	.236	.030 - .050	.358	.257	.010 - .020	.365	.257	.015 - .030	.370	.140	.010 - .020	.372	.278	.025 - .042
.346	.163	.006 - .015	.352	.240	.040 - .060	.359	.069	.030 - .050	.365	.265	.042 - .062	.370	.140	.030 - .042	.372	.311	.015 - .030
<b>.346</b>	<b>.166</b>	<b>.005 - .010</b>	<b>.352</b>	<b>.254</b>	<b>.005 - .010</b>	.359	.127	.025 - .040	<b>.365</b>	<b>.268</b>	<b>.005 - .010</b>	.370	.146	.025 - .048	.372	.312	.005 - .008
.346	.172	.040 - .060	.352	.255	.030 - .050	.359	.137	.010 - .020	.365	.270	.020 - .040	.370	.158	.010 - .020	.372	.312	.020 - .035
.346	.172	.072 - .090	.352	.263	.010 - .020	.359	.158	.010 - .020	<b>.365</b>	<b>.307</b>	<b>.005 - .010</b>	.370	.159	.035 - .060	<b>.372</b>	<b>.315</b>	<b>.005 - .010</b>
<b>.346</b>	<b>.180</b>	<b>.005 - .010</b>	.353	.062	.015 - .025	.359	.159	.020 - .035	<b>.365</b>	<b>.312</b>	<b>.005 - .010</b>	.370	.160	.070 - .080	.373	.039	.025 - .035
<b>.346</b>	<b>.196</b>	<b>.005 - .010</b>	.353	.128	.020 - .040	.359	.190	.020 - .040	.365	.312	.010 - .020	.370	.171	.005 - .020	.373	.041	.010 - .020
.346	.207	.030 - .050	.353	.143	.020 - .040	.359	.195	.030 - .050	<b>.365</b>	<b>.315</b>	<b>.005 - .010</b>	.370	.173	.020 - .040	.373	.068	.015 - .030
.346	.216	.020 - .030	.353	.143	.060 - .075	.359	.204	.010 - .025	<b>.366</b>	<b>.077</b>	<b>.005 - .010</b>	.370	.180	.020 - .030	.373	.081	.040 - .062
.346	.219	.010 - .020	.353	.157	.015 - .030	.359	.210	.025 - .042	.366	.129	.015 - .025	.370	.189	.020 - .040	.373	.127	.005 - .015
<b>.346</b>	<b>.253</b>	<b>.005 - .010</b>	<b>.353</b>	<b>.158</b>	<b>.005 - .010</b>	.359	.221	.025 - .040	.366	.158	.015 - .030	<b>.370</b>	<b>.191</b>	<b>.005 - .010</b>	.373	.142	.062 - .078
<b>.346</b>	<b>.289</b>	<b>.005 - .010</b>	.353	.158	.015 - .030	.359	.257	.010 - .020	.366	.190	.040 - .060	.370	.196	.010 - .020	.373	.157	.020 - .040
.347	.157	.020 - .030	.353	.159	.030 - .050	.359	.258	.020 - .040	<b>.366</b>	<b>.206</b>	<b>.005 - .010</b>	.370	.199	.015 - .025	.373	.159	.020 - .040
.347	.174	.030 - .050	.353	.172	.025 - .040	.359	.260	.031 - .042	.366	.206	.010 - .020	<b>.370</b>	<b>.205</b>	<b>.005 - .010</b>	.373	.165	.005 - .015
.347	.203	.025 - .040	.353	.190	.015 - .030	.359	.267	.020 - .032	.366	.218	.016 - .032	.370	.206	.025 - .040	.373	.168	.010 - .020
.347	.220	.015 - .030	.353	.225	.032 - .050	.359	.284	.010 - .020	.366	.219	.015 - .030	.370	.211	.060 - .080	<b>.373</b>	<b>.174</b>	<b>.005 - .010</b>
.347	.234	.040 - .060	.353	.226	.020 - .042	<b>.359</b>	<b>.293</b>	<b>.005 - .010</b>	.366	.225	.020 - .040	.370	.212	.040 - .050	.373	.175	.050 - .078
.347	.253	.016 - .025	.353	.232	.020 - .040	.359	.293	.010 - .015	.366	.253	.005 - .015	.370	.218	.040 - .060	.373	.189	.030 - .050
.347	.256	.006 - .016	<b>.353</b>	<b>.237</b>	<b>.005 - .010</b>	<b>.360</b>	<b>.038</b>	<b>.005 - .010</b>	<b>.366</b>	<b>.254</b>	<b>.005 - .010</b>	.370	.220	.015 - .030	.373	.191	.030 - .050
<b>.347</b>	<b>.263</b>	<b>.005 - .010</b>	.353	.242	.015 - .025	<b>.360</b>	<b>.080</b>	<b>.005 - .010</b>	.366	.254	.015 - .030	.370	.254	.020 - .040	.373	.191	.050 - .072
<b>.347</b>	<b>.287</b>	<b>.005 - .010</b>	<b>.353</b>	<b>.254</b>	<b>.005 - .010</b>	<b>.360</b>	<b>.095</b>	<b>.005 - .010</b>	.366	.268	.030 - .050	.370	.256	.015 - .030	.373	.192	.010 - .015
.348	.168	.020 - .040	<b>.353</b>	<b>.281</b>	<b>.005 - .010</b>	.360	.102	.015 - .030	.366	.272	.025 - .035	<b>.370</b>	<b>.261</b>	<b>.005 - .010</b>	.373	.192	.040 - .060
<b>.348</b>	<b>.172</b>	<b>.005 - .010</b>	<b>.354</b>	<b>.048</b>	<b>.005 - .010</b>	.360	.136	.006 - .012	.366	.274	.010 - .020	.370	.269	.040 - .060	<b>.373</b>	<b>.193</b>	<b>.005 - .010</b>
.348	.173	.010 - .020	.354	.052	.030 - .050	.360	.164	.020 - .032	.366	.294	.005 - .012	.370	.300	.020 - .030	.373	.193	.040 - .060
.348	.173	.030 - .042	.354	.061	.015 - .025	.360	.171	.025 - .040	.366	.305	.016 - .025	<b>.370</b>	<b>.330</b>	<b>.005 - .010</b>	<b>.373</b>	<b>.196</b>	<b>.005 - .010</b>
.348	.225	.025 - .042	.354	.070	.015 - .025	<b>.360</b>	<b>.175</b>	<b>.005 - .010</b>	.366	.312	.015 - .025	.371	.099	.025 - .040	<b>.373</b>	<b>.200</b>	<b>.005 - .010</b>
.349	.123	.010 - .020	.354	.099	.010 - .020	.360	.175	.010 - .020	.367	.098	.030 - .050	.371	.129	.050 - .070	<b>.373</b>	<b>.210</b>	<b>.005 - .010</b>
.349	.176	.010 - .015	<b>.354</b>	<b>.125</b>	<b>.005 - .010</b>	.360	.177	.050 - .070	.367	.105	.015 - .025	.371	.130	.050 - .075	.373	.222	.015 - .030
.349	.191	.035 - .050	.354	.125	.050 - .070	.360	.186	.040 - .060	.367	.125	.090 - .125	.371	.131	.020 - .030	.373	.238	.030 - .050
.349	.192	.015 - .030	.354	.128	.025 - .040	.360	.190	.030 - .050	.367	.176	.050 - .062	<b>.371</b>	<b>.150</b>	<b>.005 - .010</b>	.373	.253	.040 - .060
.349	.197	.020 - .030	.354	.144	.030 - .050	.360	.192	.060 - .090	<b>.367</b>	<b>.186</b>	<b>.005 - .010</b>	<b>.371</b>	<b>.176</b>	<b>.005 - .010</b>	.373	.256	.042 - .060
.349	.220	.015 - .030	.354	.145	.020 - .040	<b>.360</b>	<b>.193</b>	<b>.005 - .010</b>	.367	.258	.050 - .060	.371	.184	.010 - .020	.373	.317	.010 - .020
.349	.252	.015 - .030	.354	.147	.020 - .035	.360	.193	.010 - .015	.367	.260	.015 - .030	.371	.195	.050 - .070	<b>.373</b>	<b>.318</b>	<b>.005 - .010</b>
.349	.285	.020 - .030	.354	.161	.010 - .020	.360	.203	.030 - .042	<b>.367</b>	<b>.264</b>	<b>.005 - .010</b>	.371	.201	.040 - .060	<b>.374</b>	<b>.049</b>	<b>.005 - .010</b>
<b>.349</b>	<b>.290</b>	<b>.005 - .010</b>	.354	.162	.010 - .020	.360	.207	.050 - .062	.367	.272	.020 - .040	.371	.206	.060 - .083	.374	.083	.036 - .050
<b>.350</b>	<b>.060</b>	<b>.005 - .010</b>	.354	.204	.040 - .060	.360	.230	.010 - .020	<b>.367</b>	<b>.273</b>	<b>.005 - .010</b>	.371	.222	.030 - .050	<b>.374</b>	<b>.099</b>	<b>.005 - .010</b>
<b>.350</b>	<b>.089</b>	<b>.005 - .010</b>	<b>.354</b>	<b>.226</b>	<b>.005 - .010</b>	<b>.360</b>	<b>.245</b>	<b>.005 - .010</b>	<b>.368</b>	<b>.061</b>	<b>.005 - .010</b>	<b>.371</b>	<b>.233</b>	<b>.005 - .010</b>	.374	.130	.010 - .020
<b>.350</b>	<b>.090</b>	<b>.005 - .010</b>	<b>.354</b>	<b>.238</b>	<b>.005 - .010</b>	.360	.260	.025 - .042	<b>.368</b>	<b>.063</b>	<b>.005 - .010</b>	.371	.245	.050 - .075	.374	.138	.005 - .015
.350	.121	.010 - .020	.354	.238	.025 - .040	<b>.360</b>	<b>.277</b>	<b>.005 - .010</b>	.368	.080	.020 - .030	.371	.250	.005 - .020	.374	.149	.010 - .015
<b>.350</b>	<b>.122</b>	<b>.005 - .010</b>	<b>.354</b>	<b>.245</b>	<b>.005 - .010</b>	.360	.312	.015 - .025	.368	.122	.025 - .042	.371	.250	.020 - .032	.374	.157	.025 - .040
<b>.350</b>	<b>.154</b>	<b>.005 - .010</b>	.355	.070	.015 - .030	.361	.243	.025 - .040	.368	.124	.040 - .050	.371	.252	.035 - .050	.374	.168	.025 - .040
.350	.167	.015 - .030	.355	.083	.030 - .050	<b>.361</b>	<b>.281</b>	<b>.005 - .010</b>	<b>.368</b>	<b>.154</b>	<b>.005 - .010</b>	.371	.253	.015 - .030	.374	.172	.040 - .060
.350	.168	.030 - .050	.355	.131	.050 - .078	<b>.361</b>	<b>.296</b>	<b>.005 - .010</b>	.368	.168	.025 - .040	.371	.255	.005 - .012	.374	.173	.040 - .060
<b>.350</b>	<b>.171</b>	<b>.005 - .010</b>	.355	.158	.025 - .042	<b>.362</b>	<b>.121</b>	<b>.005 - .010</b>	.368	.193	.020 - .040	<b>.371</b>	<b>.256</b>	<b>.005 - .010</b>	.374	.175	.040 - .060
.350	.181	.025 - .040	.355	.159	.040 - .060	.362	.143	.015 - .030	.368	.194	.050 - .070	<b>.371</b>	<b>.260</b>	<b>.005 - .010</b>	.374	.180	.020 - .030
<b>.350</b>	<b>.194</b>	<b>.005 - .010</b>	.355	.160	.040 - .060	<b>.362</b>	<b>.220</b>	<b>.005 - .010</b>	.368	.195	.070 - .090	.371	.260	.010 - .020	.374	.180	.060 - .080
.350	.195	.060 - .080	.355	.175	.040 - .060	.362	.221	.01									

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.374	.257	.040 - .060	.375	.213	.015 - .025	<b>.376</b>	<b>.269</b>	<b>.005 - .010</b>	.380	.095	.015 - .030	.386	.141	.010 - .020	<b>.392</b>	<b>.219</b>	<b>.005 - .010</b>
<b>.374</b>	<b>.280</b>	<b>.005 - .010</b>	.375	.218	.060 - .080	.376	.271	.010 - .020	.380	.096	.060 - .080	.386	.162	.050 - .062	.392	.280	.035 - .050
.374	.320	.010 - .020	<b>.375</b>	<b>.220</b>	<b>.005 - .010</b>	.376	.271	.020 - .040	.380	.097	.040 - .060	.386	.181	.040 - .060	<b>.392</b>	<b>.328</b>	<b>.005 - .010</b>
.375	.041	.040 - .050	.375	.223	.050 - .070	.376	.276	.040 - .060	<b>.380</b>	<b>.116</b>	<b>.005 - .010</b>	.386	.225	.020 - .040	<b>.392</b>	<b>.337</b>	<b>.005 - .010</b>
.375	.045	.006 - .015	.375	.226	.015 - .030	<b>.376</b>	<b>.301</b>	<b>.005 - .010</b>	.380	.126	.030 - .050	.386	.250	.015 - .030	<b>.393</b>	<b>.042</b>	<b>.005 - .010</b>
.375	.086	.015 - .030	<b>.375</b>	<b>.237</b>	<b>.005 - .010</b>	<b>.376</b>	<b>.316</b>	<b>.005 - .010</b>	.380	.148	.025 - .040	.386	.250	.025 - .040	.393	.103	.010 - .020
<b>.375</b>	<b>.091</b>	<b>.005 - .010</b>	.375	.237	.050 - .075	<b>.377</b>	<b>.031</b>	<b>.005 - .010</b>	.380	.149	.080 - .100	.386	.301	.020 - .040	.393	.111	.025 - .040
.375	.091	.020 - .030	<b>.375</b>	<b>.238</b>	<b>.005 - .010</b>	.377	.035	.015 - .025	.380	.162	.040 - .060	.386	.313	.020 - .030	<b>.393</b>	<b>.120</b>	<b>.005 - .010</b>
.375	.095	.090 - .104	.375	.238	.015 - .030	.377	.047	.030 - .042	<b>.380</b>	<b>.173</b>	<b>.005 - .010</b>	.387	.091	.030 - .050	.393	.158	.005 - .020
<b>.375</b>	<b>.100</b>	<b>.005 - .010</b>	.375	.245	.050 - .060	.377	.068	.030 - .042	.380	.175	.015 - .025	.387	.118	.020 - .030	.393	.196	.040 - .050
.375	.100	.020 - .030	.375	.248	.010 - .020	<b>.377</b>	<b>.071</b>	<b>.005 - .010</b>	.380	.175	.060 - .090	.387	.171	.060 - .090	.393	.201	.030 - .050
.375	.101	.070 - .080	<b>.375</b>	<b>.250</b>	<b>.005 - .010</b>	.377	.100	.015 - .030	<b>.380</b>	<b>.180</b>	<b>.005 - .010</b>	.387	.189	.032 - .048	<b>.393</b>	<b>.209</b>	<b>.005 - .010</b>
.375	.103	.030 - .050	.375	.250	.020 - .030	.377	.101	.020 - .030	.380	.186	.015 - .025	.387	.258	.020 - .040	<b>.393</b>	<b>.214</b>	<b>.005 - .010</b>
.375	.110	.030 - .040	.375	.250	.040 - .060	.377	.110	.020 - .030	<b>.380</b>	<b>.190</b>	<b>.005 - .010</b>	<b>.387</b>	<b>.280</b>	<b>.005 - .010</b>	.393	.230	.025 - .040
<b>.375</b>	<b>.111</b>	<b>.005 - .010</b>	<b>.375</b>	<b>.252</b>	<b>.005 - .010</b>	.377	.114	.020 - .040	.380	.191	.020 - .040	.387	.318	.008 - .020	<b>.393</b>	<b>.237</b>	<b>.005 - .010</b>
.375	.114	.030 - .042	.375	.252	.010 - .015	<b>.377</b>	<b>.115</b>	<b>.005 - .010</b>	<b>.380</b>	<b>.192</b>	<b>.005 - .010</b>	.387	.328	.010 - .020	<b>.393</b>	<b>.239</b>	<b>.005 - .010</b>
.375	.120	.030 - .060	<b>.375</b>	<b>.253</b>	<b>.005 - .010</b>	.377	.134	.015 - .030	<b>.380</b>	<b>.194</b>	<b>.005 - .010</b>	.388	.090	.015 - .025	<b>.393</b>	<b>.240</b>	<b>.005 - .010</b>
.375	.123	.030 - .050	.375	.253	.015 - .025	<b>.377</b>	<b>.140</b>	<b>.005 - .010</b>	<b>.380</b>	<b>.195</b>	<b>.005 - .010</b>	.388	.127	.008 - .020	.393	.240	.015 - .030
.375	.123	.050 - .075	<b>.375</b>	<b>.254</b>	<b>.005 - .010</b>	.377	.145	.050 - .060	.380	.195	.015 - .025	<b>.388</b>	<b>.136</b>	<b>.005 - .010</b>	.393	.240	.030 - .050
.375	.125	.010 - .015	.375	.254	.020 - .040	.377	.147	.010 - .020	.380	.204	.012 - .025	.388	.171	.075 - .090	.393	.256	.020 - .040
.375	.125	.050 - .070	.375	.255	.020 - .030	.377	.156	.030 - .060	.380	.215	.030 - .050	.388	.205	.025 - .040	<b>.393</b>	<b>.277</b>	<b>.005 - .010</b>
.375	.126	.010 - .020	.375	.257	.025 - .040	.377	.157	.070 - .090	<b>.380</b>	<b>.226</b>	<b>.005 - .010</b>	<b>.388</b>	<b>.211</b>	<b>.005 - .010</b>	<b>.393</b>	<b>.279</b>	<b>.005 - .010</b>
.375	.129	.010 - .020	.375	.258	.010 - .020	.377	.171	.025 - .040	<b>.380</b>	<b>.262</b>	<b>.005 - .010</b>	.388	.215	.040 - .060	.393	.285	.010 - .020
.375	.129	.020 - .036	.375	.267	.020 - .030	.377	.173	.030 - .050	.380	.264	.025 - .040	.388	.252	.015 - .030	.393	.287	.005 - .015
.375	.133	.050 - .062	.375	.274	.010 - .020	.377	.182	.025 - .048	<b>.380</b>	<b>.276</b>	<b>.005 - .010</b>	.388	.264	.025 - .040	.393	.314	.025 - .035
<b>.375</b>	<b>.135</b>	<b>.005 - .010</b>	.375	.280	.030 - .042	.377	.185	.010 - .020	.380	.277	.010 - .020	<b>.388</b>	<b>.280</b>	<b>.005 - .010</b>	<b>.393</b>	<b>.315</b>	<b>.005 - .010</b>
.375	.143	.075 - .090	<b>.375</b>	<b>.281</b>	<b>.005 - .010</b>	.377	.189	.030 - .060	.380	.280	.030 - .040	.388	.280	.015 - .030	<b>.394</b>	<b>.083</b>	<b>.005 - .010</b>
<b>.375</b>	<b>.144</b>	<b>.005 - .010</b>	.375	.281	.030 - .040	.377	.190	.015 - .030	.380	.285	.032 - .050	.388	.288	.015 - .030	<b>.394</b>	<b>.095</b>	<b>.005 - .010</b>
.375	.144	.010 - .015	<b>.375</b>	<b>.282</b>	<b>.005 - .010</b>	.377	.191	.025 - .040	<b>.381</b>	<b>.094</b>	<b>.005 - .010</b>	.389	.078	.015 - .030	.394	.095	.010 - .020
.375	.144	.020 - .040	.375	.285	.008 - .015	.377	.194	.025 - .040	.381	.099	.025 - .040	.389	.130	.020 - .035	.394	.157	.040 - .060
.375	.145	.025 - .040	.375	.303	.025 - .040	.377	.194	.040 - .060	<b>.381</b>	<b>.114</b>	<b>.005 - .010</b>	.389	.198	.020 - .040	.394	.158	.040 - .060
.375	.147	.030 - .050	<b>.375</b>	<b>.313</b>	<b>.005 - .010</b>	.377	.219	.032 - .042	<b>.381</b>	<b>.116</b>	<b>.005 - .010</b>	.389	.199	.015 - .030	.394	.168	.050 - .075
.375	.148	.030 - .050	.375	.316	.020 - .040	.377	.220	.020 - .040	.381	.124	.005 - .012	.389	.200	.015 - .030	.394	.196	.050 - .075
.375	.150	.020 - .040	.375	.318	.020 - .032	.377	.223	.030 - .050	.381	.126	.030 - .050	.389	.205	.005 - .012	.394	.207	.050 - .075
.375	.150	.090 - .105	.376	.084	.008 - .016	.377	.225	.015 - .030	.381	.131	.040 - .060	.389	.223	.012 - .020	.394	.208	.070 - .090
.375	.152	.080 - .100	.376	.117	.015 - .030	.377	.230	.010 - .020	<b>.381</b>	<b>.138</b>	<b>.005 - .010</b>	<b>.389</b>	<b>.227</b>	<b>.005 - .010</b>	<b>.394</b>	<b>.237</b>	<b>.005 - .010</b>
<b>.375</b>	<b>.153</b>	<b>.005 - .010</b>	.376	.117	.030 - .040	.377	.253	.015 - .030	.381	.148	.025 - .040	.389	.276	.020 - .030	.394	.239	.025 - .040
.375	.153	.030 - .050	.376	.122	.015 - .030	.377	.253	.040 - .060	<b>.381</b>	<b>.150</b>	<b>.005 - .010</b>	<b>.390</b>	<b>.039</b>	<b>.005 - .010</b>	<b>.394</b>	<b>.240</b>	<b>.005 - .010</b>
.375	.156	.005 - .012	.376	.126	.012 - .020	.377	.254	.025 - .040	.381	.163	.030 - .050	.390	.087	.020 - .030	.394	.240	.010 - .025
<b>.375</b>	<b>.158</b>	<b>.005 - .010</b>	.376	.130	.025 - .040	.377	.255	.040 - .062	.381	.175	.075 - .090	.390	.129	.015 - .030	.394	.243	.015 - .030
.375	.160	.010 - .020	.376	.141	.020 - .040	.377	.262	.030 - .050	.381	.178	.015 - .030	.390	.145	.015 - .025	<b>.394</b>	<b>.251</b>	<b>.005 - .010</b>
.375	.161	.020 - .040	.376	.156	.010 - .020	<b>.377</b>	<b>.265</b>	<b>.005 - .010</b>	.381	.186	.015 - .030	.390	.145	.060 - .080	.394	.251	.060 - .080
.375	.162	.006 - .010	.376	.157	.010 - .020	.377	.267	.006 - .012	.381	.195	.040 - .060	<b>.390</b>	<b>.157</b>	<b>.005 - .010</b>	.394	.255	.045 - .064
.375	.162	.010 - .020	.376	.157	.075 - .090	.377	.276	.010 - .020	.381	.200	.020 - .030	.390	.162	.020 - .030	.394	.260	.040 - .060
.375	.162	.080 - .100	.376	.158	.050 - .070	.377	.315	.010 - .020	<b>.381</b>	<b>.203</b>	<b>.005 - .010</b>	.390	.169	.025 - .050	<b>.394</b>	<b>.319</b>	<b>.005 - .010</b>
<b>.375</b>	<b>.163</b>	<b>.005 - .010</b>	.376	.159	.050 - .075	<b>.378</b>	<b>.061</b>	<b>.005 - .010</b>	<b>.381</b>	<b>.212</b>	<b>.005 - .010</b>	.390	.181	.030 - .050	.395	.099	.030 - .050
.375	.165	.042 - .062	<b>.376</b>	<b>.161</b>	<b>.005 - .010</b>	<b>.378</b>	<b>.062</b>	<b>.005 - .010</b>	.381	.255	.015 - .030	<b>.390</b>	<b>.185</b>	<b>.005 - .010</b>	.395	.165	.015 - .030
.375	.169	.015 - .030	<b>.376</b>	<b>.169</b>	<b>.005 - .010</b>	.378	.064	.015 - .025	.381	.260	.015 - .030	.390	.195	.020 - .032	.395	.172	.020 - .035
.375	.169	.030 - .050	<b>.376</b>	<b>.172</b>	<b>.005 - .010</b>	<b>.378</b>	<b>.127</b>	<b>.005 - .010</b>	<b>.381</b>	<b>.290</b>	<b>.005 - .010</b>	.390	.195	.030 - .050	.395	.174	.015 - .030
<b>.375</b>	<b>.172</b>	<b>.005 - .010</b>	.376	.172	.040 - .060	.378	.130	.010 - .020	<b>.381</b>	<b>.294</b>	<b>.005 - .010</b>	.390	.198	.015 - .030	.395	.186	.070 - .090
.375	.172	.030 - .050	.376	.174	.075 - .090	.378	.160	.010 - .020	.381	.300	.020 - .035	.390	.201	.070 - .090	.395	.191	.025 - .040
.375	.173	.020 - .030	.376	.177	.020 - .035	.378	.164	.010 - .030	.381	.315	.020 - .036	.390	.217	.015 - .025	.395	.191	.075 - .093
.375	.175	.005 - .012	.376	.182	.010 - .020	.378	.171	.032 - .050	.382	.132	.025 - .040	.390	.217	.025 - .030	<b>.395</b>	<b>.195</b>	<b>.005 - .010</b>
.375	.177	.060 - .075	.376	.186	.060 - .080	<b>.378</b>	<b>.178</b>	<b>.005 - .010</b>	.382	.163	.030 - .050	.390	.235	.050 - .080	<b>.395</b>	<b>.200</b>	<b>.005 - .010</b>
.375	.180	.060 - .080	.376	.187	.030 - .050	.378	.200	.010 - .020	.382	.175	.015 - .030	<b>.390</b>	<b>.236</b>	<b>.005 - .010</b>	.395	.210	.025 - .040
<b>.375</b>	<b>.188</b>	<b>.005 - .010</b>	<b>.376</b>	<b>.189</b>	<b>.005 - .010</b>	.378	.202	.015 - .030	.382	.189	.050 - .072	.390	.236	.010 - .020	.395	.219	.010 - .020
.375	.188	.015 - .030	.376	.190	.020 - .032	<b>.378</b>	<b>.244</b>	<b>.005 - .010</b>	<b>.382</b>	<b>.195</b>	<b>.005 - .010</b>	.390	.236	.020 - .040	.395	.220	.015 - .035
.375	.189	.080 - .104	.376	.190	.060 - .080	.378	.251	.020 - .030	<b>.382</b>	<b>.204</b>	<b>.005 - .010</b>	.390	.236	.050 - .080	.395	.225	.010 - .020
.375	.190	.080 - .104	.376	.191	.040 - .060	.378	.252	.010 - .020	.382	.207	.030 - .050	.390	.241	.060 - .080	.395	.236	.040 - .060
.375	.191	.040 - .060	.376	.194	.030 - .050	.378	.252	.040 - .060	.382	.225	.030 - .050	.390	.257	.015 - .030	.395	.243	.005 - .015
.375	.191	.060 - .090	<b>.376</b>	<b>.196</b>	<b>.005 - .010</b>	.378	.255	.015 - .025	.382	.252	.015 - .025	<b>.390</b>	<b>.258</b>	<b>.005 - .010</b>	.395	.246	.015 - .030
<b>.375</b>	<b>.192</b>	<b>.005 - .010</b>	<b>.376</b>	<b>.197</b>													

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.396	.333	.020 - .030	.401	.219	.020 - .040	.406	.204	.030 - .050	<b>.412</b>	<b>.236</b>	<b>.005 - .010</b>	.421	.251	.015 - .030	.428	.213	.020 - .040
.396	.338	.005 - .008	.401	.221	.060 - .075	.406	.209	.030 - .050	.412	.290	.040 - .060	<b>.421</b>	<b>.252</b>	<b>.005 - .010</b>	<b>.428</b>	<b>.241</b>	<b>.005 - .010</b>
<b>.397</b>	<b>.025</b>	<b>.005 - .010</b>	.401	.237	.035 - .050	.406	.218	.025 - .040	.412	.326	.010 - .040	.421	.268	.025 - .040	.428	.311	.025 - .040
<b>.397</b>	<b>.032</b>	<b>.005 - .010</b>	.401	.241	.030 - .050	.406	.220	.025 - .042	<b>.413</b>	<b>.169</b>	<b>.005 - .010</b>	<b>.421</b>	<b>.279</b>	<b>.005 - .010</b>	.428	.316	.025 - .040
.397	.105	.008 - .016	.401	.251	.025 - .040	.406	.221	.010 - .020	.413	.187	.010 - .020	<b>.421</b>	<b>.280</b>	<b>.005 - .010</b>	.428	.318	.010 - .020
.397	.109	.005 - .015	.401	.258	.015 - .025	<b>.406</b>	<b>.224</b>	<b>.005 - .010</b>	.413	.212	.010 - .020	<b>.421</b>	<b>.291</b>	<b>.005 - .010</b>	<b>.429</b>	<b>.135</b>	<b>.005 - .010</b>
.397	.153	.025 - .040	<b>.401</b>	<b>.263</b>	<b>.005 - .010</b>	.406	.242	.062 - .080	.413	.222	.042 - .072	.421	.319	.020 - .030	.429	.161	.020 - .040
<b>.397</b>	<b>.176</b>	<b>.005 - .010</b>	<b>.401</b>	<b>.298</b>	<b>.005 - .010</b>	.406	.250	.020 - .035	<b>.413</b>	<b>.223</b>	<b>.005 - .010</b>	<b>.421</b>	<b>.322</b>	<b>.005 - .010</b>	.429	.189	.010 - .020
.397	.183	.010 - .020	<b>.401</b>	<b>.328</b>	<b>.005 - .010</b>	.406	.252	.050 - .070	<b>.413</b>	<b>.229</b>	<b>.005 - .010</b>	.422	.038	.020 - .036	<b>.429</b>	<b>.199</b>	<b>.005 - .010</b>
.397	.196	.010 - .015	.401	.328	.020 - .030	.406	.257	.025 - .042	<b>.413</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.422</b>	<b>.123</b>	<b>.005 - .010</b>	.429	.257	.010 - .020
.397	.212	.005 - .015	.402	.099	.015 - .025	<b>.406</b>	<b>.260</b>	<b>.005 - .010</b>	<b>.413</b>	<b>.326</b>	<b>.005 - .010</b>	.422	.129	.010 - .025	.429	.260	.015 - .030
<b>.397</b>	<b>.231</b>	<b>.005 - .010</b>	.402	.145	.015 - .030	.406	.262	.025 - .040	.413	.379	.010 - .020	.422	.130	.015 - .025	.429	.260	.035 - .060
.397	.255	.070 - .090	.402	.145	.032 - .060	.406	.264	.036 - .050	.414	.081	.030 - .050	.422	.189	.025 - .035	<b>.430</b>	<b>.111</b>	<b>.005 - .010</b>
.397	.267	.020 - .040	<b>.402</b>	<b>.157</b>	<b>.005 - .010</b>	<b>.406</b>	<b>.269</b>	<b>.005 - .010</b>	.414	.162	.030 - .050	.422	.282	.040 - .060	.430	.115	.010 - .020
.397	.280	.040 - .050	.402	.162	.060 - .080	.406	.276	.042 - .062	.414	.212	.080 - .100	.422	.335	.010 - .020	.430	.120	.005 - .012
.397	.298	.015 - .030	.402	.193	.015 - .025	<b>.406</b>	<b>.278</b>	<b>.005 - .010</b>	<b>.414</b>	<b>.252</b>	<b>.005 - .010</b>	<b>.422</b>	<b>.375</b>	<b>.005 - .010</b>	.430	.128	.032 - .042
.397	.315	.032 - .042	.402	.256	.030 - .050	.406	.284	.020 - .040	.414	.252	.040 - .060	<b>.423</b>	<b>.129</b>	<b>.005 - .010</b>	.430	.130	.030 - .050
.397	.320	.020 - .040	.402	.270	.040 - .060	<b>.406</b>	<b>.304</b>	<b>.005 - .010</b>	<b>.414</b>	<b>.261</b>	<b>.005 - .010</b>	.423	.153	.005 - .015	.430	.159	.020 - .040
.397	.325	.015 - .025	.402	.281	.048 - .062	<b>.407</b>	<b>.063</b>	<b>.005 - .010</b>	.414	.277	.035 - .045	.423	.226	.040 - .060	.430	.161	.010 - .020
.398	.117	.020 - .035	.402	.300	.015 - .030	<b>.407</b>	<b>.175</b>	<b>.005 - .010</b>	.414	.282	.020 - .030	.423	.250	.020 - .035	.430	.175	.015 - .030
<b>.398</b>	<b>.188</b>	<b>.005 - .010</b>	<b>.402</b>	<b>.359</b>	<b>.005 - .010</b>	<b>.407</b>	<b>.207</b>	<b>.005 - .010</b>	.414	.315	.010 - .020	.423	.254	.020 - .030	.430	.180	.020 - .040
.398	.200	.070 - .080	<b>.403</b>	<b>.144</b>	<b>.005 - .010</b>	.407	.207	.010 - .015	.415	.092	.040 - .060	.423	.269	.060 - .078	.430	.189	.030 - .050
<b>.398</b>	<b>.225</b>	<b>.005 - .010</b>	.403	.189	.025 - .036	.407	.225	.020 - .040	.415	.179	.040 - .070	.423	.270	.060 - .080	.430	.190	.020 - .040
.398	.241	.040 - .060	.403	.192	.020 - .040	.407	.237	.020 - .040	.415	.192	.070 - .090	.423	.271	.050 - .070	.430	.191	.020 - .040
.398	.286	.025 - .048	.403	.193	.016 - .025	.407	.253	.010 - .015	.415	.243	.008 - .020	<b>.423</b>	<b>.278</b>	<b>.025 - .050</b>	.430	.191	.042 - .060
<b>.398</b>	<b>.303</b>	<b>.005 - .010</b>	<b>.403</b>	<b>.203</b>	<b>.005 - .010</b>	.407	.257	.010 - .020	.415	.250	.042 - .060	.423	.314	.010 - .020	.430	.191	.060 - .080
.398	.304	.015 - .030	.403	.263	.030 - .050	.407	.261	.008 - .016	.415	.250	.060 - .080	.423	.319	.015 - .025	.430	.200	.070 - .090
<b>.399</b>	<b>.169</b>	<b>.005 - .010</b>	<b>.404</b>	<b>.100</b>	<b>.005 - .010</b>	.407	.262	.005 - .008	<b>.415</b>	<b>.253</b>	<b>.005 - .010</b>	.423	.328	.030 - .042	.430	.206	.080 - .100
.399	.200	.020 - .040	<b>.404</b>	<b>.128</b>	<b>.005 - .010</b>	.407	.262	.025 - .040	.415	.265	.050 - .070	.423	.345	.010 - .020	.430	.215	.032 - .042
<b>.399</b>	<b>.223</b>	<b>.005 - .010</b>	.404	.173	.060 - .080	.407	.265	.015 - .025	.415	.281	.050 - .072	<b>.424</b>	<b>.139</b>	<b>.030 - .050</b>	.430	.258	.020 - .040
.399	.226	.050 - .070	.404	.180	.060 - .080	.407	.265	.020 - .036	.415	.285	.015 - .025	.424	.169	.005 - .030	.430	.265	.060 - .080
.399	.260	.070 - .090	.404	.189	.025 - .040	.407	.320	.010 - .020	.415	.324	.025 - .035	<b>.424</b>	<b>.190</b>	<b>.005 - .010</b>	<b>.430</b>	<b>.279</b>	<b>.005 - .010</b>
.399	.284	.010 - .020	.404	.190	.025 - .040	.408	.083	.020 - .030	<b>.416</b>	<b>.121</b>	<b>.005 - .010</b>	.424	.190	.010 - .020	.430	.285	.020 - .030
<b>.399</b>	<b>.290</b>	<b>.005 - .010</b>	.404	.195	.010 - .020	.408	.083	.030 - .050	.416	.128	.040 - .060	.424	.196	.040 - .060	.430	.308	.010 - .020
<b>.399</b>	<b>.362</b>	<b>.005 - .010</b>	<b>.404</b>	<b>.197</b>	<b>.005 - .010</b>	.408	.134	.025 - .040	<b>.416</b>	<b>.160</b>	<b>.005 - .010</b>	<b>.424</b>	<b>.230</b>	<b>.015 - .025</b>	.430	.314	.030 - .050
.400	.066	.025 - .048	.404	.210	.030 - .050	.408	.166	.015 - .030	.416	.180	.020 - .030	<b>.424</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.430</b>	<b>.339</b>	<b>.005 - .010</b>
<b>.400</b>	<b>.091</b>	<b>.005 - .010</b>	.404	.220	.025 - .040	.408	.166	.025 - .040	.416	.205	.062 - .080	<b>.424</b>	<b>.325</b>	<b>.005 - .010</b>	.430	.343	.015 - .030
<b>.400</b>	<b>.119</b>	<b>.005 - .010</b>	<b>.404</b>	<b>.246</b>	<b>.005 - .010</b>	.408	.172	.005 - .015	.416	.218	.010 - .020	.425	.138	.030 - .050	<b>.430</b>	<b>.364</b>	<b>.005 - .010</b>
.400	.139	.020 - .035	<b>.404</b>	<b>.252</b>	<b>.005 - .010</b>	<b>.408</b>	<b>.173</b>	<b>.005 - .010</b>	.416	.241	.008 - .020	.425	.147	.020 - .030	<b>.430</b>	<b>.372</b>	<b>.005 - .010</b>
<b>.400</b>	<b>.142</b>	<b>.005 - .010</b>	.404	.260	.015 - .025	.408	.194	.040 - .060	.416	.251	.025 - .040	.425	.165	.015 - .030	.430	.372	.010 - .020
.400	.147	.025 - .048	.404	.265	.015 - .030	.408	.240	.020 - .040	.416	.260	.025 - .040	.425	.191	.060 - .080	<b>.430</b>	<b>.376</b>	<b>.005 - .010</b>
.400	.151	.010 - .020	.404	.280	.060 - .080	.408	.261	.005 - .015	.417	.251	.048 - .062	<b>.425</b>	<b>.197</b>	<b>.005 - .010</b>	.430	.379	.015 - .020
.400	.151	.040 - .060	.404	.313	.005 - .012	.408	.297	.010 - .020	.417	.356	.010 - .020	<b>.425</b>	<b>.212</b>	<b>.005 - .010</b>	<b>.431</b>	<b>.040</b>	<b>.005 - .010</b>
<b>.400</b>	<b>.153</b>	<b>.005 - .010</b>	.404	.320	.005 - .020	.409	.129	.015 - .030	.418	.149	.050 - .070	.425	.250	.015 - .030	.431	.126	.035 - .050
.400	.168	.042 - .062	<b>.405</b>	<b>.099</b>	<b>.005 - .010</b>	.409	.167	.015 - .025	.418	.190	.025 - .040	.425	.256	.050 - .070	.431	.127	.025 - .040
<b>.400</b>	<b>.172</b>	<b>.005 - .010</b>	<b>.405</b>	<b>.107</b>	<b>.005 - .010</b>	.409	.172	.020 - .040	.418	.190	.030 - .050	.425	.261	.050 - .062	.431	.157	.025 - .040
.400	.182	.016 - .032	.405	.108	.030 - .050	.409	.194	.035 - .050	.418	.206	.010 - .015	.425	.284	.030 - .050	<b>.431</b>	<b>.158</b>	<b>.005 - .010</b>
<b>.400</b>	<b>.192</b>	<b>.005 - .010</b>	<b>.405</b>	<b>.137</b>	<b>.005 - .010</b>	.409	.210	.060 - .083	.418	.257	.025 - .040	.425	.317	.015 - .030	<b>.431</b>	<b>.195</b>	<b>.005 - .010</b>
.400	.192	.032 - .060	.405	.156	.040 - .060	.409	.244	.030 - .040	.418	.289	.020 - .030	.425	.319	.040 - .050	.431	.197	.020 - .030
.400	.198	.015 - .030	.405	.162	.015 - .025	.409	.313	.015 - .030	.418	.315	.035 - .050	.425	.326	.020 - .030	.431	.235	.005 - .012
.400	.200	.015 - .025	<b>.405</b>	<b>.168</b>	<b>.005 - .010</b>	.409	.322	.015 - .030	.419	.125	.050 - .072	.425	.336	.020 - .030	.431	.238	.030 - .060
<b>.400</b>	<b>.202</b>	<b>.005 - .010</b>	.405	.175	.040 - .060	<b>.410</b>	<b>.063</b>	<b>.005 - .010</b>	.419	.148	.062 - .090	.425	.343	.020 - .040	<b>.431</b>	<b>.259</b>	<b>.005 - .010</b>
<b>.400</b>	<b>.203</b>	<b>.005 - .010</b>	<b>.405</b>	<b>.184</b>	<b>.005 - .010</b>	<b>.410</b>	<b>.201</b>	<b>.005 - .010</b>	.419	.173	.080 - .104	<b>.425</b>	<b>.344</b>	<b>.005 - .010</b>	.431	.259	.015 - .030
.400	.206	.050 - .070	<b>.405</b>	<b>.201</b>	<b>.005 - .010</b>	.410	.201	.090 - .105	.419	.224	.040 - .060	<b>.425</b>	<b>.345</b>	<b>.005 - .010</b>	.431	.294	.015 - .025
<b>.400</b>	<b>.210</b>	<b>.005 - .010</b>	.405	.202	.020 - .040	.410	.220	.025 - .040	<b>.419</b>	<b>.303</b>	<b>.005 - .010</b>	<b>.426</b>	<b>.140</b>	<b>.015 - .030</b>	<b>.432</b>	<b>.080</b>	<b>.005 - .010</b>
.400	.210	.010 - .020	.405	.202	.048 - .072	.410	.223	.010 - .020	.419	.313	.025 - .040	.426	.215	.005 - .015	.432	.117	.030 - .050
.400	.225	.050 - .070	.405	.243	.010 - .015	<b>.410</b>	<b>.254</b>	<b>.005 - .010</b>	<b>.419</b>	<b>.329</b>	<b>.005 - .010</b>	.426	.216	.070 - .090	.432	.118	.015 - .030
<b>.400</b>	<b>.252</b>	<b>.005 - .010</b>	.405	.250	.020 - .030	.410	.256	.030 - .042	.419	.329	.015 - .025	<b>.426</b>	<b>.219</b>	<b>.005 - .010</b>	.432	.120	.015 - .030
.400	.254	.010 - .020	.405	.252	.030 - .050	<b>.410</b>	<b>.261</b>	<b>.005 - .010</b>	<b>.419</b>	<b>.345</b>	<b>.005 - .010</b>	.426	.225	.010 - .020	.432	.122	.030 - .050
<b>.400</b>	<b>.255</b>	<b>.005 - .010</b>	.405	.253	.025 - .040	<b>.410</b>	<b>.300</b>	<b>.005 - .010</b>	.420	.129	.020 - .030	.426	.234	.025 - .040	.432	.125	.032 - .062
.400	.255	.015 - .030	.405	.257	.005 - .007	.410	.306	.015 - .030	.420	.170	.015 - .030	.426	.256	.040 - .060	.432	.130	.01

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.433	.202	.015 - .030	.436	.253	.030 - .050	.437	.281	.042 - .062	.439	.174	.025 - .050	<b>.442</b>	<b>.286</b>	<b>.005 - .010</b>	.450	.174	.025 - .040
.433	.203	.005 - .030	.436	.254	.010 - .020	.437	.284	.015 - .030	.439	.185	.090 - .105	.442	.317	.040 - .060	<b>.450</b>	<b>.182</b>	<b>.005 - .010</b>
<b>.433</b>	<b>.220</b>	<b>.005 - .010</b>	<b>.436</b>	<b>.256</b>	<b>.005 - .010</b>	.437	.287	.010 - .020	.439	.189	.010 - .020	.443	.190	.025 - .040	<b>.450</b>	<b>.192</b>	<b>.005 - .010</b>
<b>.433</b>	<b>.224</b>	<b>.005 - .010</b>	<b>.436</b>	<b>.263</b>	<b>.005 - .010</b>	.437	.302	.005 - .012	.439	.189	.048 - .075	.443	.191	.025 - .040	.450	.200	.015 - .030
.433	.237	.030 - .050	.436	.279	.010 - .025	<b>.437</b>	<b>.312</b>	<b>.005 - .010</b>	.439	.190	.060 - .080	<b>.443</b>	<b>.223</b>	<b>.005 - .010</b>	.450	.200	.060 - .080
<b>.433</b>	<b>.238</b>	<b>.005 - .010</b>	.436	.282	.025 - .045	.437	.316	.010 - .015	<b>.439</b>	<b>.192</b>	<b>.005 - .010</b>	.443	.224	.040 - .060	<b>.450</b>	<b>.201</b>	<b>.005 - .010</b>
<b>.433</b>	<b>.239</b>	<b>.005 - .010</b>	.436	.282	.060 - .075	.437	.321	.020 - .040	.439	.203	.040 - .060	.443	.295	.016 - .025	<b>.450</b>	<b>.216</b>	<b>.005 - .010</b>
.433	.243	.020 - .030	.436	.283	.010 - .020	<b>.437</b>	<b>.325</b>	<b>.005 - .010</b>	.439	.203	.060 - .090	.443	.336	.040 - .060	.450	.223	.015 - .025
.433	.243	.030 - .050	.436	.287	.005 - .015	.437	.328	.020 - .030	.439	.207	.040 - .060	<b>.444</b>	<b>.165</b>	<b>.005 - .010</b>	.450	.237	.030 - .050
.433	.251	.010 - .020	<b>.436</b>	<b>.314</b>	<b>.005 - .010</b>	.437	.329	.040 - .060	.439	.251	.060 - .080	.444	.196	.015 - .030	<b>.450</b>	<b>.240</b>	<b>.005 - .010</b>
.433	.251	.020 - .030	.436	.316	.010 - .020	<b>.437</b>	<b>.343</b>	<b>.005 - .010</b>	.439	.252	.060 - .080	.444	.318	.030 - .050	.450	.251	.020 - .040
.433	.253	.008 - .016	.436	.316	.025 - .042	.437	.343	.040 - .060	.439	.253	.010 - .025	.444	.347	.020 - .040	.450	.251	.080 - .100
.433	.253	.050 - .070	<b>.436</b>	<b>.318</b>	<b>.005 - .010</b>	<b>.437</b>	<b>.365</b>	<b>.005 - .010</b>	.439	.260	.025 - .040	<b>.444</b>	<b>.349</b>	<b>.005 - .010</b>	<b>.450</b>	<b>.252</b>	<b>.005 - .010</b>
.433	.276	.020 - .040	.436	.334	.015 - .030	<b>.437</b>	<b>.376</b>	<b>.005 - .010</b>	.439	.264	.060 - .075	.445	.095	.030 - .050	.450	.252	.010 - .020
<b>.433</b>	<b>.315</b>	<b>.005 - .010</b>	.436	.375	.015 - .030	.437	.376	.015 - .025	<b>.439</b>	<b>.276</b>	<b>.005 - .010</b>	.445	.116	.050 - .070	.450	.254	.025 - .040
.433	.315	.015 - .030	<b>.436</b>	<b>.378</b>	<b>.005 - .010</b>	<b>.438</b>	<b>.048</b>	<b>.005 - .010</b>	<b>.439</b>	<b>.315</b>	<b>.005 - .010</b>	.445	.136	.010 - .020	.450	.256	.010 - .020
<b>.433</b>	<b>.317</b>	<b>.005 - .010</b>	<b>.436</b>	<b>.397</b>	<b>.005 - .010</b>	.438	.058	.020 - .035	.439	.317	.040 - .060	.445	.206	.035 - .050	.450	.260	.025 - .040
.433	.321	.035 - .050	<b>.437</b>	<b>.039</b>	<b>.005 - .010</b>	<b>.438</b>	<b>.093</b>	<b>.005 - .010</b>	<b>.440</b>	<b>.024</b>	<b>.005 - .010</b>	<b>.445</b>	<b>.212</b>	<b>.005 - .010</b>	.450	.264	.050 - .070
<b>.433</b>	<b>.330</b>	<b>.005 - .010</b>	.437	.096	.015 - .025	.438	.094	.025 - .040	.440	.052	.025 - .040	.445	.252	.015 - .025	.450	.280	.050 - .075
.433	.347	.015 - .030	.437	.120	.040 - .060	.438	.119	.015 - .030	.440	.090	.035 - .050	.445	.265	.040 - .060	.450	.290	.080 - .100
.433	.348	.030 - .040	.437	.125	.005 - .015	.438	.125	.025 - .042	<b>.440</b>	<b>.105</b>	<b>.005 - .010</b>	.445	.325	.010 - .020	.450	.292	.015 - .025
.433	.351	.015 - .030	.437	.126	.025 - .050	.438	.129	.015 - .030	.440	.127	.010 - .020	.445	.331	.030 - .050	.450	.295	.015 - .030
<b>.434</b>	<b>.043</b>	<b>.005 - .010</b>	.437	.127	.015 - .030	.438	.136	.010 - .015	.440	.129	.030 - .050	.445	.348	.020 - .040	<b>.450</b>	<b>.316</b>	<b>.005 - .010</b>
.434	.079	.030 - .050	.437	.127	.040 - .060	<b>.438</b>	<b>.138</b>	<b>.005 - .010</b>	.440	.140	.025 - .040	<b>.445</b>	<b>.383</b>	<b>.005 - .010</b>	.450	.316	.020 - .030
.434	.094	.040 - .060	.437	.128	.030 - .050	.438	.147	.030 - .050	.440	.158	.030 - .050	.445	.383	.020 - .040	<b>.450</b>	<b>.317</b>	<b>.005 - .010</b>
.434	.103	.040 - .060	.437	.129	.010 - .020	.438	.162	.030 - .060	.440	.168	.040 - .060	<b>.445</b>	<b>.385</b>	<b>.005 - .010</b>	.450	.317	.015 - .025
.434	.160	.090 - .125	.437	.129	.032 - .042	<b>.438</b>	<b>.169</b>	<b>.005 - .010</b>	.440	.170	.025 - .050	.445	.390	.010 - .015	<b>.450</b>	<b>.320</b>	<b>.005 - .010</b>
.434	.176	.020 - .040	.437	.130	.025 - .042	.438	.193	.050 - .070	<b>.440</b>	<b>.173</b>	<b>.005 - .010</b>	.446	.049	.010 - .020	.450	.320	.042 - .060
<b>.434</b>	<b>.196</b>	<b>.005 - .010</b>	.437	.133	.050 - .062	<b>.438</b>	<b>.196</b>	<b>.005 - .010</b>	.440	.190	.100 - .125	.446	.151	.062 - .090	.450	.350	.015 - .025
<b>.434</b>	<b>.198</b>	<b>.005 - .010</b>	.437	.141	.048 - .072	.438	.196	.010 - .020	.440	.195	.035 - .050	<b>.446</b>	<b>.162</b>	<b>.005 - .010</b>	.450	.368	.010 - .020
<b>.434</b>	<b>.224</b>	<b>.005 - .010</b>	.437	.142	.040 - .060	.438	.198	.025 - .035	.440	.202	.070 - .090	.446	.171	.040 - .060	.450	.370	.015 - .030
.434	.236	.032 - .062	.437	.143	.040 - .060	<b>.438</b>	<b>.200</b>	<b>.005 - .010</b>	.440	.210	.010 - .020	.446	.197	.010 - .020	.450	.375	.025 - .042
<b>.434</b>	<b>.253</b>	<b>.005 - .010</b>	.437	.144	.025 - .035	.438	.200	.075 - .090	<b>.440</b>	<b>.211</b>	<b>.005 - .010</b>	.446	.208	.050 - .070	.451	.188	.020 - .030
<b>.434</b>	<b>.255</b>	<b>.005 - .010</b>	.437	.147	.020 - .040	.438	.201	.025 - .050	.440	.217	.070 - .090	<b>.446</b>	<b>.256</b>	<b>.005 - .010</b>	.451	.241	.025 - .040
.434	.271	.050 - .070	.437	.150	.010 - .020	.438	.202	.020 - .040	.440	.218	.005 - .020	<b>.446</b>	<b>.270</b>	<b>.005 - .010</b>	.451	.267	.030 - .050
<b>.434</b>	<b>.282</b>	<b>.005 - .010</b>	.437	.157	.015 - .030	.438	.203	.075 - .090	.440	.228	.015 - .030	.446	.270	.020 - .040	<b>.451</b>	<b>.274</b>	<b>.005 - .010</b>
.434	.286	.020 - .030	<b>.437</b>	<b>.158</b>	<b>.005 - .010</b>	.438	.205	.070 - .090	.440	.228	.030 - .040	.446	.307	.030 - .050	.451	.315	.040 - .062
<b>.434</b>	<b>.315</b>	<b>.005 - .010</b>	.437	.166	.010 - .020	.438	.206	.020 - .030	.440	.237	.050 - .075	.446	.319	.032 - .060	<b>.451</b>	<b>.317</b>	<b>.005 - .010</b>
.434	.316	.015 - .025	.437	.166	.035 - .050	.438	.210	.042 - .060	<b>.440</b>	<b>.245</b>	<b>.005 - .010</b>	.446	.325	.032 - .060	.451	.334	.020 - .030
.434	.316	.025 - .040	.437	.169	.008 - .016	.438	.216	.005 - .012	<b>.440</b>	<b>.250</b>	<b>.005 - .010</b>	.447	.127	.020 - .040	.451	.344	.030 - .050
<b>.434</b>	<b>.318</b>	<b>.005 - .010</b>	.437	.171	.030 - .050	.438	.216	.080 - .100	.440	.252	.010 - .025	.447	.194	.030 - .050	.451	.353	.010 - .020
<b>.434</b>	<b>.320</b>	<b>.005 - .010</b>	.437	.183	.050 - .062	.438	.232	.035 - .050	<b>.440</b>	<b>.253</b>	<b>.005 - .010</b>	.447	.202	.025 - .040	.451	.378	.020 - .030
.434	.330	.030 - .050	.437	.191	.010 - .015	<b>.438</b>	<b>.236</b>	<b>.005 - .010</b>	.440	.260	.010 - .020	.447	.223	.025 - .050	<b>.451</b>	<b>.395</b>	<b>.005 - .010</b>
.434	.350	.025 - .035	.437	.191	.080 - .104	<b>.438</b>	<b>.247</b>	<b>.005 - .010</b>	.440	.260	.050 - .070	.447	.230	.025 - .040	.452	.102	.015 - .030
.435	.064	.035 - .062	.437	.192	.050 - .075	.438	.249	.050 - .075	<b>.440</b>	<b>.265</b>	<b>.005 - .010</b>	<b>.447</b>	<b>.236</b>	<b>.005 - .010</b>	.452	.257	.010 - .020
.435	.067	.020 - .040	.437	.194	.020 - .030	<b>.438</b>	<b>.255</b>	<b>.005 - .010</b>	.440	.275	.020 - .045	.447	.250	.020 - .040	<b>.452</b>	<b>.284</b>	<b>.005 - .010</b>
<b>.435</b>	<b>.077</b>	<b>.005 - .010</b>	.437	.194	.040 - .050	.438	.255	.015 - .030	.440	.283	.040 - .062	.447	.254	.010 - .020	.452	.328	.040 - .060
.435	.080	.012 - .025	.437	.194	.080 - .104	.438	.256	.025 - .050	.440	.304	.030 - .050	.447	.270	.020 - .030	.453	.236	.030 - .050
.435	.082	.030 - .050	.437	.197	.040 - .060	.438	.257	.030 - .050	.440	.314	.040 - .060	.447	.313	.015 - .025	.453	.243	.020 - .030
.435	.112	.007 - .012	.437	.197	.105 - .125	<b>.438</b>	<b>.258</b>	<b>.005 - .010</b>	.440	.316	.020 - .036	<b>.447</b>	<b>.337</b>	<b>.005 - .010</b>	.453	.275	.010 - .020
.435	.149	.060 - .083	<b>.437</b>	<b>.198</b>	<b>.005 - .010</b>	<b>.438</b>	<b>.259</b>	<b>.005 - .010</b>	.440	.316	.036 - .050	.447	.375	.020 - .036	.453	.300	.030 - .050
.435	.160	.010 - .020	.437	.199	.015 - .032	.438	.262	.030 - .050	.440	.328	.040 - .060	.447	.380	.015 - .030	.453	.330	.031 - .048
.435	.174	.025 - .040	.437	.204	.020 - .030	.438	.265	.030 - .060	.440	.355	.015 - .025	<b>.448</b>	<b>.094</b>	<b>.005 - .010</b>	.453	.354	.040 - .060
.435	.182	.060 - .083	.437	.205	.020 - .035	.438	.266	.015 - .030	.440	.381	.010 - .020	.448	.139	.030 - .040	.453	.378	.031 - .042
.435	.190	.070 - .090	.437	.215	.020 - .040	.438	.274	.015 - .030	<b>.440</b>	<b>.390</b>	<b>.005 - .010</b>	.448	.181	.006 - .012	.453	.398	.010 - .020
.435	.198	.005 - .015	.437	.217	.060 - .080	.438	.276	.030 - .050	.441	.042	.010 - .020	<b>.448</b>	<b>.189</b>	<b>.005 - .010</b>	<b>.454</b>	<b>.107</b>	<b>.005 - .010</b>
.435	.198	.048 - .072	.437	.218	.015 - .030	.438	.281	.060 - .080	.441	.093	.005 - .020	.448	.191	.030 - .048	.454	.136	.030 - .050
.435	.200	.050 - .075	.437	.218	.030 - .062	<b>.438</b>	<b>.282</b>	<b>.005 - .010</b>	<b>.441</b>	<b>.143</b>	<b>.005 - .010</b>	.448	.203	.015 - .030	.454	.193	.070 - .090
.435	.203	.005 - .008	.437	.219	.008 - .016	.438	.282	.010 - .020	.441	.143	.010 - .020	.448	.205	.030 - .060	<b>.454</b>	<b>.228</b>	<b>.005 - .010</b>
.435	.214	.040 - .062	.437	.220	.040 - .060	.438	.282	.050 - .075	.441	.151	.030 - .050	.448	.215	.020 - .040	.454	.320	.025 - .040
.435	.223	.025 - .050	<b>.437</b>	<b>.222</b>	<b>.005 - .010</b>	.438	.284	.050 - .075	.441	.168	.030 - .050	.448	.223	.025 - .040	<b>.454</b>	<b>.390</b>	<b>.005 - .010</b>
.435	.237	.015 - .030	.437	.225	.032 - .062	.438	.297	.015 - .025	.441	.172	.062 - .083	.448	.251	.032 - .060	<b>.454</b>	<b>.421</b>	

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.456	.257	.020 - .030	<b>.465</b>	<b>.261</b>	<b>.005 - .010</b>	.470	.138	.015 - .025	.472	.315	.025 - .040	.478	.316	.025 - .040	.485	.170	.040 - .060
<b>.456</b>	<b>.261</b>	<b>.005 - .010</b>	.465	.283	.075 - .100	.470	.143	.012 - .025	<b>.472</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.478</b>	<b>.322</b>	<b>.005 - .010</b>	<b>.485</b>	<b>.200</b>	<b>.005 - .010</b>
<b>.456</b>	<b>.378</b>	<b>.005 - .010</b>	.465	.283	.100 - .125	.470	.143	.030 - .050	.472	.319	.020 - .030	.478	.325	.050 - .070	<b>.485</b>	<b>.257</b>	<b>.005 - .010</b>
.456	.390	.010 - .020	.465	.314	.015 - .025	<b>.470</b>	<b>.149</b>	<b>.005 - .010</b>	<b>.472</b>	<b>.379</b>	<b>.005 - .010</b>	<b>.478</b>	<b>.343</b>	<b>.005 - .010</b>	<b>.485</b>	<b>.258</b>	<b>.005 - .010</b>
.457	.252	.050 - .075	<b>.465</b>	<b>.345</b>	<b>.005 - .010</b>	.470	.150	.060 - .090	.472	.387	.025 - .035	.478	.375	.050 - .062	.485	.260	.015 - .025
<b>.457</b>	<b>.254</b>	<b>.005 - .010</b>	<b>.465</b>	<b>.402</b>	<b>.005 - .010</b>	.470	.158	.050 - .070	.472	.399	.010 - .020	<b>.479</b>	<b>.127</b>	<b>.005 - .010</b>	.485	.312	.030 - .050
.457	.313	.050 - .060	.465	.402	.010 - .020	.470	.159	.050 - .070	<b>.473</b>	<b>.039</b>	<b>.005 - .010</b>	.479	.160	.050 - .075	.485	.313	.010 - .020
<b>.457</b>	<b>.363</b>	<b>.005 - .010</b>	.466	.125	.015 - .030	.470	.176	.060 - .080	.473	.070	.010 - .020	<b>.479</b>	<b>.178</b>	<b>.005 - .010</b>	<b>.485</b>	<b>.317</b>	<b>.005 - .010</b>
.457	.407	.015 - .025	.466	.127	.020 - .040	.470	.187	.110 - .130	<b>.473</b>	<b>.157</b>	<b>.005 - .010</b>	.479	.210	.025 - .036	.485	.319	.010 - .020
.458	.172	.062 - .090	.466	.189	.020 - .040	<b>.470</b>	<b>.200</b>	<b>.005 - .010</b>	.473	.172	.120 - .135	<b>.479</b>	<b>.219</b>	<b>.020 - .040</b>	.485	.320	.010 - .020
.458	.250	.040 - .062	.466	.191	.020 - .045	.470	.210	.035 - .050	<b>.473</b>	<b>.205</b>	<b>.005 - .010</b>	<b>.479</b>	<b>.294</b>	<b>.005 - .010</b>	.485	.320	.020 - .040
.459	.172	.050 - .075	.466	.198	.040 - .060	.470	.218	.010 - .025	.473	.238	.030 - .050	.479	.377	.015 - .030	.485	.328	.032 - .050
<b>.459</b>	<b>.173</b>	<b>.005 - .010</b>	.466	.205	.020 - .030	.470	.218	.025 - .040	.473	.240	.010 - .020	.479	.380	.005 - .008	.485	.336	.010 - .020
.459	.173	.035 - .050	.466	.210	.020 - .035	.470	.228	.010 - .020	.473	.242	.030 - .050	<b>.479</b>	<b>.385</b>	<b>.005 - .010</b>	.485	.347	.020 - .030
.459	.194	.040 - .050	.466	.218	.050 - .070	<b>.470</b>	<b>.239</b>	<b>.005 - .010</b>	.473	.243	.010 - .020	<b>.479</b>	<b>.412</b>	<b>.005 - .010</b>	.485	.350	.020 - .030
.459	.290	.060 - .080	.466	.251	.025 - .040	.470	.255	.047 - .060	.473	.248	.020 - .030	.479	.424	.020 - .025	.485	.354	.010 - .020
.459	.312	.040 - .060	.466	.259	.080 - .100	.470	.255	.060 - .085	<b>.473</b>	<b>.262</b>	<b>.005 - .010</b>	.480	.062	.020 - .040	.485	.376	.015 - .025
.459	.337	.040 - .060	<b>.466</b>	<b>.264</b>	<b>.005 - .010</b>	.470	.265	.032 - .048	.473	.284	.030 - .050	<b>.480</b>	<b>.159</b>	<b>.005 - .010</b>	.485	.386	.015 - .025
.459	.347	.020 - .030	.466	.290	.020 - .030	.470	.276	.050 - .075	.473	.289	.030 - .050	<b>.480</b>	<b>.170</b>	<b>.005 - .010</b>	.485	.411	.020 - .040
.459	.350	.020 - .030	<b>.466</b>	<b>.293</b>	<b>.005 - .010</b>	.470	.290	.015 - .030	.473	.317	.010 - .020	<b>.480</b>	<b>.192</b>	<b>.005 - .010</b>	.485	.412	.020 - .040
.460	.040	.010 - .020	.466	.319	.010 - .020	.470	.312	.020 - .030	<b>.473</b>	<b>.318</b>	<b>.005 - .010</b>	.480	.196	.040 - .060	<b>.485</b>	<b>.431</b>	<b>.005 - .010</b>
.460	.143	.020 - .040	<b>.466</b>	<b>.321</b>	<b>.005 - .010</b>	<b>.470</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.473</b>	<b>.319</b>	<b>.005 - .010</b>	.480	.215	.030 - .050	.486	.062	.030 - .050
<b>.460</b>	<b>.159</b>	<b>.005 - .010</b>	.466	.344	.015 - .030	<b>.470</b>	<b>.317</b>	<b>.005 - .010</b>	<b>.473</b>	<b>.320</b>	<b>.005 - .010</b>	.480	.237	.040 - .060	.486	.128	.015 - .030
<b>.460</b>	<b>.194</b>	<b>.005 - .010</b>	<b>.466</b>	<b>.380</b>	<b>.005 - .010</b>	.470	.319	.015 - .030	.473	.320	.010 - .020	<b>.480</b>	<b>.250</b>	<b>.005 - .010</b>	.486	.220	.025 - .040
<b>.460</b>	<b>.306</b>	<b>.005 - .010</b>	.467	.103	.010 - .020	.470	.324	.020 - .040	<b>.473</b>	<b>.321</b>	<b>.005 - .010</b>	.480	.251	.030 - .050	.486	.224	.040 - .060
.460	.319	.020 - .040	.467	.189	.075 - .105	<b>.470</b>	<b>.338</b>	<b>.005 - .010</b>	.473	.397	.005 - .015	.480	.276	.010 - .020	.486	.230	.030 - .050
.460	.378	.030 - .042	.467	.201	.015 - .030	.470	.340	.005 - .012	.473	.397	.015 - .030	.480	.350	.020 - .040	.486	.260	.010 - .020
.460	.380	.005 - .015	<b>.467</b>	<b>.204</b>	<b>.005 - .010</b>	.470	.341	.050 - .075	.474	.126	.010 - .020	<b>.480</b>	<b>.354</b>	<b>.005 - .010</b>	.486	.315	.015 - .030
<b>.461</b>	<b>.091</b>	<b>.005 - .010</b>	.467	.213	.015 - .030	.470	.350	.006 - .015	<b>.474</b>	<b>.238</b>	<b>.005 - .010</b>	.480	.368	.015 - .025	<b>.486</b>	<b>.327</b>	<b>.005 - .010</b>
.461	.215	.045 - .060	.467	.218	.015 - .020	<b>.470</b>	<b>.360</b>	<b>.005 - .010</b>	.474	.260	.020 - .040	.480	.370	.015 - .030	.486	.327	.035 - .050
<b>.461</b>	<b>.334</b>	<b>.005 - .010</b>	.467	.245	.025 - .040	<b>.470</b>	<b>.369</b>	<b>.005 - .010</b>	.474	.260	.050 - .070	<b>.480</b>	<b>.380</b>	<b>.005 - .010</b>	<b>.486</b>	<b>.355</b>	<b>.005 - .010</b>
.461	.355	.015 - .025	.467	.251	.050 - .072	.470	.373	.020 - .035	.474	.261	.040 - .060	<b>.480</b>	<b>.391</b>	<b>.005 - .010</b>	.486	.404	.010 - .020
.462	.062	.030 - .050	.467	.260	.030 - .050	.470	.380	.030 - .040	<b>.474</b>	<b>.278</b>	<b>.005 - .010</b>	<b>.481</b>	<b>.089</b>	<b>.005 - .010</b>	.487	.042	.025 - .042
.462	.090	.025 - .042	.467	.294	.020 - .030	.470	.384	.015 - .025	<b>.474</b>	<b>.279</b>	<b>.005 - .010</b>	.481	.126	.020 - .040	.487	.071	.010 - .020
.462	.158	.040 - .060	.467	.323	.005 - .015	<b>.470</b>	<b>.418</b>	<b>.005 - .010</b>	<b>.474</b>	<b>.284</b>	<b>.005 - .010</b>	<b>.481</b>	<b>.161</b>	<b>.005 - .010</b>	<b>.487</b>	<b>.120</b>	<b>.005 - .010</b>
<b>.462</b>	<b>.165</b>	<b>.005 - .010</b>	<b>.467</b>	<b>.380</b>	<b>.005 - .010</b>	.471	.126	.040 - .050	<b>.474</b>	<b>.317</b>	<b>.005 - .010</b>	.481	.188	.020 - .030	.487	.225	.010 - .032
.462	.203	.010 - .030	<b>.467</b>	<b>.382</b>	<b>.005 - .010</b>	.471	.130	.030 - .050	.474	.317	.010 - .015	.481	.245	.015 - .030	.487	.233	.040 - .060
<b>.462</b>	<b>.288</b>	<b>.005 - .010</b>	<b>.467</b>	<b>.420</b>	<b>.005 - .010</b>	.471	.130	.060 - .080	.474	.320	.030 - .050	.481	.247	.025 - .040	.487	.256	.025 - .040
.462	.318	.070 - .080	.468	.084	.010 - .025	<b>.471</b>	<b>.149</b>	<b>.005 - .010</b>	.474	.381	.005 - .012	<b>.481</b>	<b>.256</b>	<b>.005 - .010</b>	.487	.257	.010 - .020
<b>.462</b>	<b>.324</b>	<b>.005 - .010</b>	.468	.128	.005 - .015	.471	.170	.020 - .030	.474	.396	.015 - .025	<b>.481</b>	<b>.318</b>	<b>.005 - .010</b>	.487	.270	.090 - .110
.462	.377	.015 - .025	.468	.150	.030 - .050	<b>.471</b>	<b>.174</b>	<b>.005 - .010</b>	.475	.147	.020 - .040	<b>.481</b>	<b>.336</b>	<b>.005 - .010</b>	<b>.487</b>	<b>.272</b>	<b>.005 - .010</b>
.463	.073	.015 - .030	.468	.222	.040 - .060	.471	.197	.030 - .040	.475	.192	.060 - .080	.481	.361	.040 - .060	.487	.321	.040 - .060
.463	.166	.015 - .030	.468	.254	.010 - .015	.471	.203	.115 - .135	<b>.475</b>	<b>.196</b>	<b>.005 - .010</b>	.481	.383	.010 - .020	.487	.327	.030 - .040
.463	.188	.060 - .080	<b>.468</b>	<b>.257</b>	<b>.005 - .010</b>	.471	.205	.100 - .125	.475	.227	.020 - .030	.481	.387	.010 - .020	.487	.336	.025 - .040
.463	.189	.025 - .040	.468	.259	.010 - .020	<b>.471</b>	<b>.206</b>	<b>.005 - .010</b>	.475	.259	.010 - .020	.481	.390	.050 - .060	.487	.337	.020 - .040
.463	.222	.025 - .040	.468	.259	.070 - .090	<b>.471</b>	<b>.218</b>	<b>.005 - .010</b>	.475	.259	.020 - .030	<b>.481</b>	<b>.402</b>	<b>.005 - .010</b>	<b>.487</b>	<b>.355</b>	<b>.005 - .010</b>
.463	.224	.010 - .020	.468	.261	.005 - .015	.471	.222	.020 - .030	<b>.475</b>	<b>.279</b>	<b>.005 - .010</b>	.482	.173	.030 - .050	.487	.355	.010 - .020
.463	.245	.030 - .060	<b>.468</b>	<b>.287</b>	<b>.005 - .010</b>	.471	.223	.040 - .050	<b>.475</b>	<b>.286</b>	<b>.005 - .010</b>	.482	.190	.020 - .040	<b>.487</b>	<b>.364</b>	<b>.005 - .010</b>
.463	.258	.050 - .075	.468	.312	.050 - .070	.471	.224	.020 - .040	.475	.334	.040 - .060	.482	.315	.020 - .040	<b>.487</b>	<b>.399</b>	<b>.005 - .010</b>
.463	.263	.060 - .075	<b>.468</b>	<b>.320</b>	<b>.005 - .010</b>	<b>.471</b>	<b>.254</b>	<b>.005 - .010</b>	<b>.475</b>	<b>.360</b>	<b>.005 - .010</b>	<b>.482</b>	<b>.329</b>	<b>.050 - .075</b>	<b>.487</b>	<b>.402</b>	<b>.005 - .010</b>
.463	.267	.030 - .050	<b>.468</b>	<b>.321</b>	<b>.005 - .010</b>	.471	.256	.035 - .050	.475	.368	.015 - .030	.482	.332	.020 - .040	.488	.054	.025 - .040
<b>.463</b>	<b>.270</b>	<b>.005 - .010</b>	.468	.321	.048 - .072	<b>.471</b>	<b>.259</b>	<b>.005 - .010</b>	.475	.368	.030 - .040	<b>.482</b>	<b>.334</b>	<b>.005 - .010</b>	.488	.096	.060 - .090
<b>.463</b>	<b>.288</b>	<b>.005 - .010</b>	.468	.390	.015 - .030	.471	.287	.005 - .015	<b>.475</b>	<b>.378</b>	<b>.005 - .010</b>	.482	.359	.010 - .020	.488	.118	.080 - .104
.463	.321	.030 - .050	.468	.400	.020 - .040	.471	.318	.050 - .070	.475	.380	.010 - .020	.482	.359	.020 - .040	.488	.193	.050 - .070
.463	.322	.015 - .030	<b>.468</b>	<b>.405</b>	<b>.005 - .010</b>	.471	.319	.010 - .020	.475	.397	.020 - .030	<b>.482</b>	<b>.396</b>	<b>.005 - .010</b>	.488	.281	.032 - .062
.463	.333	.030 - .050	.469	.100	.020 - .040	<b>.471</b>	<b>.322</b>	<b>.005 - .010</b>	.475	.400	.020 - .040	.483	.033	.010 - .020	<b>.488</b>	<b>.315</b>	<b>.005 - .010</b>
.463	.391	.020 - .030	.469	.149	.080 - .104	.471	.348	.025 - .042	.475	.411	.010 - .020	.483	.077	.020 - .040	.488	.365	.010 - .020
<b>.464</b>	<b>.129</b>	<b>.005 - .010</b>	.469	.184	.005 - .010	.471	.378	.005 - .012	.475	.424	.015 - .025	<b>.483</b>	<b>.149</b>	<b>.005 - .010</b>	<b>.488</b>	<b>.400</b>	<b>.005 - .010</b>
.464	.159	.060 - .080	<b>.469</b>	<b>.192</b>	<b>.005 - .010</b>	<b>.471</b>	<b>.387</b>	<b>.005 - .010</b>	.475	.424	.025 - .040	.483	.149	.040 - .060	.489	.180	.030 - .050
.464	.160	.015 - .030	.469	.192	.015 - .030	.472	.097	.005 - .008	.476	.144	.032 - .060	.483	.152	.030 - .060	.489	.189	.025 - .040
.464	.190	.030 - .050	.469	.206	.075 - .100	.472	.0										

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.490	.302	.005 - .010	.494	.262	.025 - .040	.496	.318	.060 - .080	.498	.302	.025 - .040	.500	.112	.030 - .050	.500	.230	.032 - .048
.490	.313	.015 - .030	.494	.265	.010 - .020	<b>.496</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.498</b>	<b>.315</b>	<b>.005 - .010</b>	.500	.113	.020 - .040	<b>.500</b>	<b>.231</b>	<b>.005 - .010</b>
.490	.315	.015 - .020	.494	.265	.040 - .060	.496	.332	.030 - .050	.498	.321	.010 - .020	<b>.500</b>	<b>.114</b>	<b>.005 - .010</b>	.500	.233	.100 - .125
.490	.316	.015 - .020	<b>.494</b>	<b>.273</b>	<b>.005 - .010</b>	.496	.343	.030 - .042	.498	.323	.020 - .040	.500	.114	.020 - .030	.500	.234	.100 - .120
<b>.490</b>	<b>.344</b>	<b>.005 - .010</b>	<b>.494</b>	<b>.274</b>	<b>.005 - .010</b>	.496	.346	.050 - .070	.498	.328	.060 - .075	.500	.116	.020 - .040	<b>.500</b>	<b>.235</b>	<b>.005 - .010</b>
.490	.353	.010 - .020	.494	.278	.010 - .020	.496	.349	.050 - .075	.498	.337	.015 - .030	.500	.121	.005 - .012	.500	.237	.008 - .016
.490	.360	.020 - .040	<b>.494</b>	<b>.280</b>	<b>.005 - .010</b>	.496	.353	.050 - .070	.498	.339	.020 - .035	.500	.125	.007 - .015	.500	.237	.072 - .093
.490	.377	.050 - .070	<b>.494</b>	<b>.282</b>	<b>.005 - .010</b>	.496	.377	.050 - .070	.498	.344	.015 - .025	.500	.125	.010 - .018	.500	.237	.100 - .125
.490	.378	.010 - .020	.494	.314	.015 - .030	<b>.496</b>	<b>.380</b>	<b>.005 - .010</b>	<b>.498</b>	<b>.377</b>	<b>.005 - .010</b>	.500	.125	.035 - .062	.500	.238	.105 - .125
.490	.378	.025 - .042	.494	.314	.030 - .050	.496	.380	.025 - .040	.498	.380	.010 - .015	.500	.129	.025 - .050	.500	.245	.020 - .030
<b>.490</b>	<b>.380</b>	<b>.005 - .010</b>	.494	.321	.010 - .020	.496	.381	.015 - .030	<b>.498</b>	<b>.392</b>	<b>.005 - .010</b>	.500	.129	.050 - .075	.500	.250	.010 - .020
.490	.391	.016 - .025	<b>.494</b>	<b>.323</b>	<b>.005 - .010</b>	.496	.381	.020 - .040	.498	.392	.032 - .042	.500	.131	.010 - .020	.500	.250	.040 - .060
.490	.393	.030 - .042	.494	.323	.062 - .078	.496	.381	.050 - .075	.498	.399	.015 - .025	.500	.131	.040 - .060	.500	.250	.120 - .134
<b>.490</b>	<b>.412</b>	<b>.005 - .010</b>	.494	.325	.025 - .035	.496	.390	.030 - .040	<b>.498</b>	<b>.408</b>	<b>.005 - .010</b>	.500	.132	.040 - .060	.500	.251	.015 - .030
.490	.416	.005 - .015	<b>.494</b>	<b>.367</b>	<b>.005 - .010</b>	<b>.496</b>	<b>.400</b>	<b>.005 - .010</b>	<b>.498</b>	<b>.426</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.133</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.252</b>	<b>.005 - .010</b>
.491	.136	.020 - .040	.494	.370	.008 - .015	<b>.496</b>	<b>.433</b>	<b>.005 - .010</b>	.499	.065	.015 - .025	.500	.136	.012 - .020	.500	.252	.015 - .025
<b>.491</b>	<b>.172</b>	<b>.005 - .010</b>	<b>.494</b>	<b>.373</b>	<b>.005 - .010</b>	<b>.496</b>	<b>.437</b>	<b>.005 - .010</b>	.499	.072	.050 - .075	.500	.140	.010 - .020	.500	.252	.020 - .032
.491	.207	.020 - .030	<b>.494</b>	<b>.380</b>	<b>.005 - .010</b>	.497	.098	.030 - .050	.499	.090	.040 - .060	.500	.141	.008 - .016	.500	.252	.035 - .050
<b>.491</b>	<b>.250</b>	<b>.005 - .010</b>	.494	.399	.025 - .040	.497	.137	.030 - .048	.499	.094	.042 - .062	.500	.142	.030 - .042	.500	.252	.050 - .070
.491	.252	.100 - .134	.494	.420	.008 - .015	.497	.138	.030 - .048	.499	.118	.060 - .080	.500	.142	.100 - .125	.500	.252	.072 - .090
<b>.491</b>	<b>.253</b>	<b>.005 - .010</b>	.495	.034	.015 - .025	.497	.166	.010 - .020	.499	.123	.050 - .060	<b>.500</b>	<b>.144</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.253</b>	<b>.005 - .010</b>
.491	.253	.060 - .075	<b>.495</b>	<b>.040</b>	<b>.005 - .010</b>	.497	.191	.060 - .080	<b>.499</b>	<b>.125</b>	<b>.005 - .010</b>	.500	.144	.020 - .030	.500	.253	.010 - .020
.491	.254	.050 - .075	.495	.063	.020 - .035	.497	.193	.025 - .040	.499	.142	.030 - .050	.500	.145	.007 - .020	.500	.253	.020 - .032
.491	.256	.040 - .060	.495	.073	.040 - .062	<b>.497</b>	<b>.196</b>	<b>.005 - .010</b>	.499	.170	.020 - .030	.500	.146	.035 - .050	.500	.253	.035 - .050
.491	.265	.090 - .105	.495	.136	.030 - .050	<b>.497</b>	<b>.215</b>	<b>.005 - .010</b>	.499	.175	.050 - .072	.500	.147	.035 - .050	<b>.500</b>	<b>.254</b>	<b>.005 - .010</b>
.491	.266	.010 - .020	.495	.143	.100 - .125	.497	.220	.020 - .040	.499	.189	.010 - .020	.500	.150	.008 - .016	.500	.254	.010 - .020
.491	.266	.020 - .030	.495	.158	.030 - .060	.497	.220	.050 - .070	.499	.190	.020 - .030	.500	.150	.032 - .050	.500	.254	.060 - .083
<b>.491</b>	<b>.267</b>	<b>.005 - .010</b>	.495	.162	.048 - .075	.497	.250	.015 - .030	.499	.192	.005 - .012	<b>.500</b>	<b>.153</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.255</b>	<b>.005 - .010</b>
<b>.491</b>	<b>.268</b>	<b>.005 - .010</b>	.495	.184	.070 - .090	<b>.497</b>	<b>.252</b>	<b>.005 - .010</b>	.499	.192	.015 - .030	.500	.155	.100 - .125	.500	.255	.020 - .030
.491	.317	.010 - .020	.495	.190	.010 - .020	.497	.252	.015 - .025	<b>.499</b>	<b>.193</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.160</b>	<b>.005 - .010</b>	.500	.257	.005 - .015
.491	.320	.010 - .020	.495	.191	.020 - .030	<b>.497</b>	<b>.253</b>	<b>.005 - .010</b>	.499	.193	.050 - .075	.500	.163	.050 - .072	.500	.257	.030 - .050
.491	.338	.030 - .050	<b>.495</b>	<b>.195</b>	<b>.005 - .010</b>	.497	.254	.015 - .030	<b>.499</b>	<b>.194</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.167</b>	<b>.005 - .010</b>	.500	.257	.050 - .062
.491	.385	.015 - .030	.495	.200	.030 - .050	.497	.254	.040 - .060	.499	.201	.050 - .075	.500	.168	.025 - .040	.500	.257	.062 - .090
<b>.491</b>	<b>.393</b>	<b>.005 - .010</b>	.495	.203	.050 - .070	.497	.259	.010 - .020	.499	.203	.080 - .100	.500	.168	.050 - .075	.500	.257	.090 - .104
.492	.124	.110 - .130	.495	.210	.025 - .040	.497	.259	.020 - .040	.499	.215	.010 - .020	.500	.170	.025 - .050	.500	.258	.100 - .120
.492	.193	.030 - .050	.495	.215	.010 - .020	.497	.280	.015 - .030	<b>.499</b>	<b>.229</b>	<b>.005 - .010</b>	.500	.172	.006 - .015	.500	.259	.100 - .125
.492	.201	.040 - .050	.495	.223	.050 - .070	.497	.287	.005 - .015	.499	.239	.030 - .040	.500	.172	.010 - .020	<b>.500</b>	<b>.260</b>	<b>.005 - .010</b>
.492	.204	.105 - .125	.495	.225	.075 - .090	.497	.315	.005 - .012	.499	.240	.048 - .070	.500	.172	.030 - .050	<b>.500</b>	<b>.260</b>	<b>.005 - .010</b>
.492	.250	.020 - .040	.495	.236	.010 - .020	.497	.316	.035 - .050	<b>.499</b>	<b>.243</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.173</b>	<b>.005 - .010</b>	.500	.260	.010 - .020
.492	.254	.030 - .042	.495	.252	.040 - .060	.497	.318	.015 - .030	<b>.499</b>	<b>.246</b>	<b>.005 - .010</b>	.500	.176	.050 - .070	.500	.261	.050 - .075
.492	.254	.042 - .060	.495	.282	.042 - .072	.497	.319	.015 - .030	.499	.254	.035 - .060	.500	.177	.060 - .075	<b>.500</b>	<b>.263</b>	<b>.005 - .010</b>
.492	.255	.030 - .050	.495	.285	.015 - .025	<b>.497</b>	<b>.324</b>	<b>.005 - .010</b>	.499	.258	.015 - .030	.500	.180	.025 - .040	.500	.263	.050 - .075
.492	.260	.070 - .090	.495	.285	.025 - .040	<b>.497</b>	<b>.337</b>	<b>.005 - .010</b>	.499	.259	.030 - .050	.500	.182	.060 - .090	.500	.263	.105 - .120
<b>.492</b>	<b>.276</b>	<b>.005 - .010</b>	.495	.286	.015 - .040	.497	.344	.062 - .075	.499	.264	.010 - .020	.500	.187	.020 - .035	<b>.500</b>	<b>.265</b>	<b>.005 - .010</b>
.492	.281	.030 - .050	.495	.298	.025 - .045	.497	.347	.005 - .015	.499	.265	.025 - .040	.500	.187	.105 - .125	.500	.265	.025 - .040
.492	.328	.012 - .020	.495	.310	.010 - .030	.497	.347	.020 - .030	.499	.281	.080 - .100	.500	.188	.030 - .050	.500	.265	.050 - .070
.492	.377	.030 - .050	.495	.322	.020 - .040	<b>.497</b>	<b>.406</b>	<b>.005 - .010</b>	<b>.499</b>	<b>.313</b>	<b>.005 - .010</b>	.500	.189	.005 - .012	.500	.265	.090 - .104
<b>.492</b>	<b>.379</b>	<b>.005 - .010</b>	.495	.327	.080 - .100	.497	.410	.020 - .030	.499	.318	.050 - .070	.500	.189	.100 - .125	<b>.500</b>	<b>.266</b>	<b>.005 - .010</b>
<b>.492</b>	<b>.380</b>	<b>.005 - .010</b>	.495	.329	.015 - .030	<b>.497</b>	<b>.437</b>	<b>.005 - .010</b>	.499	.323	.010 - .020	.500	.190	.090 - .104	.500	.266	.015 - .025
.492	.393	.020 - .042	.495	.337	.060 - .080	<b>.497</b>	<b>.442</b>	<b>.005 - .010</b>	.499	.323	.040 - .060	<b>.500</b>	<b>.191</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.268</b>	<b>.005 - .010</b>
.493	.125	.015 - .030	.495	.347	.035 - .050	.497	.442	.025 - .030	<b>.499</b>	<b>.329</b>	<b>.005 - .010</b>	.500	.194	.062 - .090	.500	.268	.010 - .020
.493	.131	.020 - .040	.495	.361	.050 - .065	.498	.063	.050 - .062	<b>.499</b>	<b>.373</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.195</b>	<b>.005 - .010</b>	.500	.269	.020 - .036
.493	.145	.070 - .090	.495	.363	.040 - .060	.498	.078	.040 - .060	.499	.381	.005 - .015	.500	.196	.010 - .020	<b>.500</b>	<b>.270</b>	<b>.005 - .010</b>
.493	.193	.075 - .090	.495	.381	.010 - .020	.498	.082	.042 - .062	.499	.381	.040 - .060	.500	.196	.105 - .125	.500	.270	.015 - .025
<b>.493</b>	<b>.198</b>	<b>.005 - .010</b>	.495	.401	.010 - .025	.498	.096	.030 - .050	<b>.499</b>	<b>.394</b>	<b>.005 - .010</b>	<b>.500</b>	<b>.197</b>	<b>.005 - .010</b>	.500	.270	.070 - .090
<b>.493</b>	<b>.207</b>	<b>.005 - .010</b>	.495	.440	.005 - .008	.498	.122	.020 - .040	.499	.409	.025 - .042	.500	.197	.020 - .040	<b>.500</b>	<b>.275</b>	<b>.005 - .010</b>
.493	.244	.050 - .070	.496	.041													

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.500	.316	.010 - .020	.501	.256	.062 - .090	<b>.505</b>	<b>.194</b>	<b>.005 - .010</b>	<b>.512</b>	<b>.320</b>	<b>.005 - .010</b>	<b>.520</b>	<b>.324</b>	<b>.005 - .010</b>	.530	.099	.015 - .030
.500	.316	.030 - .050	<b>.501</b>	<b>.263</b>	<b>.005 - .010</b>	.505	.250	.020 - .030	<b>.512</b>	<b>.321</b>	<b>.005 - .010</b>	<b>.520</b>	<b>.333</b>	<b>.005 - .010</b>	.530	.130	.040 - .060
<b>.500</b>	<b>.317</b>	<b>.005 - .010</b>	.501	.272	.090 - .105	.505	.254	.010 - .020	<b>.512</b>	<b>.322</b>	<b>.005 - .010</b>	.520	.346	.020 - .030	.530	.153	.080 - .104
.500	.317	.070 - .090	.501	.281	.050 - .070	.505	.324	.050 - .070	.512	.322	.060 - .080	<b>.520</b>	<b>.380</b>	<b>.005 - .010</b>	<b>.530</b>	<b>.180</b>	<b>.005 - .010</b>
.500	.318	.010 - .020	.501	.281	.080 - .104	.505	.335	.025 - .040	<b>.512</b>	<b>.394</b>	<b>.005 - .010</b>	<b>.520</b>	<b>.392</b>	<b>.005 - .010</b>	<b>.530</b>	<b>.191</b>	<b>.005 - .010</b>
.500	.319	.025 - .045	.501	.283	.010 - .020	.505	.341	.025 - .042	.512	.395	.015 - .025	.520	.430	.010 - .020	.530	.206	.100 - .125
.500	.319	.030 - .050	.501	.283	.080 - .100	.505	.341	.050 - .075	<b>.512</b>	<b>.433</b>	<b>.005 - .010</b>	<b>.520</b>	<b>.440</b>	<b>.005 - .010</b>	.530	.222	.020 - .035
.500	.320	.015 - .025	<b>.501</b>	<b>.300</b>	<b>.005 - .010</b>	.505	.355	.025 - .040	<b>.513</b>	<b>.137</b>	<b>.005 - .010</b>	<b>.520</b>	<b>.455</b>	<b>.005 - .010</b>	<b>.530</b>	<b>.253</b>	<b>.005 - .010</b>
<b>.500</b>	<b>.321</b>	<b>.005 - .010</b>	.501	.313	.005 - .008	.505	.386	.020 - .030	.513	.153	.040 - .060	.521	.145	.075 - .090	.530	.254	.015 - .030
<b>.500</b>	<b>.323</b>	<b>.005 - .010</b>	.501	.313	.050 - .070	.505	.390	.030 - .050	.513	.174	.030 - .050	.521	.239	.040 - .050	.530	.255	.015 - .030
.500	.327	.020 - .040	<b>.501</b>	<b>.318</b>	<b>.005 - .010</b>	<b>.505</b>	<b>.396</b>	<b>.005 - .010</b>	.513	.197	.015 - .030	.521	.325	.010 - .020	.530	.270	.100 - .125
.500	.327	.062 - .080	.501	.318	.070 - .090	.505	.399	.020 - .040	.513	.237	.070 - .090	.521	.340	.072 - .090	.530	.272	.100 - .125
.500	.328	.048 - .070	.501	.322	.020 - .040	.505	.401	.030 - .050	.513	.240	.030 - .050	.521	.380	.025 - .040	.530	.273	.100 - .125
.500	.332	.080 - .100	.501	.340	.070 - .090	<b>.505</b>	<b>.457</b>	<b>.005 - .010</b>	.513	.268	.005 - .012	<b>.521</b>	<b>.440</b>	<b>.005 - .010</b>	<b>.530</b>	<b>.277</b>	<b>.005 - .010</b>
.500	.334	.010 - .020	.501	.345	.025 - .040	<b>.506</b>	<b>.053</b>	<b>.005 - .010</b>	.513	.287	.050 - .070	.522	.251	.042 - .072	<b>.530</b>	<b>.312</b>	<b>.005 - .010</b>
<b>.500</b>	<b>.338</b>	<b>.005 - .010</b>	.501	.370	.050 - .070	.506	.220	.040 - .060	<b>.513</b>	<b>.360</b>	<b>.005 - .010</b>	<b>.522</b>	<b>.265</b>	<b>.005 - .010</b>	.530	.314	.015 - .030
.500	.338	.050 - .070	.501	.375	.016 - .030	.506	.221	.040 - .060	.513	.373	.015 - .030	.522	.353	.015 - .025	.530	.314	.050 - .070
.500	.348	.015 - .030	<b>.501</b>	<b>.376</b>	<b>.005 - .010</b>	<b>.506</b>	<b>.257</b>	<b>.005 - .010</b>	<b>.513</b>	<b>.383</b>	<b>.005 - .010</b>	.522	.413	.030 - .050	.530	.316	.025 - .040
.500	.350	.040 - .060	.501	.379	.030 - .050	.506	.258	.040 - .060	<b>.513</b>	<b>.440</b>	<b>.005 - .010</b>	.522	.435	.015 - .030	.530	.320	.025 - .040
.500	.352	.006 - .012	<b>.501</b>	<b>.380</b>	<b>.005 - .010</b>	<b>.506</b>	<b>.275</b>	<b>.005 - .010</b>	.514	.194	.070 - .090	<b>.522</b>	<b>.437</b>	<b>.005 - .010</b>	.530	.344	.060 - .083
<b>.500</b>	<b>.356</b>	<b>.005 - .010</b>	.501	.386	.010 - .020	<b>.507</b>	<b>.107</b>	<b>.005 - .010</b>	<b>.514</b>	<b>.203</b>	<b>.005 - .010</b>	.523	.118	.025 - .040	<b>.530</b>	<b>.375</b>	<b>.005 - .010</b>
.500	.360	.015 - .030	<b>.501</b>	<b>.397</b>	<b>.005 - .010</b>	.507	.125	.030 - .040	.514	.210	.040 - .060	.523	.252	.070 - .090	<b>.530</b>	<b>.377</b>	<b>.005 - .010</b>
.500	.360	.020 - .040	.501	.402	.020 - .030	.507	.221	.010 - .020	<b>.514</b>	<b>.392</b>	<b>.005 - .010</b>	.523	.396	.015 - .030	.530	.388	.010 - .020
.500	.368	.020 - .040	.501	.404	.015 - .030	.507	.232	.060 - .078	.514	.431	.030 - .040	<b>.523</b>	<b>.402</b>	<b>.005 - .010</b>	<b>.530</b>	<b>.393</b>	<b>.005 - .010</b>
<b>.500</b>	<b>.370</b>	<b>.005 - .010</b>	.501	.409	.030 - .048	.507	.253	.050 - .075	.514	.454	.020 - .030	.523	.406	.032 - .050	.530	.397	.025 - .035
.500	.373	.008 - .015	.501	.413	.015 - .025	<b>.507</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.515</b>	<b>.149</b>	<b>.005 - .010</b>	.523	.411	.040 - .060	<b>.530</b>	<b>.417</b>	<b>.005 - .010</b>
.500	.375	.040 - .062	.502	.124	.060 - .083	<b>.507</b>	<b>.360</b>	<b>.005 - .010</b>	.515	.163	.030 - .050	.523	.428	.015 - .030	.530	.450	.015 - .030
.500	.375	.050 - .075	<b>.502</b>	<b>.130</b>	<b>.005 - .010</b>	<b>.507</b>	<b>.368</b>	<b>.005 - .010</b>	.515	.191	.050 - .070	.524	.286	.030 - .048	<b>.530</b>	<b>.468</b>	<b>.005 - .010</b>
.500	.376	.015 - .030	.502	.131	.025 - .040	.507	.368	.010 - .030	.515	.206	.080 - .104	.524	.323	.020 - .030	.530	.468	.015 - .030
<b>.500</b>	<b>.377</b>	<b>.005 - .010</b>	<b>.502</b>	<b>.142</b>	<b>.005 - .010</b>	.507	.375	.010 - .020	<b>.515</b>	<b>.218</b>	<b>.005 - .010</b>	.524	.323	.040 - .060	<b>.530</b>	<b>.490</b>	<b>.005 - .010</b>
.500	.377	.030 - .050	.502	.161	.012 - .025	.507	.446	.020 - .030	.515	.227	.030 - .050	.524	.387	.015 - .025	.531	.143	.015 - .030
.500	.377	.036 - .060	.502	.183	.080 - .104	.508	.223	.050 - .070	<b>.515</b>	<b>.228</b>	<b>.005 - .010</b>	<b>.524</b>	<b>.396</b>	<b>.005 - .010</b>	.531	.143	.030 - .050
.500	.378	.005 - .012	.502	.185	.032 - .062	.508	.269	.010 - .020	.515	.308	.008 - .015	.524	.409	.010 - .020	.531	.158	.032 - .048
.500	.378	.040 - .060	.502	.188	.062 - .090	.508	.280	.020 - .036	.515	.310	.008 - .015	.524	.463	.025 - .040	.531	.180	.050 - .075
.500	.383	.030 - .050	.502	.189	.030 - .050	.508	.280	.025 - .040	.515	.315	.008 - .015	.525	.068	.015 - .032	.531	.191	.012 - .020
.500	.388	.020 - .036	.502	.190	.062 - .090	.508	.285	.015 - .025	.515	.316	.008 - .015	.525	.156	.090 - .105	.531	.200	.015 - .030
<b>.500</b>	<b>.390</b>	<b>.005 - .010</b>	.502	.190	.080 - .100	<b>.508</b>	<b>.312</b>	<b>.005 - .010</b>	<b>.515</b>	<b>.318</b>	<b>.005 - .010</b>	.525	.187	.015 - .030	.531	.202	.015 - .030
.500	.390	.015 - .030	.502	.194	.060 - .080	<b>.508</b>	<b>.315</b>	<b>.005 - .010</b>	.515	.322	.015 - .025	.525	.258	.060 - .080	<b>.531</b>	<b>.206</b>	<b>.005 - .010</b>
.500	.390	.030 - .060	.502	.196	.040 - .060	.508	.329	.050 - .075	<b>.515</b>	<b>.377</b>	<b>.005 - .010</b>	<b>.525</b>	<b>.308</b>	<b>.005 - .010</b>	.531	.206	.015 - .030
<b>.500</b>	<b>.396</b>	<b>.005 - .010</b>	.502	.245	.025 - .036	<b>.508</b>	<b>.336</b>	<b>.005 - .010</b>	.515	.378	.020 - .030	.525	.346	.060 - .080	<b>.531</b>	<b>.213</b>	<b>.005 - .010</b>
.500	.396	.010 - .030	.502	.262	.040 - .060	.508	.355	.040 - .060	<b>.515</b>	<b>.385</b>	<b>.005 - .010</b>	.525	.378	.030 - .050	.531	.230	.105 - .125
.500	.402	.005 - .015	.502	.263	.030 - .050	<b>.508</b>	<b>.366</b>	<b>.005 - .010</b>	.515	.388	.020 - .040	.525	.390	.060 - .080	.531	.254	.060 - .083
<b>.500</b>	<b>.412</b>	<b>.005 - .010</b>	.502	.303	.075 - .100	.508	.430	.030 - .040	.515	.390	.010 - .020	.525	.401	.020 - .040	.531	.257	.010 - .020
.500	.415	.012 - .016	<b>.502</b>	<b>.315</b>	<b>.005 - .010</b>	.509	.031	.030 - .050	.515	.394	.005 - .008	<b>.525</b>	<b>.428</b>	<b>.005 - .010</b>	.531	.257	.040 - .060
.500	.441	.010 - .020	.502	.315	.025 - .040	.509	.064	.030 - .050	<b>.515</b>	<b>.397</b>	<b>.005 - .010</b>	.525	.428	.006 - .015	.531	.264	.030 - .050
<b>.500</b>	<b>.446</b>	<b>.005 - .010</b>	.502	.329	.020 - .030	.509	.080	.030 - .050	.515	.420	.020 - .032	.526	.195	.030 - .050	.531	.271	.025 - .035
<b>.500</b>	<b>.450</b>	<b>.005 - .010</b>	.502	.378	.025 - .040	.509	.219	.025 - .042	.516	.156	.030 - .050	.526	.256	.030 - .050	.531	.295	.015 - .030
.501	.061	.010 - .020	<b>.502</b>	<b>.386</b>	<b>.005 - .010</b>	.509	.285	.010 - .020	.516	.195	.008 - .015	.526	.270	.010 - .020	.531	.317	.010 - .020
.501	.099	.050 - .075	<b>.503</b>	<b>.131</b>	<b>.005 - .010</b>	.509	.286	.010 - .020	<b>.516</b>	<b>.239</b>	<b>.005 - .010</b>	.526	.437	.015 - .030	.531	.317	.040 - .060
.501	.130	.030 - .050	.503	.131	.100 - .120	.509	.298	.050 - .070	.516	.246	.005 - .020	.527	.129	.015 - .025	.531	.330	.040 - .060
.501	.131	.025 - .040	.503	.142	.030 - .060	.509	.430	.020 - .035	.516	.246	.010 - .020	<b>.527</b>	<b>.145</b>	<b>.005 - .010</b>	.531	.335	.100 - .120
<b>.501</b>	<b>.136</b>	<b>.005 - .010</b>	.503	.153	.040 - .050	.510	.053	.015 - .025	<b>.516</b>	<b>.315</b>	<b>.005 - .010</b>	.527	.346	.040 - .060	.531	.346	.042 - .062
.501	.136	.010 - .020	.503	.157	.050 - .062	.510	.156	.025 - .042	<b>.516</b>	<b>.320</b>	<b>.005 - .010</b>	.527	.348	.032 - .050	.531	.348	.050 - .072
.501	.139	.075 - .105	<b>.503</b>	<b>.159</b>	<b>.005 - .010</b>	.510	.210	.075 - .090	.516	.387	.020 - .040	<b>.527</b>	<b>.369</b>	<b>.005 - .010</b>	.531	.350	.040 - .062
.501	.143	.070 - .090	.503	.280	.075 - .100	<b>.510</b>	<b>.269</b>	<b>.005 - .010</b>	<b>.516</b>	<b>.388</b>	<b>.005 - .010</b>	.527	.393	.030 - .050	.531	.386	.010 - .020
<b>.501</b>	<b>.158</b>	<b>.005 - .010</b>	.503	.281	.010 - .020	.510	.280	.040 - .050	.516	.438	.020 - .032	.527	.437	.010 - .020	.531	.406	.050 - .060
.501	.168	.045 - .060	<b>.503</b>	<b>.315</b>	<b>.005 - .010</b>	.510	.280	.050 - .075	<b>.516</b>	<b>.445</b>	<b>.005 - .010</b>	.527	.443	.020 - .040	.531	.463	.015 - .030
<b>.501</b>	<b>.170</b>	<b>.005 - .010</b>	<b>.503</b>	<b>.316</b>	<b>.005 - .010</b>	.510	.341	.042 - .062	.517	.331	.030 - .050	.528	.128	.010 - .020	.532	.073	.010 - .020
.501	.182	.010 - .025	.503	.318	.050 - .070	.510	.398	.040 - .050	.517	.340	.015 - .030	.528	.152	.005 - .012	.532	.166	.100 - .125
.501	.182	.080 - .104	<b>.503</b>	<b>.363</b>	<b>.005 - .010</b>	.510	.414	.007 - .020	.517	.341	.040 - .060	.528	.209	.010 - .020	<b>.532</b>	<b>.201</b>	<b>.005 - .010</b>
.501	.191	.090 - .100	<b>.503</b>	<b>.383</b>	<b>.005 - .010</b>	<b>.511</b>	<b>.150</b>	<b>.005 - .010</b>	<b>.517</b>	<b>.346</b>	<b>.005 - .010</b>	.528	.236	.040 - .060	.532	.207	.062 - .090
.501	.192																

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.534	.193	.015 - .030	<b>.543</b>	<b>.333</b>	<b>.005 - .010</b>	.550	.315	.032 - .048	.552	.396	.050 - .075	<b>.559</b>	<b>.471</b>	<b>.005 - .010</b>	.561	.314	.036 - .060
.534	.207	.030 - .050	.543	.346	.030 - .050	<b>.550</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.552</b>	<b>.397</b>	<b>.005 - .010</b>	.559	.471	.015 - .030	.561	.320	.090 - .110
<b>.534</b>	<b>.220</b>	<b>.005 - .010</b>	.543	.377	.015 - .025	.550	.316	.015 - .030	<b>.552</b>	<b>.398</b>	<b>.005 - .010</b>	<b>.559</b>	<b>.480</b>	<b>.005 - .010</b>	.561	.331	.100 - .120
.534	.284	.060 - .083	<b>.544</b>	<b>.189</b>	<b>.005 - .010</b>	.550	.317	.015 - .030	.552	.400	.025 - .040	.560	.113	.015 - .030	.561	.360	.015 - .025
.534	.361	.062 - .080	.544	.226	.010 - .020	<b>.550</b>	<b>.319</b>	<b>.005 - .010</b>	.552	.401	.010 - .015	.560	.118	.016 - .030	<b>.561</b>	<b>.367</b>	<b>.005 - .010</b>
.534	.394	.030 - .050	<b>.544</b>	<b>.324</b>	<b>.005 - .010</b>	.550	.322	.030 - .050	.552	.425	.040 - .050	.560	.120	.075 - .104	.561	.377	.020 - .030
.534	.441	.030 - .042	<b>.544</b>	<b>.385</b>	<b>.005 - .010</b>	.550	.323	.008 - .020	.552	.434	.015 - .030	.560	.128	.015 - .030	.561	.381	.075 - .093
.535	.064	.012 - .020	<b>.544</b>	<b>.421</b>	<b>.005 - .010</b>	<b>.550</b>	<b>.332</b>	<b>.005 - .010</b>	<b>.552</b>	<b>.438</b>	<b>.005 - .010</b>	.560	.131	.060 - .083	.561	.397	.020 - .032
.535	.228	.075 - .104	.544	.449	.015 - .030	.550	.344	.060 - .083	<b>.552</b>	<b>.478</b>	<b>.005 - .010</b>	.560	.135	.050 - .070	<b>.561</b>	<b>.407</b>	<b>.005 - .010</b>
.535	.238	.010 - .020	<b>.544</b>	<b>.463</b>	<b>.005 - .010</b>	.550	.357	.040 - .062	.553	.212	.060 - .080	.560	.149	.005 - .020	<b>.561</b>	<b>.421</b>	<b>.005 - .010</b>
.535	.244	.015 - .030	.544	.502	.010 - .020	<b>.550</b>	<b>.375</b>	<b>.005 - .010</b>	<b>.553</b>	<b>.229</b>	<b>.005 - .010</b>	.560	.161	.040 - .062	.561	.435	.010 - .020
.535	.298	.010 - .020	.545	.100	.042 - .060	.550	.375	.010 - .020	<b>.553</b>	<b>.237</b>	<b>.005 - .010</b>	<b>.560</b>	<b>.172</b>	<b>.005 - .010</b>	.561	.440	.035 - .060
.535	.310	.025 - .042	.545	.187	.005 - .012	.550	.381	.040 - .060	.553	.242	.040 - .060	.560	.180	.005 - .015	.561	.459	.010 - .020
.535	.320	.016 - .025	.545	.244	.005 - .015	.550	.390	.070 - .090	<b>.553</b>	<b>.320</b>	<b>.005 - .010</b>	.560	.190	.030 - .050	<b>.562</b>	<b>.090</b>	<b>.005 - .010</b>
.535	.325	.010 - .020	.545	.244	.030 - .060	<b>.550</b>	<b>.398</b>	<b>.005 - .010</b>	.553	.396	.015 - .030	.560	.192	.008 - .016	<b>.562</b>	<b>.130</b>	<b>.005 - .010</b>
<b>.535</b>	<b>.335</b>	<b>.005 - .010</b>	.545	.260	.050 - .070	.550	.400	.050 - .070	.554	.154	.015 - .030	.560	.194	.032 - .048	.562	.134	.030 - .050
.535	.338	.025 - .040	<b>.545</b>	<b>.313</b>	<b>.005 - .010</b>	.550	.404	.020 - .040	<b>.554</b>	<b>.240</b>	<b>.005 - .010</b>	.560	.196	.015 - .025	.562	.146	.032 - .050
.535	.343	.008 - .015	.545	.319	.030 - .050	.550	.408	.040 - .060	.554	.258	.025 - .035	<b>.560</b>	<b>.200</b>	<b>.005 - .010</b>	.562	.148	.040 - .060
<b>.535</b>	<b>.357</b>	<b>.005 - .010</b>	.545	.346	.042 - .062	.550	.409	.060 - .075	.554	.318	.090 - .110	.560	.202	.032 - .050	.562	.152	.035 - .050
.535	.378	.012 - .025	.545	.378	.040 - .060	.550	.427	.025 - .042	<b>.554</b>	<b>.330</b>	<b>.005 - .010</b>	.560	.203	.012 - .020	.562	.158	.036 - .050
.535	.379	.010 - .020	.545	.382	.040 - .062	.550	.429	.035 - .050	<b>.554</b>	<b>.370</b>	<b>.005 - .010</b>	<b>.560</b>	<b>.206</b>	<b>.005 - .010</b>	.562	.158	.050 - .075
<b>.535</b>	<b>.445</b>	<b>.005 - .010</b>	<b>.545</b>	<b>.385</b>	<b>.005 - .010</b>	<b>.550</b>	<b>.479</b>	<b>.005 - .010</b>	.554	.370	.010 - .020	.560	.207	.030 - .050	.562	.165	.008 - .015
.536	.105	.030 - .050	.545	.409	.010 - .020	<b>.550</b>	<b>.498</b>	<b>.005 - .010</b>	.554	.379	.010 - .020	.560	.225	.006 - .010	.562	.166	.050 - .070
.536	.191	.075 - .090	.545	.410	.020 - .030	<b>.551</b>	<b>.081</b>	<b>.005 - .010</b>	.554	.405	.030 - .048	.560	.226	.015 - .025	<b>.562</b>	<b>.169</b>	<b>.005 - .010</b>
<b>.536</b>	<b>.242</b>	<b>.005 - .010</b>	<b>.545</b>	<b>.442</b>	<b>.005 - .010</b>	.551	.095	.012 - .020	.554	.468	.010 - .025	.560	.228	.060 - .083	.562	.191	.040 - .060
.536	.259	.100 - .125	<b>.545</b>	<b>.445</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.141</b>	<b>.005 - .010</b>	.555	.131	.060 - .080	.560	.246	.040 - .060	.562	.193	.040 - .060
.536	.324	.025 - .040	<b>.546</b>	<b>.217</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.161</b>	<b>.005 - .010</b>	.555	.154	.020 - .040	.560	.254	.100 - .120	.562	.194	.060 - .080
.536	.346	.010 - .015	<b>.546</b>	<b>.259</b>	<b>.005 - .010</b>	.551	.166	.030 - .050	.555	.173	.105 - .135	.560	.258	.060 - .080	.562	.195	.050 - .070
.537	.104	.016 - .025	.546	.271	.010 - .020	.551	.166	.090 - .105	.555	.253	.080 - .104	.560	.259	.048 - .060	.562	.202	.030 - .050
.537	.243	.105 - .125	.546	.375	.030 - .050	.551	.172	.080 - .100	.555	.265	.020 - .040	<b>.560</b>	<b>.262</b>	<b>.005 - .010</b>	.562	.204	.075 - .090
.537	.283	.105 - .125	.546	.378	.015 - .030	<b>.551</b>	<b>.201</b>	<b>.005 - .010</b>	<b>.555</b>	<b>.318</b>	<b>.005 - .010</b>	.560	.263	.010 - .035	.562	.205	.020 - .040
.537	.370	.040 - .060	.546	.410	.020 - .030	.551	.220	.015 - .025	.555	.320	.060 - .080	.560	.263	.032 - .050	<b>.562</b>	<b>.207</b>	<b>.005 - .010</b>
<b>.537</b>	<b>.375</b>	<b>.005 - .010</b>	<b>.547</b>	<b>.144</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.236</b>	<b>.005 - .010</b>	.555	.328	.050 - .078	.560	.273	.010 - .020	.562	.218	.048 - .072
.537	.409	.025 - .040	.547	.160	.010 - .015	<b>.551</b>	<b>.238</b>	<b>.005 - .010</b>	<b>.555</b>	<b>.438</b>	<b>.005 - .010</b>	.560	.280	.040 - .060	.562	.222	.010 - .020
.538	.210	.030 - .060	<b>.547</b>	<b>.214</b>	<b>.005 - .010</b>	.551	.238	.012 - .020	<b>.555</b>	<b>.440</b>	<b>.005 - .010</b>	<b>.560</b>	<b>.286</b>	<b>.005 - .010</b>	.562	.222	.050 - .070
.538	.257	.015 - .030	<b>.547</b>	<b>.256</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.240</b>	<b>.005 - .010</b>	.555	.475	.030 - .045	<b>.560</b>	<b>.295</b>	<b>.005 - .010</b>	.562	.233	.005 - .015
.538	.340	.030 - .050	<b>.547</b>	<b>.258</b>	<b>.005 - .010</b>	.551	.240	.030 - .050	.556	.120	.030 - .050	<b>.560</b>	<b>.311</b>	<b>.005 - .010</b>	.562	.240	.050 - .070
.538	.342	.040 - .060	<b>.547</b>	<b>.312</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.253</b>	<b>.005 - .010</b>	.556	.123	.030 - .060	.560	.313	.062 - .090	.562	.241	.015 - .030
.538	.385	.050 - .075	.547	.317	.050 - .070	<b>.551</b>	<b>.278</b>	<b>.005 - .010</b>	.556	.136	.030 - .050	.560	.313	.090 - .120	.562	.251	.110 - .130
<b>.538</b>	<b>.440</b>	<b>.005 - .010</b>	.547	.320	.030 - .050	.551	.284	.030 - .050	.556	.172	.040 - .060	.560	.317	.040 - .060	.562	.252	.005 - .015
<b>.538</b>	<b>.457</b>	<b>.005 - .010</b>	<b>.547</b>	<b>.406</b>	<b>.005 - .010</b>	.551	.294	.012 - .025	.556	.197	.030 - .050	.560	.320	.020 - .040	.562	.252	.015 - .030
.539	.195	.025 - .050	.548	.095	.040 - .060	<b>.551</b>	<b>.315</b>	<b>.005 - .010</b>	<b>.556</b>	<b>.200</b>	<b>.005 - .010</b>	.560	.331	.005 - .015	.562	.252	.030 - .042
.539	.252	.060 - .080	.548	.170	.050 - .070	<b>.551</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.556</b>	<b>.263</b>	<b>.005 - .010</b>	<b>.560</b>	<b>.336</b>	<b>.005 - .010</b>	.562	.252	.050 - .070
<b>.539</b>	<b>.318</b>	<b>.005 - .010</b>	<b>.548</b>	<b>.303</b>	<b>.005 - .010</b>	.551	.316	.010 - .030	.556	.281	.075 - .104	.560	.343	.040 - .060	.562	.252	.070 - .090
<b>.539</b>	<b>.366</b>	<b>.005 - .010</b>	.548	.303	.010 - .016	.551	.316	.030 - .050	.556	.317	.040 - .060	.560	.345	.090 - .110	.562	.252	.105 - .125
.539	.367	.025 - .040	.548	.325	.060 - .080	<b>.551</b>	<b>.317</b>	<b>.005 - .010</b>	.556	.383	.040 - .060	<b>.560</b>	<b>.370</b>	<b>.005 - .010</b>	<b>.562</b>	<b>.253</b>	<b>.005 - .010</b>
.539	.380	.025 - .042	.548	.329	.025 - .040	.551	.318	.050 - .070	.557	.242	.010 - .020	.560	.375	.050 - .070	.562	.257	.062 - .090
<b>.539</b>	<b>.399</b>	<b>.005 - .010</b>	<b>.548</b>	<b>.397</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.320</b>	<b>.005 - .010</b>	.557	.317	.020 - .040	.560	.377	.005 - .015	.562	.261	.030 - .050
.539	.399	.015 - .030	.548	.401	.050 - .070	<b>.551</b>	<b>.321</b>	<b>.005 - .010</b>	.557	.317	.040 - .060	.560	.379	.020 - .040	<b>.562</b>	<b>.263</b>	<b>.005 - .010</b>
<b>.539</b>	<b>.420</b>	<b>.005 - .010</b>	.548	.452	.030 - .050	<b>.551</b>	<b>.322</b>	<b>.005 - .010</b>	.557	.380	.040 - .060	<b>.560</b>	<b>.380</b>	<b>.005 - .010</b>	.562	.263	.015 - .030
.539	.469	.007 - .015	.548	.453	.025 - .040	.551	.357	.015 - .030	.557	.387	.025 - .040	.560	.381	.015 - .030	.562	.264	.015 - .030
.540	.162	.032 - .062	<b>.549</b>	<b>.099</b>	<b>.005 - .010</b>	.551	.377	.010 - .020	.557	.396	.050 - .070	.560	.381	.040 - .060	.562	.265	.050 - .075
.540	.229	.030 - .050	<b>.549</b>	<b>.216</b>	<b>.005 - .010</b>	.551	.378	.010 - .020	.557	.421	.010 - .020	<b>.560</b>	<b>.384</b>	<b>.005 - .010</b>	.562	.265	.070 - .090
.540	.280	.030 - .060	<b>.549</b>	<b>.316</b>	<b>.005 - .010</b>	.551	.378	.080 - .100	.557	.446	.020 - .040	.560	.390	.030 - .060	.562	.266	.100 - .125
.540	.282	.042 - .062	<b>.549</b>	<b>.326</b>	<b>.005 - .010</b>	<b>.551</b>	<b>.385</b>	<b>.005 - .010</b>	<b>.558</b>	<b>.288</b>	<b>.005 - .010</b>	.560	.392	.035 - .060	.562	.269	.030 - .050
.540	.284	.015 - .030	.549	.334	.025 - .040	.551	.387	.010 - .020	.558	.327	.050 - .070	<b>.560</b>	<b>.401</b>	<b>.005 - .010</b>	.562	.275	.050 - .075
.540	.321	.010 - .020	.549	.452	.030 - .060	<b>.551</b>	<b>.394</b>	<b>.005 - .010</b>	.558	.331	.020 - .035	<b>.560</b>	<b>.410</b>	<b>.005 - .010</b>	.562	.281	.032 - .050
.540	.333	.015 - .025	.549	.455	.010 - .020	.551	.394	.020 - .040	.558	.331	.035 - .050	<b>.560</b>	<b>.420</b>	<b>.005 - .010</b>	.562	.282	.080 - .100
.540	.347	.078 - .104	.550	.032	.010 - .020	.551	.395	.050 - .070	.558	.360	.005 - .012	.560	.421	.030 - .050	.562	.289	.050 - .070
.540	.348	.015 - .030	.550	.105	.042 - .060	.551	.399	.010 - .020	.558	.361	.036 - .060	.560	.459	.005 - .015	.562	.290	.025 - .040
.540	.388	.050 - .070	<b>.550</b>	<b>.120</b>	<b>.005 - .010</b>	.551	.418	.036 - .060	.558	.414	.030 - .050</						

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.562	.344	.060 - .080	<b>.565</b>	<b>.066</b>	<b>.005 - .010</b>	.571	.373	.020 - .035	.580	.255	.050 - .070	<b>.590</b>	<b>.237</b>	<b>.005 - .010</b>	.593	.464	.015 - .030
<b>.562</b>	<b>.374</b>	<b>.005 - .010</b>	.565	.093	.080 - .090	.572	.256	.005 - .008	.580	.258	.080 - .104	<b>.590</b>	<b>.238</b>	<b>.005 - .010</b>	.593	.468	.020 - .040
.562	.375	.050 - .070	.565	.120	.015 - .030	.572	.470	.030 - .040	<b>.580</b>	<b>.283</b>	<b>.005 - .010</b>	.590	.292	.010 - .020	<b>.593</b>	<b>.472</b>	<b>.005 - .010</b>
<b>.562</b>	<b>.376</b>	<b>.005 - .010</b>	.565	.174	.025 - .040	.573	.129	.050 - .070	.580	.324	.025 - .035	<b>.590</b>	<b>.295</b>	<b>.005 - .010</b>	.593	.478	.005 - .015
.562	.376	.048 - .062	.565	.186	.010 - .015	.573	.130	.050 - .070	.580	.330	.080 - .104	.590	.314	.060 - .080	<b>.593</b>	<b>.497</b>	<b>.005 - .010</b>
.562	.381	.040 - .060	.565	.236	.083 - .105	.573	.205	.050 - .070	.580	.346	.042 - .062	<b>.590</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.594</b>	<b>.283</b>	<b>.005 - .010</b>
.562	.383	.030 - .050	.565	.240	.050 - .080	.573	.266	.025 - .040	.580	.377	.090 - .105	.590	.317	.040 - .060	<b>.594</b>	<b>.315</b>	<b>.005 - .010</b>
.562	.385	.015 - .025	.565	.280	.105 - .125	.573	.394	.040 - .060	<b>.580</b>	<b>.379</b>	<b>.005 - .010</b>	.590	.317	.070 - .090	<b>.594</b>	<b>.325</b>	<b>.005 - .010</b>
.562	.385	.050 - .070	.565	.315	.005 - .015	.573	.395	.025 - .045	.580	.380	.010 - .020	.590	.318	.030 - .050	.594	.358	.015 - .025
.562	.386	.020 - .040	.565	.316	.060 - .080	.573	.474	.030 - .050	<b>.580</b>	<b>.398</b>	<b>.005 - .010</b>	.590	.327	.050 - .075	.594	.375	.070 - .090
.562	.387	.040 - .060	.565	.353	.050 - .072	.573	.525	.015 - .025	.580	.416	.042 - .062	.590	.329	.042 - .062	<b>.594</b>	<b>.378</b>	<b>.005 - .010</b>
.562	.388	.005 - .015	.565	.453	.025 - .035	.574	.199	.025 - .042	.580	.432	.010 - .020	.590	.331	.010 - .020	.594	.378	.083 - .104
.562	.391	.075 - .090	.566	.151	.040 - .060	.574	.296	.015 - .030	.580	.432	.020 - .032	<b>.590</b>	<b>.334</b>	<b>.005 - .010</b>	.594	.383	.015 - .030
<b>.562</b>	<b>.392</b>	<b>.005 - .010</b>	<b>.566</b>	<b>.201</b>	<b>.005 - .010</b>	.574	.297	.090 - .105	.580	.444	.025 - .040	.590	.339	.035 - .060	<b>.594</b>	<b>.405</b>	<b>.005 - .010</b>
.562	.396	.025 - .040	<b>.566</b>	<b>.266</b>	<b>.005 - .010</b>	<b>.574</b>	<b>.298</b>	<b>.005 - .010</b>	.580	.450	.025 - .040	.590	.340	.010 - .020	.594	.423	.025 - .040
.562	.420	.020 - .030	.566	.299	.050 - .075	.574	.300	.032 - .062	.581	.197	.090 - .125	.590	.340	.032 - .050	.594	.452	.040 - .060
.562	.420	.050 - .070	<b>.566</b>	<b>.321</b>	<b>.005 - .010</b>	<b>.574</b>	<b>.397</b>	<b>.005 - .010</b>	.581	.223	.050 - .070	.590	.344	.032 - .050	.594	.506	.015 - .025
.562	.437	.015 - .025	.566	.328	.010 - .015	.574	.406	.020 - .030	.581	.437	.030 - .050	.590	.345	.040 - .060	.595	.144	.008 - .016
.562	.437	.050 - .075	.566	.330	.040 - .060	.574	.482	.070 - .090	.582	.063	.020 - .040	<b>.590</b>	<b>.355</b>	<b>.005 - .010</b>	.595	.186	.070 - .090
.562	.439	.010 - .025	<b>.566</b>	<b>.334</b>	<b>.005 - .010</b>	.575	.151	.040 - .062	.582	.286	.020 - .040	.590	.376	.020 - .032	.595	.193	.075 - .090
<b>.562</b>	<b>.500</b>	<b>.005 - .010</b>	.566	.334	.040 - .060	.575	.180	.010 - .020	.582	.400	.015 - .030	<b>.590</b>	<b>.378</b>	<b>.005 - .010</b>	.595	.195	.010 - .020
.562	.505	.020 - .030	.566	.342	.093 - .104	.575	.186	.070 - .090	.583	.344	.070 - .090	.590	.379	.025 - .040	.595	.251	.010 - .020
.563	.101	.025 - .040	.566	.378	.060 - .090	.575	.189	.080 - .100	.583	.378	.015 - .030	<b>.590</b>	<b>.386</b>	<b>.005 - .010</b>	.595	.253	.020 - .030
<b>.563</b>	<b>.145</b>	<b>.005 - .010</b>	.566	.446	.040 - .060	.575	.199	.060 - .080	.583	.410	.030 - .050	.590	.390	.032 - .062	.595	.256	.015 - .030
.563	.176	.025 - .040	.566	.447	.040 - .060	.575	.200	.025 - .042	<b>.584</b>	<b>.301</b>	<b>.005 - .010</b>	.590	.396	.005 - .012	.595	.353	.025 - .040
.563	.186	.100 - .125	.566	.448	.010 - .020	.575	.251	.010 - .020	<b>.584</b>	<b>.327</b>	<b>.005 - .010</b>	<b>.590</b>	<b>.397</b>	<b>.005 - .010</b>	.595	.413	.050 - .070
.563	.191	.020 - .030	.566	.450	.015 - .030	<b>.575</b>	<b>.258</b>	<b>.005 - .010</b>	<b>.584</b>	<b>.350</b>	<b>.005 - .010</b>	.590	.397	.030 - .050	.595	.430	.040 - .060
.563	.194	.100 - .125	.566	.505	.015 - .025	.575	.260	.075 - .090	<b>.584</b>	<b>.358</b>	<b>.005 - .010</b>	.590	.410	.040 - .060	<b>.595</b>	<b>.436</b>	<b>.005 - .010</b>
.563	.197	.030 - .050	<b>.566</b>	<b>.507</b>	<b>.005 - .010</b>	<b>.575</b>	<b>.287</b>	<b>.005 - .010</b>	<b>.584</b>	<b>.431</b>	<b>.005 - .010</b>	.590	.426	.070 - .080	.595	.437	.040 - .060
<b>.563</b>	<b>.218</b>	<b>.005 - .010</b>	.567	.190	.010 - .020	.575	.312	.100 - .125	.584	.446	.030 - .050	<b>.590</b>	<b>.439</b>	<b>.005 - .010</b>	.595	.495	.030 - .050
.563	.218	.100 - .125	.567	.227	.007 - .012	.575	.320	.020 - .040	.585	.104	.025 - .040	.590	.471	.015 - .025	.596	.099	.030 - .050
.563	.253	.005 - .015	.567	.234	.010 - .020	.575	.322	.010 - .020	.585	.183	.015 - .030	<b>.590</b>	<b>.480</b>	<b>.005 - .010</b>	.596	.129	.025 - .040
.563	.259	.030 - .050	.567	.260	.040 - .060	.575	.335	.016 - .025	.585	.264	.025 - .040	.590	.480	.010 - .020	.596	.401	.020 - .040
.563	.277	.020 - .040	.567	.263	.030 - .050	<b>.575</b>	<b>.346</b>	<b>.005 - .010</b>	.585	.327	.050 - .070	.590	.498	.025 - .040	.596	.409	.010 - .020
.563	.285	.100 - .125	.567	.301	.040 - .060	.575	.346	.010 - .030	.585	.328	.070 - .090	.590	.523	.005 - .008	.596	.443	.050 - .075
<b>.563</b>	<b>.313</b>	<b>.005 - .010</b>	.567	.336	.090 - .104	.575	.360	.025 - .042	.585	.364	.060 - .080	.591	.079	.020 - .030	<b>.596</b>	<b>.485</b>	<b>.005 - .010</b>
.563	.313	.025 - .042	.567	.379	.015 - .025	.575	.394	.060 - .080	.585	.372	.025 - .040	.591	.115	.020 - .040	.596	.485	.025 - .040
.563	.317	.010 - .020	.567	.408	.040 - .060	.575	.399	.060 - .090	<b>.585</b>	<b>.377</b>	<b>.005 - .010</b>	.591	.200	.040 - .060	.596	.503	.020 - .040
.563	.317	.020 - .040	.567	.409	.030 - .050	.575	.412	.010 - .020	<b>.585</b>	<b>.380</b>	<b>.005 - .010</b>	.591	.217	.015 - .025	.596	.510	.025 - .040
<b>.563</b>	<b>.318</b>	<b>.005 - .010</b>	.567	.504	.020 - .030	.575	.440	.040 - .060	<b>.585</b>	<b>.397</b>	<b>.005 - .010</b>	.591	.240	.075 - .090	.597	.130	.005 - .015
.563	.320	.015 - .030	.568	.109	.040 - .060	.575	.446	.010 - .030	.585	.405	.050 - .070	<b>.591</b>	<b>.277</b>	<b>.005 - .010</b>	.597	.251	.062 - .078
.563	.321	.072 - .090	<b>.568</b>	<b>.138</b>	<b>.005 - .010</b>	.575	.464	.020 - .040	.586	.132	.010 - .020	.591	.296	.050 - .070	.597	.305	.025 - .040
.563	.350	.015 - .025	.568	.210	.042 - .072	<b>.575</b>	<b>.485</b>	<b>.005 - .010</b>	.586	.327	.015 - .030	.591	.317	.010 - .020	.597	.388	.005 - .015
.563	.359	.025 - .040	<b>.568</b>	<b>.224</b>	<b>.005 - .010</b>	.575	.485	.030 - .040	<b>.586</b>	<b>.415</b>	<b>.005 - .010</b>	.591	.321	.015 - .030	.597	.406	.025 - .040
.563	.373	.015 - .030	.568	.255	.050 - .070	.576	.147	.090 - .104	.586	.433	.040 - .060	.591	.324	.040 - .060	.597	.452	.016 - .025
.563	.377	.010 - .020	<b>.568</b>	<b>.305</b>	<b>.005 - .010</b>	.576	.218	.030 - .040	<b>.586</b>	<b>.447</b>	<b>.005 - .010</b>	<b>.591</b>	<b>.326</b>	<b>.005 - .010</b>	.597	.452	.025 - .040
.563	.379	.015 - .030	.568	.312	.050 - .062	.577	.096	.012 - .025	<b>.586</b>	<b>.477</b>	<b>.005 - .010</b>	.591	.435	.050 - .070	.597	.512	.020 - .030
.563	.379	.040 - .060	<b>.568</b>	<b>.317</b>	<b>.005 - .010</b>	.577	.199	.060 - .090	<b>.586</b>	<b>.484</b>	<b>.005 - .010</b>	.591	.511	.010 - .020	.597	.513	.020 - .030
.563	.380	.015 - .030	<b>.568</b>	<b>.360</b>	<b>.005 - .010</b>	.577	.253	.050 - .070	.586	.500	.030 - .040	<b>.592</b>	<b>.147</b>	<b>.005 - .010</b>	<b>.598</b>	<b>.180</b>	<b>.005 - .010</b>
.563	.380	.070 - .090	.568	.378	.010 - .030	.577	.325	.042 - .062	<b>.586</b>	<b>.525</b>	<b>.005 - .010</b>	<b>.592</b>	<b>.221</b>	<b>.005 - .010</b>	.598	.215	.032 - .062
.563	.381	.010 - .020	.568	.413	.015 - .025	.577	.328	.090 - .120	.587	.195	.032 - .050	<b>.592</b>	<b>.236</b>	<b>.005 - .010</b>	.598	.264	.010 - .020
.563	.385	.020 - .030	.568	.414	.020 - .040	.577	.353	.025 - .040	.587	.231	.015 - .025	.592	.258	.030 - .050	.598	.271	.025 - .040
.563	.387	.020 - .030	.569	.205	.050 - .070	.577	.376	.010 - .025	.587	.345	.030 - .050	.592	.315	.010 - .015	.598	.304	.025 - .040
.563	.387	.030 - .050	.569	.207	.025 - .040	.578	.173	.025 - .042	<b>.587</b>	<b>.373</b>	<b>.005 - .010</b>	<b>.592</b>	<b>.317</b>	<b>.005 - .010</b>	<b>.598</b>	<b>.313</b>	<b>.005 - .010</b>
.563	.398	.030 - .050	.569	.243	.010 - .015	.578	.203	.005 - .012	.587	.400	.050 - .070	<b>.592</b>	<b>.322</b>	<b>.005 - .010</b>	.598	.313	.010 - .020
.563	.405	.030 - .060	<b>.569</b>	<b>.257</b>	<b>.005 - .010</b>	.578	.203	.030 - .060	.587	.411	.040 - .060	.592	.330	.040 - .062	.598	.321	.010 - .020
.563	.405	.060 - .080	.569	.324	.015 - .030	.578	.257	.050 - .075	.587								

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.600	.118	.015 - .030	<b>.604</b>	<b>.255</b>	<b>.005 - .010</b>	.610	.472	.050 - .075	.616	.192	.070 - .090	<b>.620</b>	<b>.200</b>	<b>.005 - .010</b>	.622	.159	.048 - .075
.600	.119	.080 - .100	<b>.604</b>	<b>.307</b>	<b>.005 - .010</b>	.610	.476	.040 - .060	<b>.616</b>	<b>.251</b>	<b>.005 - .010</b>	.620	.214	.050 - .070	<b>.622</b>	<b>.166</b>	<b>.005 - .010</b>
.600	.128	.032 - .048	.604	.308	.010 - .020	.611	.089	.040 - .060	.616	.256	.020 - .032	.620	.250	.010 - .020	.622	.174	.008 - .016
.600	.138	.040 - .060	.604	.308	.020 - .030	.611	.192	.020 - .030	<b>.616</b>	<b>.259</b>	<b>.005 - .010</b>	.620	.250	.020 - .035	.622	.175	.007 - .015
.600	.138	.080 - .105	.604	.340	.040 - .060	.611	.243	.062 - .090	.616	.268	.015 - .030	.620	.252	.020 - .040	.622	.180	.016 - .025
.600	.156	.025 - .040	.604	.347	.031 - .042	<b>.611</b>	<b>.261</b>	<b>.005 - .010</b>	.616	.323	.010 - .020	.620	.254	.010 - .020	.622	.190	.020 - .040
.600	.157	.025 - .040	.604	.381	.025 - .040	.611	.265	.105 - .125	.616	.328	.025 - .040	.620	.255	.015 - .020	<b>.622</b>	<b>.191</b>	<b>.005 - .010</b>
.600	.168	.070 - .090	.604	.384	.015 - .030	<b>.611</b>	<b>.273</b>	<b>.005 - .010</b>	.616	.377	.050 - .075	.620	.257	.040 - .060	.622	.196	.030 - .048
<b>.600</b>	<b>.176</b>	<b>.005 - .010</b>	<b>.604</b>	<b>.407</b>	<b>.005 - .010</b>	<b>.611</b>	<b>.278</b>	<b>.005 - .010</b>	.616	.377	.075 - .090	<b>.620</b>	<b>.260</b>	<b>.005 - .010</b>	.622	.205	.030 - .050
<b>.600</b>	<b>.200</b>	<b>.005 - .010</b>	.604	.407	.010 - .030	.611	.315	.050 - .010	<b>.616</b>	<b>.384</b>	<b>.005 - .010</b>	<b>.620</b>	<b>.268</b>	<b>.005 - .010</b>	.622	.206	.030 - .060
.600	.203	.020 - .040	.604	.439	.030 - .050	<b>.611</b>	<b>.347</b>	<b>.005 - .010</b>	.616	.386	.062 - .083	.620	.281	.040 - .060	.622	.214	.015 - .030
.600	.210	.075 - .090	.604	.508	.015 - .030	.611	.350	.030 - .050	.616	.412	.020 - .040	.620	.322	.040 - .060	.622	.220	.010 - .020
.600	.217	.050 - .075	.605	.163	.015 - .030	<b>.611</b>	<b>.352</b>	<b>.005 - .010</b>	.616	.480	.040 - .060	.620	.334	.050 - .070	.622	.230	.060 - .090
<b>.600</b>	<b>.236</b>	<b>.005 - .010</b>	.605	.313	.015 - .030	.611	.379	.025 - .040	<b>.616</b>	<b>.505</b>	<b>.005 - .010</b>	.620	.346	.016 - .025	.622	.250	.005 - .015
.600	.237	.040 - .060	.605	.317	.075 - .090	.611	.405	.060 - .083	<b>.617</b>	<b>.310</b>	<b>.005 - .010</b>	.620	.348	.050 - .070	<b>.622</b>	<b>.251</b>	<b>.005 - .010</b>
<b>.600</b>	<b>.241</b>	<b>.005 - .010</b>	.605	.359	.025 - .040	.611	.460	.025 - .040	.617	.318	.015 - .025	.620	.350	.025 - .042	.622	.258	.025 - .040
.600	.241	.010 - .020	.605	.388	.070 - .090	.611	.480	.050 - .070	<b>.617</b>	<b>.351</b>	<b>.005 - .010</b>	.620	.350	.042 - .062	.622	.261	.036 - .050
.600	.241	.020 - .030	<b>.605</b>	<b>.453</b>	<b>.005 - .010</b>	.612	.194	.100 - .125	.617	.359	.025 - .040	.620	.370	.015 - .025	.622	.284	.010 - .025
<b>.600</b>	<b>.252</b>	<b>.005 - .010</b>	.605	.453	.040 - .060	.612	.198	.008 - .020	<b>.617</b>	<b>.362</b>	<b>.005 - .010</b>	.620	.378	.020 - .035	.622	.284	.032 - .042
<b>.600</b>	<b>.253</b>	<b>.005 - .010</b>	<b>.605</b>	<b>.566</b>	<b>.005 - .010</b>	.612	.214	.030 - .050	<b>.617</b>	<b>.385</b>	<b>.005 - .010</b>	.620	.380	.080 - .100	.622	.302	.050 - .070
.600	.253	.015 - .030	<b>.606</b>	<b>.203</b>	<b>.005 - .010</b>	.612	.433	.040 - .060	.617	.448	.065 - .080	.620	.381	.015 - .025	.622	.314	.075 - .100
.600	.253	.040 - .060	.606	.285	.060 - .083	.612	.440	.042 - .062	.617	.496	.010 - .020	.620	.384	.100 - .125	.622	.314	.100 - .125
.600	.254	.015 - .030	.606	.312	.075 - .100	.612	.444	.010 - .030	<b>.617</b>	<b>.514</b>	<b>.005 - .010</b>	.620	.390	.100 - .125	.622	.315	.100 - .125
<b>.600</b>	<b>.255</b>	<b>.005 - .010</b>	.606	.380	.040 - .060	<b>.612</b>	<b>.467</b>	<b>.005 - .010</b>	<b>.617</b>	<b>.560</b>	<b>.005 - .010</b>	.620	.394	.010 - .020	.622	.317	.040 - .060
.600	.265	.010 - .020	.606	.389	.050 - .075	.612	.510	.040 - .050	.618	.120	.015 - .030	.620	.406	.005 - .012	.622	.320	.025 - .040
<b>.600</b>	<b>.266</b>	<b>.005 - .010</b>	.606	.400	.020 - .030	<b>.612</b>	<b>.520</b>	<b>.005 - .010</b>	.618	.124	.040 - .060	.620	.406	.020 - .030	.622	.320	.050 - .070
<b>.600</b>	<b>.267</b>	<b>.005 - .010</b>	.606	.462	.020 - .040	.613	.040	.020 - .030	.618	.185	.040 - .050	.620	.406	.030 - .060	.622	.325	.007 - .015
.600	.269	.025 - .040	.606	.480	.040 - .060	.613	.278	.050 - .070	<b>.618</b>	<b>.215</b>	<b>.005 - .010</b>	.620	.408	.030 - .050	.622	.325	.015 - .025
<b>.600</b>	<b>.270</b>	<b>.005 - .010</b>	.607	.247	.020 - .040	.613	.331	.050 - .070	.618	.216	.010 - .020	.620	.409	.030 - .050	<b>.622</b>	<b>.343</b>	<b>.005 - .010</b>
<b>.600</b>	<b>.282</b>	<b>.005 - .010</b>	.607	.251	.030 - .050	.613	.350	.050 - .070	.618	.259	.040 - .060	.620	.410	.080 - .105	<b>.622</b>	<b>.374</b>	<b>.005 - .010</b>
<b>.600</b>	<b>.285</b>	<b>.005 - .010</b>	<b>.607</b>	<b>.333</b>	<b>.005 - .010</b>	.613	.377	.015 - .030	<b>.618</b>	<b>.262</b>	<b>.005 - .010</b>	.620	.420	.020 - .040	.622	.376	.015 - .025
.600	.296	.015 - .025	.607	.388	.080 - .105	.613	.391	.025 - .040	<b>.618</b>	<b>.364</b>	<b>.005 - .010</b>	.620	.420	.040 - .060	.622	.377	.025 - .040
.600	.296	.030 - .050	<b>.607</b>	<b>.461</b>	<b>.005 - .010</b>	<b>.613</b>	<b>.402</b>	<b>.005 - .010</b>	.618	.364	.062 - .078	.620	.440	.025 - .042	.622	.377	.090 - .105
.600	.296	.080 - .105	.608	.204	.010 - .020	.613	.451	.030 - .050	.618	.381	.040 - .060	.620	.442	.032 - .048	.622	.378	.015 - .030
<b>.600</b>	<b>.300</b>	<b>.005 - .010</b>	.608	.249	.030 - .050	<b>.613</b>	<b>.472</b>	<b>.005 - .010</b>	.618	.382	.020 - .040	<b>.620</b>	<b>.476</b>	<b>.005 - .010</b>	<b>.622</b>	<b>.384</b>	<b>.005 - .010</b>
.600	.322	.030 - .040	.608	.252	.015 - .030	.613	.521	.020 - .042	<b>.618</b>	<b>.393</b>	<b>.005 - .010</b>	.620	.484	.020 - .030	.622	.389	.060 - .075
.600	.322	.060 - .080	.608	.252	.030 - .040	.614	.094	.040 - .060	.618	.400	.080 - .104	.620	.490	.020 - .040	<b>.622</b>	<b>.390</b>	<b>.005 - .010</b>
.600	.361	.015 - .030	.608	.253	.020 - .040	.614	.198	.050 - .072	.618	.435	.050 - .075	<b>.620</b>	<b>.500</b>	<b>.005 - .010</b>	.622	.391	.050 - .075
.600	.380	.015 - .030	.608	.254	.020 - .040	.614	.198	.075 - .090	<b>.618</b>	<b>.440</b>	<b>.005 - .010</b>	.620	.503	.010 - .025	.622	.391	.075 - .105
.600	.380	.030 - .040	.608	.283	.020 - .030	.614	.199	.060 - .078	<b>.618</b>	<b>.475</b>	<b>.005 - .010</b>	.620	.509	.010 - .025	.622	.400	.010 - .020
.600	.401	.010 - .020	.608	.283	.030 - .040	.614	.200	.060 - .083	<b>.618</b>	<b>.500</b>	<b>.005 - .010</b>	.620	.515	.005 - .015	.622	.407	.006 - .016
.600	.406	.020 - .030	.608	.293	.040 - .060	<b>.614</b>	<b>.268</b>	<b>.005 - .010</b>	<b>.618</b>	<b>.507</b>	<b>.005 - .010</b>	.620	.522	.015 - .030	.622	.409	.005 - .015
.600	.408	.040 - .060	.608	.350	.020 - .032	.614	.330	.015 - .030	.618	.526	.032 - .042	<b>.620</b>	<b>.530</b>	<b>.005 - .010</b>	.622	.411	.025 - .040
.600	.413	.010 - .020	.608	.392	.030 - .050	.614	.354	.050 - .070	<b>.618</b>	<b>.531</b>	<b>.005 - .010</b>	<b>.620</b>	<b>.532</b>	<b>.005 - .010</b>	<b>.622</b>	<b>.438</b>	<b>.005 - .010</b>
<b>.600</b>	<b>.421</b>	<b>.005 - .010</b>	<b>.608</b>	<b>.397</b>	<b>.005 - .010</b>	.614	.373	.050 - .070	<b>.618</b>	<b>.549</b>	<b>.005 - .010</b>	<b>.620</b>	<b>.550</b>	<b>.005 - .010</b>	.622	.445	.015 - .030
<b>.600</b>	<b>.434</b>	<b>.005 - .010</b>	.608	.397	.010 - .020	.614	.388	.015 - .030	.618	.551	.015 - .025	.621	.062	.030 - .050	.622	.450	.050 - .070
.600	.450	.040 - .060	.608	.509	.010 - .025	.614	.402	.010 - .020	<b>.618</b>	<b>.556</b>	<b>.005 - .010</b>	<b>.621</b>	<b>.075</b>	<b>.005 - .010</b>	<b>.622</b>	<b>.453</b>	<b>.005 - .010</b>
.600	.460	.030 - .050	.609	.128	.030 - .050	.614	.434	.030 - .050	.618	.560	.015 - .025	<b>.621</b>	<b>.091</b>	<b>.005 - .010</b>	<b>.622</b>	<b>.461</b>	<b>.005 - .010</b>
<b>.600</b>	<b>.498</b>	<b>.005 - .010</b>	<b>.609</b>	<b>.274</b>	<b>.005 - .010</b>	<b>.614</b>	<b>.479</b>	<b>.005 - .010</b>	.619	.125	.050 - .070	.621	.125	.050 - .070	.622	.488	.050 - .070
<b>.600</b>	<b>.503</b>	<b>.005 - .010</b>	.609	.297	.020 - .032	.614	.482	.008 - .020	.619	.158	.100 - .125	.621	.159	.030 - .042	.622	.500	.010 - .020
.600	.505	.020 - .030	.609	.400	.040 - .060	<b>.614</b>	<b>.534</b>	<b>.005 - .010</b>	.619	.171	.015 - .030	.621	.161	.090 - .120	.622	.503	.010 - .020
<b>.600</b>	<b>.517</b>	<b>.005 - .010</b>	.609	.487	.030 - .050	<b>.614</b>	<b>.540</b>	<b>.005 - .010</b>	.619	.171	.050 - .075	<b>.621</b>	<b>.172</b>	<b>.005 - .010</b>	.622	.503	.020 - .030
<b>.600</b>	<b>.550</b>	<b>.005 - .010</b>	.609	.487	.040 - .060	.615	.041	.015 - .030	.619	.238	.030 - .050	.621	.182	.105 - .125	.622	.532	.008 - .015
.601	.159	.080 - .100	.609	.506	.020 - .030	.615	.099	.020 - .030	.619	.306	.025 - .040	<b>.621</b>	<b>.194</b>	<b>.005 - .010</b>	.622	.533	.005 - .015
<b>.601</b>	<b>.165</b>	<b>.005 - .010</b>	.609	.546	.015 - .025	.615	.110	.020 - .030	.619	.324	.020 - .030	.621	.253	.062 - .080	<b>.622</b>	<b>.534</b>	<b>.005 - .010</b>
<b>.601</b>	<b>.227</b>	<b>.005 - .010</b>	.609	.551	.015 - .025	.615	.126	.020 - .030	.619	.326	.02						

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
<b>.623</b>	<b>.265</b>	<b>.005 - .010</b>	<b>.625</b>	<b>.087</b>	<b>.005 - .010</b>	.625	.298	.015 - .030	.625	.476	.040 - .060	.627	.283	.030 - .048	<b>.630</b>	<b>.316</b>	<b>.005 - .010</b>
.623	.265	.010 - .020	<b>.625</b>	<b>.096</b>	<b>.005 - .010</b>	.625	.299	.020 - .030	.625	.479	.010 - .020	.627	.285	.042 - .062	.630	.316	.010 - .020
.623	.265	.060 - .075	.625	.102	.020 - .040	.625	.299	.030 - .050	.625	.479	.030 - .050	.627	.313	.090 - .120	.630	.316	.070 - .090
.623	.268	.010 - .015	<b>.625</b>	<b>.115</b>	<b>.005 - .010</b>	.625	.302	.050 - .070	.625	.485	.005 - .008	.627	.314	.015 - .030	.630	.317	.010 - .020
.623	.281	.012 - .025	.625	.127	.010 - .020	.625	.311	.042 - .062	.625	.500	.032 - .050	.627	.323	.105 - .125	<b>.630</b>	<b>.319</b>	<b>.005 - .010</b>
.623	.281	.015 - .030	.625	.128	.030 - .050	<b>.625</b>	<b>.312</b>	<b>.005 - .010</b>	.625	.500	.050 - .060	.627	.334	.100 - .125	.630	.319	.030 - .050
.623	.281	.050 - .075	.625	.128	.040 - .062	.625	.312	.030 - .042	.625	.501	.020 - .030	.627	.335	.100 - .125	<b>.630</b>	<b>.320</b>	<b>.005 - .010</b>
.623	.304	.075 - .105	.625	.129	.020 - .030	.625	.312	.050 - .075	.625	.506	.030 - .050	.627	.344	.050 - .070	<b>.630</b>	<b>.321</b>	<b>.005 - .010</b>
.623	.317	.050 - .075	.625	.129	.025 - .040	.625	.312	.105 - .125	.625	.570	.015 - .030	.627	.344	.100 - .125	.630	.326	.060 - .080
<b>.623</b>	<b>.320</b>	<b>.005 - .010</b>	.625	.130	.012 - .020	<b>.625</b>	<b>.314</b>	<b>.005 - .010</b>	.626	.096	.015 - .025	.627	.349	.080 - .104	.630	.330	.010 - .020
.623	.320	.015 - .030	.625	.136	.080 - .104	.625	.314	.015 - .030	.626	.100	.015 - .030	<b>.627</b>	<b>.375</b>	<b>.005 - .010</b>	.630	.331	.050 - .070
.623	.326	.040 - .060	.625	.139	.025 - .042	.625	.315	.025 - .040	<b>.626</b>	<b>.104</b>	<b>.005 - .010</b>	.627	.376	.080 - .104	<b>.630</b>	<b>.336</b>	<b>.005 - .010</b>
.623	.328	.010 - .025	.625	.139	.075 - .105	.625	.316	.040 - .060	.626	.113	.030 - .050	.627	.378	.030 - .050	.630	.346	.040 - .060
.623	.330	.050 - .075	.625	.145	.020 - .032	.625	.318	.090 - .125	<b>.626</b>	<b>.129</b>	<b>.005 - .010</b>	.627	.379	.030 - .050	.630	.368	.050 - .075
.623	.330	.075 - .090	<b>.625</b>	<b>.151</b>	<b>.005 - .010</b>	.625	.318	.120 - .134	.626	.129	.110 - .130	.627	.380	.050 - .070	<b>.630</b>	<b>.384</b>	<b>.005 - .010</b>
.623	.375	.010 - .020	.625	.157	.100 - .125	.625	.319	.020 - .040	.626	.133	.030 - .060	.627	.385	.083 - .120	.630	.384	.020 - .040
.623	.390	.050 - .070	<b>.625</b>	<b>.158</b>	<b>.005 - .010</b>	.625	.320	.010 - .020	.626	.156	.020 - .035	<b>.627</b>	<b>.389</b>	<b>.005 - .010</b>	.630	.387	.010 - .020
<b>.623</b>	<b>.404</b>	<b>.005 - .010</b>	.625	.160	.075 - .104	.625	.320	.020 - .032	.626	.193	.020 - .030	<b>.627</b>	<b>.392</b>	<b>.005 - .010</b>	<b>.630</b>	<b>.395</b>	<b>.005 - .010</b>
.623	.460	.050 - .075	.625	.166	.025 - .042	.625	.320	.032 - .050	.626	.193	.050 - .075	.627	.406	.050 - .070	.630	.395	.010 - .020
.623	.465	.012 - .020	.625	.171	.015 - .025	.625	.321	.015 - .030	.626	.198	.025 - .040	<b>.627</b>	<b>.442</b>	<b>.005 - .010</b>	<b>.630</b>	<b>.397</b>	<b>.005 - .010</b>
.623	.474	.008 - .016	.625	.171	.035 - .050	.625	.321	.050 - .070	.626	.204	.030 - .050	.627	.475	.020 - .030	.630	.397	.070 - .090
<b>.623</b>	<b>.492</b>	<b>.005 - .010</b>	.625	.171	.050 - .075	.625	.322	.045 - .075	.626	.204	.120 - .156	.627	.486	.012 - .025	.630	.400	.025 - .040
.623	.500	.005 - .012	.625	.171	.080 - .105	.625	.323	.060 - .075	.626	.207	.050 - .070	.627	.505	.050 - .070	.630	.400	.060 - .090
.623	.501	.010 - .020	.625	.171	.105 - .125	<b>.625</b>	<b>.324</b>	<b>.005 - .010</b>	.626	.217	.100 - .125	<b>.627</b>	<b>.510</b>	<b>.005 - .010</b>	.630	.401	.015 - .030
.623	.504	.050 - .062	.625	.187	.025 - .050	.625	.327	.070 - .080	<b>.626</b>	<b>.229</b>	<b>.005 - .010</b>	.627	.510	.020 - .040	<b>.630</b>	<b>.403</b>	<b>.005 - .010</b>
<b>.623</b>	<b>.505</b>	<b>.005 - .010</b>	<b>.625</b>	<b>.189</b>	<b>.005 - .010</b>	<b>.625</b>	<b>.328</b>	<b>.005 - .010</b>	.626	.253	.060 - .080	<b>.627</b>	<b>.527</b>	<b>.005 - .010</b>	<b>.630</b>	<b>.404</b>	<b>.005 - .010</b>
<b>.623</b>	<b>.515</b>	<b>.005 - .010</b>	.625	.189	.030 - .060	.625	.328	.075 - .100	.626	.262	.100 - .125	.627	.547	.007 - .012	.630	.415	.080 - .105
.623	.531	.010 - .020	.625	.190	.060 - .090	.625	.328	.100 - .125	.626	.268	.020 - .040	.628	.096	.030 - .050	.630	.417	.050 - .070
<b>.623</b>	<b>.532</b>	<b>.005 - .010</b>	.625	.191	.025 - .042	.625	.330	.025 - .040	.626	.268	.040 - .060	<b>.628</b>	<b>.125</b>	<b>.005 - .010</b>	.630	.440	.070 - .090
.624	.087	.010 - .020	.625	.192	.050 - .070	<b>.625</b>	<b>.331</b>	<b>.005 - .010</b>	<b>.626</b>	<b>.281</b>	<b>.005 - .010</b>	.628	.166	.050 - .070	.630	.475	.010 - .020
.624	.094	.070 - .090	.625	.193	.100 - .125	.625	.336	.090 - .120	.626	.281	.010 - .020	.628	.191	.040 - .060	<b>.630</b>	<b>.499</b>	<b>.005 - .010</b>
<b>.624</b>	<b>.108</b>	<b>.005 - .010</b>	.625	.195	.090 - .125	<b>.625</b>	<b>.343</b>	<b>.005 - .010</b>	.626	.282	.020 - .040	<b>.628</b>	<b>.198</b>	<b>.005 - .010</b>	.630	.518	.010 - .020
<b>.624</b>	<b>.109</b>	<b>.005 - .010</b>	.625	.196	.020 - .040	.625	.343	.115 - .134	.626	.312	.035 - .050	.628	.208	.020 - .040	<b>.630</b>	<b>.554</b>	<b>.005 - .010</b>
.624	.128	.025 - .040	.625	.200	.030 - .040	.625	.348	.080 - .104	.626	.314	.005 - .015	.628	.232	.030 - .050	.631	.150	.040 - .060
.624	.156	.050 - .070	<b>.625</b>	<b>.201</b>	<b>.005 - .010</b>	.625	.349	.083 - .104	.626	.315	.040 - .060	.628	.238	.050 - .070	.631	.154	.050 - .070
.624	.168	.060 - .080	.625	.202	.050 - .075	.625	.356	.042 - .062	.626	.317	.010 - .015	<b>.628</b>	<b>.271</b>	<b>.005 - .010</b>	<b>.631</b>	<b>.238</b>	<b>.005 - .010</b>
.624	.173	.020 - .032	.625	.205	.050 - .075	.625	.372	.030 - .050	.626	.326	.020 - .030	.628	.287	.090 - .105	.631	.240	.010 - .020
.624	.173	.032 - .050	.625	.205	.075 - .090	.625	.375	.005 - .012	.626	.339	.100 - .125	.628	.331	.105 - .120	.631	.315	.015 - .030
.624	.177	.010 - .020	.625	.207	.005 - .015	.625	.375	.090 - .105	.626	.344	.025 - .040	.628	.375	.060 - .083	<b>.631</b>	<b>.316</b>	<b>.005 - .010</b>
.624	.178	.015 - .030	.625	.210	.100 - .125	.625	.375	.105 - .120	<b>.626</b>	<b>.377</b>	<b>.005 - .010</b>	<b>.628</b>	<b>.477</b>	<b>.005 - .010</b>	<b>.631</b>	<b>.318</b>	<b>.005 - .010</b>
.624	.196	.032 - .042	.625	.211	.040 - .060	<b>.625</b>	<b>.377</b>	<b>.005 - .010</b>	<b>.626</b>	<b>.379</b>	<b>.005 - .010</b>	.628	.483	.030 - .050	<b>.631</b>	<b>.319</b>	<b>.005 - .010</b>
<b>.624</b>	<b>.204</b>	<b>.005 - .010</b>	<b>.625</b>	<b>.220</b>	<b>.005 - .010</b>	.625	.378	.015 - .030	<b>.626</b>	<b>.381</b>	<b>.005 - .010</b>	.628	.510	.010 - .020	<b>.631</b>	<b>.320</b>	<b>.005 - .010</b>
<b>.624</b>	<b>.220</b>	<b>.005 - .010</b>	.625	.222	.050 - .070	.625	.378	.060 - .080	<b>.626</b>	<b>.386</b>	<b>.005 - .010</b>	.628	.511	.040 - .060	.631	.374	.105 - .125
.624	.249	.050 - .070	<b>.625</b>	<b>.223</b>	<b>.005 - .010</b>	<b>.625</b>	<b>.379</b>	<b>.005 - .010</b>	.626	.386	.050 - .075	.628	.555	.020 - .030	.631	.378	.060 - .080
.624	.250	.050 - .075	.625	.226	.032 - .042	.625	.380	.025 - .042	<b>.626</b>	<b>.392</b>	<b>.005 - .010</b>	.629	.095	.062 - .078	.631	.386	.060 - .080
.624	.253	.100 - .125	.625	.230	.075 - .090	.625	.381	.100 - .125	.626	.394	.015 - .030	.629	.149	.015 - .030	.631	.387	.010 - .020
<b>.624</b>	<b>.254</b>	<b>.005 - .010</b>	.625	.236	.025 - .042	.625	.382	.030 - .050	.626	.408	.090 - .105	<b>.629</b>	<b>.177</b>	<b>.005 - .010</b>	<b>.631</b>	<b>.396</b>	<b>.005 - .010</b>
.624	.255	.040 - .075	<b>.625</b>	<b>.238</b>	<b>.005 - .010</b>	.625	.382	.050 - .075	.626	.409	.020 - .030	<b>.629</b>	<b>.226</b>	<b>.005 - .010</b>	.631	.399	.010 - .020
.624	.264	.050 - .070	.625	.238	.032 - .050	.625	.382	.060 - .090	.626	.422	.070 - .090	.629	.290	.050 - .083	.631	.403	.060 - .080
.624	.298	.050 - .075	.625	.238	.060 - .072	.625	.382	.090 - .120	.626	.442	.005 - .015	.629	.292	.042 - .060	.631	.411	.020 - .030
<b>.624</b>	<b>.312</b>	<b>.005 - .010</b>	.625	.240	.050 - .070	<b>.625</b>	<b>.385</b>	<b>.005 - .010</b>	.626	.442	.015 - .025	<b>.629</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.631</b>	<b>.437</b>	<b>.005 - .010</b>
.624	.313	.025 - .045	<b>.625</b>	<b>.251</b>	<b>.005 - .010</b>	.625	.386	.032 - .048	<b>.626</b>	<b>.468</b>	<b>.005 - .010</b>	<b>.629</b>	<b>.319</b>	<b>.005 - .010</b>	.631	.452	.060 - .080
.624	.315	.100 - .125	.625	.251	.032 - .042	.625	.390	.015 - .030	<b>.626</b>	<b>.470</b>	<b>.005 - .010</b>	.629	.356	.010 - .020	.632	.160	.030 - .040
.624	.324	.030 - .042	.625	.252	.036 - .050	.625	.390	.040 - .062	<b>.626</b>	<b>.478</b>	<b>.005 - .010</b>	.629	.391	.030 - .050	<b>.632</b>	<b>.239</b>	<b>.005 - .010</b>
.624	.328	.050 - .070	.625	.252	.083 - .105	.625	.392	.020 - .042	.626	.495	.040 - .060	.629	.472	.030 - .042	.632	.253	.015 - .030
.624	.330	.060 - .090	<b>.625</b>	<b>.253</b>	<b>.005 - .010</b>	.625	.393	.010 - .020	.626	.499	.010 - .020	.629	.472	.060 - .080	.632	.261	.020 - .040
.624																	

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.634	.330	.005 - .010	.641	.533	.030 - .040	<b>.650</b>	<b>.317</b>	<b>.005 - .010</b>	<b>.655</b>	<b>.530</b>	<b>.005 - .010</b>	.661	.529	.015 - .025	.670	.168	.040 - .060
.634	.354	.010 - .015	.641	.533	.040 - .060	<b>.650</b>	<b>.319</b>	<b>.005 - .010</b>	.656	.118	.030 - .050	.661	.531	.010 - .020	.670	.169	.040 - .060
.634	.354	.015 - .030	.642	.153	.030 - .050	.650	.325	.050 - .075	.656	.190	.075 - .090	<b>.661</b>	<b>.551</b>	<b>.005 - .010</b>	.670	.190	.015 - .032
.634	.459	.020 - .030	.642	.254	.015 - .030	.650	.357	.015 - .030	.656	.195	.050 - .075	<b>.661</b>	<b>.583</b>	<b>.005 - .010</b>	<b>.670</b>	<b>.234</b>	<b>.005 - .010</b>
.634	.477	.008 - .016	<b>.642</b>	<b>.411</b>	<b>.005 - .010</b>	.650	.374	.015 - .030	.656	.196	.020 - .040	.662	.201	.050 - .070	<b>.670</b>	<b>.237</b>	<b>.005 - .010</b>
<b>.634</b>	<b>.478</b>	<b>.005 - .010</b>	<b>.642</b>	<b>.449</b>	<b>.005 - .010</b>	.650	.377	.020 - .030	.656	.258	.030 - .050	.662	.393	.040 - .060	<b>.670</b>	<b>.239</b>	<b>.005 - .010</b>
.634	.512	.010 - .020	.642	.477	.070 - .090	.650	.380	.050 - .070	.656	.267	.050 - .075	.662	.432	.060 - .080	<b>.670</b>	<b>.240</b>	<b>.005 - .010</b>
.635	.179	.010 - .015	.642	.482	.020 - .040	<b>.650</b>	<b>.397</b>	<b>.005 - .010</b>	<b>.656</b>	<b>.278</b>	<b>.005 - .010</b>	.662	.461	.030 - .050	<b>.670</b>	<b>.253</b>	<b>.005 - .010</b>
.635	.200	.025 - .040	.642	.536	.007 - .012	.650	.404	.040 - .060	.656	.290	.070 - .090	.663	.457	.050 - .070	.670	.257	.040 - .060
.635	.204	.010 - .020	<b>.643</b>	<b>.169</b>	<b>.005 - .010</b>	<b>.650</b>	<b>.424</b>	<b>.005 - .010</b>	.656	.320	.025 - .040	<b>.663</b>	<b>.504</b>	<b>.005 - .010</b>	.670	.260	.020 - .030
.635	.312	.035 - .050	<b>.643</b>	<b>.174</b>	<b>.005 - .010</b>	.650	.469	.050 - .070	.656	.341	.030 - .050	.664	.256	.100 - .125	.670	.280	.010 - .020
.635	.356	.010 - .020	.643	.322	.015 - .030	<b>.650</b>	<b>.500</b>	<b>.005 - .010</b>	.656	.377	.015 - .030	<b>.664</b>	<b>.259</b>	<b>.005 - .010</b>	<b>.670</b>	<b>.300</b>	<b>.005 - .010</b>
.635	.375	.032 - .042	<b>.643</b>	<b>.370</b>	<b>.005 - .010</b>	.650	.503	.015 - .030	.656	.387	.030 - .050	.664	.259	.105 - .125	<b>.670</b>	<b>.315</b>	<b>.005 - .010</b>
<b>.635</b>	<b>.376</b>	<b>.005 - .010</b>	<b>.643</b>	<b>.502</b>	<b>.005 - .010</b>	.650	.505	.020 - .030	.656	.397	.015 - .025	.664	.413	.030 - .050	<b>.670</b>	<b>.317</b>	<b>.005 - .010</b>
<b>.635</b>	<b>.410</b>	<b>.005 - .010</b>	.643	.503	.015 - .030	.650	.507	.010 - .020	.656	.404	.080 - .104	.664	.503	.025 - .050	.670	.319	.050 - .070
.635	.443	.020 - .030	<b>.644</b>	<b>.171</b>	<b>.005 - .010</b>	.650	.534	.025 - .040	.656	.406	.090 - .125	.665	.173	.050 - .075	.670	.330	.050 - .075
.635	.470	.030 - .042	.644	.316	.020 - .035	.650	.553	.010 - .020	<b>.656</b>	<b>.453</b>	<b>.005 - .010</b>	.665	.249	.030 - .050	<b>.670</b>	<b>.331</b>	<b>.005 - .010</b>
.635	.531	.025 - .040	.644	.346	.015 - .030	.651	.147	.042 - .060	.656	.453	.025 - .040	.665	.251	.075 - .090	.670	.350	.020 - .040
.636	.179	.008 - .015	.644	.396	.025 - .040	.651	.160	.020 - .030	.656	.460	.025 - .035	.665	.334	.050 - .070	.670	.350	.080 - .100
.636	.381	.015 - .030	.644	.454	.025 - .040	<b>.651</b>	<b>.229</b>	<b>.005 - .010</b>	.656	.470	.035 - .050	.665	.334	.110 - .130	.670	.360	.040 - .050
<b>.636</b>	<b>.384</b>	<b>.005 - .010</b>	.644	.477	.020 - .030	.651	.315	.010 - .020	<b>.656</b>	<b>.489</b>	<b>.005 - .010</b>	.665	.374	.120 - .140	.670	.378	.060 - .080
.636	.393	.020 - .030	.644	.503	.020 - .040	.651	.374	.010 - .020	.656	.500	.030 - .050	.665	.397	.070 - .090	.670	.382	.030 - .060
.636	.410	.005 - .015	.645	.152	.030 - .050	.651	.377	.030 - .050	.656	.503	.010 - .020	.665	.434	.040 - .060	.670	.398	.040 - .060
.636	.454	.015 - .030	.645	.170	.035 - .050	<b>.651</b>	<b>.379</b>	<b>.005 - .010</b>	<b>.656</b>	<b>.510</b>	<b>.005 - .010</b>	.665	.515	.025 - .040	<b>.670</b>	<b>.439</b>	<b>.005 - .010</b>
<b>.636</b>	<b>.565</b>	<b>.005 - .010</b>	.645	.214	.010 - .020	.651	.380	.015 - .030	<b>.656</b>	<b>.511</b>	<b>.005 - .010</b>	.665	.550	.005 - .012	.670	.474	.070 - .090
.637	.244	.020 - .040	.645	.316	.020 - .032	<b>.651</b>	<b>.394</b>	<b>.005 - .010</b>	.656	.511	.020 - .030	.665	.576	.030 - .048	.670	.480	.010 - .020
<b>.637</b>	<b>.356</b>	<b>.005 - .010</b>	.645	.347	.025 - .040	<b>.651</b>	<b>.398</b>	<b>.005 - .010</b>	.656	.515	.015 - .030	.666	.143	.015 - .030	.670	.481	.040 - .060
.637	.381	.025 - .040	.645	.393	.050 - .062	.651	.450	.010 - .020	.656	.528	.015 - .030	.666	.168	.075 - .090	.670	.495	.040 - .062
.637	.425	.012 - .020	.645	.434	.032 - .048	.651	.465	.010 - .020	.656	.563	.020 - .040	.666	.256	.075 - .090	.670	.503	.020 - .040
.638	.156	.032 - .048	.645	.518	.040 - .060	.651	.485	.040 - .060	.656	.565	.010 - .020	.666	.267	.040 - .062	<b>.670</b>	<b>.545</b>	<b>.005 - .010</b>
.638	.263	.040 - .060	.646	.210	.060 - .080	<b>.651</b>	<b>.505</b>	<b>.005 - .010</b>	.657	.216	.060 - .080	.666	.453	.015 - .025	.670	.574	.030 - .050
.638	.506	.025 - .040	.646	.210	.090 - .110	.651	.551	.005 - .012	.657	.250	.080 - .105	.666	.475	.020 - .040	.671	.200	.025 - .042
.639	.325	.010 - .020	.646	.255	.020 - .030	.651	.551	.015 - .030	.657	.255	.015 - .030	.666	.478	.030 - .050	<b>.671</b>	<b>.239</b>	<b>.005 - .010</b>
.639	.394	.020 - .040	.646	.273	.020 - .035	.652	.096	.062 - .078	.657	.330	.075 - .100	<b>.666</b>	<b>.537</b>	<b>.005 - .010</b>	<b>.671</b>	<b>.264</b>	<b>.005 - .010</b>
.639	.415	.025 - .040	.646	.316	.005 - .012	.652	.118	.062 - .090	.657	.338	.105 - .125	.666	.564	.010 - .020	.671	.311	.078 - .090
.639	.438	.030 - .050	.646	.344	.020 - .030	.652	.193	.030 - .050	<b>.657</b>	<b>.363</b>	<b>.005 - .010</b>	<b>.666</b>	<b>.579</b>	<b>.005 - .010</b>	<b>.671</b>	<b>.315</b>	<b>.005 - .010</b>
.639	.439	.040 - .050	.646	.393	.090 - .105	<b>.652</b>	<b>.376</b>	<b>.005 - .010</b>	<b>.657</b>	<b>.413</b>	<b>.005 - .010</b>	.667	.213	.012 - .020	.671	.316	.015 - .030
<b>.639</b>	<b>.453</b>	<b>.005 - .010</b>	<b>.646</b>	<b>.447</b>	<b>.005 - .010</b>	.652	.400	.010 - .020	<b>.657</b>	<b>.417</b>	<b>.005 - .010</b>	.667	.270	.025 - .040	<b>.671</b>	<b>.319</b>	<b>.005 - .010</b>
.639	.524	.025 - .035	<b>.646</b>	<b>.539</b>	<b>.005 - .010</b>	.652	.406	.015 - .030	.657	.530	.020 - .040	.667	.275	.025 - .042	<b>.671</b>	<b>.322</b>	<b>.005 - .010</b>
<b>.639</b>	<b>.550</b>	<b>.005 - .010</b>	<b>.647</b>	<b>.131</b>	<b>.005 - .010</b>	<b>.652</b>	<b>.412</b>	<b>.005 - .010</b>	.657	.531	.040 - .060	.667	.319	.042 - .062	.671	.325	.015 - .030
.639	.576	.015 - .030	.647	.191	.030 - .050	<b>.652</b>	<b>.435</b>	<b>.005 - .010</b>	.657	.538	.040 - .060	<b>.667</b>	<b>.336</b>	<b>.005 - .010</b>	.671	.345	.020 - .040
.640	.036	.015 - .030	.647	.283	.030 - .050	.652	.439	.020 - .040	.657	.613	.016 - .025	.667	.347	.015 - .030	.671	.385	.070 - .090
.640	.073	.025 - .040	.647	.381	.105 - .125	<b>.652</b>	<b>.453</b>	<b>.005 - .010</b>	.658	.255	.010 - .020	<b>.667</b>	<b>.496</b>	<b>.005 - .010</b>	.671	.386	.100 - .125
.640	.168	.025 - .040	.647	.407	.030 - .050	.652	.501	.030 - .042	.658	.314	.030 - .050	<b>.667</b>	<b>.595</b>	<b>.005 - .010</b>	<b>.671</b>	<b>.391</b>	<b>.005 - .010</b>
.640	.175	.025 - .040	.647	.472	.015 - .030	.652	.510	.010 - .020	.658	.375	.010 - .020	.668	.218	.060 - .080	.671	.391	.050 - .075
.640	.186	.030 - .050	<b>.647</b>	<b>.492</b>	<b>.005 - .010</b>	.653	.154	.040 - .062	.658	.437	.005 - .012	<b>.668</b>	<b>.316</b>	<b>.005 - .010</b>	.671	.395	.020 - .030
.640	.251	.020 - .030	<b>.648</b>	<b>.093</b>	<b>.005 - .010</b>	.653	.238	.040 - .062	.658	.478	.015 - .025	<b>.668</b>	<b>.317</b>	<b>.005 - .010</b>	<b>.671</b>	<b>.474</b>	<b>.005 - .010</b>
.640	.251	.030 - .040	.648	.144	.020 - .040	.653	.316	.010 - .020	.658	.479	.030 - .042	.668	.333	.050 - .075	.671	.507	.008 - .015
<b>.640</b>	<b>.256</b>	<b>.005 - .010</b>	.648	.202	.008 - .015	.653	.376	.010 - .020	.658	.511	.030 - .060	.668	.340	.035 - .050	.672	.128	.100 - .125
<b>.640</b>	<b>.334</b>	<b>.005 - .010</b>	.648	.209	.015 - .030	.653	.392	.050 - .075	.658	.511	.060 - .070	.668	.348	.010 - .015	.672	.325	.015 - .030
.640	.342	.040 - .060	<b>.648</b>	<b>.266</b>	<b>.005 - .010</b>	.653	.392	.075 - .090	<b>.658</b>	<b>.572</b>	<b>.005 - .010</b>	.668	.406	.040 - .060	.672	.326	.080 - .100
.640	.361	.030 - .050	.648	.298	.050 - .075	.653	.414	.050 - .070	.659	.125	.015 - .025	.668	.472	.010 - .020	.672	.326	.100 - .125
.640	.377	.030 - .040	.648	.382	.005 - .012	<b>.653</b>	<b>.442</b>	<b>.005 - .010</b>	.659	.256	.100 - .120	<b>.669</b>	<b>.031</b>	<b>.005 - .010</b>	<b>.672</b>	<b>.346</b>	<b>.005 - .010</b>
.640	.390	.050 - .075	.648	.490	.010 - .020	.654	.142	.040 - .060	.659	.265	.020 - .035	<b>.669</b>	<b>.114</b>	<b>.005 - .010</b>	<b>.672</b>	<b>.362</b>	<b>.005 - .010</b>
<b>.640</b>	<b>.400</b>	<b>.005 - .010</b>	.648	.493	.015 - .030	.654	.267	.030 - .050	.659	.288	.050 - .070	<b>.669</b>	<b>.138</b>	<b>.005 - .010</b>	<b>.672</b>	<b>.375</b>	<b>.005 - .010</b>
.640	.429	.012 - .020	<b>.648</b>	<b>.521</b>	<b>.005 - .010</b>	<b>.654</b>	<b>.270</b>	<b>.005 - .010</b>	.659	.313	.020 - .040	<b>.669</b>	<b>.163</b>	<b>.005 - .010</b>	.672	.407	.010 - .020
.640	.441	.010 - .020	<b>.648</b>	<b>.551</b>	<b>.005 - .010</b>	.654	.276	.010 - .020	.659	.335	.060 - .075	<b>.669</b>	<b>.200</b>	<b>.005 - .010</b>	<b>.672</b>	<b>.415</b>	<b>.005 - .010</b>
.640	.443	.025 - .040	.649	.126	.020 - .050	.654	.363	.050 - .075	.659	.381	.090 - .100	.669	.204	.020 - .040	.672	.442	.030 - .040
.640	.444	.015 - .030	.649	.203	.025 - .040	.654	.389	.025 - .040	.659	.501	.015 - .030	.669	.204	.040 - .060	.672	.445	.025 - .040
.640	.446	.015 - .030	.649	.266	.125 - .135	.654	.480	.010 - .020	.660	.125	.020 - .030	<b>.669</b>	<b>.237</b>	<b>.005 - .010</b>	.672	.445	.040 - .060
.640	.451	.080 - .090	<b>.649</b>	<b>.281</b>	<b>.005 - .010</b>	.654	.510	.025 - .040	.660	.213	.070 - .090	<b>.669</b>	<b>.316</b>	<b>.005 - .010</b>	.672	.490	.050 - .070
.640	.485	.020 - .040	.649	.286													

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.674	.562	.020 - .030	.680	.500	.032 - .050	.685	.392	.090 - .110	<b>.687</b>	<b>.379</b>	<b>.005 - .010</b>	<b>.689</b>	<b>.273</b>	<b>.005 - .010</b>	.693	.396	.050 - .075
<b>.675</b>	<b>.095</b>	<b>.005 - .010</b>	.680	.504	.020 - .040	.685	.410	.060 - .078	.687	.380	.025 - .040	.689	.281	.050 - .070	.693	.410	.025 - .040
.675	.203	.020 - .040	.680	.514	.020 - .040	.685	.423	.100 - .125	.687	.384	.010 - .020	.689	.313	.020 - .040	.693	.438	.020 - .030
<b>.675</b>	<b>.224</b>	<b>.005 - .010</b>	.680	.524	.030 - .050	.685	.427	.032 - .042	.687	.384	.020 - .040	.689	.319	.025 - .040	<b>.693</b>	<b>.443</b>	<b>.005 - .010</b>
.675	.280	.060 - .090	<b>.680</b>	<b>.559</b>	<b>.005 - .010</b>	<b>.685</b>	<b>.441</b>	<b>.005 - .010</b>	<b>.687</b>	<b>.385</b>	<b>.005 - .010</b>	<b>.689</b>	<b>.320</b>	<b>.005 - .010</b>	.693	.539	.050 - .070
.675	.284	.032 - .050	.680	.564	.030 - .050	.685	.450	.008 - .020	.687	.386	.070 - .090	.689	.325	.040 - .060	.695	.195	.015 - .025
.675	.400	.025 - .040	<b>.680</b>	<b>.565</b>	<b>.005 - .010</b>	.685	.470	.050 - .070	.687	.393	.005 - .015	.689	.345	.040 - .060	.695	.196	.032 - .062
.675	.416	.015 - .030	.680	.565	.032 - .050	.685	.473	.060 - .080	.687	.397	.050 - .075	.689	.375	.010 - .020	.695	.264	.005 - .012
<b>.675</b>	<b>.440</b>	<b>.005 - .010</b>	.681	.190	.030 - .050	.685	.475	.020 - .040	.687	.406	.040 - .050	.689	.377	.050 - .070	.695	.265	.030 - .060
<b>.675</b>	<b>.442</b>	<b>.005 - .010</b>	.681	.251	.050 - .070	.685	.478	.015 - .030	.687	.407	.060 - .070	<b>.689</b>	<b>.398</b>	<b>.005 - .010</b>	<b>.695</b>	<b>.282</b>	<b>.005 - .010</b>
.675	.447	.080 - .100	.681	.264	.030 - .050	.685	.520	.010 - .020	.687	.433	.050 - .080	.689	.401	.015 - .030	.695	.335	.025 - .040
.675	.458	.020 - .040	<b>.681</b>	<b>.391</b>	<b>.005 - .010</b>	.685	.533	.060 - .083	.687	.433	.105 - .125	.689	.402	.032 - .048	.695	.353	.010 - .020
.675	.460	.010 - .020	<b>.681</b>	<b>.395</b>	<b>.005 - .010</b>	.685	.568	.030 - .050	.687	.438	.010 - .020	.689	.408	.100 - .125	.695	.412	.080 - .104
<b>.675</b>	<b>.480</b>	<b>.005 - .010</b>	.681	.395	.030 - .050	.685	.609	.010 - .030	.687	.441	.020 - .040	<b>.689</b>	<b>.435</b>	<b>.005 - .010</b>	.695	.414	.012 - .025
.675	.480	.040 - .060	.681	.401	.020 - .030	.686	.066	.036 - .050	.687	.441	.050 - .070	<b>.689</b>	<b>.437</b>	<b>.005 - .010</b>	.695	.518	.030 - .040
.675	.500	.040 - .060	.681	.401	.030 - .040	<b>.686</b>	<b>.094</b>	<b>.005 - .010</b>	.687	.443	.030 - .060	.689	.468	.100 - .125	<b>.695</b>	<b>.520</b>	<b>.005 - .010</b>
.675	.515	.025 - .048	<b>.681</b>	<b>.440</b>	<b>.005 - .010</b>	.686	.135	.030 - .050	.687	.443	.100 - .125	<b>.689</b>	<b>.471</b>	<b>.005 - .010</b>	<b>.695</b>	<b>.557</b>	<b>.005 - .010</b>
<b>.675</b>	<b>.582</b>	<b>.005 - .010</b>	.681	.503	.015 - .030	.686	.136	.040 - .060	.687	.445	.012 - .020	.689	.472	.030 - .050	.695	.558	.015 - .030
.676	.288	.010 - .025	<b>.681</b>	<b>.515</b>	<b>.005 - .010</b>	.686	.147	.015 - .025	.687	.452	.010 - .020	.689	.493	.040 - .060	.695	.626	.015 - .025
<b>.676</b>	<b>.440</b>	<b>.005 - .010</b>	.682	.129	.015 - .025	.686	.159	.080 - .100	.687	.455	.050 - .075	.689	.494	.050 - .075	.696	.037	.007 - .015
.676	.500	.025 - .042	.682	.333	.070 - .090	<b>.686</b>	<b>.161</b>	<b>.005 - .010</b>	.687	.455	.080 - .100	<b>.689</b>	<b>.500</b>	<b>.005 - .010</b>	.696	.147	.005 - .015
.676	.565	.020 - .040	.682	.351	.050 - .070	.686	.167	.040 - .060	.687	.465	.080 - .100	.689	.517	.030 - .050	<b>.696</b>	<b>.156</b>	<b>.005 - .010</b>
.677	.168	.020 - .030	<b>.682</b>	<b>.365</b>	<b>.005 - .010</b>	.686	.167	.105 - .135	.687	.468	.040 - .060	.689	.564	.010 - .020	.696	.166	.062 - .090
<b>.677</b>	<b>.387</b>	<b>.005 - .010</b>	<b>.682</b>	<b>.395</b>	<b>.005 - .010</b>	.686	.198	.042 - .060	.687	.469	.050 - .080	.689	.564	.020 - .030	.696	.178	.062 - .078
.677	.441	.060 - .080	.682	.400	.032 - .048	.686	.202	.100 - .125	.687	.475	.015 - .030	.689	.565	.010 - .020	.696	.196	.050 - .070
.677	.458	.025 - .040	.682	.439	.025 - .040	.686	.252	.040 - .060	.687	.481	.050 - .070	.689	.577	.030 - .050	.696	.281	.090 - .120
.677	.468	.010 - .020	.682	.440	.020 - .030	.686	.253	.042 - .062	.687	.487	.025 - .040	.690	.076	.010 - .020	.696	.458	.025 - .042
.677	.476	.040 - .060	.682	.472	.062 - .078	.686	.269	.050 - .072	.687	.500	.010 - .020	<b>.690</b>	<b>.167</b>	<b>.005 - .010</b>	<b>.696</b>	<b>.498</b>	<b>.005 - .010</b>
<b>.677</b>	<b>.523</b>	<b>.005 - .010</b>	<b>.682</b>	<b>.486</b>	<b>.005 - .010</b>	<b>.686</b>	<b>.270</b>	<b>.005 - .010</b>	.687	.500	.030 - .050	.690	.173	.050 - .070	.696	.531	.015 - .030
<b>.677</b>	<b>.525</b>	<b>.005 - .010</b>	.682	.578	.015 - .030	.686	.313	.100 - .120	<b>.687</b>	<b>.503</b>	<b>.005 - .010</b>	.690	.188	.040 - .060	.697	.313	.090 - .110
<b>.677</b>	<b>.534</b>	<b>.005 - .010</b>	.682	.601	.020 - .030	.686	.345	.060 - .080	<b>.687</b>	<b>.506</b>	<b>.005 - .010</b>	.690	.190	.010 - .020	.697	.532	.025 - .040
.678	.193	.060 - .090	.683	.121	.050 - .070	.686	.346	.025 - .035	.687	.511	.020 - .040	.690	.192	.060 - .080	<b>.698</b>	<b>.231</b>	<b>.005 - .010</b>
.678	.256	.035 - .060	.683	.172	.010 - .025	.686	.360	.015 - .025	.687	.513	.042 - .062	.690	.202	.030 - .050	<b>.698</b>	<b>.361</b>	<b>.005 - .010</b>
.678	.384	.020 - .032	.683	.345	.070 - .090	.686	.377	.060 - .080	.687	.517	.030 - .048	.690	.206	.050 - .075	<b>.698</b>	<b>.477</b>	<b>.005 - .010</b>
<b>.678</b>	<b>.440</b>	<b>.005 - .010</b>	<b>.683</b>	<b>.376</b>	<b>.005 - .010</b>	.686	.379	.025 - .040	<b>.687</b>	<b>.564</b>	<b>.005 - .010</b>	.690	.220	.020 - .032	<b>.698</b>	<b>.500</b>	<b>.005 - .010</b>
.678	.442	.012 - .020	.683	.378	.015 - .030	.686	.381	.080 - .105	.687	.566	.005 - .015	.690	.254	.050 - .070	<b>.698</b>	<b>.527</b>	<b>.005 - .010</b>
.678	.449	.040 - .060	.683	.396	.070 - .090	.686	.385	.048 - .062	.688	.130	.050 - .060	.690	.264	.105 - .125	.698	.541	.025 - .040
.678	.504	.015 - .030	.683	.400	.032 - .042	.686	.390	.048 - .062	.688	.168	.050 - .060	.690	.265	.100 - .125	.698	.542	.030 - .060
<b>.678</b>	<b>.507</b>	<b>.005 - .010</b>	.683	.406	.040 - .060	.686	.392	.050 - .062	.688	.205	.025 - .040	.690	.280	.050 - .075	.698	.564	.010 - .020
.678	.529	.005 - .007	.683	.440	.015 - .030	.686	.395	.010 - .020	.688	.206	.040 - .060	.690	.281	.050 - .070	<b>.698</b>	<b>.602</b>	<b>.005 - .010</b>
.678	.530	.015 - .030	.683	.478	.025 - .035	<b>.686</b>	<b>.398</b>	<b>.005 - .010</b>	.688	.216	.050 - .070	.690	.317	.080 - .100	<b>.698</b>	<b>.626</b>	<b>.005 - .010</b>
.678	.564	.035 - .050	.683	.488	.080 - .104	<b>.686</b>	<b>.421</b>	<b>.005 - .010</b>	.688	.253	.010 - .020	.690	.323	.020 - .030	.699	.070	.040 - .060
.678	.568	.010 - .020	.683	.510	.030 - .062	.686	.437	.015 - .030	.688	.259	.040 - .060	.690	.323	.050 - .070	.699	.210	.060 - .080
<b>.678</b>	<b>.591</b>	<b>.005 - .010</b>	.683	.570	.040 - .050	.686	.438	.050 - .075	<b>.688</b>	<b>.263</b>	<b>.005 - .010</b>	.690	.343	.050 - .070	<b>.699</b>	<b>.376</b>	<b>.005 - .010</b>
<b>.678</b>	<b>.593</b>	<b>.005 - .010</b>	.683	.575	.040 - .060	.686	.483	.050 - .075	<b>.688</b>	<b>.263</b>	<b>.170 - .190</b>	.690	.344	.100 - .120	<b>.699</b>	<b>.380</b>	<b>.005 - .010</b>
<b>.678</b>	<b>.606</b>	<b>.005 - .010</b>	.683	.579	.015 - .025	.686	.500	.030 - .050	<b>.688</b>	<b>.284</b>	<b>.005 - .010</b>	<b>.690</b>	<b>.354</b>	<b>.005 - .010</b>	<b>.699</b>	<b>.483</b>	<b>.005 - .010</b>
.679	.111	.048 - .062	.684	.234	.062 - .078	.686	.500	.050 - .070	.688	.311	.010 - .020	<b>.690</b>	<b>.365</b>	<b>.005 - .010</b>	.699	.500	.010 - .020
.679	.206	.035 - .060	.684	.247	.050 - .075	.686	.502	.025 - .042	.688	.311	.020 - .040	.690	.376	.010 - .020	<b>.699</b>	<b>.502</b>	<b>.005 - .010</b>
.679	.221	.010 - .015	<b>.684</b>	<b>.303</b>	<b>.005 - .010</b>	<b>.686</b>	<b>.512</b>	<b>.005 - .010</b>	.688	.313	.120 - .140	.690	.376	.020 - .030	.699	.503	.070 - .090
.679	.395	.030 - .050	.684	.323	.020 - .040	.686	.520	.015 - .030	<b>.688</b>	<b>.316</b>	<b>.005 - .010</b>	.690	.385	.090 - .104	.699	.514	.060 - .080
.679	.396	.015 - .030	<b>.684</b>	<b>.399</b>	<b>.005 - .010</b>	.687	.119	.015 - .030	.688	.326	.015 - .030	.690	.436	.100 - .125	.699	.562	.040 - .060
.679	.403	.050 - .075	.684	.412	.100 - .125	.687	.187	.030 - .050	.688	.330	.030 - .050	.690	.475	.030 - .050	<b>.700</b>	<b>.093</b>	<b>.005 - .010</b>
<b>.679</b>	<b>.411</b>	<b>.005 - .010</b>	.684	.443	.005 - .012	.687	.189	.010 - .015	<b>.688</b>	<b>.334</b>	<b>.005 - .010</b>	.690	.494	.075 - .090	.700	.096	.050 - .062
.679	.441	.030 - .050	.684	.510	.050 - .070	.687	.189	.040 - .060	.688	.343	.070 - .090	.690	.503	.050 - .070	.700	.120	.070 - .090
.679	.457	.030 - .040	.684	.542	.035 - .050	<b>.687</b>	<b>.191</b>	<b>.005 - .010</b>	.688	.344	.070 - .090	.690	.530	.040 - .060	.700	.138	.010 - .020
.679	.457	.040 - .060	.684	.568	.025 - .045	.687	.194	.125 - .156	<b>.688</b>	<b>.349</b>	<b>.005 - .010</b>	.690	.533	.072 - .090	.700	.159	.040 - .060
.679	.482	.015 - .031	.684	.581	.015 - .025	.687	.198	.090 - .105	.688	.350	.050 - .070	<b>.690</b>	<b>.542</b>	<b>.005 - .010</b>	.700	.164	.010 - .020
.679	.482	.042 - .062	.684	.593	.030 - .040	.687	.199	.015 - .020	.688	.352	.050 - .070	.690	.566	.030 - .050	.700	.168	.050 - .070
.679	.501	.015 - .030	.684	.613	.015 - .030	.687	.200	.032 - .042	.688	.376	.005 - .015	.690	.569	.010 - .020	.700	.169	.040 - .060
<b>.679</b>	<b>.509</b>	<b>.005 - .010</b>	.685	.143	.040 - .060	.687	.219	.036 - .050	.688	.376	.025 - .042	.690	.575	.010 - .020	<b>.700</b>	<b>.176</b>	<b>.005 - .010</b>
<b>.680</b>	<b>.163</b>	<b>.005 - .010</b>	.685	.158	.060 - .083	.687	.221	.020 - .032	.688	.378	.050 - .075	.690	.615	.020 - .030	<b>.700</b>	<b>.193</b>	<b>.005 - .010</b>
.680	.200	.032 - .050	<b>.685</b>	<b>.225</b>	<b>.005 - .010</b>	.687	.221	.050 - .062	.688	.384	.050 - .070	.690	.625	.010 - .020	.700	.210	.050 - .070
<b>.680</b>	<b>.253</b>	<b>.005 - .010</b>	.685</														

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.700	.377	.020 - .040	.702	.401	.025 - .040	<b>.708</b>	<b>.305</b>	<b>.005 - .010</b>	.710	.330	.010 - .020	.717	.318	.025 - .040	.721	.601	.020 - .040
<b>.700</b>	<b>.378</b>	<b>.005 - .010</b>	.702	.437	.050 - .105	<b>.708</b>	<b>.315</b>	<b>.005 - .010</b>	.710	.342	.020 - .030	.717	.322	.032 - .050	.722	.221	.080 - .100
.700	.378	.015 - .030	.702	.487	.050 - .070	<b>.708</b>	<b>.319</b>	<b>.005 - .010</b>	.710	.354	.008 - .020	.717	.438	.030 - .050	.722	.233	.050 - .070
.700	.380	.040 - .060	.702	.504	.012 - .025	.708	.319	.050 - .070	.710	.376	.020 - .040	.717	.440	.080 - .100	.722	.265	.050 - .075
<b>.700</b>	<b>.381</b>	<b>.005 - .010</b>	<b>.702</b>	<b>.505</b>	<b>.005 - .010</b>	<b>.708</b>	<b>.322</b>	<b>.005 - .010</b>	.710	.413	.050 - .072	<b>.717</b>	<b>.447</b>	<b>.005 - .010</b>	.722	.314	.050 - .075
.700	.383	.040 - .060	.702	.516	.050 - .075	.708	.335	.020 - .030	<b>.710</b>	<b>.454</b>	<b>.005 - .010</b>	.717	.473	.015 - .030	.722	.320	.050 - .080
.700	.385	.090 - .105	.702	.561	.015 - .030	<b>.708</b>	<b>.338</b>	<b>.005 - .010</b>	.710	.473	.010 - .020	.717	.476	.025 - .040	.722	.324	.030 - .050
.700	.394	.135 - .156	.702	.595	.025 - .040	.708	.339	.040 - .060	<b>.710</b>	<b>.474</b>	<b>.005 - .010</b>	<b>.717</b>	<b>.478</b>	<b>.005 - .010</b>	.722	.376	.100 - .125
<b>.700</b>	<b>.397</b>	<b>.005 - .010</b>	.703	.119	.030 - .050	<b>.708</b>	<b>.375</b>	<b>.005 - .010</b>	.710	.475	.015 - .030	.717	.515	.050 - .075	.722	.481	.050 - .060
.700	.405	.120 - .134	.703	.206	.025 - .040	<b>.708</b>	<b>.393</b>	<b>.005 - .010</b>	.710	.497	.030 - .050	<b>.717</b>	<b>.548</b>	<b>.005 - .010</b>	.722	.500	.072 - .090
.700	.406	.050 - .060	<b>.703</b>	<b>.263</b>	<b>.005 - .010</b>	.708	.393	.010 - .020	.710	.505	.050 - .070	<b>.717</b>	<b>.628</b>	<b>.005 - .010</b>	.722	.515	.010 - .020
.700	.406	.125 - .150	.703	.409	.010 - .020	.708	.394	.050 - .070	.710	.507	.020 - .035	.718	.131	.030 - .050	.722	.540	.078 - .090
<b>.700</b>	<b>.411</b>	<b>.005 - .010</b>	<b>.703</b>	<b>.443</b>	<b>.010 - .010</b>	.708	.404	.050 - .070	<b>.710</b>	<b>.525</b>	<b>.005 - .010</b>	.718	.160	.048 - .062	.722	.636	.010 - .020
.700	.411	.040 - .060	.703	.480	.030 - .050	.708	.413	.080 - .100	.710	.526	.010 - .025	.718	.189	.015 - .030	<b>.723</b>	<b>.221</b>	<b>.005 - .010</b>
.700	.417	.005 - .020	.703	.482	.050 - .070	.708	.415	.025 - .040	.710	.530	.070 - .090	<b>.718</b>	<b>.205</b>	<b>.005 - .010</b>	.723	.221	.025 - .040
<b>.700</b>	<b>.435</b>	<b>.005 - .010</b>	.703	.516	.020 - .040	<b>.708</b>	<b>.512</b>	<b>.005 - .010</b>	.710	.533	.050 - .070	.718	.252	.010 - .025	.723	.314	.040 - .060
<b>.700</b>	<b>.437</b>	<b>.005 - .010</b>	.703	.525	.030 - .050	.708	.512	.020 - .040	.710	.575	.040 - .060	.718	.257	.025 - .040	.723	.382	.030 - .060
<b>.700</b>	<b>.441</b>	<b>.005 - .010</b>	.703	.540	.040 - .060	.708	.550	.020 - .036	.710	.578	.040 - .060	.718	.262	.020 - .040	<b>.723</b>	<b>.632</b>	<b>.005 - .010</b>
.700	.441	.010 - .020	.703	.635	.010 - .020	.708	.551	.045 - .060	<b>.710</b>	<b>.620</b>	<b>.005 - .010</b>	.718	.282	.062 - .083	.724	.173	.030 - .050
<b>.700</b>	<b>.450</b>	<b>.005 - .010</b>	.704	.259	.050 - .070	.708	.575	.010 - .025	<b>.711</b>	<b>.168</b>	<b>.005 - .010</b>	.718	.313	.015 - .030	.724	.201	.020 - .040
.700	.450	.060 - .080	.704	.264	.060 - .080	<b>.708</b>	<b>.630</b>	<b>.005 - .010</b>	<b>.711</b>	<b>.320</b>	<b>.005 - .010</b>	<b>.718</b>	<b>.353</b>	<b>.005 - .010</b>	.724	.382	.020 - .040
<b>.700</b>	<b>.455</b>	<b>.005 - .010</b>	.704	.268	.060 - .090	<b>.708</b>	<b>.632</b>	<b>.005 - .010</b>	.711	.407	.020 - .032	.718	.375	.030 - .060	.724	.508	.025 - .040
.700	.456	.030 - .050	.704	.343	.060 - .080	.708	.636	.015 - .030	.711	.407	.032 - .050	.718	.378	.025 - .050	.724	.519	.020 - .040
.700	.465	.020 - .040	.704	.366	.010 - .020	<b>.708</b>	<b>.641</b>	<b>.005 - .010</b>	.711	.485	.040 - .060	<b>.718</b>	<b>.380</b>	<b>.005 - .010</b>	.725	.089	.062 - .078
<b>.700</b>	<b>.473</b>	<b>.005 - .010</b>	.704	.366	.020 - .040	<b>.709</b>	<b>.145</b>	<b>.005 - .010</b>	.711	.486	.040 - .060	.718	.380	.070 - .090	.725	.128	.040 - .060
<b>.700</b>	<b>.476</b>	<b>.005 - .010</b>	.704	.475	.010 - .025	.709	.149	.030 - .060	.711	.526	.015 - .025	.718	.395	.010 - .020	.725	.187	.060 - .090
<b>.700</b>	<b>.500</b>	<b>.005 - .010</b>	.704	.478	.040 - .060	.709	.181	.060 - .080	.712	.177	.020 - .032	<b>.718</b>	<b>.398</b>	<b>.005 - .010</b>	.725	.296	.100 - .125
.700	.501	.070 - .090	.704	.480	.015 - .030	<b>.709</b>	<b>.239</b>	<b>.005 - .010</b>	.712	.200	.005 - .015	<b>.718</b>	<b>.406</b>	<b>.005 - .010</b>	<b>.725</b>	<b>.339</b>	<b>.005 - .010</b>
.700	.502	.010 - .020	.704	.497	.020 - .035	.709	.239	.010 - .020	<b>.712</b>	<b>.234</b>	<b>.005 - .010</b>	.718	.408	.030 - .050	.725	.339	.020 - .030
.700	.502	.080 - .100	.704	.503	.060 - .080	<b>.709</b>	<b>.243</b>	<b>.005 - .010</b>	<b>.712</b>	<b>.236</b>	<b>.005 - .010</b>	.718	.438	.090 - .125	.725	.458	.010 - .020
<b>.700</b>	<b>.504</b>	<b>.005 - .010</b>	.704	.503	.090 - .100	.709	.253	.160 - .180	.712	.246	.080 - .105	<b>.718</b>	<b>.464</b>	<b>.005 - .010</b>	.725	.540	.050 - .070
.700	.504	.015 - .030	.704	.532	.030 - .050	.709	.259	.040 - .060	<b>.712</b>	<b>.252</b>	<b>.005 - .010</b>	<b>.718</b>	<b>.487</b>	<b>.005 - .010</b>	.725	.548	.020 - .040
.700	.506	.015 - .030	<b>.704</b>	<b>.553</b>	<b>.005 - .010</b>	.709	.313	.005 - .015	.712	.525	.040 - .060	.718	.518	.020 - .040	.726	.183	.050 - .070
.700	.506	.025 - .042	.704	.600	.020 - .040	.709	.313	.090 - .110	.712	.530	.030 - .050	<b>.718</b>	<b>.562</b>	<b>.005 - .010</b>	.726	.304	.010 - .020
.700	.510	.010 - .025	<b>.704</b>	<b>.626</b>	<b>.005 - .010</b>	<b>.709</b>	<b>.314</b>	<b>.005 - .010</b>	.712	.567	.015 - .030	.718	.562	.025 - .040	.726	.315	.020 - .030
.700	.514	.020 - .030	.705	.085	.005 - .012	<b>.709</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.712</b>	<b>.646</b>	<b>.005 - .010</b>	.718	.593	.015 - .020	<b>.726</b>	<b>.343</b>	<b>.005 - .010</b>
.700	.514	.040 - .060	<b>.705</b>	<b>.098</b>	<b>.005 - .010</b>	.709	.316	.015 - .030	.713	.116	.050 - .070	<b>.718</b>	<b>.595</b>	<b>.005 - .010</b>	.726	.375	.105 - .125
.700	.531	.020 - .040	.705	.253	.050 - .072	<b>.709</b>	<b>.317</b>	<b>.005 - .010</b>	.713	.199	.015 - .030	.718	.600	.045 - .060	.726	.406	.030 - .050
<b>.700</b>	<b>.532</b>	<b>.005 - .010</b>	.705	.265	.020 - .040	<b>.709</b>	<b>.320</b>	<b>.005 - .010</b>	.713	.206	.080 - .100	.718	.638	.006 - .015	.726	.439	.020 - .040
.700	.533	.030 - .050	<b>.705</b>	<b>.274</b>	<b>.005 - .010</b>	<b>.709</b>	<b>.321</b>	<b>.005 - .010</b>	.713	.400	.015 - .025	.718	.638	.020 - .030	<b>.726</b>	<b>.632</b>	<b>.005 - .010</b>
.700	.535	.040 - .050	<b>.705</b>	<b>.311</b>	<b>.005 - .010</b>	<b>.709</b>	<b>.322</b>	<b>.005 - .010</b>	<b>.713</b>	<b>.410</b>	<b>.005 - .010</b>	.719	.132	.030 - .050	.727	.257	.020 - .040
<b>.700</b>	<b>.550</b>	<b>.005 - .010</b>	<b>.705</b>	<b>.312</b>	<b>.005 - .010</b>	.709	.327	.040 - .060	.713	.437	.060 - .075	.719	.196	.040 - .060	<b>.727</b>	<b>.397</b>	<b>.005 - .010</b>
.700	.555	.015 - .030	<b>.705</b>	<b>.317</b>	<b>.005 - .010</b>	.709	.347	.050 - .070	.713	.540	.040 - .060	.719	.198	.015 - .030	<b>.727</b>	<b>.448</b>	<b>.005 - .010</b>
<b>.700</b>	<b>.560</b>	<b>.005 - .010</b>	.705	.383	.010 - .020	.709	.352	.015 - .030	.713	.595	.010 - .020	<b>.719</b>	<b>.237</b>	<b>.005 - .010</b>	.727	.500	.015 - .030
.700	.560	.015 - .030	<b>.705</b>	<b>.438</b>	<b>.005 - .010</b>	<b>.709</b>	<b>.386</b>	<b>.005 - .010</b>	<b>.713</b>	<b>.672</b>	<b>.005 - .010</b>	.719	.240	.015 - .030	.727	.512	.010 - .020
.700	.564	.025 - .040	.705	.516	.025 - .040	.709	.392	.010 - .020	.714	.101	.020 - .030	.719	.254	.008 - .016	.727	.570	.040 - .060
.700	.564	.050 - .072	<b>.705</b>	<b>.531</b>	<b>.005 - .010</b>	.709	.394	.010 - .020	.714	.111	.020 - .030	.719	.324	.015 - .030	.727	.586	.015 - .030
.700	.565	.040 - .060	.705	.550	.030 - .050	<b>.709</b>	<b>.395</b>	<b>.005 - .010</b>	.714	.118	.020 - .030	.719	.329	.080 - .100	.728	.219	.010 - .020
.700	.566	.015 - .032	.705	.634	.015 - .025	<b>.709</b>	<b>.397</b>	<b>.005 - .010</b>	.714	.125	.020 - .030	.719	.374	.010 - .015	<b>.728</b>	<b>.251</b>	<b>.005 - .010</b>
<b>.700</b>	<b>.578</b>	<b>.005 - .010</b>	.706	.254	.030 - .050	.709	.397	.005 - .015	.714	.140	.020 - .030	<b>.719</b>	<b>.378</b>	<b>.005 - .010</b>	.728	.253	.025 - .040
.700	.600	.010 - .020	<b>.706</b>	<b>.347</b>	<b>.005 - .010</b>	.709	.397	.010 - .020	<b>.714</b>	<b>.182</b>	<b>.005 - .010</b>	.719	.380	.070 - .090	.728	.259	.025 - .040
<b>.700</b>	<b>.608</b>	<b>.005 - .010</b>	.706	.395	.062 - .083	.709	.399	.010 - .020	.714	.223	.050 - .070	.719	.395	.040 - .060	.728	.291	.025 - .040
<b>.700</b>	<b>.615</b>	<b>.005 - .010</b>	.706	.398	.050 - .070	<b>.709</b>	<b>.437</b>	<b>.005 - .010</b>	.714	.299	.020 - .030	.719	.439	.080 - .105	.728	.292	.025 - .042
<b>.700</b>	<b>.631</b>	<b>.005 - .010</b>	<b>.706</b>	<b>.402</b>	<b>.005 - .010</b>	.709	.437	.030 - .050	.714	.390	.048 - .072	.719	.441	.070 - .090	.728	.328	.025 - .040
.701	.130	.060 - .080	<b>.706</b>	<b>.420</b>	<b>.005 - .010</b>	.709	.455	.090 - .105	.714	.414	.040 - .060	.719	.453	.050 - .070	.728	.375	.060 - .090
.701	.153	.048 - .062	.														

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.730	.482	.020 - .040	.736	.516	.030 - .050	.741	.531	.050 - .070	.745	.455	.032 - .050	.748	.180	.008 - .016	.749	.347	.020 - .035
.730	.492	.030 - .050	<b>.736</b>	<b>.565</b>	<b>.005 - .010</b>	.741	.563	.030 - .050	.745	.468	.005 - .012	.748	.201	.060 - .090	<b>.749</b>	<b>.350</b>	<b>.005 - .010</b>
.730	.506	.040 - .060	.736	.578	.015 - .025	.741	.570	.020 - .040	<b>.745</b>	<b>.509</b>	<b>.005 - .010</b>	<b>.748</b>	<b>.237</b>	<b>.060 - .010</b>	<b>.749</b>	<b>.351</b>	<b>.005 - .010</b>
.730	.519	.050 - .070	.736	.595	.040 - .062	<b>.741</b>	<b>.640</b>	<b>.005 - .010</b>	.745	.510	.020 - .040	<b>.748</b>	<b>.238</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.364</b>	<b>.005 - .010</b>
<b>.730</b>	<b>.571</b>	<b>.005 - .010</b>	.736	.601	.015 - .030	<b>.741</b>	<b>.690</b>	<b>.005 - .010</b>	.745	.541	.010 - .025	.748	.239	.050 - .070	.749	.375	.025 - .040
.730	.615	.020 - .030	.736	.633	.015 - .030	<b>.742</b>	<b>.149</b>	<b>.005 - .010</b>	.745	.558	.010 - .020	.748	.241	.040 - .060	.749	.379	.036 - .060
.730	.630	.030 - .042	.736	.650	.025 - .040	.742	.226	.075 - .100	<b>.745</b>	<b>.560</b>	<b>.005 - .010</b>	.748	.249	.050 - .075	<b>.749</b>	<b>.386</b>	<b>.005 - .010</b>
.731	.206	.030 - .050	.737	.318	.015 - .025	.742	.251	.040 - .060	.745	.562	.020 - .030	<b>.748</b>	<b>.252</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.387</b>	<b>.005 - .010</b>
.731	.410	.070 - .090	<b>.737</b>	<b>.364</b>	<b>.005 - .010</b>	.742	.346	.020 - .030	<b>.745</b>	<b>.571</b>	<b>.005 - .010</b>	.748	.254	.060 - .090	.749	.397	.015 - .025
<b>.731</b>	<b>.416</b>	<b>.005 - .010</b>	.737	.419	.030 - .060	.742	.360	.050 - .060	.745	.576	.042 - .060	<b>.748</b>	<b>.255</b>	<b>.005 - .010</b>	.749	.402	.100 - .120
.731	.416	.070 - .080	.737	.503	.060 - .083	.742	.378	.080 - .104	.745	.591	.030 - .050	.748	.259	.008 - .016	.749	.403	.005 - .008
.731	.426	.010 - .020	<b>.737</b>	<b>.505</b>	<b>.005 - .010</b>	.742	.380	.030 - .050	<b>.745</b>	<b>.599</b>	<b>.005 - .010</b>	<b>.748</b>	<b>.315</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.408</b>	<b>.005 - .010</b>
.731	.433	.030 - .050	.737	.505	.050 - .070	.742	.387	.100 - .135	<b>.745</b>	<b>.605</b>	<b>.005 - .010</b>	<b>.748</b>	<b>.316</b>	<b>.005 - .010</b>	.749	.424	.040 - .060
.731	.453	.100 - .120	.737	.537	.030 - .050	.742	.389	.042 - .062	.745	.626	.040 - .060	.748	.316	.160 - .190	.749	.437	.042 - .060
.731	.482	.020 - .040	<b>.737</b>	<b>.546</b>	<b>.005 - .010</b>	.742	.426	.050 - .070	.745	.661	.010 - .015	<b>.748</b>	<b>.317</b>	<b>.005 - .010</b>	.749	.438	.010 - .020
<b>.731</b>	<b>.564</b>	<b>.005 - .010</b>	.737	.550	.025 - .040	.742	.443	.025 - .040	.745	.693	.010 - .020	<b>.748</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.440</b>	<b>.005 - .010</b>
.732	.043	.010 - .020	.738	.342	.042 - .060	.742	.443	.040 - .060	.746	.100	.032 - .050	<b>.748</b>	<b>.322</b>	<b>.005 - .010</b>	.749	.440	.050 - .070
.732	.159	.070 - .090	<b>.738</b>	<b>.346</b>	<b>.005 - .010</b>	.742	.466	.060 - .075	.746	.125	.015 - .030	.748	.328	.105 - .134	.749	.445	.005 - .015
.732	.163	.015 - .030	.738	.538	.015 - .030	.742	.474	.080 - .100	.746	.166	.050 - .075	.748	.331	.015 - .030	<b>.749</b>	<b>.468</b>	<b>.005 - .010</b>
<b>.732</b>	<b>.165</b>	<b>.005 - .010</b>	.738	.540	.015 - .025	.742	.517	.005 - .008	.746	.200	.060 - .080	.748	.357	.070 - .090	.749	.471	.050 - .070
.732	.199	.042 - .060	<b>.738</b>	<b>.544</b>	<b>.005 - .010</b>	.742	.517	.015 - .030	.746	.253	.040 - .060	<b>.748</b>	<b>.376</b>	<b>.005 - .010</b>	.749	.474	.050 - .070
.732	.199	.060 - .080	<b>.738</b>	<b>.595</b>	<b>.005 - .010</b>	.742	.566	.025 - .040	<b>.746</b>	<b>.260</b>	<b>.005 - .010</b>	.748	.384	.020 - .040	.749	.499	.020 - .030
.732	.253	.010 - .015	.739	.222	.040 - .060	.742	.593	.025 - .040	<b>.746</b>	<b>.285</b>	<b>.005 - .010</b>	<b>.748</b>	<b>.385</b>	<b>.005 - .010</b>	.749	.499	.050 - .075
.732	.263	.040 - .062	.739	.305	.010 - .020	.742	.671	.010 - .020	<b>.746</b>	<b>.316</b>	<b>.005 - .010</b>	.748	.393	.060 - .080	.749	.499	.060 - .080
.732	.281	.050 - .075	.739	.333	.050 - .070	.743	.144	.070 - .090	.746	.316	.010 - .020	<b>.748</b>	<b>.397</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.503</b>	<b>.005 - .010</b>
<b>.732</b>	<b>.290</b>	<b>.005 - .010</b>	.739	.407	.060 - .080	.743	.271	.050 - .075	.746	.316	.020 - .030	<b>.748</b>	<b>.400</b>	<b>.005 - .010</b>	.749	.504	.090 - .120
.732	.443	.015 - .030	.739	.431	.070 - .090	<b>.743</b>	<b>.390</b>	<b>.005 - .010</b>	.746	.318	.078 - .090	<b>.748</b>	<b>.451</b>	<b>.005 - .010</b>	.749	.507	.008 - .016
.732	.475	.008 - .015	.739	.505	.015 - .030	.743	.488	.060 - .080	.746	.319	.040 - .060	.748	.461	.010 - .020	<b>.749</b>	<b>.517</b>	<b>.005 - .010</b>
.732	.502	.025 - .042	<b>.739</b>	<b>.519</b>	<b>.005 - .010</b>	<b>.743</b>	<b>.531</b>	<b>.005 - .010</b>	.746	.379	.040 - .060	<b>.748</b>	<b>.462</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.528</b>	<b>.005 - .010</b>
.733	.159	.070 - .090	.739	.522	.015 - .030	<b>.743</b>	<b>.541</b>	<b>.005 - .010</b>	.746	.386	.060 - .070	.748	.473	.005 - .015	<b>.749</b>	<b>.531</b>	<b>.005 - .010</b>
.733	.389	.010 - .020	.739	.565	.015 - .030	.743	.556	.005 - .008	.746	.390	.006 - .010	.748	.501	.090 - .105	.749	.562	.010 - .020
.733	.435	.030 - .050	<b>.739</b>	<b>.576</b>	<b>.005 - .010</b>	.743	.572	.040 - .060	.746	.393	.110 - .130	.748	.503	.010 - .020	<b>.749</b>	<b>.563</b>	<b>.005 - .010</b>
.733	.515	.050 - .070	.739	.605	.040 - .060	<b>.743</b>	<b>.596</b>	<b>.005 - .010</b>	.746	.395	.030 - .050	.748	.503	.025 - .040	.749	.594	.010 - .020
.733	.650	.010 - .015	<b>.739</b>	<b>.632</b>	<b>.005 - .010</b>	.743	.600	.010 - .020	<b>.746</b>	<b>.405</b>	<b>.005 - .010</b>	.748	.504	.050 - .070	.749	.595	.035 - .062
.734	.162	.015 - .030	<b>.739</b>	<b>.634</b>	<b>.005 - .010</b>	.743	.600	.075 - .080	.746	.437	.042 - .060	.748	.507	.020 - .036	<b>.749</b>	<b>.609</b>	<b>.005 - .010</b>
<b>.734</b>	<b>.187</b>	<b>.005 - .010</b>	.739	.656	.025 - .040	.743	.623	.010 - .020	<b>.746</b>	<b>.438</b>	<b>.005 - .010</b>	.748	.511	.010 - .020	.749	.620	.015 - .030
.734	.198	.070 - .090	.740	.143	.070 - .080	.743	.630	.016 - .025	.746	.445	.040 - .060	.748	.513	.070 - .090	.749	.626	.040 - .060
.734	.203	.040 - .060	<b>.740</b>	<b>.200</b>	<b>.005 - .010</b>	.744	.187	.100 - .120	.746	.469	.030 - .060	<b>.748</b>	<b>.553</b>	<b>.005 - .010</b>	.749	.633	.010 - .020
.734	.203	.060 - .080	<b>.740</b>	<b>.206</b>	<b>.005 - .010</b>	.744	.215	.030 - .050	.746	.480	.015 - .025	.748	.563	.015 - .030	.749	.640	.030 - .050
.734	.258	.040 - .060	<b>.740</b>	<b>.318</b>	<b>.005 - .010</b>	.744	.236	.010 - .020	.746	.499	.020 - .040	.748	.570	.005 - .012	<b>.749</b>	<b>.644</b>	<b>.005 - .010</b>
.734	.260	.032 - .050	.740	.341	.050 - .070	.744	.262	.015 - .030	.746	.500	.005 - .012	.748	.573	.012 - .020	.749	.650	.040 - .050
.734	.316	.010 - .020	.740	.344	.020 - .030	.744	.370	.015 - .030	<b>.746</b>	<b>.521</b>	<b>.005 - .010</b>	<b>.748</b>	<b>.582</b>	<b>.005 - .010</b>	<b>.749</b>	<b>.669</b>	<b>.005 - .010</b>
.734	.376	.030 - .050	.740	.352	.020 - .040	.744	.383	.035 - .050	.746	.531	.005 - .012	.748	.626	.040 - .060			
.734	.380	.010 - .015	.740	.377	.050 - .075	<b>.744</b>	<b>.388</b>	<b>.005 - .010</b>	.746	.531	.010 - .020	.748	.632	.015 - .030			
.734	.406	.050 - .075	.740	.377	.062 - .093	.744	.403	.031 - .048	.746	.533	.030 - .050	<b>.748</b>	<b>.634</b>	<b>.005 - .010</b>			
.734	.406	.090 - .105	.740	.380	.030 - .060	.744	.409	.050 - .070	.746	.565	.075 - .090	.748	.634	.020 - .030			
.734	.406	.100 - .125	.740	.380	.100 - .125	.744	.413	.105 - .125	.746	.579	.025 - .048	.748	.635	.015 - .025			
.734	.420	.093 - .130	<b>.740</b>	<b>.386</b>	<b>.005 - .010</b>	<b>.744</b>	<b>.430</b>	<b>.005 - .010</b>	.746	.608	.050 - .070	.748	.644	.025 - .040			
.734	.466	.060 - .075	<b>.740</b>	<b>.390</b>	<b>.005 - .010</b>	.744	.449	.060 - .080	<b>.746</b>	<b>.621</b>	<b>.005 - .010</b>	.748	.670	.005 - .015			
.734	.485	.020 - .030	.740	.390	.030 - .050	.744	.450	.050 - .075	.746	.634	.010 - .020	<b>.748</b>	<b>.693</b>	<b>.005 - .010</b>			
.734	.515	.030 - .042	<b>.740</b>	<b>.391</b>	<b>.005 - .010</b>	.744	.500	.005 - .012	<b>.746</b>	<b>.670</b>	<b>.005 - .010</b>	.749	.064	.030 - .050	.750	.063	.025 - .048
<b>.734</b>	<b>.531</b>	<b>.005 - .010</b>	.740	.410	.105 - .125	<b>.744</b>	<b>.504</b>	<b>.005 - .010</b>	.747	.131	.025 - .040	.749	.087	.015 - .030	<b>.750</b>	<b>.078</b>	<b>.005 - .010</b>
.734	.630	.032 - .048	.740	.412	.062 - .075	.744	.507	.040 - .062	.747	.143	.030 - .050	.749	.160	.008 - .016	.750	.090	.010 - .015
.735	.282	.050 - .070	<b>.740</b>	<b>.439</b>	<b>.005 - .010</b>	.744	.507	.060 - .075	.747	.214	.065 - .080	.749	.161	.060 - .090	.750	.096	.060 - .090
.735	.321	.030 - .060	.740	.440	.010 - .020	.744	.532	.010 - .020	<b>.747</b>	<b>.235</b>	<b>.005 - .010</b>	.749	.181	.060 - .090	.750	.102	.015 - .025
.735	.346	.050 - .060	.740	.453	.020 - .040	<b>.744</b>	<b>.561</b>	<b>.005 - .010</b>	.747	.261	.015 - .025	.749	.190	.010 - .020	<b>.750</b>	<b>.118</b>	<b>.005 - .010</b>
.735	.346	.060 - .080	<b>.740</b>	<b>.489</b>	<b>.005 - .010</b>	.744	.599	.005 - .012	<b>.747</b>	<b>.315</b>	<b>.005 - .010</b>	.749	.194	.090 - .125	.750	.125	.012 - .025
.735	.369	.060 - .080	.740	.489	.015 - .030	<b>.745</b>	<b>.095</b>	<b>.005 - .010</b>	.747	.316	.030 - .040	.749	.200	.020 - .042	<b>.750</b>	<b>.126</b>	<b>.005 - .010</b>
.735	.380	.105 - .156	.740	.489	.030 - .040	.745	.120	.015 - .030	.747	.317	.040 - .060	.749	.203	.125 - .156	<b>.750</b>	<b>.128</b>	<b>.005 - .010</b>
.735	.385	.020 - .030	.740	.489	.070 - .080	.745	.120	.030 - .040	.747	.324	.020 - .030	<b>.749</b>	<b>.204</b>	<b>.005 - .010</b>	.750	.129	.090 - .104
<b>.735</b>	<b>.393</b>	<b>.005 - .010</b>	.740	.501	.008 - .015	.745	.126	.032 - .050	.747	.376	.010 - .020	.749	.204	.042 - .060	<b>.750</b>	<b>.134</b>	<b>.005 - .010</b>
.735	.393	.090 - .110	.740	.502	.080 - .100	.745	.143	.035 - .055	.747	.377	.010 - .015	.749	.220	.105 - .135	.750	.146	.010 - .025
.735	.401																

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.750	.190	.105 - .125	.750	.320	.015 - .025	<b>.750</b>	<b>.500</b>	<b>.005 - .010</b>	.751	.205	.060 - .080	.752	.303	.005 - .012	.760	.126	.015 - .030
.750	.191	.050 - .075	<b>.750</b>	<b>.321</b>	<b>.005 - .010</b>	.750	.500	.010 - .020	.751	.206	.040 - .075	.752	.315	.104 - .135	.760	.150	.020 - .040
.750	.192	.050 - .070	.750	.325	.125 - .156	.750	.500	.030 - .040	.751	.218	.020 - .032	.752	.317	.010 - .020	.760	.256	.080 - .104
.750	.193	.010 - .020	.750	.326	.025 - .040	.750	.500	.040 - .060	.751	.218	.032 - .050	<b>.752</b>	<b>.319</b>	<b>.005 - .010</b>	.760	.260	.030 - .062
.750	.193	.050 - .075	.750	.327	.062 - .090	.750	.502	.005 - .007	.751	.229	.015 - .030	.752	.319	.015 - .030	.760	.322	.050 - .070
.750	.194	.042 - .062	.750	.329	.070 - .090	.750	.502	.010 - .020	<b>.751</b>	<b>.239</b>	<b>.005 - .010</b>	.752	.320	.050 - .070	.760	.385	.040 - .060
<b>.750</b>	<b>.195</b>	<b>.005 - .010</b>	.750	.330	.025 - .040	.750	.502	.080 - .100	.751	.242	.080 - .105	<b>.752</b>	<b>.322</b>	<b>.005 - .010</b>	.760	.482	.040 - .060
.750	.195	.100 - .125	<b>.750</b>	<b>.331</b>	<b>.005 - .010</b>	<b>.750</b>	<b>.503</b>	<b>.005 - .010</b>	.751	.244	.050 - .070	<b>.752</b>	<b>.340</b>	<b>.005 - .010</b>	.760	.565	.020 - .040
<b>.750</b>	<b>.197</b>	<b>.005 - .010</b>	<b>.750</b>	<b>.333</b>	<b>.005 - .010</b>	.750	.503	.010 - .020	.751	.250	.080 - .100	.752	.375	.062 - .075	.760	.571	.070 - .090
.750	.198	.025 - .040	.750	.337	.042 - .072	.750	.504	.015 - .025	.751	.250	.125 - .140	<b>.752</b>	<b>.379</b>	<b>.090 - .110</b>	.760	.579	.005 - .008
.750	.198	.080 - .105	.750	.344	.075 - .100	.750	.505	.025 - .042	.751	.255	.050 - .070	.752	.380	.090 - .120	.760	.592	.020 - .035
.750	.200	.030 - .060	<b>.750</b>	<b>.345</b>	<b>.005 - .010</b>	.750	.505	.030 - .050	.751	.257	.050 - .070	.752	.388	.050 - .070	.760	.624	.020 - .030
.750	.203	.030 - .050	.750	.345	.060 - .090	.750	.505	.083 - .105	.751	.265	.005 - .015	<b>.752</b>	<b>.389</b>	<b>.005 - .010</b>	<b>.760</b>	<b>.664</b>	<b>.005 - .010</b>
.750	.204	.050 - .070	.750	.345	.090 - .125	<b>.750</b>	<b>.506</b>	<b>.005 - .010</b>	.751	.266	.032 - .050	.752	.406	.060 - .083	.761	.141	.005 - .015
.750	.206	.070 - .090	.750	.350	.072 - .090	.750	.506	.010 - .020	.751	.272	.100 - .125	.752	.431	.090 - .125	.761	.184	.005 - .015
.750	.209	.030 - .050	.750	.356	.070 - .080	.750	.510	.010 - .020	.751	.296	.050 - .070	.752	.461	.008 - .012	.761	.561	.030 - .050
<b>.750</b>	<b>.218</b>	<b>.005 - .010</b>	.750	.359	.015 - .020	.750	.511	.030 - .060	<b>.751</b>	<b>.303</b>	<b>.005 - .010</b>	.752	.475	.030 - .050	<b>.762</b>	<b>.250</b>	<b>.005 - .010</b>
.750	.223	.125 - .156	.750	.359	.100 - .125	<b>.750</b>	<b>.512</b>	<b>.005 - .010</b>	.751	.315	.015 - .030	.752	.502	.008 - .012	.762	.445	.040 - .060
<b>.750</b>	<b>.229</b>	<b>.005 - .010</b>	.750	.362	.050 - .075	.750	.512	.050 - .075	.751	.322	.050 - .075	.752	.504	.010 - .020	<b>.762</b>	<b>.616</b>	<b>.005 - .010</b>
.750	.232	.050 - .075	<b>.750</b>	<b>.364</b>	<b>.005 - .010</b>	.750	.513	.010 - .020	.751	.325	.015 - .030	.752	.504	.030 - .050	<b>.763</b>	<b>.660</b>	<b>.005 - .010</b>
.750	.242	.030 - .050	.750	.374	.010 - .020	.750	.513	.025 - .040	.751	.331	.075 - .093	.752	.505	.015 - .030	.764	.315	.050 - .075
.750	.250	.005 - .015	<b>.750</b>	<b>.375</b>	<b>.005 - .010</b>	.750	.513	.050 - .075	<b>.751</b>	<b>.332</b>	<b>.005 - .010</b>	.752	.516	.005 - .015	.764	.528	.060 - .080
.750	.250	.048 - .062	.750	.376	.010 - .020	.750	.514	.100 - .125	.751	.335	.090 - .125	.752	.555	.040 - .050	<b>.764</b>	<b>.707</b>	<b>.005 - .010</b>
<b>.750</b>	<b>.251</b>	<b>.005 - .010</b>	.750	.376	.040 - .060	.750	.517	.030 - .050	.751	.343	.025 - .040	.752	.555	.050 - .070	.765	.117	.040 - .062
.750	.251	.015 - .030	.750	.376	.100 - .125	.750	.525	.050 - .070	<b>.751</b>	<b>.361</b>	<b>.005 - .010</b>	.752	.564	.050 - .070	.765	.222	.030 - .050
<b>.750</b>	<b>.252</b>	<b>.005 - .010</b>	<b>.750</b>	<b>.377</b>	<b>.005 - .010</b>	.750	.530	.040 - .060	.751	.376	.005 - .015	.752	.591	.060 - .090	.765	.265	.100 - .125
.750	.252	.032 - .042	.750	.378	.005 - .008	.750	.530	.090 - .105	.751	.379	.040 - .060	.752	.624	.050 - .070	<b>.765</b>	<b>.285</b>	<b>.005 - .010</b>
.750	.252	.050 - .070	.750	.378	.156 - .187	.750	.531	.010 - .020	<b>.751</b>	<b>.380</b>	<b>.005 - .010</b>	.753	.133	.075 - .090	.765	.293	.040 - .060
.750	.252	.060 - .080	.750	.379	.015 - .030	.750	.532	.020 - .032	.751	.380	.010 - .020	.753	.276	.010 - .020	.765	.312	.050 - .062
.750	.253	.025 - .040	.750	.379	.030 - .040	.750	.532	.100 - .125	.751	.387	.105 - .125	.753	.318	.050 - .070	.765	.331	.025 - .040
<b>.750</b>	<b>.254</b>	<b>.005 - .010</b>	.750	.381	.048 - .062	.750	.533	.050 - .070	.751	.395	.020 - .030	.753	.330	.110 - .130	.765	.348	.025 - .035
.750	.254	.080 - .100	.750	.382	.020 - .040	.750	.536	.040 - .060	.751	.400	.050 - .080	.753	.337	.100 - .125	<b>.765</b>	<b>.406</b>	<b>.005 - .010</b>
.750	.256	.040 - .060	.750	.383	.060 - .083	.750	.545	.015 - .030	.751	.420	.110 - .130	.753	.375	.100 - .125	<b>.765</b>	<b>.508</b>	<b>.005 - .010</b>
.750	.257	.090 - .120	<b>.750</b>	<b>.384</b>	<b>.005 - .010</b>	<b>.750</b>	<b>.549</b>	<b>.005 - .010</b>	<b>.751</b>	<b>.435</b>	<b>.005 - .010</b>	.753	.381	.134 - .187	.765	.533	.015 - .030
<b>.750</b>	<b>.259</b>	<b>.005 - .010</b>	.750	.384	.010 - .020	.750	.550	.020 - .030	.751	.438	.050 - .070	.753	.384	.050 - .070	.765	.625	.050 - .070
.750	.259	.010 - .020	<b>.750</b>	<b>.385</b>	<b>.005 - .010</b>	.750	.551	.010 - .020	.751	.440	.050 - .070	.753	.405	.050 - .072	.766	.505	.030 - .050
.750	.259	.020 - .032	.750	.387	.050 - .080	.750	.562	.040 - .060	.751	.448	.050 - .070	.753	.472	.100 - .120	.766	.518	.050 - .070
.750	.260	.090 - .104	.750	.388	.025 - .040	.750	.563	.010 - .020	.751	.455	.010 - .020	.753	.484	.025 - .050	.766	.535	.080 - .100
.750	.260	.100 - .125	.750	.389	.050 - .070	.750	.563	.040 - .060	.751	.463	.050 - .070	.753	.526	.030 - .060	.766	.557	.025 - .040
.750	.261	.060 - .080	.750	.390	.007 - .015	<b>.750</b>	<b>.564</b>	<b>.005 - .010</b>	.751	.470	.075 - .090	<b>.753</b>	<b>.527</b>	<b>.005 - .010</b>	.766	.585	.015 - .030
.750	.264	.005 - .015	.750	.390	.025 - .040	.750	.564	.030 - .060	<b>.751</b>	<b>.499</b>	<b>.005 - .010</b>	.753	.609	.025 - .050	.766	.610	.030 - .050
.750	.264	.062 - .083	.750	.390	.080 - .105	.750	.565	.010 - .020	.751	.499	.010 - .020	.753	.627	.005 - .015	<b>.766</b>	<b>.676</b>	<b>.005 - .010</b>
.750	.264	.080 - .104	.750	.391	.050 - .070	.750	.565	.020 - .040	.751	.499	.015 - .025	.754	.265	.030 - .060	.767	.073	.025 - .040
.750	.265	.050 - .070	.750	.394	.100 - .125	.750	.566	.012 - .020	.751	.500	.050 - .070	<b>.754</b>	<b>.393</b>	<b>.005 - .010</b>	.767	.084	.015 - .030
.750	.265	.090 - .120	.750	.395	.020 - .050	.750	.569	.050 - .062	<b>.751</b>	<b>.503</b>	<b>.005 - .010</b>	.754	.428	.048 - .062	.767	.224	.090 - .110
.750	.266	.072 - .090	.750	.396	.060 - .070	.750	.582	.030 - .050	.751	.503	.036 - .060	.754	.469	.040 - .060	.767	.301	.100 - .125
.750	.266	.120 - .135	.750	.402	.042 - .060	<b>.750</b>	<b>.584</b>	<b>.005 - .010</b>	.751	.503	.080 - .090	.754	.509	.030 - .050	.767	.576	.030 - .050
.750	.267	.010 - .025	.750	.406	.010 - .020	<b>.750</b>	<b>.590</b>	<b>.005 - .010</b>	.751	.503	.090 - .110	.754	.532	.080 - .105	.767	.588	.015 - .030
.750	.268	.010 - .020	.750	.406	.020 - .030	<b>.750</b>	<b>.595</b>	<b>.005 - .010</b>	.751	.504	.010 - .020	<b>.755</b>	<b>.222</b>	<b>.005 - .010</b>	<b>.767</b>	<b>.699</b>	<b>.005 - .010</b>
.750	.268	.060 - .080	.750	.407	.120 - .134	.750	.595	.010 - .020	.751	.504	.060 - .080	<b>.755</b>	<b>.281</b>	<b>.005 - .010</b>	.768	.235	.040 - .060
<b>.750</b>	<b>.270</b>	<b>.005 - .010</b>	.750	.413	.005 - .015	<b>.750</b>	<b>.625</b>	<b>.005 - .010</b>	.751	.505	.010 - .020	.755	.378	.060 - .080	.768	.378	.110 - .130
<b>.750</b>	<b>.277</b>	<b>.005 - .010</b>	<b>.750</b>	<b>.415</b>	<b>.005 - .010</b>	.750	.625	.025 - .040	.751	.505	.035 - .050	.755	.385	.025 - .042	.768	.415	.050 - .070
<b>.750</b>	<b>.281</b>	<b>.005 - .010</b>	.750	.419	.080 - .100	.750	.625	.036 - .050	.751	.505	.080 - .105	<b>.755</b>	<b>.393</b>	<b>.005 - .010</b>	.768	.416	.050 - .070
.750	.281	.032 - .042	.750	.420	.105 - .125	.750	.626	.015 - .030	.751	.506	.015 - .025	.755	.513	.030 - .040	.768	.471	.010 - .020
.750	.281	.062 - .078	<b>.750</b>	<b>.426</b>	<b>.005 - .010</b>	.750	.630	.005 - .015	.751	.508	.020 - .030	.755	.532	.020 - .040	.768	.530	.010 - .020
.750	.282	.105 - .135	<b>.750</b>	<b>.437</b>	<b>.005 - .010</b>	.750	.630	.040 - .060	.751	.513	.090 - .120	.755	.552	.030 - .040	.768	.530	.020 - .030
.750	.283	.170 - .190	.750	.438	.040 - .062	<b>.750</b>	<b>.632</b>	<b>.005 - .010</b>	.751	.515	.025 - .040	<b>.755</b>	<b>.554</b>	<b>.005 - .010</b>	.768	.545	.020 - .040
.750	.285	.															

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.771	.554	.010 - .020	.780	.422	.015 - .025	.784	.612	.020 - .030	.787	.551	.010 - .020	.791	.056	.015 - .030	.799	.671	.005 - .010
.771	.639	.050 - .060	.780	.422	.025 - .040	.785	.170	.042 - .062	.787	.551	.020 - .030	.791	.323	.050 - .070	.799	.673	.005 - .010
<b>.771</b>	<b>.700</b>	<b>.005 - .010</b>	.780	.425	.010 - .020	.785	.238	.006 - .010	<b>.787</b>	<b>.577</b>	<b>.005 - .010</b>	.791	.400	.010 - .020	<b>.799</b>	<b>.674</b>	<b>.005 - .010</b>
.772	.188	.020 - .040	.780	.460	.030 - .060	<b>.785</b>	<b>.343</b>	<b>.005 - .010</b>	<b>.787</b>	<b>.603</b>	<b>.005 - .010</b>	.791	.401	.025 - .040	<b>.799</b>	<b>.694</b>	<b>.005 - .010</b>
.772	.250	.040 - .060	<b>.780</b>	<b>.484</b>	<b>.005 - .010</b>	<b>.785</b>	<b>.357</b>	<b>.005 - .010</b>	<b>.787</b>	<b>.610</b>	<b>.005 - .010</b>	.791	.531	.010 - .020	<b>.799</b>	<b>.701</b>	<b>.005 - .010</b>
<b>.772</b>	<b>.404</b>	<b>.005 - .010</b>	.780	.498	.080 - .104	.785	.392	.110 - .130	.787	.610	.060 - .080	.791	.674	.010 - .020	.800	.190	.020 - .040
.772	.412	.050 - .060	.780	.500	.015 - .030	<b>.785</b>	<b>.406</b>	<b>.005 - .010</b>	.787	.630	.030 - .050	.792	.317	.062 - .083	.800	.194	.050 - .070
<b>.773</b>	<b>.126</b>	<b>.005 - .010</b>	.780	.503	.006 - .012	.785	.450	.050 - .070	<b>.787</b>	<b>.631</b>	<b>.005 - .010</b>	.792	.420	.020 - .030	.800	.200	.025 - .040
.773	.238	.062 - .080	<b>.780</b>	<b>.510</b>	<b>.005 - .010</b>	.785	.475	.015 - .025	.787	.648	.025 - .040	.792	.485	.025 - .040	.800	.222	.065 - .080
.773	.370	.060 - .080	.780	.510	.015 - .030	.785	.475	.030 - .050	<b>.787</b>	<b>.661</b>	<b>.005 - .010</b>	.792	.517	.010 - .020	.800	.225	.040 - .060
.773	.480	.015 - .030	.780	.511	.030 - .050	.785	.482	.100 - .125	.787	.680	.060 - .080	<b>.792</b>	<b>.606</b>	<b>.005 - .010</b>	.800	.250	.020 - .030
.773	.656	.020 - .040	.780	.520	.007 - .015	.785	.512	.060 - .080	<b>.787</b>	<b>.697</b>	<b>.005 - .010</b>	.792	.672	.010 - .020	.800	.252	.008 - .015
<b>.773</b>	<b>.692</b>	<b>.005 - .010</b>	.780	.527	.075 - .090	<b>.785</b>	<b>.523</b>	<b>.005 - .010</b>	.788	.128	.010 - .020	.792	.695	.015 - .030	.800	.254	.025 - .040
.774	.251	.050 - .070	.780	.529	.025 - .040	.785	.523	.010 - .020	.788	.218	.040 - .060	.793	.438	.080 - .100	<b>.800</b>	<b>.256</b>	<b>.005 - .010</b>
.774	.556	.050 - .070	.780	.562	.031 - .048	.785	.530	.030 - .050	<b>.788</b>	<b>.227</b>	<b>.005 - .010</b>	.793	.439	.060 - .090	.800	.315	.010 - .020
.774	.605	.010 - .020	.780	.566	.030 - .050	.785	.548	.042 - .062	.788	.237	.080 - .100	.793	.471	.025 - .048	<b>.800</b>	<b>.316</b>	<b>.005 - .010</b>
.774	.634	.010 - .020	.780	.579	.005 - .015	<b>.785</b>	<b>.594</b>	<b>.005 - .010</b>	.788	.243	.030 - .050	.793	.505	.025 - .040	.800	.320	.105 - .125
<b>.774</b>	<b>.705</b>	<b>.005 - .010</b>	.780	.591	.060 - .090	<b>.785</b>	<b>.656</b>	<b>.005 - .010</b>	.788	.317	.010 - .020	.793	.575	.032 - .050	.800	.327	.020 - .040
.775	.228	.050 - .072	<b>.780</b>	<b>.593</b>	<b>.005 - .010</b>	.786	.157	.015 - .030	<b>.788</b>	<b>.322</b>	<b>.005 - .010</b>	<b>.794</b>	<b>.285</b>	<b>.005 - .010</b>	.800	.345	.075 - .104
.775	.231	.042 - .062	.780	.598	.050 - .070	.786	.198	.015 - .030	.788	.355	.010 - .020	.794	.420	.090 - .110	.800	.370	.005 - .012
<b>.775</b>	<b>.252</b>	<b>.005 - .010</b>	.780	.627	.020 - .030	.786	.253	.070 - .090	<b>.788</b>	<b>.376</b>	<b>.005 - .010</b>	.794	.477	.135 - .160	<b>.800</b>	<b>.377</b>	<b>.005 - .010</b>
.775	.324	.100 - .125	.780	.640	.030 - .050	<b>.786</b>	<b>.257</b>	<b>.005 - .010</b>	.788	.394	.125 - .156	.794	.552	.070 - .090	<b>.800</b>	<b>.378</b>	<b>.005 - .010</b>
.775	.335	.015 - .030	.780	.640	.050 - .070	<b>.786</b>	<b>.300</b>	<b>.005 - .010</b>	<b>.788</b>	<b>.395</b>	<b>.005 - .010</b>	<b>.795</b>	<b>.116</b>	<b>.005 - .010</b>	.800	.378	.015 - .030
.775	.368	.080 - .090	.780	.672	.015 - .030	<b>.786</b>	<b>.382</b>	<b>.005 - .010</b>	.788	.397	.005 - .015	<b>.795</b>	<b>.159</b>	<b>.005 - .010</b>	.800	.378	.062 - .078
.775	.379	.005 - .012	.780	.684	.025 - .040	.786	.396	.040 - .060	.788	.403	.005 - .008	.795	.170	.090 - .125	.800	.379	.010 - .020
.775	.428	.025 - .040	.780	.685	.005 - .012	.786	.436	.050 - .070	.788	.403	.015 - .030	<b>.795</b>	<b>.175</b>	<b>.005 - .010</b>	.800	.380	.040 - .060
<b>.775</b>	<b>.457</b>	<b>.005 - .010</b>	.781	.111	.025 - .040	.786	.443	.100 - .120	.788	.414	.020 - .040	.795	.187	.030 - .050	.800	.387	.020 - .040
.775	.464	.048 - .070	.781	.142	.010 - .020	.786	.446	.040 - .060	<b>.788</b>	<b>.440</b>	<b>.005 - .010</b>	.795	.197	.008 - .016	<b>.800</b>	<b>.397</b>	<b>.005 - .010</b>
.775	.469	.080 - .100	.781	.172	.010 - .020	.786	.452	.010 - .020	<b>.788</b>	<b>.452</b>	<b>.005 - .010</b>	.795	.267	.048 - .062	<b>.800</b>	<b>.398</b>	<b>.005 - .010</b>
.775	.500	.075 - .090	<b>.781</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.786</b>	<b>.474</b>	<b>.005 - .010</b>	.788	.476	.030 - .050	.795	.281	.040 - .060	.800	.426	.105 - .135
.775	.525	.100 - .125	.781	.317	.010 - .030	<b>.786</b>	<b>.477</b>	<b>.005 - .010</b>	.788	.478	.030 - .050	.795	.340	.005 - .012	<b>.800</b>	<b>.437</b>	<b>.005 - .010</b>
.775	.555	.020 - .030	<b>.781</b>	<b>.335</b>	<b>.005 - .010</b>	.786	.502	.010 - .020	.788	.483	.070 - .090	.795	.392	.010 - .020	.800	.439	.030 - .050
.775	.643	.005 - .015	.781	.402	.010 - .020	<b>.786</b>	<b>.505</b>	<b>.005 - .010</b>	.788	.487	.040 - .060	.795	.427	.090 - .105	<b>.800</b>	<b>.440</b>	<b>.005 - .010</b>
.775	.643	.015 - .030	.781	.430	.048 - .062	.786	.505	.010 - .020	.788	.488	.040 - .050	.795	.482	.030 - .050	.800	.441	.010 - .020
.776	.196	.015 - .030	.781	.448	.015 - .030	.786	.515	.010 - .020	.788	.512	.060 - .090	.795	.509	.030 - .060	<b>.800</b>	<b>.442</b>	<b>.005 - .010</b>
.776	.197	.020 - .035	<b>.781</b>	<b>.485</b>	<b>.005 - .010</b>	.786	.531	.020 - .030	.788	.521	.048 - .062	.795	.577	.090 - .105	.800	.464	.040 - .060
.776	.240	.025 - .040	.781	.488	.050 - .060	.786	.535	.005 - .012	<b>.788</b>	<b>.545</b>	<b>.005 - .010</b>	.795	.655	.030 - .040	.800	.490	.030 - .050
.776	.283	.030 - .050	.781	.501	.005 - .015	.786	.535	.015 - .030	.788	.555	.040 - .060	<b>.795</b>	<b>.680</b>	<b>.005 - .010</b>	.800	.502	.010 - .020
<b>.776</b>	<b>.386</b>	<b>.005 - .010</b>	.781	.518	.040 - .060	.786	.556	.040 - .060	.788	.566	.080 - .100	.795	.680	.030 - .040	.800	.504	.005 - .015
.776	.432	.070 - .090	.781	.531	.008 - .012	.786	.572	.050 - .070	.788	.596	.030 - .050	.795	.730	.025 - .035	.800	.504	.015 - .030
.776	.598	.050 - .070	.781	.557	.020 - .040	.786	.594	.010 - .020	.788	.697	.010 - .015	.795	.731	.030 - .040	<b>.800</b>	<b>.505</b>	<b>.005 - .010</b>
.776	.646	.020 - .040	.781	.600	.015 - .030	.786	.598	.030 - .050	.789	.114	.025 - .040	<b>.796</b>	<b>.286</b>	<b>.005 - .010</b>	<b>.800</b>	<b>.505</b>	<b>.005 - .010</b>
.776	.653	.040 - .050	.781	.605	.032 - .050	.786	.626	.030 - .050	<b>.789</b>	<b>.221</b>	<b>.005 - .010</b>	.796	.290	.025 - .040	.800	.510	.020 - .040
.777	.328	.156 - .187	.781	.621	.040 - .060	.786	.631	.030 - .050	.789	.255	.010 - .020	.796	.353	.030 - .040	.800	.530	.030 - .050
.777	.392	.020 - .030	.781	.625	.050 - .075	.787	.129	.030 - .050	.789	.262	.040 - .050	.796	.397	.050 - .070	<b>.800</b>	<b>.544</b>	<b>.005 - .010</b>
.777	.421	.025 - .040	.781	.627	.040 - .060	.787	.141	.040 - .060	.789	.312	.042 - .060	.796	.509	.040 - .060	.800	.550	.060 - .075
<b>.777</b>	<b>.572</b>	<b>.005 - .010</b>	<b>.781</b>	<b>.628</b>	<b>.005 - .010</b>	.787	.142	.030 - .060	<b>.789</b>	<b>.316</b>	<b>.005 - .010</b>	.796	.520	.005 - .012	<b>.800</b>	<b>.551</b>	<b>.005 - .010</b>
.777	.613	.050 - .070	.781	.629	.025 - .042	.787	.161	.050 - .070	<b>.789</b>	<b>.326</b>	<b>.005 - .010</b>	.796	.521	.030 - .060	<b>.800</b>	<b>.557</b>	<b>.005 - .010</b>
.778	.221	.010 - .015	.781	.629	.040 - .060	.787	.203	.040 - .060	.789	.354	.060 - .080	.796	.525	.010 - .020	<b>.800</b>	<b>.558</b>	<b>.005 - .010</b>
.778	.266	.062 - .075	.781	.640	.060 - .070	.787	.228	.052 - .072	<b>.789</b>	<b>.438</b>	<b>.005 - .010</b>	.796	.579	.040 - .060	.800	.558	.010 - .015
.778	.363	.070 - .090	.782	.368	.010 - .020	<b>.787</b>	<b>.238</b>	<b>.005 - .010</b>	.789	.478	.050 - .070	.796	.602	.025 - .040	.800	.560	.070 - .090
.778	.386	.030 - .050	.782	.437	.090 - .105	.787	.256	.010 - .020	.789	.478	.070 - .080	<b>.796</b>	<b>.610</b>	<b>.005 - .010</b>	.800	.575	.025 - .040
.778	.408	.020 - .040	.782	.440	.015 - .030	.787	.257	.025 - .040	<b>.789</b>	<b>.498</b>	<b>.005 - .010</b>	.796	.610	.050 - .070	<b>.800</b>	<b>.582</b>	<b>.005 - .010</b>
.778	.435	.120 - .135	.782	.442	.070 - .090	.787	.257	.040 - .060	.789	.543	.010 - .020	.796	.630	.030 - .040	<b>.800</b>	<b>.594</b>	<b>.005 - .010</b>
.778	.534	.062 - .078	.782	.482	.070 - .090	<b>.787</b>	<b>.279</b>	<b>.005 - .010</b>	.789	.630	.010 - .020	<b>.797</b>	<b>.349</b>	<b>.005 - .010</b>	<b>.800</b>	<b>.619</b>	<b>.005 - .010</b>
.779	.190	.030 - .050	.782	.500	.030 - .060	<b>.787</b>	<b>.315</b>	<b>.005 - .010</b>	.790	.175	.050 - .070	<b>.797</b>	<b>.413</b>	<b>.005 - .010</b>	.800	.623	.050 - .075
.779	.264	.025 - .040	.782	.513	.030 - .050	.787	.315	.010 - .020	.790	.250	.032 - .042	.797	.561	.020 - .040	.800	.628	.025 - .040
.779	.270	.060 - .090	.782	.517	.080 - .100	<b>.787</b>	<b>.317</b>	<b>.005 - .010</b>	<b>.790</b>	<b>.319</b>	<b>.005 - .010</b>	.797	.691	.025 - .040	.800	.628	.036 - .050
.779	.323	.015 - .030	.782	.530	.093 - .103	<b>.787</b>	<b>.318</b>	<b>.005 - .010</b>	<b>.790</b>	<b>.320</b>	<b>.005 - .010</b>	.798	.312	.010 - .025	.800	.628	.060 - .080
.779	.378	.090 - .105	<b>.782</b>	<b>.542</b>	<b>.005 - .010</b>	<b>.787</b>	<b>.319</b>	<b>.005 - .010</b>	.790	.350	.025 - .048	<b>.798</b>	<b>.378</b>	<b>.005 - .010</b>	.800	.631	.010 - .020
.779	.395	.032 - .060	.782	.546	.010 - .020	.787	.324	.015 - .030	.790	.375	.015 - .030	<b>.798</b>	<b>.578</b>	<b>.005 - .010</b>	<b>.800</b>	<b>.639</b>	<b>.005 - .010</b>
.779	.422	.030 - .050	.782	.562	.060 - .083	<b>.787</b>	<b>.329</b>	<b>.005 - .010</b>	.790	.377	.020 - .040	.798	.578</				

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.801	.376	.015 - .030	.809	.096	.015 - .032	.811	.576	.026 - .052	.813	.435	.100 - .125	<b>.820</b>	<b>.315</b>	<b>.005 - .010</b>	.828	.317	.010 - .015
.801	.400	.025 - .040	.809	.099	.005 - .015	.811	.577	.025 - .042	.813	.441	.050 - .070	.820	.320	.040 - .060	.828	.407	.015 - .030
<b>.801</b>	<b>.439</b>	<b>.005 - .010</b>	.809	.157	.050 - .070	.811	.595	.035 - .060	.813	.450	.040 - .060	<b>.820</b>	<b>.348</b>	<b>.005 - .010</b>	.828	.447	.060 - .080
<b>.801</b>	<b>.490</b>	<b>.005 - .010</b>	.809	.250	.020 - .030	<b>.811</b>	<b>.623</b>	<b>.005 - .010</b>	<b>.813</b>	<b>.493</b>	<b>.005 - .010</b>	<b>.820</b>	<b>.380</b>	<b>.005 - .010</b>	.828	.499	.005 - .008
.801	.502	.015 - .025	.809	.257	.030 - .050	<b>.811</b>	<b>.630</b>	<b>.005 - .010</b>	.813	.500	.050 - .083	.820	.392	.010 - .020	<b>.828</b>	<b>.504</b>	<b>.005 - .010</b>
<b>.801</b>	<b>.505</b>	<b>.005 - .010</b>	.809	.288	.070 - .090	<b>.811</b>	<b>.656</b>	<b>.005 - .010</b>	.813	.504	.105 - .135	.820	.395	.050 - .075	.828	.504	.010 - .020
.801	.596	.015 - .025	.809	.321	.025 - .042	.811	.658	.020 - .030	.813	.510	.020 - .040	.820	.405	.135 - .160	<b>.828</b>	<b>.530</b>	<b>.005 - .010</b>
.801	.598	.015 - .030	.809	.336	.050 - .070	.812	.127	.025 - .040	.813	.562	.080 - .100	.820	.442	.025 - .040	.828	.590	.015 - .030
.801	.629	.040 - .060	<b>.809</b>	<b>.377</b>	<b>.005 - .010</b>	.812	.130	.015 - .030	<b>.813</b>	<b>.563</b>	<b>.005 - .010</b>	.820	.450	.012 - .025	<b>.828</b>	<b>.655</b>	<b>.005 - .010</b>
.801	.650	.010 - .020	<b>.809</b>	<b>.385</b>	<b>.005 - .010</b>	.812	.136	.040 - .060	.813	.563	.010 - .020	.820	.453	.015 - .025	<b>.828</b>	<b>.727</b>	<b>.005 - .010</b>
<b>.801</b>	<b>.657</b>	<b>.005 - .010</b>	.809	.414	.070 - .090	.812	.141	.005 - .015	.813	.597	.020 - .040	.820	.482	.070 - .090	.829	.137	.025 - .048
<b>.801</b>	<b>.674</b>	<b>.005 - .010</b>	.809	.475	.070 - .090	.812	.141	.015 - .040	.813	.631	.010 - .020	<b>.820</b>	<b>.500</b>	<b>.005 - .010</b>	.829	.250	.030 - .050
.802	.257	.060 - .080	.809	.483	.032 - .042	.812	.191	.020 - .040	.813	.634	.060 - .080	.820	.536	.050 - .070	.829	.283	.020 - .030
.802	.261	.040 - .062	<b>.809</b>	<b>.504</b>	<b>.005 - .010</b>	<b>.812</b>	<b>.192</b>	<b>.005 - .010</b>	.813	.659	.035 - .048	.820	.559	.050 - .075	.829	.414	.007 - .090
.802	.346	.020 - .035	.809	.570	.050 - .070	.812	.219	.062 - .075	<b>.813</b>	<b>.680</b>	<b>.005 - .010</b>	.820	.564	.100 - .125	.829	.430	.100 - .125
.802	.387	.050 - .075	.809	.601	.020 - .040	.812	.221	.080 - .100	.813	.680	.010 - .030	.820	.565	.100 - .125	.829	.468	.100 - .125
.802	.453	.025 - .040	<b>.809</b>	<b>.625</b>	<b>.005 - .010</b>	.812	.245	.020 - .036	<b>.813</b>	<b>.728</b>	<b>.005 - .010</b>	<b>.820</b>	<b>.566</b>	<b>.005 - .010</b>	.829	.475	.080 - .104
.802	.516	.040 - .060	<b>.810</b>	<b>.057</b>	<b>.005 - .010</b>	.812	.253	.080 - .104	.814	.412	.060 - .080	.820	.572	.105 - .125	.829	.480	.105 - .135
<b>.802</b>	<b>.596</b>	<b>.005 - .010</b>	.810	.116	.015 - .032	.812	.269	.050 - .070	.814	.522	.040 - .060	<b>.820</b>	<b>.600</b>	<b>.005 - .010</b>	<b>.829</b>	<b>.500</b>	<b>.005 - .010</b>
.802	.611	.025 - .040	.810	.142	.040 - .060	.812	.312	.040 - .060	.814	.532	.090 - .105	.820	.678	.010 - .020	.829	.503	.025 - .040
<b>.802</b>	<b>.701</b>	<b>.005 - .010</b>	.810	.150	.040 - .060	.812	.314	.025 - .042	.814	.598	.050 - .075	.820	.698	.005 - .015	.829	.648	.050 - .070
.802	.704	.025 - .040	.810	.166	.025 - .040	.812	.315	.015 - .030	.814	.628	.020 - .030	.820	.698	.015 - .030	.829	.653	.040 - .060
.802	.752	.005 - .008	<b>.810</b>	<b>.185</b>	<b>.005 - .010</b>	.812	.375	.150 - .180	.814	.637	.042 - .062	.820	.726	.015 - .025	.829	.761	.020 - .030
.803	.261	.050 - .075	.810	.192	.005 - .062	.812	.376	.156 - .190	<b>.814</b>	<b>.641</b>	<b>.005 - .010</b>	.821	.144	.032 - .048	.830	.160	.060 - .090
.803	.264	.010 - .020	.810	.198	.030 - .050	.812	.378	.050 - .062	.814	.751	.020 - .030	.821	.266	.010 - .020	.830	.187	.020 - .040
.803	.345	.080 - .105	.810	.210	.025 - .042	.812	.378	.062 - .083	.815	.129	.020 - .040	.821	.416	.100 - .125	<b>.830</b>	<b>.379</b>	<b>.005 - .010</b>
.803	.422	.015 - .030	.810	.218	.100 - .125	.812	.379	.025 - .032	.815	.221	.020 - .030	<b>.821</b>	<b>.596</b>	<b>.005 - .010</b>	.830	.379	.025 - .035
.803	.517	.105 - .125	.810	.250	.062 - .078	.812	.390	.031 - .048	.815	.255	.060 - .075	.821	.596	.015 - .030	.830	.405	.040 - .060
<b>.803</b>	<b>.569</b>	<b>.005 - .010</b>	.810	.255	.090 - .125	.812	.390	.040 - .060	.815	.260	.048 - .062	<b>.821</b>	<b>.625</b>	<b>.005 - .010</b>	.830	.461	.015 - .030
.803	.715	.010 - .025	.810	.315	.020 - .040	.812	.391	.080 - .100	.815	.281	.105 - .120	.821	.636	.060 - .080	.830	.475	.025 - .040
.804	.134	.050 - .072	<b>.810</b>	<b>.355</b>	<b>.005 - .010</b>	.812	.398	.015 - .030	<b>.815</b>	<b>.309</b>	<b>.005 - .010</b>	.821	.727	.030 - .048	<b>.830</b>	<b>.515</b>	<b>.005 - .010</b>
.804	.191	.060 - .080	.810	.355	.035 - .050	.812	.406	.075 - .090	.815	.439	.025 - .040	.822	.200	.020 - .030	.830	.530	.090 - .120
<b>.804</b>	<b>.313</b>	<b>.005 - .010</b>	<b>.810</b>	<b>.379</b>	<b>.005 - .010</b>	.812	.409	.050 - .072	.815	.444	.005 - .012	.822	.523	.060 - .080	.830	.556	.010 - .025
.804	.330	.050 - .072	.810	.379	.060 - .090	.812	.409	.075 - .090	.815	.468	.025 - .036	.822	.693	.050 - .070	.830	.564	.100 - .125
.804	.409	.100 - .125	.810	.385	.080 - .105	.812	.411	.015 - .125	.815	.500	.015 - .030	<b>.823</b>	<b>.407</b>	<b>.005 - .010</b>	.830	.565	.030 - .050
<b>.804</b>	<b>.602</b>	<b>.005 - .010</b>	<b>.810</b>	<b>.395</b>	<b>.005 - .010</b>	.812	.436	.100 - .125	.815	.527	.080 - .104	.823	.523	.070 - .090	.830	.590	.070 - .090
<b>.805</b>	<b>.312</b>	<b>.005 - .010</b>	.810	.405	.060 - .080	.812	.437	.015 - .030	.815	.555	.030 - .050	<b>.823</b>	<b>.755</b>	<b>.005 - .010</b>	.830	.605	.025 - .040
.805	.564	.090 - .110	.810	.413	.005 - .012	.812	.441	.032 - .048	.815	.556	.015 - .025	.823	.755	.010 - .020	.830	.628	.025 - .040
.805	.573	.060 - .080	.810	.419	.062 - .078	.812	.442	.062 - .075	.815	.578	.080 - .100	<b>.824</b>	<b>.321</b>	<b>.005 - .010</b>	.830	.632	.025 - .040
<b>.805</b>	<b>.632</b>	<b>.005 - .010</b>	<b>.810</b>	<b>.443</b>	<b>.005 - .010</b>	.812	.456	.104 - .125	.815	.669	.025 - .040	<b>.824</b>	<b>.333</b>	<b>.005 - .010</b>	.830	.636	.015 - .030
<b>.805</b>	<b>.656</b>	<b>.005 - .010</b>	.810	.455	.060 - .093	.812	.469	.030 - .050	.816	.439	.015 - .030	.824	.543	.025 - .040	.830	.649	.010 - .020
<b>.805</b>	<b>.672</b>	<b>.005 - .010</b>	.810	.475	.025 - .042	.812	.473	.015 - .020	.816	.456	.070 - .090	.824	.605	.042 - .062	.830	.693	.020 - .035
.805	.692	.010 - .020	<b>.810</b>	<b>.480</b>	<b>.005 - .010</b>	<b>.812</b>	<b>.501</b>	<b>.005 - .010</b>	.816	.510	.005 - .012	<b>.825</b>	<b>.238</b>	<b>.005 - .010</b>	<b>.830</b>	<b>.696</b>	<b>.005 - .010</b>
<b>.806</b>	<b>.209</b>	<b>.005 - .010</b>	.810	.501	.080 - .100	.812	.501	.010 - .020	.816	.520	.015 - .025	<b>.825</b>	<b>.317</b>	<b>.005 - .010</b>	.830	.711	.015 - .030
.806	.262	.040 - .060	.810	.507	.010 - .025	.812	.506	.060 - .080	.817	.319	.060 - .083	<b>.825</b>	<b>.319</b>	<b>.005 - .010</b>	<b>.831</b>	<b>.239</b>	<b>.005 - .010</b>
<b>.806</b>	<b>.300</b>	<b>.005 - .010</b>	.810	.514	.080 - .100	.812	.508	.015 - .025	.817	.321	.015 - .030	.825	.319	.010 - .020	.831	.584	.015 - .025
<b>.806</b>	<b>.350</b>	<b>.005 - .010</b>	.810	.514	.100 - .125	.812	.509	.050 - .075	.817	.455	.060 - .090	<b>.825</b>	<b>.399</b>	<b>.005 - .010</b>	<b>.831</b>	<b>.649</b>	<b>.005 - .010</b>
.806	.378	.060 - .083	.810	.522	.040 - .060	.812	.515	.042 - .060	.817	.505	.050 - .070	.825	.400	.015 - .030	.832	.461	.010 - .025
.806	.407	.030 - .050	.810	.533	.025 - .050	.812	.517	.030 - .040	<b>.817</b>	<b>.631</b>	<b>.005 - .010</b>	.825	.483	.040 - .060	.832	.520	.050 - .070
.806	.469	.030 - .050	.810	.543	.020 - .040	.812	.524	.050 - .070	<b>.817</b>	<b>.660</b>	<b>.005 - .010</b>	.825	.525	.010 - .020	<b>.832</b>	<b>.551</b>	<b>.005 - .010</b>
.806	.631	.020 - .040	.810	.545	.020 - .040	.812	.530	.032 - .042	<b>.817</b>	<b>.661</b>	<b>.005 - .010</b>	.825	.527	.090 - .125	<b>.832</b>	<b>.595</b>	<b>.005 - .010</b>
<b>.806</b>	<b>.636</b>	<b>.005 - .010</b>	<b>.810</b>	<b>.551</b>	<b>.005 - .010</b>	.812	.540	.010 - .020	.817	.690	.012 - .020	.825	.543	.015 - .030	<b>.832</b>	<b>.598</b>	<b>.005 - .010</b>
.806	.641	.060 - .083	.810	.561	.120 - .140	<b>.812</b>	<b>.561</b>	<b>.005 - .010</b>	<b>.817</b>	<b>.711</b>	<b>.005 - .010</b>	.825	.577	.020 - .040	.832	.751	.030 - .040
.806	.650	.050 - .070	.810	.564	.005 - .015	.812	.561	.010 - .030	.817	.750	.010 - .020	.825	.624	.005 - .015	<b>.833</b>	<b>.607</b>	<b>.005 - .010</b>
<b>.806</b>	<b>.671</b>	<b>.005 - .010</b>	.810	.565	.025 - .050	.812	.577	.020 - .040	.818	.264	.030 - .040	<b>.825</b>	<b>.709</b>	<b>.005 - .010</b>	.833	.730	.030 - .042
.806	.691	.020 - .040	.810	.569	.020 - .040	.812	.591	.020 - .030	.818	.317	.030 - .040	.826	.314	.030 - .050	.833	.770	.010 - .020
<b>.806</b>	<b>.692</b>	<b>.005 - .010&lt;/</b>															

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.838	.482	.031 - .048	<b>.846</b>	<b>.327</b>	<b>.005 - .010</b>	.851	.164	.050 - .070	.857	.692	.030 - .050	.862	.312	.025 - .042	.866	.397	.010 - .015
.838	.483	.050 - .075	.846	.455	.030 - .060	<b>.851</b>	<b>.173</b>	<b>.005 - .010</b>	.858	.352	.100 - .125	.862	.407	.015 - .025	.866	.401	.105 - .125
<b>.838</b>	<b>.508</b>	<b>.005 - .010</b>	.846	.456	.035 - .050	.851	.184	.040 - .062	.858	.564	.030 - .060	.862	.427	.020 - .030	<b>.866</b>	<b>.416</b>	<b>.005 - .010</b>
.838	.618	.040 - .060	<b>.846</b>	<b>.639</b>	<b>.005 - .010</b>	.851	.184	.060 - .090	.858	.596	.030 - .050	.862	.518	.090 - .125	<b>.866</b>	<b>.439</b>	<b>.005 - .010</b>
<b>.838</b>	<b>.665</b>	<b>.005 - .010</b>	.846	.639	.020 - .040	.851	.185	.060 - .090	.858	.619	.050 - .070	.862	.529	.050 - .075	<b>.866</b>	<b>.444</b>	<b>.005 - .010</b>
.839	.316	.015 - .030	.846	.658	.032 - .050	.851	.384	.104 - .134	<b>.858</b>	<b>.630</b>	<b>.005 - .010</b>	.862	.538	.015 - .030	<b>.866</b>	<b>.473</b>	<b>.005 - .010</b>
<b>.839</b>	<b>.502</b>	<b>.005 - .010</b>	.846	.662	.010 - .020	.851	.385	.010 - .020	.858	.649	.030 - .050	.862	.572	.060 - .075	<b>.866</b>	<b>.474</b>	<b>.005 - .010</b>
.839	.591	.010 - .015	.846	.663	.030 - .060	<b>.851</b>	<b>.401</b>	<b>.005 - .010</b>	.858	.650	.008 - .020	.862	.680	.020 - .032	.866	.474	.010 - .020
.839	.628	.050 - .070	.846	.670	.040 - .060	.851	.421	.105 - .120	.858	.653	.025 - .040	.862	.751	.030 - .050	.866	.475	.010 - .020
<b>.839</b>	<b>.652</b>	<b>.005 - .010</b>	.846	.697	.015 - .030	.851	.450	.030 - .050	.858	.720	.030 - .050	.863	.272	.062 - .078	.866	.484	.070 - .090
.840	.246	.104 - .125	<b>.846</b>	<b>.757</b>	<b>.005 - .010</b>	<b>.851</b>	<b>.503</b>	<b>.005 - .010</b>	.858	.725	.040 - .060	.863	.375	.025 - .040	.866	.496	.100 - .125
.840	.292	.020 - .040	<b>.847</b>	<b>.253</b>	<b>.005 - .010</b>	.851	.513	.040 - .060	.858	.773	.010 - .020	.863	.422	.090 - .120	.866	.500	.010 - .020
.840	.313	.105 - .125	<b>.847</b>	<b>.323</b>	<b>.005 - .010</b>	<b>.851</b>	<b>.571</b>	<b>.005 - .010</b>	.859	.064	.030 - .050	<b>.863</b>	<b>.505</b>	<b>.005 - .010</b>	.866	.531	.025 - .040
.840	.316	.015 - .030	<b>.847</b>	<b>.416</b>	<b>.005 - .010</b>	<b>.851</b>	<b>.640</b>	<b>.005 - .010</b>	.859	.171	.010 - .020	<b>.863</b>	<b>.531</b>	<b>.005 - .010</b>	.866	.543	.030 - .060
.840	.340	.010 - .025	<b>.847</b>	<b>.422</b>	<b>.005 - .010</b>	<b>.851</b>	<b>.655</b>	<b>.005 - .010</b>	.859	.265	.075 - .090	.863	.531	.030 - .050	.866	.545	.020 - .040
.840	.384	.010 - .025	<b>.847</b>	<b>.500</b>	<b>.005 - .010</b>	.851	.671	.040 - .060	.859	.380	.005 - .015	.863	.540	.015 - .030	.866	.562	.015 - .030
.840	.387	.015 - .030	<b>.847</b>	<b>.522</b>	<b>.005 - .010</b>	.852	.187	.040 - .060	.859	.439	.020 - .030	.863	.679	.040 - .062	.866	.568	.040 - .060
<b>.840</b>	<b>.390</b>	<b>.005 - .010</b>	.848	.067	.010 - .020	.852	.257	.062 - .090	.859	.450	.005 - .020	.863	.680	.005 - .008	.866	.591	.030 - .050
.840	.470	.060 - .083	.848	.199	.025 - .040	<b>.852</b>	<b>.409</b>	<b>.005 - .010</b>	.859	.454	.015 - .030	.863	.682	.010 - .020	<b>.866</b>	<b>.592</b>	<b>.005 - .010</b>
<b>.840</b>	<b>.503</b>	<b>.005 - .010</b>	<b>.848</b>	<b>.317</b>	<b>.005 - .010</b>	.852	.409	.010 - .020	.859	.489	.020 - .030	<b>.863</b>	<b>.688</b>	<b>.005 - .010</b>	.866	.626	.040 - .060
.840	.515	.025 - .040	<b>.848</b>	<b>.323</b>	<b>.005 - .010</b>	.852	.503	.020 - .030	.859	.508	.025 - .050	.863	.759	.015 - .030	.866	.627	.025 - .040
<b>.840</b>	<b>.535</b>	<b>.005 - .010</b>	.848	.323	.010 - .020	.852	.528	.015 - .030	.859	.515	.032 - .042	.863	.759	.030 - .050	.866	.631	.010 - .020
.840	.545	.100 - .135	.848	.492	.050 - .070	.852	.534	.015 - .025	.859	.628	.020 - .030	<b>.864</b>	<b>.208</b>	<b>.005 - .010</b>	.866	.637	.015 - .030
.840	.556	.032 - .040	<b>.848</b>	<b>.540</b>	<b>.005 - .010</b>	.852	.543	.025 - .040	<b>.859</b>	<b>.629</b>	<b>.005 - .010</b>	<b>.864</b>	<b>.316</b>	<b>.005 - .010</b>	.866	.638	.060 - .070
<b>.840</b>	<b>.558</b>	<b>.005 - .010</b>	.848	.685	.032 - .062	.852	.628	.020 - .040	.859	.646	.020 - .040	<b>.864</b>	<b>.368</b>	<b>.005 - .010</b>	<b>.866</b>	<b>.642</b>	<b>.005 - .010</b>
<b>.840</b>	<b>.569</b>	<b>.005 - .010</b>	.848	.750	.010 - .020	.852	.685	.020 - .032	.859	.650	.030 - .050	.864	.430	.040 - .060	<b>.866</b>	<b>.643</b>	<b>.005 - .010</b>
.840	.631	.030 - .060	.849	.151	.030 - .060	.852	.685	.032 - .062	.859	.650	.050 - .070	.864	.505	.015 - .025	.866	.697	.015 - .025
.840	.633	.007 - .015	.849	.386	.050 - .075	.853	.266	.030 - .060	.859	.671	.040 - .060	.864	.536	.080 - .104	.866	.750	.015 - .030
.840	.643	.075 - .090	.849	.401	.040 - .060	<b>.853</b>	<b>.357</b>	<b>.005 - .010</b>	.859	.675	.030 - .050	.864	.595	.005 - .008	<b>.866</b>	<b>.756</b>	<b>.005 - .010</b>
.840	.650	.048 - .062	<b>.849</b>	<b>.413</b>	<b>.005 - .010</b>	.853	.401	.040 - .060	<b>.859</b>	<b>.705</b>	<b>.005 - .010</b>	.864	.620	.010 - .020	.866	.758	.010 - .030
.840	.674	.010 - .020	<b>.849</b>	<b>.497</b>	<b>.005 - .010</b>	.853	.408	.050 - .070	<b>.859</b>	<b>.779</b>	<b>.005 - .010</b>	.864	.628	.050 - .070	.867	.129	.020 - .040
.840	.675	.015 - .030	<b>.849</b>	<b>.520</b>	<b>.005 - .010</b>	.853	.438	.016 - .025	.860	.036	.032 - .042	<b>.864</b>	<b>.633</b>	<b>.005 - .010</b>	.867	.336	.090 - .120
.840	.676	.020 - .035	<b>.849</b>	<b>.606</b>	<b>.005 - .010</b>	.853	.467	.010 - .020	.860	.171	.015 - .030	.864	.639	.042 - .062	.867	.360	.020 - .040
.840	.682	.015 - .030	.849	.631	.010 - .020	.853	.628	.040 - .060	.860	.192	.090 - .125	.864	.781	.010 - .020	.867	.370	.025 - .040
.840	.711	.020 - .040	<b>.850</b>	<b>.155</b>	<b>.005 - .010</b>	<b>.853</b>	<b>.632</b>	<b>.005 - .010</b>	.860	.225	.030 - .040	<b>.865</b>	<b>.205</b>	<b>.005 - .010</b>	.867	.381	.030 - .060
.840	.731	.030 - .050	.850	.174	.025 - .040	<b>.853</b>	<b>.750</b>	<b>.005 - .010</b>	.860	.252	.015 - .030	.865	.260	.020 - .040	<b>.867</b>	<b>.387</b>	<b>.005 - .010</b>
.840	.748	.015 - .025	.850	.175	.050 - .070	<b>.854</b>	<b>.077</b>	<b>.005 - .010</b>	.860	.261	.010 - .020	.865	.351	.020 - .030	.867	.394	.010 - .020
.841	.440	.025 - .040	.850	.180	.120 - .135	.854	.329	.050 - .075	.860	.261	.020 - .030	.865	.398	.020 - .040	<b>.867</b>	<b>.398</b>	<b>.005 - .010</b>
.841	.631	.030 - .050	.850	.200	.020 - .040	.854	.352	.100 - .125	.860	.265	.075 - .090	.865	.412	.060 - .080	.867	.405	.090 - .105
<b>.841</b>	<b>.651</b>	<b>.005 - .010</b>	.850	.200	.060 - .080	.854	.578	.010 - .020	.860	.314	.075 - .090	<b>.865</b>	<b>.434</b>	<b>.005 - .010</b>	<b>.867</b>	<b>.413</b>	<b>.005 - .010</b>
.841	.663	.015 - .030	.850	.240	.048 - .072	.854	.583	.030 - .050	.860	.321	.062 - .090	<b>.865</b>	<b>.471</b>	<b>.005 - .010</b>	<b>.867</b>	<b>.452</b>	<b>.005 - .010</b>
.841	.752	.010 - .020	.850	.250	.015 - .030	<b>.854</b>	<b>.605</b>	<b>.005 - .010</b>	<b>.860</b>	<b>.338</b>	<b>.005 - .010</b>	.865	.476	.020 - .040	.867	.474	.090 - .110
.842	.378	.025 - .042	.850	.251	.120 - .140	<b>.854</b>	<b>.650</b>	<b>.005 - .010</b>	.860	.340	.020 - .030	<b>.865</b>	<b>.477</b>	<b>.005 - .010</b>	.867	.560	.040 - .060
.842	.470	.050 - .070	<b>.850</b>	<b>.283</b>	<b>.005 - .010</b>	<b>.854</b>	<b>.655</b>	<b>.005 - .010</b>	.860	.384	.005 - .015	.865	.479	.070 - .090	<b>.867</b>	<b>.566</b>	<b>.005 - .010</b>
.842	.593	.080 - .095	.850	.302	.105 - .125	.854	.808	.015 - .020	.860	.428	.100 - .125	.865	.492	.036 - .060	.867	.593	.015 - .030
.842	.631	.005 - .008	.850	.316	.090 - .105	<b>.855</b>	<b>.078</b>	<b>.005 - .010</b>	.860	.439	.020 - .035	.865	.493	.010 - .020	.867	.608	.080 - .120
.842	.632	.010 - .020	.850	.319	.060 - .080	.855	.130	.060 - .080	.860	.458	.010 - .020	.865	.551	.080 - .100	.867	.632	.025 - .040
<b>.842</b>	<b>.690</b>	<b>.005 - .010</b>	.850	.330	.020 - .040	.855	.229	.050 - .075	.860	.488	.010 - .020	.865	.553	.010 - .020	.867	.638	.012 - .020
<b>.842</b>	<b>.764</b>	<b>.005 - .010</b>	.850	.350	.080 - .104	.855	.242	.020 - .040	<b>.860</b>	<b>.496</b>	<b>.005 - .010</b>	<b>.865</b>	<b>.566</b>	<b>.005 - .010</b>	.867	.670	.015 - .030
.843	.142	.010 - .020	<b>.850</b>	<b>.377</b>	<b>.005 - .010</b>	.855	.327	.048 - .072	.860	.540	.040 - .060	.865	.597	.042 - .062	.867	.688	.005 - .008
.843	.210	.040 - .060	.850	.377	.010 - .020	.855	.331	.030 - .050	.860	.562	.015 - .030	.865	.626	.040 - .060	.867	.690	.010 - .020
<b>.843</b>	<b>.260</b>	<b>.005 - .010</b>	<b>.850</b>	<b>.378</b>	<b>.005 - .010</b>	<b>.855</b>	<b>.375</b>	<b>.005 - .010</b>	.860	.563	.005 - .015	<b>.865</b>	<b>.630</b>	<b>.005 - .010</b>	.867	.704	.025 - .040
.843	.390	.070 - .090	.850	.382	.100 - .125	.855	.375	.032 - .062	<b>.860</b>	<b>.592</b>	<b>.005 - .010</b>	<b>.865</b>	<b>.634</b>	<b>.005 - .010</b>	.867	.710	.010 - .030
.843	.453	.100 - .125	.850	.384	.100 - .125	.855	.503	.010 - .020	<b>.860</b>	<b>.600</b>	<b>.005 - .010</b>	.865	.634	.050 - .070	.867	.724	.040 - .060
<b>.843</b>	<b>.500</b>	<b>.005 - .010</b>	<b>.850</b>	<b>.433</b>	<b>.005 - .010</b>	.855	.503	.060 - .080	.860	.625	.050 - .070	<b>.865</b>	<b>.635</b>	<b>.005 - .010</b>	<b>.867</b>	<b>.753</b>	<b>.005 - .010</b>
.843	.559	.050 - .072	.850	.495	.015 - .025	<b>.855</b>	<b>.512</b>	<b>.005 - .010</b>	.860	.629	.030 - .050	.865	.650	.020 - .030	.867	.760	.015 - .030
<b>.843</b>	<b>.630</b>	<b>.005 - .010</b>	<b>.850</b>	<b>.502</b>	<b>.005 - .010</b>	.855	.531	.010 - .020	.860	.634	.020 - .030	.865	.672	.010 - .015	<b>.868</b>	<b>.237</b>	<b>.005 - .010</b>
.843	.656	.010 - .020	<b>.850</b>	<b>.503</b>	<b>.005 - .010</b>	<b>.855</b>	<b>.562</b>	<b>.005 - .010</b>	.860	.645	.040 - .060	<b>.865</b>	<b>.698</b>	<b>.005 - .010</b>	<b>.868</b>	<b>.238</b>	<b>.005 - .010</b>
.843	.782	.020 - .030	<b>.850</b>	<b>.509</b>	<b>.005 - .010</b>	<b>.855</b>	<b>.598</b>	<b>.005 - .010</b>	<b>.860</b>	<b>.691</b>	<b>.005 - .010</b>	<b>.865</b>	<b>.714</b>	<b>.005 - .010</b>	.868	.315	.015 - .030
.844	.099	.025 - .040	.850	.510	.005 - .012	.855	.599	.105 - .135	.860	.698	.030 - .050	.865	.715	.032 - .042	.868	.315	.040 - .060
<b>.844</b>	<b>.397</b>	<b>.005 - .010</b>	.850	.513	.040 - .062	.855	.651	.050 - .062	.860	.705	.005 - .015	.865	.755	.032 - .050	<b>.868</b>	<b>.317&lt;/</b>	

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.868	.736	.010 - .020	<b>.871</b>	<b>.590</b>	<b>.005 - .010</b>	.874	.377	.060 - .080	.875	.362	.012 - .020	.875	.674	.010 - .020	.877	.755	.042 - .062
.868	.751	.010 - .020	.871	.673	.010 - .020	.874	.384	.068 - .016	<b>.875</b>	<b>.367</b>	<b>.005 - .010</b>	.875	.687	.050 - .080	<b>.877</b>	<b>.836</b>	<b>.005 - .010</b>
.868	.760	.025 - .040	.871	.675	.015 - .030	.874	.392	.015 - .030	.875	.375	.100 - .125	.875	.690	.075 - .090	.878	.125	.020 - .040
.869	.279	.105 - .135	.871	.771	.025 - .040	.874	.398	.125 - .156	<b>.875</b>	<b>.376</b>	<b>.005 - .010</b>	.875	.691	.040 - .060	.878	.187	.020 - .040
.869	.393	.020 - .035	.872	.153	.040 - .060	.874	.410	.080 - .100	.875	.377	.010 - .020	.875	.693	.030 - .050	.878	.219	.015 - .020
.869	.430	.125 - .156	.872	.189	.005 - .015	<b>.874</b>	<b>.420</b>	<b>.005 - .010</b>	.875	.380	.105 - .134	<b>.875</b>	<b>.698</b>	<b>.005 - .010</b>	.878	.219	.020 - .040
.869	.430	.156 - .187	.872	.219	.060 - .083	.874	.439	.105 - .125	.875	.382	.015 - .030	<b>.875</b>	<b>.719</b>	<b>.005 - .010</b>	.878	.229	.040 - .060
.869	.508	.050 - .070	.872	.221	.080 - .100	.874	.501	.105 - .125	.875	.383	.150 - .180	.875	.719	.060 - .080	.878	.264	.060 - .083
.869	.539	.010 - .020	.872	.254	.010 - .020	.874	.502	.105 - .125	.875	.384	.008 - .016	.875	.735	.050 - .070	.878	.285	.090 - .120
<b>.869</b>	<b>.575</b>	<b>.005 - .010</b>	<b>.872</b>	<b>.261</b>	<b>.010 - .010</b>	.874	.505	.050 - .070	.875	.390	.060 - .075	.875	.746	.010 - .020	.878	.376	.025 - .040
.869	.628	.020 - .040	.872	.267	.030 - .050	.874	.508	.040 - .060	.875	.391	.040 - .060	.875	.750	.030 - .050	.878	.387	.048 - .062
.869	.628	.060 - .080	.872	.269	.032 - .042	.874	.509	.010 - .020	<b>.875</b>	<b>.393</b>	<b>.005 - .010</b>	.875	.751	.005 - .015	.878	.402	.060 - .075
.869	.667	.020 - .030	.872	.306	.020 - .030	.874	.510	.075 - .090	.875	.395	.090 - .125	.875	.755	.010 - .020	.878	.406	.025 - .040
.870	.125	.005 - .015	.872	.320	.042 - .062	.874	.512	.060 - .080	.875	.396	.010 - .020	.875	.756	.025 - .040	.878	.437	.020 - .040
.870	.170	.025 - .040	.872	.334	.010 - .025	.874	.513	.015 - .030	.875	.397	.050 - .070	.876	.067	.015 - .030	.878	.446	.050 - .075
.870	.184	.040 - .062	.872	.334	.040 - .050	<b>.874</b>	<b>.514</b>	<b>.005 - .010</b>	.875	.405	.100 - .120	.876	.093	.020 - .040	.878	.473	.135 - .156
<b>.870</b>	<b>.186</b>	<b>.005 - .010</b>	.872	.376	.010 - .020	.874	.526	.050 - .070	.875	.406	.050 - .060	.876	.127	.060 - .080	.878	.478	.010 - .020
.870	.196	.005 - .015	<b>.872</b>	<b>.394</b>	<b>.005 - .010</b>	.874	.533	.030 - .060	.875	.412	.100 - .125	<b>.876</b>	<b>.130</b>	<b>.005 - .010</b>	.878	.501	.020 - .040
<b>.870</b>	<b>.202</b>	<b>.005 - .010</b>	.872	.394	.015 - .025	.874	.535	.032 - .048	.875	.413	.005 - .015	<b>.876</b>	<b>.164</b>	<b>.005 - .010</b>	.878	.516	.100 - .125
<b>.870</b>	<b>.239</b>	<b>.005 - .010</b>	<b>.872</b>	<b>.399</b>	<b>.010 - .010</b>	.874	.540	.030 - .050	.875	.415	.060 - .083	.876	.173	.050 - .070	.878	.518	.100 - .125
.870	.248	.040 - .060	.872	.402	.010 - .020	.874	.579	.015 - .030	.875	.430	.015 - .030	.876	.282	.040 - .060	.878	.523	.100 - .125
.870	.264	.100 - .125	.872	.475	.060 - .083	.874	.601	.070 - .090	.875	.436	.060 - .080	.876	.282	.156 - .187	.878	.531	.020 - .040
.870	.280	.120 - .150	.872	.476	.055 - .085	<b>.874</b>	<b>.603</b>	<b>.005 - .010</b>	.875	.437	.050 - .080	.876	.284	.040 - .060	.878	.562	.025 - .040
.870	.307	.010 - .030	.872	.562	.075 - .090	<b>.874</b>	<b>.621</b>	<b>.005 - .010</b>	.875	.438	.010 - .020	.876	.287	.100 - .125	.878	.570	.005 - .012
.870	.312	.013 - .028	.872	.593	.075 - .104	.874	.624	.020 - .040	<b>.875</b>	<b>.439</b>	<b>.005 - .010</b>	.876	.317	.030 - .050	<b>.878</b>	<b>.585</b>	<b>.005 - .010</b>
.870	.313	.015 - .025	<b>.872</b>	<b>.605</b>	<b>.005 - .010</b>	.874	.625	.015 - .025	.875	.440	.015 - .030	.876	.328	.005 - .008	.878	.593	.025 - .050
.870	.316	.012 - .020	<b>.872</b>	<b>.626</b>	<b>.005 - .010</b>	.874	.627	.030 - .050	.875	.440	.100 - .125	.876	.328	.105 - .125	.878	.627	.020 - .030
.870	.320	.040 - .060	<b>.872</b>	<b>.687</b>	<b>.005 - .010</b>	.874	.645	.030 - .050	.875	.448	.030 - .050	.876	.340	.160 - .190	<b>.878</b>	<b>.628</b>	<b>.005 - .010</b>
.870	.345	.025 - .040	.872	.725	.040 - .060	<b>.874</b>	<b>.658</b>	<b>.005 - .010</b>	<b>.875</b>	<b>.452</b>	<b>.005 - .010</b>	.876	.343	.025 - .040	.878	.632	.040 - .060
<b>.870</b>	<b>.352</b>	<b>.005 - .010</b>	<b>.872</b>	<b>.728</b>	<b>.005 - .010</b>	.874	.660	.010 - .020	.875	.453	.025 - .040	.876	.350	.015 - .025	<b>.878</b>	<b>.648</b>	<b>.005 - .010</b>
.870	.354	.060 - .080	<b>.872</b>	<b>.755</b>	<b>.010 - .010</b>	.874	.688	.015 - .030	.875	.453	.060 - .080	.876	.378	.090 - .105	.878	.660	.015 - .030
.870	.381	.090 - .120	.872	.755	.015 - .025	.874	.751	.020 - .030	.875	.456	.090 - .125	.876	.397	.030 - .050	.878	.689	.020 - .040
.870	.387	.135 - .187	<b>.872</b>	<b>.760</b>	<b>.005 - .010</b>	<b>.875</b>	<b>.070</b>	<b>.005 - .010</b>	.875	.473	.100 - .125	<b>.876</b>	<b>.461</b>	<b>.005 - .010</b>	<b>.878</b>	<b>.742</b>	<b>.005 - .010</b>
.870	.437	.060 - .080	.872	.807	.010 - .015	<b>.875</b>	<b>.086</b>	<b>.005 - .010</b>	.875	.475	.025 - .040	.876	.471	.040 - .062	<b>.878</b>	<b>.826</b>	<b>.005 - .010</b>
.870	.440	.156 - .187	.873	.140	.048 - .062	.875	.087	.020 - .040	.875	.481	.120 - .135	<b>.876</b>	<b>.503</b>	<b>.005 - .010</b>	.879	.172	.090 - .120
.870	.450	.090 - .120	.873	.153	.050 - .075	.875	.111	.020 - .040	.875	.486	.020 - .040	.876	.506	.090 - .120	.879	.250	.025 - .040
.870	.459	.010 - .020	.873	.194	.070 - .090	.875	.129	.020 - .040	.875	.500	.040 - .060	.876	.515	.080 - .104	.879	.327	.048 - .062
.870	.461	.040 - .060	<b>.873</b>	<b>.195</b>	<b>.005 - .010</b>	.875	.133	.032 - .042	.875	.500	.075 - .090	.876	.516	.125 - .156	.879	.376	.010 - .020
<b>.870</b>	<b>.472</b>	<b>.005 - .010</b>	.873	.224	.020 - .040	.875	.140	.015 - .030	.875	.501	.006 - .012	.876	.519	.060 - .083	.879	.399	.050 - .070
.870	.502	.030 - .040	.873	.307	.007 - .016	<b>.875</b>	<b>.150</b>	<b>.005 - .010</b>	.875	.501	.015 - .030	.876	.522	.100 - .125	.879	.431	.050 - .070
.870	.505	.040 - .050	.873	.312	.030 - .050	.875	.153	.040 - .060	.875	.502	.015 - .030	.876	.533	.110 - .130	.879	.515	.025 - .040
.870	.505	.050 - .075	.873	.361	.105 - .125	<b>.875</b>	<b>.158</b>	<b>.005 - .010</b>	.875	.504	.100 - .125	.876	.551	.100 - .120	.879	.516	.040 - .060
.870	.508	.105 - .135	<b>.873</b>	<b>.365</b>	<b>.005 - .010</b>	.875	.168	.072 - .090	<b>.875</b>	<b>.505</b>	<b>.005 - .010</b>	<b>.876</b>	<b>.563</b>	<b>.005 - .010</b>	.879	.593	.050 - .070
<b>.870</b>	<b>.512</b>	<b>.005 - .010</b>	.873	.378	.040 - .060	.875	.168	.090 - .120	.875	.505	.031 - .042	.876	.565	.020 - .040	.879	.635	.050 - .075
.870	.520	.075 - .090	<b>.873</b>	<b>.381</b>	<b>.005 - .010</b>	.875	.172	.048 - .062	.875	.506	.090 - .125	.876	.600	.060 - .075	.880	.165	.050 - .075
<b>.870</b>	<b>.540</b>	<b>.005 - .010</b>	.873	.387	.015 - .025	.875	.175	.040 - .060	.875	.507	.030 - .060	.876	.616	.048 - .062	.880	.170	.110 - .130
<b>.870</b>	<b>.557</b>	<b>.005 - .010</b>	<b>.873</b>	<b>.388</b>	<b>.005 - .010</b>	.875	.180	.062 - .075	.875	.507	.042 - .062	.876	.622	.040 - .060	.880	.192	.015 - .030
.870	.562	.005 - .012	.873	.405	.015 - .030	.875	.184	.020 - .040	.875	.507	.100 - .125	<b>.876</b>	<b>.625</b>	<b>.005 - .010</b>	.880	.219	.032 - .050
.870	.562	.030 - .060	.873	.410	.105 - .135	.875	.187	.090 - .105	.875	.513	.032 - .042	.876	.626	.050 - .075	<b>.880</b>	<b>.260</b>	<b>.005 - .010</b>
.870	.578	.040 - .060	<b>.873</b>	<b>.412</b>	<b>.005 - .010</b>	.875	.192	.025 - .042	.875	.513	.105 - .135	.876	.632	.030 - .050	.880	.260	.156 - .187
.870	.580	.010 - .020	.873	.436	.050 - .075	.875	.196	.050 - .075	<b>.875</b>	<b>.517</b>	<b>.005 - .010</b>	.876	.633	.062 - .080	<b>.880</b>	<b>.265</b>	<b>.005 - .010</b>
.870	.581	.042 - .060	.873	.440	.105 - .135	.875	.203	.062 - .090	.875	.518	.090 - .110	.876	.672	.090 - .105	.880	.302	.005 - .015
.870	.608	.030 - .060	.873	.467	.015 - .030	<b>.875</b>	<b>.226</b>	<b>.005 - .010</b>	.875	.527	.032 - .048	.876	.675	.030 - .040	.880	.324	.050 - .070
.870	.610	.005 - .012	.873	.470	.030 - .050	<b>.875</b>	<b>.236</b>	<b>.005 - .010</b>	.875	.562	.050 - .072	.876	.681	.060 - .080	.880	.333	.042 - .060
.870	.625	.015 - .030	.873	.503	.015 - .030	.875	.236	.042 - .060	<b>.875</b>	<b>.563</b>	<b>.005 - .010</b>	.876	.692	.020 - .030	.880	.340	.160 - .190
.870	.628	.025 - .040	.873	.503	.050 - .070	<b>.875</b>	<b>.250</b>	<b>.005 - .010</b>	.875	.563	.010 - .015	.876	.694	.020 - .040	<b>.880</b>	<b>.357</b>	<b>.005 - .010</b>
<b>.870</b>	<b>.629</b>	<b>.005 - .010</b>	.873	.522	.020 - .040	.875	.250	.030 - .050	.875	.563	.015 - .030	.876	.702	.010 - .020	.880	.375	.060 - .080
.870	.632	.010 - .020															

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.881	.203	.005 - .010	.895	.631	.005 - .010	.900	.810	.010 - .020	.905	.709	.015 - .030	.912	.563	.010 - .020	.921	.490	.025 - .040
.881	.548	.030 - .050	.895	.733	.050 - .070	.900	.830	.015 - .025	.905	.728	.050 - .070	.912	.656	.105 - .120	.921	.531	.025 - .040
<b>.881</b>	<b>.661</b>	<b>.005 - .010</b>	.895	.795	.010 - .020	.901	.202	.030 - .050	<b>.905</b>	<b>.785</b>	<b>.005 - .010</b>	.912	.683	.015 - .030	.921	.587	.020 - .040
.881	.681	.010 - .015	.896	.340	.050 - .070	.901	.256	.010 - .016	<b>.906</b>	<b>.316</b>	<b>.005 - .010</b>	<b>.912</b>	<b>.805</b>	<b>.005 - .010</b>	.921	.630	.010 - .020
.881	.732	.020 - .030	.896	.772	.020 - .042	.901	.292	.040 - .060	<b>.906</b>	<b>.325</b>	<b>.005 - .010</b>	.913	.493	.015 - .030	.921	.641	.010 - .020
<b>.882</b>	<b>.300</b>	<b>.005 - .010</b>	<b>.897</b>	<b>.292</b>	<b>.005 - .010</b>	.901	.361	.010 - .020	.906	.394	.010 - .020	.913	.507	.020 - .030	.921	.680	.025 - .040
<b>.882</b>	<b>.323</b>	<b>.005 - .010</b>	<b>.897</b>	<b>.407</b>	<b>.005 - .010</b>	<b>.901</b>	<b>.506</b>	<b>.005 - .010</b>	.906	.396	.010 - .020	.913	.510	.020 - .040	.921	.682	.030 - .050
<b>.882</b>	<b>.325</b>	<b>.005 - .010</b>	.897	.408	.010 - .020	.901	.506	.010 - .020	.906	.405	.010 - .020	.913	.665	.080 - .100	.921	.788	.020 - .040
.882	.500	.150 - .180	.897	.409	.025 - .040	<b>.901</b>	<b>.626</b>	<b>.005 - .010</b>	<b>.906</b>	<b>.474</b>	<b>.005 - .010</b>	<b>.913</b>	<b>.847</b>	<b>.005 - .010</b>	<b>.921</b>	<b>.790</b>	<b>.005 - .010</b>
.882	.540	.090 - .110	.897	.409	.060 - .080	.901	.626	.010 - .020	.906	.512	.006 - .012	<b>.914</b>	<b>.521</b>	<b>.005 - .010</b>	.922	.316	.105 - .125
<b>.882</b>	<b>.664</b>	<b>.005 - .010</b>	.897	.704	.025 - .040	.901	.694	.075 - .093	.906	.519	.010 - .020	.914	.596	.025 - .040	.922	.450	.080 - .100
.883	.315	.010 - .020	.897	.748	.005 - .015	.902	.316	.010 - .020	.906	.565	.080 - .100	.914	.650	.015 - .030	.922	.608	.050 - .075
.883	.500	.050 - .075	.897	.810	.010 - .020	.902	.316	.020 - .030	.906	.592	.025 - .040	.915	.350	.040 - .060	.922	.630	.010 - .020
.883	.509	.030 - .050	.898	.250	.040 - .060	<b>.902</b>	<b>.329</b>	<b>.005 - .010</b>	.906	.603	.010 - .020	.915	.446	.015 - .025	.922	.640	.030 - .050
.883	.560	.050 - .070	.898	.318	.050 - .075	<b>.902</b>	<b>.377</b>	<b>.005 - .010</b>	<b>.906</b>	<b>.609</b>	<b>.005 - .010</b>	.915	.509	.050 - .070	.922	.670	.010 - .020
.883	.622	.050 - .075	<b>.898</b>	<b>.343</b>	<b>.005 - .010</b>	.902	.504	.006 - .012	.906	.638	.093 - .125	<b>.915</b>	<b>.510</b>	<b>.005 - .010</b>	.922	.687	.020 - .030
.883	.777	.010 - .020	.898	.510	.075 - .104	<b>.902</b>	<b>.505</b>	<b>.005 - .010</b>	.906	.657	.025 - .035	.915	.616	.015 - .030	.922	.755	.020 - .040
.884	.510	.015 - .030	.898	.665	.025 - .040	.902	.505	.015 - .020	.906	.669	.015 - .030	.915	.623	.030 - .060	.922	.758	.050 - .070
.885	.150	.020 - .040	<b>.898</b>	<b>.748</b>	<b>.005 - .010</b>	<b>.902</b>	<b>.535</b>	<b>.005 - .010</b>	.906	.728	.030 - .050	<b>.915</b>	<b>.744</b>	<b>.005 - .010</b>	.923	.397	.015 - .025
.885	.212	.010 - .020	<b>.898</b>	<b>.812</b>	<b>.005 - .010</b>	<b>.902</b>	<b>.564</b>	<b>.005 - .010</b>	.906	.730	.030 - .050	.916	.150	.020 - .032	.923	.502	.015 - .030
<b>.885</b>	<b>.325</b>	<b>.005 - .010</b>	.898	.829	.015 - .030	<b>.902</b>	<b>.642</b>	<b>.005 - .010</b>	.906	.750	.010 - .020	.916	.317	.100 - .120	.923	.506	.050 - .070
<b>.885</b>	<b>.396</b>	<b>.005 - .010</b>	.899	.121	.040 - .060	<b>.902</b>	<b>.658</b>	<b>.005 - .010</b>	.906	.759	.010 - .020	.916	.507	.020 - .040	<b>.923</b>	<b>.661</b>	<b>.005 - .010</b>
.885	.443	.005 - .008	.899	.197	.030 - .050	.902	.679	.030 - .050	.906	.769	.010 - .020	.916	.532	.040 - .060	.923	.668	.030 - .050
<b>.885</b>	<b>.456</b>	<b>.005 - .010</b>	.899	.479	.020 - .040	<b>.902</b>	<b>.790</b>	<b>.030 - .050</b>	.907	.228	.040 - .060	.916	.540	.020 - .040	.923	.678	.020 - .030
.885	.456	.010 - .020	.899	.501	.010 - .020	<b>.902</b>	<b>.792</b>	<b>.005 - .010</b>	.907	.293	.070 - .090	.916	.570	.050 - .070	.923	.754	.020 - .040
.885	.565	.015 - .032	<b>.899</b>	<b>.535</b>	<b>.005 - .010</b>	.903	.252	.080 - .100	.907	.330	.050 - .060	.916	.570	.070 - .090	.923	.755	.015 - .030
.885	.626	.020 - .040	.899	.562	.025 - .040	.903	.258	.060 - .080	.907	.411	.025 - .040	.916	.571	.090 - .110	.923	.755	.030 - .050
<b>.885</b>	<b>.695</b>	<b>.005 - .010</b>	<b>.899</b>	<b>.563</b>	<b>.005 - .010</b>	.903	.315	.030 - .048	.907	.469	.100 - .120	.916	.734	.020 - .040	<b>.923</b>	<b>.820</b>	<b>.005 - .010</b>
.886	.118	.030 - .050	.899	.568	.070 - .090	.903	.330	.015 - .030	<b>.907</b>	<b>.514</b>	<b>.005 - .010</b>	.916	.735	.020 - .040	.924	.201	.100 - .125
.886	.291	.030 - .050	.899	.810	.020 - .030	<b>.903</b>	<b>.401</b>	<b>.005 - .010</b>	.907	.624	.020 - .035	.916	.795	.010 - .020	<b>.924</b>	<b>.253</b>	<b>.005 - .010</b>
<b>.886</b>	<b>.443</b>	<b>.005 - .010</b>	<b>.899</b>	<b>.814</b>	<b>.005 - .010</b>	.903	.416	.100 - .125	.907	.645	.020 - .040	.916	.804	.016 - .032	.924	.538	.010 - .015
.886	.443	.020 - .040	.899	.841	.010 - .020	.903	.500	.025 - .036	.907	.669	.060 - .080	.917	.501	.070 - .090	.924	.727	.040 - .060
.886	.531	.050 - .070	.900	.063	.010 - .020	.903	.531	.160 - .180	.907	.672	.042 - .060	.917	.506	.010 - .020	.924	.746	.020 - .040
.887	.265	.062 - .090	.900	.079	.030 - .050	.903	.664	.025 - .040	.907	.728	.005 - .015	.917	.531	.062 - .078	.925	.158	.100 - .125
.887	.325	.035 - .050	.900	.100	.015 - .030	.903	.710	.010 - .020	.907	.740	.010 - .050	.917	.596	.005 - .015	.925	.314	.010 - .015
.887	.572	.050 - .070	<b>.900</b>	<b>.154</b>	<b>.005 - .010</b>	.903	.735	.005 - .015	.907	.757	.010 - .020	.917	.623	.040 - .060	.925	.322	.070 - .090
.887	.714	.020 - .040	.900	.217	.025 - .040	.903	.760	.015 - .030	.908	.332	.135 - .156	.918	.497	.010 - .020	.925	.346	.015 - .025
<b>.887</b>	<b>.795</b>	<b>.005 - .010</b>	<b>.900</b>	<b>.252</b>	<b>.005 - .010</b>	.903	.766	.040 - .060	.908	.342	.050 - .075	<b>.918</b>	<b>.596</b>	<b>.005 - .010</b>	.925	.397	.048 - .072
.888	.382	.075 - .090	.900	.254	.040 - .060	.904	.206	.040 - .060	.908	.379	.025 - .040	<b>.918</b>	<b>.614</b>	<b>.005 - .010</b>	.925	.438	.015 - .030
<b>.888</b>	<b>.530</b>	<b>.005 - .010</b>	<b>.900</b>	<b>.376</b>	<b>.005 - .010</b>	.904	.262	.070 - .090	.908	.502	.030 - .050	.918	.762	.025 - .035	.925	.445	.060 - .083
.888	.535	.015 - .030	.900	.376	.015 - .030	<b>.904</b>	<b>.319</b>	<b>.005 - .010</b>	.908	.555	.080 - .105	.919	.257	.070 - .090	.925	.450	.025 - .040
<b>.888</b>	<b>.622</b>	<b>.005 - .010</b>	<b>.900</b>	<b>.377</b>	<b>.005 - .010</b>	.904	.319	.010 - .020	.908	.564	.015 - .030	<b>.919</b>	<b>.366</b>	<b>.005 - .010</b>	.925	.474	.050 - .070
.888	.760	.010 - .020	.900	.378	.015 - .030	<b>.904</b>	<b>.329</b>	<b>.005 - .010</b>	.908	.616	.020 - .032	<b>.919</b>	<b>.396</b>	<b>.005 - .010</b>	.925	.516	.025 - .040
.889	.395	.105 - .120	.900	.378	.030 - .040	.904	.486	.025 - .042	.908	.688	.010 - .025	.919	.493	.100 - .125	.925	.526	.015 - .030
<b>.889</b>	<b>.569</b>	<b>.005 - .010</b>	<b>.900</b>	<b>.379</b>	<b>.005 - .010</b>	.904	.629	.020 - .040	.908	.705	.030 - .048	<b>.919</b>	<b>.565</b>	<b>.005 - .010</b>	.925	.575	.070 - .090
.889	.758	.025 - .040	.900	.379	.062 - .078	.904	.629	.080 - .100	.908	.751	.060 - .080	.919	.565	.010 - .020	.925	.576	.050 - .075
.890	.192	.050 - .072	.900	.380	.010 - .020	.904	.640	.030 - .040	<b>.908</b>	<b>.753</b>	<b>.005 - .010</b>	.919	.697	.010 - .020	.925	.577	.050 - .075
.890	.273	.070 - .105	.900	.390	.030 - .060	.904	.649	.020 - .035	.908	.764	.020 - .030	<b>.919</b>	<b>.765</b>	<b>.005 - .010</b>	.925	.661	.025 - .040
.890	.405	.100 - .125	<b>.900</b>	<b>.400</b>	<b>.005 - .010</b>	.904	.690	.015 - .030	.908	.765	.020 - .040	.919	.812	.020 - .030	.925	.672	.040 - .060
.890	.438	.030 - .040	<b>.900</b>	<b>.437</b>	<b>.005 - .010</b>	.904	.750	.040 - .060	.909	.250	.030 - .040	<b>.920</b>	<b>.157</b>	<b>.005 - .010</b>	<b>.925</b>	<b>.719</b>	<b>.005 - .010</b>
.890	.504	.015 - .030	<b>.900</b>	<b>.440</b>	<b>.005 - .010</b>	<b>.904</b>	<b>.805</b>	<b>.005 - .010</b>	.909	.342	.050 - .075	.920	.163	.032 - .060	.925	.725	.010 - .020
.890	.530	.010 - .020	<b>.900</b>	<b>.441</b>	<b>.005 - .010</b>	.904	.805	.025 - .040	<b>.909</b>	<b>.364</b>	<b>.005 - .010</b>	<b>.920</b>	<b>.200</b>	<b>.005 - .010</b>	.925	.756	.010 - .020
.890	.530	.015 - .030	.900	.455	.050 - .070	.905	.127	.090 - .110	<b>.909</b>	<b>.379</b>	<b>.005 - .010</b>	.920	.230	.025 - .040	.925	.800	.012 - .025
.890	.580	.005 - .008	<b>.900</b>	<b>.489</b>	<b>.005 - .010</b>	.905	.196	.040 - .060	.909	.634	.010 - .020	<b>.920</b>	<b>.253</b>	<b>.005 - .010</b>	.925	.834	.020 - .030
<b>.890</b>	<b>.582</b>	<b>.005 - .010</b>	<b>.900</b>	<b>.500</b>	<b>.005 - .010</b>	<b>.905</b>	<b>.238</b>	<b>.005 - .010</b>	.909	.676	.007 - .015	.920	.253	.050 - .075	.926	.399	.080 - .105
<b>.890</b>	<b>.587</b>	<b>.005 - .010</b>	.900	.500	.010 - .020	<b>.905</b>	<b>.317</b>	<b>.005 - .010</b>	.909	.749	.040 - .060	.920	.265	.040 - .060	.926	.438	.045 - .060
<b>.890</b>	<b>.667</b>	<b>.005 - .010</b>	.900	.500	.020 - .030	.905	.330	.015 - .030	<b>.909</b>	<b>.796</b>	<b>.005 - .010</b>	.920	.269	.135 - .187	.926	.670	.010 - .020
.890	.711	.025 - .040	<b>.900</b>	<b>.503</b>	<b>.005 - .010</b>	.905	.344	.020 - .030	.910	.250	.080 - .104	.920	.316	.080 - .100	.926	.689	.015 - .030
.891	.582	.030 - .050	.900	.503	.010 - .020	.905	.392	.010 - .020	.910	.417	.010 - .020	<b>.920</b>	<b>.318</b>	<b>.005 - .010</b>	.926	.724	.015 - .030
<b>.891</b>	<b>.632</b>	<b>.005 - .010</b>	.900	.504	.005 - .008	.905	.392	.020 - .040	<b>.910</b>	<b>.440</b>	<b>.005 - .010</b>	<b>.920</b>	<b>.378</b>	<b>.005 - .010</b>	.927	.171	.100 - .125
.891	.669	.010 - .020	.900	.510	.015 - .030	<b>.905</b>	<b>.396</b>	<b>.005 - .010</b>	.910	.468	.075 - .090	.920	.456	.010 - .030	<b>.927</b>	<b>.264</b>	<b>.005 - .010</b>
.891	.711	.005 - .015	.900	.562	.005 - .012	.905	.398	.120 - .135	.910	.490	.130 - .156	.920	.470	.105 - .125	<		

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.929	.689	.080 - .104	.935	.683	.030 - .060	.937	.802	.025 - .040	.940	.508	.100 - .125	.944	.432	.105 - .125	<b>.948</b>	<b>.506</b>	<b>.005 - .010</b>
.929	.697	.012 - .020	.935	.685	.072 - .090	<b>.937</b>	<b>.813</b>	<b>.005 - .010</b>	.940	.509	.050 - .070	.944	.442	.005 - .020	.948	.514	.050 - .075
.930	.688	.015 - .030	.935	.685	.090 - .120	.937	.875	.025 - .035	.940	.518	.050 - .070	<b>.944</b>	<b>.473</b>	<b>.005 - .010</b>	.948	.518	.030 - .040
<b>.930</b>	<b>.199</b>	<b>.005 - .010</b>	.935	.687	.020 - .040	.938	.140	.048 - .062	.940	.520	.090 - .105	<b>.944</b>	<b>.475</b>	<b>.005 - .010</b>	.948	.518	.040 - .060
.930	.199	.050 - .083	.935	.715	.016 - .032	.938	.144	.105 - .135	.940	.525	.040 - .060	.944	.479	.020 - .030	<b>.948</b>	<b>.576</b>	<b>.005 - .010</b>
<b>.930</b>	<b>.270</b>	<b>.005 - .010</b>	.935	.719	.010 - .030	.938	.150	.050 - .072	.940	.535	.030 - .040	.944	.502	.010 - .020	.948	.666	.035 - .050
.930	.286	.070 - .090	.935	.733	.025 - .040	.938	.199	.048 - .062	.940	.553	.100 - .125	.944	.595	.020 - .040	<b>.948</b>	<b>.763</b>	<b>.005 - .010</b>
.930	.301	.015 - .030	<b>.935</b>	<b>.735</b>	<b>.005 - .010</b>	.938	.200	.030 - .060	.940	.590	.015 - .030	<b>.944</b>	<b>.633</b>	<b>.005 - .010</b>	.948	.780	.020 - .040
<b>.930</b>	<b>.377</b>	<b>.005 - .010</b>	<b>.935</b>	<b>.783</b>	<b>.005 - .010</b>	.938	.201	.100 - .120	.940	.607	.030 - .060	.944	.694	.040 - .060	.948	.864	.020 - .040
.930	.377	.010 - .020	.935	.794	.060 - .075	.938	.217	.050 - .072	.940	.610	.030 - .060	.944	.766	.020 - .040	<b>.949</b>	<b>.189</b>	<b>.005 - .010</b>
.930	.440	.020 - .040	.935	.796	.020 - .040	.938	.246	.048 - .062	<b>.940</b>	<b>.633</b>	<b>.005 - .010</b>	.944	.795	.015 - .030	.949	.380	.040 - .060
.930	.475	.040 - .060	.935	.839	.020 - .030	.938	.266	.042 - .060	<b>.940</b>	<b>.640</b>	<b>.005 - .010</b>	.945	.221	.050 - .075	<b>.949</b>	<b>.503</b>	<b>.005 - .010</b>
.930	.501	.025 - .042	.936	.266	.060 - .080	.938	.318	.048 - .062	.940	.640	.080 - .105	<b>.945</b>	<b>.240</b>	<b>.005 - .010</b>	.949	.505	.050 - .070
.930	.501	.042 - .062	.936	.310	.050 - .080	.938	.322	.035 - .060	.940	.641	.025 - .040	.945	.249	.060 - .080	.949	.507	.010 - .020
.930	.520	.020 - .040	.936	.313	.020 - .035	.938	.328	.104 - .134	.940	.646	.060 - .080	.945	.249	.100 - .125	.949	.592	.072 - .090
.930	.609	.042 - .072	.936	.390	.060 - .090	.938	.343	.048 - .062	.940	.656	.040 - .060	.945	.282	.040 - .060	<b>.950</b>	<b>.125</b>	<b>.005 - .010</b>
.930	.630	.010 - .025	.936	.406	.050 - .070	.938	.376	.048 - .062	.940	.673	.005 - .015	<b>.945</b>	<b>.314</b>	<b>.005 - .010</b>	.950	.131	.062 - .080
.930	.635	.080 - .104	.936	.480	.010 - .020	<b>.938</b>	<b>.379</b>	<b>.005 - .010</b>	.940	.673	.020 - .030	<b>.945</b>	<b>.317</b>	<b>.005 - .010</b>	.950	.186	.020 - .035
<b>.930</b>	<b>.645</b>	<b>.005 - .010</b>	<b>.936</b>	<b>.481</b>	<b>.005 - .010</b>	.938	.383	.105 - .125	<b>.940</b>	<b>.674</b>	<b>.005 - .010</b>	.945	.317	.048 - .070	<b>.950</b>	<b>.189</b>	<b>.005 - .010</b>
<b>.930</b>	<b>.700</b>	<b>.005 - .010</b>	.936	.481	.030 - .060	.938	.388	.090 - .105	.940	.686	.010 - .020	.945	.322	.010 - .020	.950	.189	.015 - .030
.930	.701	.015 - .030	<b>.936</b>	<b>.502</b>	<b>.005 - .010</b>	.938	.439	.042 - .062	.940	.700	.015 - .025	.945	.331	.070 - .090	.950	.198	.047 - .070
<b>.930</b>	<b>.710</b>	<b>.005 - .010</b>	.936	.517	.090 - .110	.938	.444	.040 - .062	.940	.701	.015 - .030	.945	.345	.020 - .040	.950	.204	.020 - .035
.930	.750	.025 - .040	<b>.936</b>	<b>.537</b>	<b>.005 - .010</b>	<b>.938</b>	<b>.458</b>	<b>.005 - .010</b>	.940	.704	.083 - .105	.945	.378	.050 - .070	.950	.219	.015 - .030
.930	.760	.005 - .008	<b>.936</b>	<b>.552</b>	<b>.005 - .010</b>	<b>.938</b>	<b>.507</b>	<b>.005 - .010</b>	.940	.710	.030 - .050	.945	.389	.050 - .075	.950	.234	.015 - .030
.930	.760	.015 - .030	.936	.627	.040 - .060	<b>.938</b>	<b>.521</b>	<b>.005 - .010</b>	.940	.721	.040 - .060	.945	.393	.030 - .050	.950	.250	.015 - .030
.931	.478	.020 - .030	.936	.641	.100 - .125	.938	.532	.105 - .125	<b>.940</b>	<b>.752</b>	<b>.005 - .010</b>	.945	.394	.010 - .020	.950	.328	.105 - .125
.931	.598	.035 - .060	.936	.645	.105 - .135	<b>.938</b>	<b>.550</b>	<b>.005 - .010</b>	.940	.766	.050 - .075	.945	.434	.156 - .187	<b>.950</b>	<b>.387</b>	<b>.005 - .010</b>
.931	.632	.105 - .125	.936	.650	.050 - .070	.938	.562	.030 - .050	.940	.788	.020 - .030	.945	.453	.156 - .187	<b>.950</b>	<b>.395</b>	<b>.005 - .010</b>
.931	.660	.020 - .030	.936	.660	.005 - .008	.938	.563	.015 - .030	.940	.830	.005 - .012	.945	.454	.156 - .187	.950	.395	.010 - .020
.931	.691	.040 - .060	.936	.718	.020 - .040	<b>.938</b>	<b>.595</b>	<b>.005 - .010</b>	.941	.119	.030 - .060	<b>.945</b>	<b>.472</b>	<b>.005 - .010</b>	.950	.395	.050 - .070
.931	.729	.050 - .070	.937	.080	.020 - .035	<b>.938</b>	<b>.596</b>	<b>.005 - .010</b>	.941	.150	.060 - .070	.945	.474	.010 - .020	<b>.950</b>	<b>.500</b>	<b>.005 - .010</b>
.931	.762	.020 - .030	.937	.092	.050 - .070	.938	.636	.030 - .050	.941	.260	.050 - .070	<b>.945</b>	<b>.477</b>	<b>.005 - .010</b>	.950	.500	.010 - .020
.931	.811	.040 - .060	.937	.110	.050 - .070	.938	.637	.080 - .104	.941	.459	.020 - .030	.945	.484	.050 - .075	.950	.500	.020 - .030
.932	.243	.050 - .070	.937	.174	.062 - .080	.938	.690	.040 - .060	<b>.941</b>	<b>.484</b>	<b>.005 - .010</b>	<b>.945</b>	<b>.502</b>	<b>.005 - .010</b>	.950	.505	.010 - .020
.932	.330	.025 - .040	.937	.257	.032 - .048	.938	.721	.020 - .040	.941	.500	.040 - .060	<b>.945</b>	<b>.512</b>	<b>.005 - .010</b>	.950	.512	.100 - .125
.932	.335	.050 - .070	.937	.275	.030 - .050	.938	.752	.015 - .030	.941	.532	.030 - .050	.945	.519	.040 - .060	.950	.531	.060 - .080
.932	.465	.090 - .110	.937	.292	.025 - .040	.938	.752	.070 - .090	.941	.555	.005 - .012	.945	.554	.010 - .020	.950	.567	.030 - .050
.932	.469	.040 - .062	.937	.315	.080 - .100	<b>.938</b>	<b>.760</b>	<b>.005 - .010</b>	.941	.566	.020 - .040	.945	.610	.060 - .080	.950	.640	.030 - .050
.932	.563	.005 - .012	.937	.319	.025 - .040	.938	.761	.015 - .030	.941	.632	.030 - .060	.945	.627	.032 - .042	.950	.640	.100 - .125
.932	.676	.015 - .030	.937	.324	.030 - .060	.938	.766	.020 - .030	<b>.941</b>	<b>.675</b>	<b>.005 - .010</b>	.945	.669	.100 - .125	.950	.696	.030 - .040
.932	.749	.050 - .070	.937	.341	.050 - .075	.938	.770	.030 - .050	.941	.717	.050 - .070	<b>.945</b>	<b>.671</b>	<b>.005 - .010</b>	.950	.775	.020 - .035
<b>.932</b>	<b>.775</b>	<b>.005 - .010</b>	.937	.375	.010 - .020	.938	.784	.015 - .030	.941	.744	.006 - .012	.945	.686	.060 - .080	.950	.807	.010 - .020
.933	.197	.010 - .020	.937	.381	.025 - .040	<b>.938</b>	<b>.831</b>	<b>.005 - .010</b>	.941	.816	.028 - .040	.945	.686	.080 - .105	.951	.156	.015 - .030
.933	.508	.032 - .060	<b>.937</b>	<b>.390</b>	<b>.005 - .010</b>	.939	.040	.010 - .020	.941	.821	.010 - .020	.945	.708	.060 - .080	.951	.376	.010 - .020
.933	.624	.025 - .040	.937	.399	.156 - .187	.939	.126	.020 - .030	.941	.880	.020 - .030	.945	.710	.030 - .050	.951	.377	.020 - .030
<b>.933</b>	<b>.688</b>	<b>.005 - .010</b>	.937	.410	.015 - .030	.939	.189	.105 - .135	.942	.171	.025 - .040	.945	.714	.060 - .080	.951	.380	.040 - .060
<b>.933</b>	<b>.726</b>	<b>.005 - .010</b>	.937	.431	.050 - .075	.939	.195	.105 - .125	<b>.942</b>	<b>.407</b>	<b>.005 - .010</b>	.945	.719	.070 - .090	.951	.388	.010 - .020
.933	.775	.010 - .020	.937	.437	.156 - .187	.939	.218	.100 - .125	.942	.455	.030 - .050	<b>.945</b>	<b>.737</b>	<b>.005 - .010</b>	.951	.500	.010 - .020
<b>.934</b>	<b>.094</b>	<b>.005 - .010</b>	.937	.440	.020 - .040	<b>.939</b>	<b>.442</b>	<b>.005 - .010</b>	.942	.455	.100 - .120	.945	.831	.015 - .030	.951	.586	.015 - .025
.934	.190	.010 - .020	.937	.444	.005 - .008	.939	.442	.015 - .030	.942	.475	.030 - .050	.945	.845	.005 - .015	<b>.951</b>	<b>.661</b>	<b>.005 - .010</b>
.934	.414	.025 - .040	.937	.460	.025 - .040	.939	.457	.008 - .016	.942	.484	.010 - .020	.946	.386	.040 - .060	.951	.741	.020 - .030
.934	.508	.020 - .040	.937	.480	.015 - .030	<b>.939</b>	<b>.496</b>	<b>.005 - .010</b>	.942	.504	.030 - .050	.946	.398	.010 - .020	.952	.125	.025 - .040
<b>.934</b>	<b>.513</b>	<b>.005 - .010</b>	<b>.937</b>	<b>.487</b>	<b>.005 - .010</b>	.939	.560	.080 - .104	.942	.508	.090 - .120	<b>.946</b>	<b>.473</b>	<b>.005 - .010</b>	.952	.166	.060 - .080
.934	.563	.048 - .078	.937	.500	.015 - .030	<b>.939</b>	<b>.563</b>	<b>.005 - .010</b>	.942	.515	.015 - .035	.946	.513	.105 - .125	.952	.198	.048 - .070
.934	.743	.020 - .040	.937	.510	.020 - .030	.939	.610	.040 - .060	<b>.942</b>	<b>.530</b>	<b>.005 - .010</b>	.946	.602	.025 - .042	.952	.213	.048 - .070
<b>.934</b>	<b>.753</b>	<b>.005 - .010</b>	.937	.510	.090 - .110	.939	.628	.015 - .025	.942	.628	.060 - .080	<b>.946</b>	<b>.678</b>	<b>.005 - .010</b>	<b>.952</b>	<b>.376</b>	<b>.005 - .010</b>
.934	.754	.005 - .012	.937	.515	.030 - .050	.939	.628	.015 - .030	<b>.942</b>	<b>.693</b>	<b>.005 - .010</b>	.946	.686	.062 - .070			

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.957	.734	.015 - .030	.968	.729	.015 - .030	.976	.525	.010 - .020	.983	.471	.008 - .015	.986	.859	.030 - .050	.991	.779	.040 - .060
<b>.957</b>	<b>.812</b>	<b>.005 - .010</b>	<b>.968</b>	<b>.741</b>	<b>.005 - .010</b>	.976	.527	.015 - .030	<b>.983</b>	<b>.502</b>	<b>.005 - .010</b>	<b>.987</b>	<b>.348</b>	<b>.005 - .010</b>	.991	.796	.020 - .030
.957	.841	.015 - .020	.968	.869	.025 - .040	<b>.976</b>	<b>.565</b>	<b>.005 - .010</b>	.983	.659	.010 - .020	<b>.987</b>	<b>.397</b>	<b>.005 - .010</b>	<b>.991</b>	<b>.877</b>	<b>.005 - .010</b>
.958	.606	.050 - .072	.969	.250	.050 - .070	.976	.640	.005 - .020	.983	.670	.020 - .040	.987	.516	.050 - .070	.991	.880	.015 - .030
.958	.779	.070 - .080	.969	.391	.030 - .050	<b>.976</b>	<b>.661</b>	<b>.005 - .010</b>	.983	.678	.060 - .080	.987	.748	.025 - .042	.991	.880	.040 - .060
.959	.300	.015 - .025	.969	.436	.050 - .075	<b>.976</b>	<b>.717</b>	<b>.005 - .010</b>	<b>.983</b>	<b>.719</b>	<b>.005 - .010</b>	.988	.255	.025 - .040	<b>.991</b>	<b>.887</b>	<b>.005 - .010</b>
.959	.328	.030 - .050	.969	.559	.020 - .040	.977	.315	.015 - .025	.983	.753	.020 - .030	.988	.354	.020 - .040	<b>.992</b>	<b>.260</b>	<b>.005 - .010</b>
.959	.420	.030 - .050	.969	.565	.020 - .030	.977	.315	.025 - .040	.984	.183	.050 - .075	.988	.505	.090 - .120	<b>.992</b>	<b>.263</b>	<b>.005 - .010</b>
.959	.641	.090 - .120	<b>.969</b>	<b>.582</b>	<b>.005 - .010</b>	.977	.550	.020 - .030	<b>.984</b>	<b>.238</b>	<b>.005 - .010</b>	.988	.506	.025 - .040	.992	.270	.005 - .015
.959	.729	.020 - .040	.969	.638	.025 - .042	.977	.560	.020 - .040	<b>.984</b>	<b>.239</b>	<b>.005 - .010</b>	.988	.597	.040 - .060	.992	.316	.110 - .130
.960	.125	.032 - .060	.969	.656	.060 - .080	.977	.626	.070 - .090	.984	.257	.105 - .125	<b>.988</b>	<b>.703</b>	<b>.005 - .010</b>	.992	.330	.110 - .130
.960	.133	.010 - .025	.969	.661	.060 - .080	.977	.720	.010 - .030	<b>.984</b>	<b>.284</b>	<b>.005 - .010</b>	.988	.736	.040 - .060	.992	.387	.020 - .040
.960	.155	.050 - .072	<b>.969</b>	<b>.750</b>	<b>.005 - .010</b>	.977	.720	.030 - .040	.984	.355	.080 - .104	.988	.758	.005 - .015	.992	.523	.025 - .040
<b>.960</b>	<b>.259</b>	<b>.005 - .010</b>	.969	.770	.010 - .025	.977	.778	.070 - .090	.984	.395	.100 - .125	.988	.759	.030 - .050	.992	.582	.030 - .050
.960	.315	.020 - .032	.969	.770	.030 - .048	.978	.180	.020 - .040	<b>.984</b>	<b>.435</b>	<b>.005 - .010</b>	<b>.988</b>	<b>.760</b>	<b>.005 - .010</b>	<b>.992</b>	<b>.669</b>	<b>.005 - .010</b>
.960	.350	.032 - .050	.969	.792	.025 - .048	.978	.437	.050 - .075	.984	.469	.080 - .100	.988	.877	.015 - .030	.992	.687	.105 - .135
.960	.450	.032 - .050	.969	.802	.015 - .030	.978	.503	.025 - .040	<b>.984</b>	<b>.473</b>	<b>.005 - .010</b>	<b>.989</b>	<b>.176</b>	<b>.005 - .010</b>	.992	.754	.040 - .060
.960	.500	.030 - .060	.970	.092	.025 - .048	<b>.978</b>	<b>.515</b>	<b>.005 - .010</b>	.984	.481	.040 - .060	.989	.201	.080 - .100	.992	.835	.010 - .015
.960	.507	.080 - .104	.970	.262	.100 - .125	.978	.515	.090 - .120	.984	.507	.070 - .090	.989	.259	.060 - .070	.993	.249	.040 - .050
<b>.960</b>	<b>.537</b>	<b>.005 - .010</b>	.970	.345	.020 - .040	.978	.659	.015 - .020	.984	.513	.105 - .125	.989	.282	.080 - .100	.993	.295	.062 - .090
.960	.550	.032 - .050	.970	.380	.025 - .040	.978	.690	.010 - .020	.984	.530	.042 - .062	.989	.400	.100 - .125	.993	.295	.090 - .120
<b>.960</b>	<b>.640</b>	<b>.005 - .010</b>	.970	.418	.070 - .080	.979	.285	.015 - .030	<b>.984</b>	<b>.531</b>	<b>.005 - .010</b>	.989	.506	.070 - .090	.993	.297	.062 - .120
<b>.960</b>	<b>.650</b>	<b>.032 - .050</b>	<b>.970</b>	<b>.440</b>	<b>.005 - .010</b>	<b>.979</b>	<b>.393</b>	<b>.005 - .010</b>	<b>.984</b>	<b>.556</b>	<b>.005 - .010</b>	.989	.515	.060 - .080	<b>.993</b>	<b>.316</b>	<b>.005 - .010</b>
.960	.650	.032 - .050	.970	.515	.080 - .100	<b>.979</b>	<b>.405</b>	<b>.005 - .010</b>	.984	.572	.040 - .060	.989	.560	.025 - .040	.993	.371	.070 - .090
.960	.705	.030 - .040	.970	.550	.010 - .020	.979	.563	.070 - .090	.984	.628	.035 - .060	<b>.989</b>	<b>.640</b>	<b>.005 - .010</b>	.993	.523	.040 - .060
.960	.705	.040 - .060	.970	.631	.156 - .187	<b>.979</b>	<b>.630</b>	<b>.005 - .010</b>	.984	.630	.015 - .025	.989	.736	.100 - .120	.993	.605	.020 - .040
.960	.728	.040 - .060	<b>.970</b>	<b>.670</b>	<b>.005 - .010</b>	<b>.979</b>	<b>.674</b>	<b>.005 - .010</b>	.984	.641	.080 - .105	<b>.989</b>	<b>.739</b>	<b>.005 - .010</b>	.993	.638	.040 - .060
.960	.740	.090 - .105	<b>.970</b>	<b>.723</b>	<b>.005 - .010</b>	.979	.678	.025 - .040	.984	.643	.060 - .080	.989	.771	.060 - .075	.993	.640	.062 - .090
.960	.750	.030 - .060	.970	.754	.040 - .060	<b>.979</b>	<b>.705</b>	<b>.005 - .010</b>	.984	.650	.100 - .125	.989	.789	.020 - .040	.993	.655	.070 - .090
.960	.751	.050 - .075	<b>.970</b>	<b>.769</b>	<b>.005 - .010</b>	.979	.710	.030 - .050	.984	.689	.020 - .030	.989	.830	.015 - .030	.994	.243	.025 - .042
<b>.960</b>	<b>.758</b>	<b>.005 - .010</b>	.970	.802	.030 - .048	.980	.246	.015 - .030	.984	.715	.050 - .075	<b>.989</b>	<b>.879</b>	<b>.005 - .010</b>	.994	.287	.090 - .110
<b>.960</b>	<b>.774</b>	<b>.005 - .010</b>	.971	.345	.105 - .135	.980	.302	.015 - .030	.984	.716	.025 - .042	.990	.125	.040 - .060	.994	.431	.010 - .020
.960	.783	.020 - .030	.971	.376	.060 - .080	<b>.980</b>	<b>.347</b>	<b>.005 - .010</b>	.984	.748	.010 - .020	.990	.126	.010 - .020	.994	.441	.090 - .110
.961	.438	.050 - .070	.971	.408	.050 - .075	.980	.395	.015 - .025	.984	.749	.040 - .060	.990	.355	.080 - .100	<b>.994</b>	<b>.484</b>	<b>.005 - .010</b>
.961	.500	.040 - .050	.971	.439	.020 - .040	.980	.407	.100 - .125	.984	.794	.070 - .090	.990	.437	.010 - .020	.994	.500	.090 - .100
<b>.961</b>	<b>.621</b>	<b>.005 - .010</b>	.971	.444	.020 - .030	<b>.980</b>	<b>.445</b>	<b>.005 - .010</b>	.984	.795	.025 - .042	.990	.442	.006 - .015	.994	.513	.130 - .150
<b>.961</b>	<b>.730</b>	<b>.005 - .010</b>	.971	.550	.030 - .050	.980	.458	.020 - .030	.984	.798	.070 - .090	.990	.443	.006 - .015	<b>.994</b>	<b>.540</b>	<b>.005 - .010</b>
.961	.844	.010 - .020	<b>.971</b>	<b>.605</b>	<b>.005 - .010</b>	<b>.980</b>	<b>.481</b>	<b>.005 - .010</b>	.984	.799	.040 - .060	.990	.454	.060 - .080	.994	.565	.040 - .060
<b>.961</b>	<b>.878</b>	<b>.005 - .010</b>	.971	.631	.080 - .104	<b>.980</b>	<b>.514</b>	<b>.005 - .010</b>	<b>.984</b>	<b>.817</b>	<b>.005 - .010</b>	.990	.456	.030 - .050	<b>.994</b>	<b>.605</b>	<b>.005 - .010</b>
.962	.045	.015 - .025	.971	.720	.104 - .125	.980	.521	.025 - .040	.984	.880	.015 - .030	.990	.469	.080 - .100	.994	.625	.050 - .075
<b>.962</b>	<b>.055</b>	<b>.005 - .010</b>	<b>.971</b>	<b>.761</b>	<b>.005 - .010</b>	.980	.600	.030 - .050	.985	.215	.040 - .060	.990	.510	.025 - .040	<b>.994</b>	<b>.721</b>	<b>.005 - .010</b>
<b>.962</b>	<b>.766</b>	<b>.005 - .010</b>	.971	.761	.010 - .020	.980	.600	.080 - .105	.985	.276	.060 - .080	<b>.990</b>	<b>.512</b>	<b>.005 - .010</b>	<b>.994</b>	<b>.813</b>	<b>.005 - .010</b>
.962	.769	.035 - .062	.971	.837	.040 - .060	.980	.640	.007 - .015	<b>.985</b>	<b>.316</b>	<b>.005 - .010</b>	.990	.516	.030 - .050	<b>.995</b>	<b>.083</b>	<b>.005 - .010</b>
<b>.963</b>	<b>.271</b>	<b>.005 - .010</b>	.971	.865	.030 - .050	.980	.664	.060 - .083	.985	.331	.070 - .090	.990	.560	.030 - .060	.995	.157	.032 - .042
.963	.283	.030 - .050	.972	.335	.040 - .060	.980	.719	.040 - .060	<b>.985</b>	<b>.395</b>	<b>.005 - .010</b>	.990	.562	.080 - .100	.995	.160	.015 - .030
.963	.451	.030 - .050	.972	.365	.010 - .020	.980	.757	.080 - .104	.985	.409	.120 - .140	.990	.562	.125 - .156	<b>.995</b>	<b>.196</b>	<b>.005 - .010</b>
.963	.500	.010 - .020	.972	.570	.100 - .130	.980	.841	.030 - .050	<b>.985</b>	<b>.443</b>	<b>.005 - .010</b>	.990	.605	.075 - .090	.995	.282	.025 - .050
<b>.963</b>	<b>.504</b>	<b>.005 - .010</b>	.972	.657	.015 - .025	.981	.396	.010 - .020	.985	.450	.025 - .035	.990	.625	.020 - .040	.995	.297	.100 - .125
.963	.659	.080 - .100	.972	.657	.080 - .105	.981	.467	.020 - .030	.985	.451	.070 - .090	.990	.626	.050 - .075	<b>.995</b>	<b>.378</b>	<b>.005 - .010</b>
.963	.758	.020 - .030	.972	.746	.050 - .070	<b>.981</b>	<b>.512</b>	<b>.005 - .010</b>	.985	.475	.010 - .015	<b>.990</b>	<b>.631</b>	<b>.005 - .010</b>	.995	.378	.010 - .020
.963	.800	.030 - .050	.972	.764	.050 - .075	.981	.525	.015 - .030	.985	.490	.120 - .156	<b>.990</b>	<b>.693</b>	<b>.005 - .010</b>	.995	.378	.020 - .030
.963	.885	.010 - .020	.973	.110	.050 - .072	<b>.981</b>	<b>.565</b>	<b>.005 - .010</b>	.985	.500	.020 - .032	.990	.703	.020 - .040	.995	.392	.050 - .070
.964	.500	.015 - .030	<b>.973</b>	<b>.567</b>	<b>.005 - .010</b>	.981	.577	.075 - .104	.985	.503	.008 - .015	.990	.735	.030 - .050	<b>.995</b>	<b>.410</b>	<b>.005 - .010</b>
.964	.652	.090 - .120	<b>.973</b>	<b>.595</b>	<b>.005 - .010</b>	.981	.586	.005 - .015	.985	.506	.100 - .120	.990	.758	.020 - .042	<b>.995</b>	<b>.447</b>	<b>.005 - .010</b>
.965	.264	.020 - .040	.973	.595	.050 - .075	.981	.730	.030 - .050	.985	.512	.030 - .050	.990	.758	.090 - .105	.995	.453	.008 - .016
.965	.506	.060 - .075	.974	.226	.050 - .075	.981	.752	.020 - .040	.985	.535	.040 - .060	.990	.759	.080 - .100	.995	.500	.070 - .090
.965	.514	.090 - .120	.974	.260	.050 - .070	.981	.845	.005 - .015	.985	.548	.010 - .015	.990	.760	.010 - .020	.995	.515	.070 - .090
.965	.580	.032 - .060	.974	.669	.015 - .025	.982	.286	.030 - .060	.985	.556	.040 - .060	.990	.760	.025 - .042	.995	.534	.083 - .105
.965	.610	.020 - .035	.974	.699	.025 - .040	.982	.345	.060 - .080	.985	.565	.062 - .080	.990	.770	.020 - .030	.995	.535	.062 - .090
.965	.620	.025 - .040	.974	.716	.120 - .135	<b>.982</b>	<b>.501</b>	<b>.005 - .010</b>	.985	.565	.080 - .105	<b>.990</b>	<b>.780</b>	<b>.005 - .010</b>	.995	.535	.090 - .120
<b>.965</b>	<b>.644</b>	<b>.005 - .010</b>	.974	.755	.050 - .070	.982	.502	.015 - .030	.985	.587	.020 - .032	.990	.810	.010 - .030	.995	.538	.015 - .030
<b>.965</b>	<b>.709</b>	<b>.005 - .010</b>	.974	.768	.030 - .050	<b>.982</b>	<b>.503</b>	<b>.005 - .010</b>	.985	.635	.060 - .080	<b>.990</b>	<b>.813</b>	<b>.005 - .010</b>	.995	.559	.125 - .187
.96																	

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
.996	.170	.005 - .010	.998	.573	.050 - .070	1.000	.117	.040 - .060	<b>1.000</b>	.332	.005 - .010	1.000	.515	.050 - .070	1.000	.751	.100 - .125
.996	.255	.005 - .010	.998	.577	.005 - .010	1.000	.118	.040 - .060	1.000	.338	.100 - .125	1.000	.515	.156 - .187	1.000	.752	.040 - .060
.996	.283	.090 - .125	.998	.578	.010 - .020	<b>1.000</b>	.129	.005 - .010	1.000	.340	.032 - .048	<b>1.000</b>	.517	.005 - .010	1.000	.752	.090 - .105
.996	.318	.005 - .010	.998	.629	.005 - .010	1.000	.131	.015 - .030	1.000	.343	.050 - .070	1.000	.518	.015 - .022	1.000	.753	.050 - .070
.996	.323	.005 - .010	.998	.630	.010 - .020	1.000	.142	.010 - .030	1.000	.354	.100 - .125	1.000	.518	.035 - .050	1.000	.754	.020 - .030
.996	.396	.100 - .125	.998	.637	.040 - .060	1.000	.142	.048 - .062	1.000	.357	.010 - .020	1.000	.518	.100 - .125	1.000	.754	.050 - .075
.996	.441	.020 - .030	.998	.662	.050 - .070	1.000	.143	.030 - .050	<b>1.000</b>	.363	.005 - .010	1.000	.520	.100 - .125	1.000	.755	.006 - .016
.996	.463	.060 - .080	.998	.672	.005 - .012	<b>1.000</b>	.147	.005 - .010	1.000	.372	.010 - .020	1.000	.531	.120 - .140	1.000	.755	.035 - .050
.996	.511	.040 - .060	.998	.678	.032 - .042	1.000	.157	.070 - .090	1.000	.375	.060 - .083	1.000	.534	.050 - .070	1.000	.755	.062 - .080
.996	.578	.075 - .090	.998	.694	.020 - .040	1.000	.170	.030 - .050	1.000	.375	.100 - .125	1.000	.535	.010 - .020	1.000	.755	.105 - .125
.996	.630	.010 - .015	.998	.748	.035 - .060	1.000	.172	.090 - .120	1.000	.375	.156 - .187	1.000	.535	.040 - .060	1.000	.756	.030 - .050
.996	.666	.040 - .060	.998	.793	.005 - .010	<b>1.000</b>	.178	.005 - .010	<b>1.000</b>	.378	.005 - .010	1.000	.549	.100 - .125	<b>1.000</b>	.759	.005 - .010
.996	.692	.010 - .020	.998	.855	.005 - .010	1.000	.187	.050 - .062	1.000	.378	.015 - .030	1.000	.550	.090 - .110	1.000	.759	.020 - .040
.996	.692	.020 - .030	.998	.877	.015 - .030	1.000	.187	.062 - .080	1.000	.378	.020 - .040	1.000	.556	.025 - .040	1.000	.760	.060 - .080
.996	.740	.050 - .070	.998	.913	.005 - .010	1.000	.187	.100 - .125	1.000	.378	.030 - .050	1.000	.562	.050 - .075	1.000	.761	.035 - .050
.996	.758	.005 - .010	.999	.036	.005 - .010	1.000	.192	.050 - .075	1.000	.379	.042 - .060	<b>1.000</b>	.563	.005 - .010	1.000	.764	.105 - .125
.996	.785	.050 - .075	.999	.096	.010 - .020	1.000	.195	.010 - .015	1.000	.379	.100 - .134	1.000	.563	.010 - .020	1.000	.765	.030 - .050
.996	.788	.005 - .010	.999	.122	.005 - .010	1.000	.195	.090 - .110	1.000	.384	.060 - .090	1.000	.564	.030 - .050	1.000	.766	.100 - .125
.996	.798	.040 - .050	.999	.201	.050 - .070	1.000	.196	.025 - .035	1.000	.386	.050 - .075	1.000	.567	.010 - .020	1.000	.767	.050 - .075
.996	.808	.040 - .060	.999	.206	.005 - .010	1.000	.199	.008 - .016	1.000	.387	.007 - .016	<b>1.000</b>	.568	.005 - .010	1.000	.768	.010 - .020
.996	.812	.060 - .080	.999	.243	.030 - .050	1.000	.199	.062 - .080	<b>1.000</b>	.388	.005 - .010	<b>1.000</b>	.572	.005 - .010	1.000	.770	.005 - .015
.996	.813	.015 - .030	.999	.252	.030 - .045	1.000	.200	.134 - .160	1.000	.389	.048 - .075	1.000	.572	.062 - .080	1.000	.770	.030 - .060
.996	.823	.005 - .010	.999	.253	.005 - .010	1.000	.205	.050 - .075	1.000	.392	.075 - .104	1.000	.578	.100 - .125	1.000	.771	.015 - .030
.996	.823	.040 - .060	.999	.267	.105 - .125	1.000	.209	.105 - .125	1.000	.392	.100 - .125	1.000	.579	.020 - .040	1.000	.776	.070 - .090
.996	.859	.040 - .060	.999	.284	.005 - .010	1.000	.215	.050 - .075	1.000	.395	.010 - .020	1.000	.590	.020 - .030	1.000	.785	.100 - .125
.996	.864	.040 - .060	.999	.344	.080 - .104	1.000	.217	.025 - .048	1.000	.403	.105 - .125	1.000	.590	.100 - .125	1.000	.787	.060 - .070
.996	.877	.005 - .010	.999	.348	.080 - .104	1.000	.217	.100 - .125	1.000	.405	.042 - .060	1.000	.594	.156 - .187	1.000	.791	.005 - .020
.996	.877	.020 - .030	.999	.356	.005 - .010	1.000	.218	.015 - .048	1.000	.405	.080 - .100	<b>1.000</b>	.600	.005 - .010	1.000	.796	.010 - .015
.996	.880	.020 - .030	.999	.372	.030 - .060	<b>1.000</b>	.219	.005 - .010	1.000	.406	.020 - .030	1.000	.605	.010 - .020	1.000	.797	.025 - .035
.996	.881	.025 - .040	.999	.375	.010 - .020	1.000	.219	.050 - .075	1.000	.407	.156 - .187	<b>1.000</b>	.610	.005 - .010	1.000	.797	.090 - .110
.997	.152	.050 - .075	.999	.375	.042 - .060	1.000	.219	.100 - .125	1.000	.409	.120 - .134	1.000	.611	.030 - .060	1.000	.797	.100 - .125
.997	.171	.040 - .062	.999	.376	.005 - .010	<b>1.000</b>	.221	.005 - .010	<b>1.000</b>	.410	.005 - .010	1.000	.623	.030 - .050	1.000	.800	.012 - .025
.997	.250	.005 - .010	.999	.382	.030 - .050	1.000	.221	.035 - .050	1.000	.414	.100 - .125	<b>1.000</b>	.624	.005 - .010	1.000	.801	.025 - .040
.997	.315	.060 - .080	.999	.392	.030 - .050	1.000	.225	.050 - .070	1.000	.415	.025 - .040	1.000	.624	.156 - .187	<b>1.000</b>	.815	.005 - .010
.997	.327	.005 - .010	.999	.401	.040 - .060	<b>1.000</b>	.228	.005 - .010	1.000	.418	.050 - .070	1.000	.625	.015 - .030	1.000	.828	.015 - .025
.997	.466	.080 - .100	.999	.444	.030 - .050	1.000	.237	.060 - .080	1.000	.434	.104 - .125	1.000	.626	.050 - .075	1.000	.837	.040 - .060
.997	.503	.030 - .050	.999	.453	.060 - .070	1.000	.239	.015 - .030	1.000	.437	.050 - .075	1.000	.627	.105 - .125	1.000	.845	.030 - .050
.997	.508	.050 - .070	.999	.505	.005 - .010	1.000	.250	.008 - .012	1.000	.437	.100 - .125	1.000	.628	.005 - .015	<b>1.000</b>	.850	.005 - .010
.997	.533	.005 - .010	.999	.518	.040 - .060	1.000	.250	.050 - .070	1.000	.438	.020 - .040	1.000	.628	.010 - .020	1.000	.851	.070 - .080
.997	.537	.040 - .062	.999	.527	.090 - .105	<b>1.000</b>	.252	.005 - .010	<b>1.000</b>	.440	.005 - .010	1.000	.628	.015 - .030	<b>1.000</b>	.855	.005 - .010
.997	.549	.020 - .040	.999	.563	.015 - .030	1.000	.252	.025 - .040	1.000	.441	.100 - .120	<b>1.000</b>	.629	.005 - .010	1.000	.875	.016 - .025
.997	.563	.125 - .187	.999	.578	.010 - .020	1.000	.252	.062 - .080	1.000	.443	.135 - .170	1.000	.630	.030 - .060	<b>1.000</b>	.876	.005 - .010
.997	.622	.005 - .010	.999	.626	.020 - .040	1.000	.253	.030 - .050	<b>1.000</b>	.444	.005 - .010	1.000	.631	.134 - .156	1.000	.879	.030 - .060
.997	.689	.050 - .070	.999	.626	.104 - .134	1.000	.253	.050 - .075	1.000	.445	.060 - .080	1.000	.632	.090 - .110	1.000	.880	.010 - .020
.997	.718	.005 - .015	.999	.629	.050 - .070	1.000	.253	.075 - .090	1.000	.447	.010 - .020	1.000	.634	.025 - .042	<b>1.000</b>	.900	.005 - .010
.997	.748	.030 - .050	.999	.633	.005 - .010	1.000	.253	.090 - .120	<b>1.000</b>	.451	.005 - .010	1.000	.634	.040 - .060	1.000	.911	.020 - .035
.997	.756	.016 - .025	.999	.657	.080 - .100	1.000	.256	.020 - .040	1.000	.452	.010 - .020	1.000	.636	.060 - .075	1.000	.957	.015 - .025
.997	.758	.005 - .010	.999	.674	.100 - .134	1.000	.258	.030 - .050	1.000	.457	.100 - .125	1.000	.638	.100 - .125	<b>1.000</b>	.958	.005 - .010
.997	.769	.025 - .040	.999	.675	.100 - .134	<b>1.000</b>	.263	.005 - .010	1.000	.465	.030 - .050	1.000	.640	.020 - .040	<b>1.001</b>	.164	.005 - .010
.998	.111	.010 - .020	.999	.680	.005 - .010	1.000	.264	.042 - .062	1.000	.468	.100 - .125	1.000	.640	.060 - .080	1.001	.203	.025 - .040
.998	.125	.040 - .060	.999	.693	.005 - .010	1.000	.265	.010 - .020	1.000	.471	.050 - .070	<b>1.000</b>	.641	.005 - .010	<b>1.001</b>	.218	.005 - .010
.998	.131	.015 - .025	.999	.700	.020 - .030	1.000	.266	.050 - .075	1.000	.475	.020 - .040	1.000	.641	.134 - .156	1.001	.247	.090 - .105
.998	.136	.015 - .030	.999	.715	.010 - .020	1.000	.268	.030 - .050	1.000	.476	.100 - .125	1.000	.646	.040 - .060	1.001	.250	.062 - .090
.998	.138	.005 - .015	.999	.754	.050 - .070	<b>1.000</b>	.270	.005 - .010	<b>1.000</b>	.480	.005 - .010	1.000	.646	.060 - .080	1.001	.250	.090 - .120
.998	.156	.050 - .075	.999	.763	.005 - .010	1.000	.272	.030 - .050	1.000	.480	.025 - .040	1.000	.655	.030 - .050	<b>1.001</b>	.251	.005 - .010
.998	.190	.005 - .010	.999	.787	.025 - .040	1.000	.273	.160 - .190	1.000	.485	.040 - .060	<b>1.000</b>	.656	.005 - .010	1.001	.253	.010 - .020
.998	.202	.050 - .075	.999	.790	.005 - .010	1.000	.278	.050 - .075	1.000	.485	.105 - .135	1.000	.669	.005 - .008	1.001	.260	.080 - .100
.998	.230	.008 - .016	.999	.822	.050 - .070	1.000	.280	.040 - .060	<b>1.000</b>	.499	.005 - .010	1.000	.669	.020 - .032			

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.001	.505	.015 - .025	1.005	.263	.100 - .125	1.020	.775	.050 - .070	1.027	.637	.020 - .030	1.038	.989	.015 - .025	<b>1.050</b>	<b>.626</b>	<b>.005 - .010</b>
<b>1.001</b>	<b>.508</b>	<b>.005 - .010</b>	1.005	.480	.060 - .075	1.020	.787	.030 - .048	1.027	.669	.075 - .100	1.039	.626	.030 - .060	1.050	.626	.010 - .020
1.001	.508	.090 - .105	1.005	.510	.025 - .040	1.020	.805	.060 - .075	1.027	.793	.060 - .083	1.039	.890	.010 - .020	1.050	.626	.025 - .050
1.001	.531	.170 - .190	1.005	.536	.100 - .125	1.020	.861	.025 - .048	1.027	.826	.020 - .040	<b>1.040</b>	<b>.138</b>	<b>.005 - .010</b>	<b>1.050</b>	<b>.629</b>	<b>.005 - .010</b>
1.001	.564	.170 - .190	1.005	.650	.080 - .100	1.020	.960	.015 - .030	1.027	.830	.060 - .080	1.040	.544	.090 - .120	<b>1.050</b>	<b>.635</b>	<b>.005 - .010</b>
1.001	.595	.050 - .070	<b>1.005</b>	<b>.900</b>	<b>.005 - .010</b>	1.020	.962	.005 - .012	1.028	.151	.090 - .105	1.040	.560	.030 - .050	1.050	.712	.032 - .060
1.001	.611	.040 - .062	<b>1.005</b>	<b>.950</b>	<b>.005 - .010</b>	1.020	.962	.010 - .020	1.028	.623	.060 - .080	1.040	.627	.020 - .040	1.050	.722	.032 - .042
1.001	.626	.010 - .020	1.006	.516	.080 - .105	1.021	.257	.050 - .075	1.028	.629	.032 - .048	1.040	.809	.012 - .025	1.050	.760	.030 - .050
1.001	.628	.040 - .062	1.006	.584	.040 - .060	1.021	.316	.040 - .060	<b>1.029</b>	<b>.318</b>	<b>.005 - .010</b>	1.040	.831	.025 - .035	1.050	.765	.010 - .020
1.001	.688	.006 - .016	1.006	.881	.015 - .030	<b>1.021</b>	<b>.575</b>	<b>.005 - .010</b>	1.029	.520	.120 - .135	1.040	.875	.025 - .040	1.050	.798	.025 - .048
1.001	.690	.050 - .070	1.007	.203	.050 - .075	1.021	.750	.025 - .040	1.029	.740	.030 - .050	1.040	.926	.020 - .030	<b>1.050</b>	<b>.804</b>	<b>.005 - .010</b>
1.001	.711	.080 - .090	1.007	.414	.015 - .025	1.021	.766	.015 - .030	1.029	.765	.050 - .070	1.041	.788	.015 - .030	1.050	.820	.030 - .050
1.001	.756	.025 - .040	1.007	.448	.015 - .025	1.021	.878	.020 - .030	1.030	.171	.050 - .070	<b>1.041</b>	<b>.909</b>	<b>.005 - .010</b>	<b>1.050</b>	<b>.826</b>	<b>.005 - .010</b>
1.001	.756	.040 - .050	1.007	.528	.080 - .105	1.021	.930	.015 - .030	1.030	.189	.075 - .090	1.042	.544	.090 - .120	<b>1.050</b>	<b>.828</b>	<b>.005 - .010</b>
1.001	.818	.080 - .105	1.007	.569	.135 - .160	<b>1.022</b>	<b>.318</b>	<b>.005 - .010</b>	1.030	.194	.030 - .050	1.042	.773	.015 - .030	<b>1.050</b>	<b>.876</b>	<b>.005 - .010</b>
<b>1.001</b>	<b>.906</b>	<b>.005 - .010</b>	1.007	.641	.015 - .030	<b>1.022</b>	<b>.394</b>	<b>.005 - .010</b>	1.030	.273	.060 - .075	1.043	.473	.105 - .135	1.050	.877	.050 - .070
1.002	.140	.042 - .060	1.007	.647	.100 - .125	1.022	.468	.030 - .050	1.030	.336	.156 - .187	1.043	.676	.070 - .090	1.050	.878	.010 - .020
1.002	.172	.010 - .025	1.007	.725	.062 - .075	1.022	.477	.010 - .020	1.030	.377	.020 - .030	1.044	.191	.032 - .060	1.050	.878	.075 - .090
<b>1.002</b>	<b>.197</b>	<b>.005 - .010</b>	1.007	.752	.036 - .050	1.022	.590	.015 - .030	1.030	.383	.015 - .030	1.044	.193	.007 - .015	<b>1.050</b>	<b>.896</b>	<b>.005 - .010</b>
1.002	.277	.010 - .020	<b>1.007</b>	<b>.764</b>	<b>.005 - .010</b>	1.022	.626	.030 - .050	1.030	.384	.010 - .015	1.044	.378	.020 - .040	1.050	.900	.030 - .050
1.002	.312	.135 - .160	1.008	.661	.060 - .080	1.022	.786	.100 - .125	1.030	.417	.030 - .050	1.044	.750	.100 - .125	<b>1.050</b>	<b>.984</b>	<b>.005 - .010</b>
1.002	.319	.060 - .080	1.008	.778	.015 - .030	1.022	.826	.030 - .050	1.030	.505	.050 - .070	1.044	.828	.025 - .042	1.051	.264	.090 - .110
<b>1.002</b>	<b>.379</b>	<b>.005 - .010</b>	1.008	.845	.050 - .070	1.022	.960	.030 - .042	1.030	.510	.062 - .080	1.044	.987	.010 - .020	1.051	.315	.008 - .015
1.002	.384	.090 - .125	1.009	.195	.025 - .042	1.023	.047	.020 - .030	1.030	.533	.110 - .130	1.045	.210	.030 - .042	1.051	.500	.010 - .020
1.002	.442	.050 - .070	1.009	.511	.030 - .050	<b>1.023</b>	<b>.127</b>	<b>.005 - .010</b>	1.030	.542	.015 - .030	1.045	.230	.008 - .016	1.051	.502	.015 - .030
1.002	.454	.025 - .042	1.010	.510	.015 - .030	1.023	.302	.030 - .040	<b>1.030</b>	<b>.649</b>	<b>.005 - .010</b>	<b>1.045</b>	<b>.252</b>	<b>.005 - .010</b>	1.051	.503	.015 - .025
<b>1.002</b>	<b>.470</b>	<b>.005 - .010</b>	1.010	.664	.025 - .040	1.023	.398	.005 - .015	1.030	.690	.090 - .125	1.045	.288	.030 - .042	<b>1.051</b>	<b>.504</b>	<b>.005 - .010</b>
1.002	.470	.050 - .075	1.010	.757	.015 - .025	<b>1.023</b>	<b>.474</b>	<b>.005 - .010</b>	1.030	.719	.100 - .125	<b>1.045</b>	<b>.300</b>	<b>.005 - .010</b>	1.051	.752	.110 - .130
1.002	.504	.100 - .125	1.011	.501	.015 - .030	1.023	.552	.060 - .080	1.030	.749	.040 - .060	1.045	.407	.030 - .050	1.051	.881	.060 - .080
1.002	.531	.035 - .050	1.012	.315	.030 - .040	<b>1.023</b>	<b>.553</b>	<b>.005 - .010</b>	1.030	.815	.020 - .030	<b>1.045</b>	<b>.465</b>	<b>.005 - .010</b>	<b>1.051</b>	<b>.964</b>	<b>.005 - .010</b>
1.002	.531	.070 - .090	1.012	.551	.030 - .040	1.023	.669	.060 - .080	1.030	.894	.050 - .075	1.045	.619	.010 - .020	<b>1.052</b>	<b>.595</b>	<b>.005 - .010</b>
<b>1.002</b>	<b>.532</b>	<b>.005 - .010</b>	1.012	.849	.015 - .030	1.023	.709	.010 - .020	1.030	.952	.005 - .015	1.045	.704	.030 - .050	<b>1.052</b>	<b>.715</b>	<b>.005 - .010</b>
1.002	.534	.025 - .040	1.012	.896	.010 - .020	1.023	.725	.050 - .070	1.031	.377	.015 - .030	<b>1.045</b>	<b>.750</b>	<b>.005 - .010</b>	1.052	.760	.105 - .125
1.002	.564	.062 - .083	<b>1.013</b>	<b>.755</b>	<b>.005 - .010</b>	<b>1.023</b>	<b>.839</b>	<b>.005 - .010</b>	<b>1.031</b>	<b>.385</b>	<b>.005 - .010</b>	1.045	.750	.020 - .032	1.052	.881	.050 - .075
1.002	.579	.015 - .030	1.013	.806	.040 - .060	1.023	.893	.015 - .030	1.031	.408	.105 - .135	1.045	.880	.025 - .040	1.053	.530	.075 - .090
1.002	.652	.015 - .030	1.013	.848	.042 - .060	<b>1.023</b>	<b>.909</b>	<b>.005 - .010</b>	1.031	.485	.020 - .040	1.046	.345	.070 - .090	1.053	.627	.070 - .090
1.002	.658	.100 - .125	1.014	.503	.060 - .080	1.024	.394	.010 - .020	<b>1.031</b>	<b>.520</b>	<b>.005 - .010</b>	1.046	.517	.035 - .050	1.053	.662	.025 - .050
1.002	.685	.060 - .083	1.014	.692	.040 - .060	<b>1.024</b>	<b>.395</b>	<b>.005 - .010</b>	1.031	.864	.080 - .100	<b>1.046</b>	<b>.908</b>	<b>.005 - .010</b>	1.053	.752	.110 - .130
1.002	.703	.050 - .070	<b>1.014</b>	<b>.848</b>	<b>.005 - .010</b>	<b>1.024</b>	<b>.398</b>	<b>.005 - .010</b>	1.031	.910	.010 - .020	1.046	.943	.020 - .035	1.053	.893	.005 - .020
1.002	.718	.020 - .040	<b>1.014</b>	<b>.860</b>	<b>.005 - .010</b>	<b>1.024</b>	<b>.473</b>	<b>.005 - .010</b>	1.031	.958	.010 - .020	<b>1.047</b>	<b>.287</b>	<b>.005 - .010</b>	<b>1.054</b>	<b>.649</b>	<b>.005 - .010</b>
1.002	.719	.062 - .083	1.014	.874	.015 - .030	<b>1.024</b>	<b>.476</b>	<b>.005 - .010</b>	1.032	.175	.100 - .125	<b>1.047</b>	<b>.480</b>	<b>.005 - .010</b>	1.054	.725	.015 - .030
1.002	.767	.020 - .040	1.014	.884	.025 - .040	<b>1.024</b>	<b>.629</b>	<b>.005 - .010</b>	1.032	.259	.062 - .090	1.047	.499	.006 - .015	<b>1.054</b>	<b>.749</b>	<b>.005 - .010</b>
1.002	.820	.020 - .040	1.015	.534	.050 - .075	1.024	.801	.030 - .050	1.032	.378	.010 - .020	<b>1.047</b>	<b>.522</b>	<b>.005 - .010</b>	1.054	.840	.008 - .012
1.002	.842	.030 - .050	1.015	.652	.060 - .080	<b>1.025</b>	<b>.315</b>	<b>.005 - .010</b>	1.032	.529	.100 - .125	1.047	.627	.070 - .090	1.054	.879	.015 - .025
1.002	.897	.025 - .040	1.015	.671	.010 - .020	<b>1.025</b>	<b>.318</b>	<b>.005 - .010</b>	1.032	.633	.080 - .100	1.047	.840	.010 - .020	1.055	.153	.050 - .070
1.003	.211	.010 - .020	<b>1.015</b>	<b>.755</b>	<b>.005 - .010</b>	1.025	.330	.020 - .040	1.032	.656	.100 - .125	<b>1.048</b>	<b>.163</b>	<b>.005 - .010</b>	1.055	.312	.020 - .040
1.003	.377	.005 - .015	<b>1.015</b>	<b>.790</b>	<b>.005 - .010</b>	1.025	.375	.030 - .040	1.032	.788	.020 - .030	1.048	.282	.090 - .105	1.055	.350	.030 - .050
<b>1.003</b>	<b>.410</b>	<b>.005 - .010</b>	1.015	.818	.100 - .125	1.025	.394	.010 - .020	1.032	.849	.070 - .090	1.048	.378	.100 - .125	1.055	.384	.020 - .035
1.003	.410	.010 - .020	1.015	.842	.050 - .070	<b>1.025</b>	<b>.395</b>	<b>.005 - .010</b>	1.032	.925	.015 - .030	1.048	.431	.042 - .062	<b>1.055</b>	<b>.461</b>	<b>.005 - .010</b>
1.003	.441	.030 - .050	1.016	.302	.100 - .125	1.025	.410	.036 - .060	1.032	.955	.020 - .040	1.048	.504	.006 - .012	1.055	.472	.010 - .025
1.003	.445	.010 - .020	1.016	.505	.050 - .070	1.025	.433	.050 - .070	1.033	.483	.080 - .100	1.048	.629	.008 - .015	1.055	.501	.020 - .040
1.003	.455	.062 - .080	<b>1.016</b>	<b>.750</b>	<b>.005 - .010</b>	1.025	.440	.090 - .110	<b>1.033</b>	<b>.757</b>	<b>.005 - .010</b>	1.048	.657	.010 - .020	1.055	.786	.015 - .030
1.003	.498	.005 - .015	<b>1.016</b>	<b>.920</b>	<b>.005 - .010</b>	<b>1.025</b>	<b>.475</b>	<b>.005 - .010</b>	1.033	.811	.050 - .075	<b>1.048</b>	<b>.688</b>	<b>.005 - .010</b>	<b>1.055</b>	<b>.791</b>	<b>.005 - .010</b>
<b>1.003</b>	<b>.508</b>	<b>.005 - .010</b>	<b>1.016</b>	<b>.929</b>	<b>.005 - .010</b>	<b>1.025</b>	<b>.477&lt;/</b>										

NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.058	.688	.105 - .125	1.062	.120	.010 - .020	1.063	.780	.050 - .070	<b>1.075</b>	<b>.804</b>	<b>.005 - .010</b>	1.090	.314	.025 - .036	<b>1.098</b>	<b>.220</b>	<b>.005 - .010</b>
1.058	.735	.050 - .083	1.062	.128	.048 - .062	1.063	.781	.060 - .080	<b>1.075</b>	<b>.810</b>	<b>.005 - .010</b>	1.090	.329	.100 - .125	1.098	.375	.070 - .090
1.058	.757	.030 - .050	1.062	.137	.080 - .100	1.063	.798	.030 - .050	<b>1.075</b>	<b>.814</b>	<b>.005 - .010</b>	1.090	.355	.015 - .030	1.098	.377	.010 - .020
1.058	.762	.075 - .100	1.062	.188	.020 - .040	<b>1.063</b>	<b>.883</b>	<b>.005 - .010</b>	1.076	.348	.050 - .075	1.090	.433	.030 - .060	1.098	.396	.120 - .140
1.058	.872	.050 - .070	1.062	.200	.042 - .062	<b>1.063</b>	<b>.889</b>	<b>.005 - .010</b>	1.076	.367	.075 - .090	1.090	.500	.100 - .125	<b>1.098</b>	<b>.420</b>	<b>.005 - .010</b>
1.058	.897	.060 - .080	1.062	.211	.050 - .083	1.064	.470	.010 - .020	<b>1.076</b>	<b>.398</b>	<b>.005 - .010</b>	1.090	.502	.040 - .060	1.098	.504	.010 - .020
1.059	.153	.015 - .030	1.062	.218	.020 - .035	<b>1.064</b>	<b>.512</b>	<b>.005 - .010</b>	1.076	.499	.015 - .030	1.090	.505	.025 - .040	<b>1.098</b>	<b>.600</b>	<b>.005 - .010</b>
1.059	.188	.040 - .060	1.062	.259	.045 - .060	<b>1.064</b>	<b>.563</b>	<b>.005 - .010</b>	1.076	.508	.083 - .104	1.090	.534	.030 - .060	1.098	.660	.105 - .125
1.059	.450	.090 - .120	1.062	.262	.007 - .015	1.064	.563	.010 - .020	1.076	.515	.015 - .025	1.090	.595	.090 - .120	<b>1.098</b>	<b>.671</b>	<b>.005 - .010</b>
1.059	.514	.015 - .030	1.062	.262	.010 - .025	<b>1.064</b>	<b>.594</b>	<b>.005 - .010</b>	1.076	.535	.060 - .080	1.090	.932	.060 - .080	1.098	.752	.120 - .140
1.059	.582	.030 - .050	1.062	.318	.008 - .016	1.064	.594	.010 - .020	1.076	.536	.060 - .080	1.091	.625	.032 - .062	1.098	.754	.120 - .156
1.059	.596	.050 - .070	1.062	.378	.015 - .030	1.064	.687	.048 - .062	1.076	.643	.075 - .090	1.091	.991	.015 - .030	<b>1.098</b>	<b>.761</b>	<b>.005 - .010</b>
<b>1.059</b>	<b>.634</b>	<b>.005 - .010</b>	1.062	.378	.100 - .125	1.064	.712	.030 - .050	1.076	.690	.080 - .104	<b>1.092</b>	<b>.070</b>	<b>.005 - .010</b>	1.098	.846	.110 - .130
1.059	.750	.050 - .070	<b>1.062</b>	<b>.436</b>	<b>.005 - .010</b>	1.064	.751	.010 - .020	1.076	.915	.015 - .025	<b>1.092</b>	<b>.239</b>	<b>.005 - .010</b>	<b>1.098</b>	<b>.929</b>	<b>.005 - .010</b>
1.059	.768	.020 - .040	1.062	.440	.080 - .104	<b>1.064</b>	<b>.790</b>	<b>.005 - .010</b>	1.077	.380	.060 - .080	1.092	.239	.010 - .020	<b>1.098</b>	<b>.939</b>	<b>.005 - .010</b>
1.059	.890	.040 - .060	1.062	.454	.020 - .040	1.064	.822	.040 - .062	1.077	.758	.050 - .075	1.092	.433	.040 - .060	<b>1.099</b>	<b>.253</b>	<b>.005 - .010</b>
1.059	.965	.015 - .025	<b>1.062</b>	<b>.472</b>	<b>.020 - .010</b>	1.064	.865	.010 - .020	1.077	.767	.025 - .040	1.092	.433	.080 - .105	<b>1.099</b>	<b>.318</b>	<b>.005 - .010</b>
1.060	.150	.060 - .080	1.062	.480	.015 - .030	1.064	.945	.030 - .040	<b>1.077</b>	<b>.830</b>	<b>.005 - .010</b>	1.092	.695	.025 - .040	<b>1.099</b>	<b>.377</b>	<b>.005 - .010</b>
1.060	.172	.010 - .020	1.062	.484	.032 - .060	1.064	.951	.015 - .030	1.077	.870	.050 - .070	1.092	.750	.015 - .025	1.099	.378	.010 - .015
1.060	.210	.010 - .020	<b>1.062</b>	<b>.515</b>	<b>.005 - .010</b>	1.065	.165	.025 - .040	1.077	.907	.020 - .050	1.092	.753	.048 - .070	1.099	.436	.020 - .040
1.060	.258	.025 - .035	1.062	.531	.100 - .125	1.065	.395	.062 - .083	1.078	.232	.025 - .040	1.092	.791	.010 - .020	<b>1.099</b>	<b>.440</b>	<b>.005 - .010</b>
1.060	.283	.156 - .187	<b>1.062</b>	<b>.537</b>	<b>.005 - .010</b>	<b>1.065</b>	<b>.434</b>	<b>.005 - .010</b>	1.078	.278	.010 - .020	<b>1.092</b>	<b>.811</b>	<b>.005 - .010</b>	<b>1.099</b>	<b>.500</b>	<b>.005 - .010</b>
1.060	.284	.040 - .062	1.062	.537	.080 - .105	1.065	.510	.015 - .036	1.078	.392	.060 - .083	1.092	.812	.015 - .030	<b>1.099</b>	<b>.508</b>	<b>.005 - .010</b>
<b>1.060</b>	<b>.318</b>	<b>.005 - .010</b>	1.062	.564	.062 - .090	1.065	.626	.156 - .187	<b>1.078</b>	<b>.456</b>	<b>.005 - .010</b>	1.093	.239	.012 - .020	1.099	.558	.010 - .020
1.060	.341	.010 - .020	<b>1.062</b>	<b>.580</b>	<b>.005 - .010</b>	1.065	.634	.075 - .090	1.078	.580	.040 - .060	1.093	.405	.030 - .060	1.099	.633	.020 - .030
1.060	.378	.105 - .135	1.062	.625	.020 - .030	<b>1.065</b>	<b>.767</b>	<b>.005 - .010</b>	1.078	.593	.050 - .075	1.093	.421	.050 - .070	1.099	.650	.110 - .130
1.060	.394	.100 - .125	1.062	.626	.048 - .062	1.065	.814	.042 - .060	<b>1.078</b>	<b>.644</b>	<b>.005 - .010</b>	1.093	.500	.050 - .075	1.099	.788	.010 - .020
1.060	.396	.025 - .048	1.062	.635	.100 - .125	1.065	.875	.010 - .025	1.078	.687	.030 - .040	1.093	.641	.015 - .030	1.099	.788	.030 - .050
<b>1.060</b>	<b>.429</b>	<b>.005 - .010</b>	1.062	.635	.134 - .156	1.065	.892	.030 - .050	1.078	.749	.020 - .040	1.093	.681	.010 - .030	1.099	.816	.015 - .025
1.060	.451	.105 - .125	1.062	.638	.050 - .070	1.065	.923	.032 - .042	1.078	.781	.031 - .042	1.093	.830	.030 - .050	1.099	.840	.015 - .025
1.060	.469	.105 - .125	1.062	.642	.060 - .080	<b>1.065</b>	<b>.967</b>	<b>.005 - .010</b>	1.078	.830	.030 - .050	1.093	.871	.025 - .040	1.099	.902	.010 - .020
<b>1.060</b>	<b>.479</b>	<b>.005 - .010</b>	1.062	.656	.075 - .090	1.066	.535	.050 - .075	1.078	.840	.010 - .020	1.093	.876	.025 - .050	1.099	.902	.020 - .030
1.060	.510	.020 - .035	1.062	.657	.075 - .090	1.066	.634	.075 - .100	<b>1.079</b>	<b>.114</b>	<b>.005 - .010</b>	1.093	.878	.050 - .075	1.100	.162	.030 - .042
1.060	.512	.156 - .188	1.062	.687	.100 - .125	<b>1.066</b>	<b>.664</b>	<b>.005 - .010</b>	1.079	.509	.030 - .050	1.093	.883	.035 - .050	1.100	.312	.010 - .020
1.060	.513	.105 - .135	1.062	.687	.156 - .187	1.066	.725	.020 - .030	1.079	.567	.025 - .040	<b>1.093</b>	<b>.957</b>	<b>.005 - .010</b>	<b>1.100</b>	<b>.316</b>	<b>.005 - .010</b>
1.060	.563	.015 - .030	1.062	.718	.015 - .032	1.066	.728	.105 - .135	1.079	.587	.025 - .040	<b>1.094</b>	<b>.313</b>	<b>.005 - .010</b>	1.100	.346	.050 - .070
1.060	.573	.060 - .080	1.062	.721	.050 - .070	1.066	.766	.030 - .040	1.079	.760	.025 - .040	1.094	.395	.040 - .060	1.100	.354	.070 - .090
1.060	.580	.062 - .090	1.062	.727	.060 - .080	1.066	.766	.040 - .060	<b>1.079</b>	<b>.955</b>	<b>.005 - .010</b>	1.094	.559	.020 - .030	1.100	.377	.010 - .020
1.060	.580	.090 - .120	1.062	.750	.100 - .125	1.066	.873	.030 - .060	<b>1.080</b>	<b>.088</b>	<b>.005 - .010</b>	1.094	.668	.080 - .100	1.100	.378	.015 - .030
1.060	.629	.015 - .030	1.062	.755	.005 - .015	1.066	.874	.030 - .050	1.080	.328	.015 - .030	1.094	.782	.025 - .040	<b>1.100</b>	<b>.380</b>	<b>.005 - .010</b>
1.060	.629	.030 - .050	1.062	.764	.100 - .125	<b>1.066</b>	<b>.967</b>	<b>.005 - .010</b>	1.080	.571	.070 - .090	<b>1.094</b>	<b>.900</b>	<b>.005 - .010</b>	1.100	.416	.015 - .030
<b>1.060</b>	<b>.658</b>	<b>.005 - .010</b>	1.062	.770	.030 - .050	1.067	.213	.030 - .050	1.080	.623	.020 - .040	1.095	.375	.025 - .050	1.100	.426	.157 - .187
1.060	.658	.025 - .040	1.062	.802	.100 - .125	1.067	.354	.060 - .080	1.080	.738	.060 - .080	1.095	.375	.060 - .080	<b>1.100</b>	<b>.439</b>	<b>.005 - .010</b>
1.060	.659	.035 - .060	1.062	.812	.005 - .012	1.067	.515	.080 - .100	1.080	.760	.020 - .040	1.095	.405	.025 - .048	<b>1.100</b>	<b>.440</b>	<b>.005 - .010</b>
1.060	.672	.060 - .083	1.062	.817	.010 - .020	1.067	.535	.050 - .075	1.080	.770	.050 - .075	1.095	.591	.100 - .125	1.100	.440	.010 - .020
1.060	.688	.010 - .020	1.062	.833	.025 - .040	1.067	.664	.010 - .020	1.080	.773	.030 - .060	1.095	.625	.010 - .020	1.100	.454	.100 - .125
<b>1.060</b>	<b>.702</b>	<b>.005 - .010</b>	1.062	.839	.025 - .042	1.068	.205	.030 - .050	<b>1.080</b>	<b>.780</b>	<b>.005 - .010</b>	1.095	.655	.042 - .062	<b>1.100</b>	<b>.500</b>	<b>.005 - .010</b>
1.060	.726	.060 - .080	1.062	.860	.010 - .020	1.068	.254	.010 - .020	1.080	.856	.020 - .035	1.095	.755	.040 - .050	<b>1.100</b>	<b>.502</b>	<b>.005 - .010</b>
1.060	.741	.025 - .040	1.062	.876	.010 - .020	1.068	.341	.100 - .125	<b>1.080</b>	<b>.906</b>	<b>.005 - .010</b>	1.095	.790	.060 - .080	<b>1.100</b>	<b>.504</b>	<b>.005 - .010</b>
<b>1.060</b>	<b>.752</b>	<b>.005 - .010</b>	1.062	.877	.020 - .040	1.068	.636	.090 - .105	<b>1.080</b>	<b>.935</b>	<b>.005 - .010</b>	1.095	.808	.015 - .030	1.100	.504	.010 - .015
1.060	.760	.020 - .030	<b>1.062</b>	<b>.930</b>	<b>.005 - .010</b>	1.068	.750	.040 - .050	1.081	.793	.030 - .050	1.095	.809	.025 - .040	1.100	.504	.015 - .020
1.060	.772	.060 - .080	1.062	.962	.010 - .020	1.068	.813	.030 - .050	<b>1.081</b>	<b>.797</b>	<b>.005 - .010</b>	1.095	.813	.105 - .135	<b>1.100</b>	<b>.505</b>	<b>.005 - .010</b>
1.060	.794	.080 - .105	1.062	.962	.020 - .030	<b>1.069</b>	<b>.153</b>	<b>.005 - .010</b>	1.083	.253	.050 - .075	1.095	.818	.050 - .075	<b>1.100</b>	<b>.506</b>	<b>.005 - .010</b>
1.060	.880	.048 - .072	1.062	.963	.010 - .020	<b>1.069</b>	<b>.390</b>	<b>.005 - .010</b>	1.083	.475	.						

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.100	.875	<b>.005 - .010</b>	1.105	.749	.030 - .050	1.113	.940	.010 - .020	1.120	.255	.100 - .125	<b>1.122</b>	<b>.891</b>	<b>.005 - .010</b>	1.125	.189	.090 - .125
1.100	.877	.025 - .040	1.105	.756	.030 - .050	1.113	.943	.025 - .040	1.120	.313	.062 - .075	1.122	.893	.015 - .030	1.125	.202	.090 - .120
1.100	.889	.015 - .030	1.105	.881	.070 - .090	1.113	1.011	.020 - .030	1.120	.359	.090 - .110	1.122	1.002	.015 - .025	1.125	.203	.040 - .060
1.100	.905	.040 - .060	1.105	.886	.020 - .030	<b>1.114</b>	<b>.209</b>	<b>.005 - .010</b>	1.120	.380	.025 - .040	1.122	1.024	.015 - .025	1.125	.203	.090 - .125
1.100	.941	.015 - .030	<b>1.105</b>	<b>.916</b>	<b>.005 - .010</b>	1.114	.312	.090 - .125	1.120	.390	.020 - .032	1.123	.208	.008 - .016	1.125	.206	.015 - .025
1.100	.952	.010 - .020	1.106	.317	.015 - .030	1.114	.436	.150 - .180	1.120	.390	.032 - .050	1.123	.314	.050 - .075	<b>1.125</b>	<b>.255</b>	<b>.005 - .010</b>
<b>1.100</b>	<b>.961</b>	<b>.005 - .010</b>	1.106	.656	.060 - .090	1.114	.551	.170 - .180	1.120	.390	.090 - .125	<b>1.123</b>	<b>.344</b>	<b>.005 - .010</b>	1.125	.255	.010 - .020
1.100	.965	.030 - .050	1.106	.782	.020 - .040	1.114	.665	.010 - .020	<b>1.120</b>	<b>.391</b>	<b>.005 - .010</b>	1.123	.399	.010 - .020	1.125	.255	.040 - .060
<b>1.100</b>	<b>.987</b>	<b>.005 - .010</b>	1.106	.790	.040 - .060	<b>1.114</b>	<b>.749</b>	<b>.005 - .010</b>	1.120	.391	.010 - .025	1.123	.409	.156 - .187	1.125	.260	.048 - .075
1.100	.987	.025 - .035	1.107	.912	.030 - .050	<b>1.115</b>	<b>.204</b>	<b>.005 - .010</b>	1.120	.391	.050 - .075	1.123	.417	.020 - .030	1.125	.260	.100 - .125
1.100	.992	.030 - .050	1.107	.983	.010 - .020	1.115	.256	.015 - .030	1.120	.420	.040 - .060	<b>1.123</b>	<b>.501</b>	<b>.005 - .010</b>	1.125	.267	.100 - .125
1.100	.994	.030 - .050	1.108	.407	.050 - .070	1.115	.500	.075 - .090	1.120	.439	.050 - .075	1.123	.503	.010 - .020	<b>1.125</b>	<b>.268</b>	<b>.005 - .010</b>
<b>1.100</b>	<b>1.000</b>	<b>.005 - .010</b>	1.108	.525	.005 - .015	<b>1.115</b>	<b>.642</b>	<b>.005 - .010</b>	1.120	.450	.100 - .125	1.123	.503	.070 - .110	1.125	.283	.062 - .083
1.100	1.007	.010 - .020	1.108	.636	.050 - .070	1.115	.644	.015 - .030	1.120	.472	.100 - .125	1.123	.516	.125 - .156	1.125	.289	.060 - .083
1.100	1.010	.010 - .020	1.108	.714	.060 - .075	<b>1.115</b>	<b>.645</b>	<b>.005 - .010</b>	1.120	.496	.040 - .060	<b>1.123</b>	<b>.524</b>	<b>.005 - .010</b>	1.125	.296	.020 - .040
<b>1.101</b>	<b>.075</b>	<b>.005 - .010</b>	1.108	.778	.030 - .050	<b>1.115</b>	<b>.663</b>	<b>.005 - .010</b>	1.120	.500	.060 - .080	1.123	.528	.080 - .100	1.125	.298	.060 - .090
1.101	.255	.110 - .130	1.108	.786	.015 - .030	<b>1.115</b>	<b>.664</b>	<b>.005 - .010</b>	1.120	.507	.008 - .016	1.123	.534	.156 - .187	1.125	.314	.008 - .015
1.101	.316	.020 - .030	1.108	.801	.030 - .040	1.115	.700	.030 - .050	1.120	.512	.005 - .015	<b>1.123</b>	<b>.636</b>	<b>.005 - .010</b>	1.125	.317	.083 - .120
<b>1.101</b>	<b>.317</b>	<b>.005 - .010</b>	<b>1.108</b>	<b>.832</b>	<b>.005 - .010</b>	<b>1.115</b>	<b>.760</b>	<b>.005 - .010</b>	1.120	.522	.100 - .125	1.123	.691	.125 - .156	<b>1.125</b>	<b>.318</b>	<b>.005 - .010</b>
1.101	.356	.015 - .030	1.108	.844	.050 - .070	1.115	.780	.050 - .070	<b>1.120</b>	<b>.573</b>	<b>.005 - .010</b>	1.123	.696	.040 - .060	<b>1.125</b>	<b>.321</b>	<b>.005 - .010</b>
<b>1.101</b>	<b>.473</b>	<b>.005 - .010</b>	1.109	.318	.010 - .020	<b>1.115</b>	<b>.807</b>	<b>.005 - .010</b>	1.120	.573	.030 - .050	1.123	.703	.040 - .060	1.125	.321	.010 - .020
1.101	.502	.010 - .020	<b>1.109</b>	<b>.488</b>	<b>.005 - .010</b>	1.115	.818	.100 - .125	1.120	.601	.060 - .080	<b>1.123</b>	<b>.750</b>	<b>.005 - .010</b>	1.125	.327	.062 - .090
1.101	.505	.015 - .025	1.109	.504	.030 - .050	1.115	.876	.050 - .075	1.120	.620	.120 - .156	1.123	.765	.020 - .040	1.125	.338	.020 - .030
1.101	.630	.020 - .040	1.109	.506	.025 - .040	1.116	.163	.010 - .020	1.120	.625	.010 - .020	<b>1.123</b>	<b>.770</b>	<b>.005 - .010</b>	1.125	.344	.062 - .083
1.101	.719	.025 - .040	1.109	.556	.020 - .030	1.116	.163	.020 - .030	<b>1.120</b>	<b>.628</b>	<b>.005 - .010</b>	1.123	.784	.040 - .060	1.125	.362	.105 - .134
<b>1.101</b>	<b>.788</b>	<b>.005 - .010</b>	<b>1.109</b>	<b>.830</b>	<b>.005 - .010</b>	1.116	.381	.020 - .030	1.120	.640	.016 - .025	1.123	.815	.030 - .060	1.125	.373	.042 - .062
<b>1.102</b>	<b>.070</b>	<b>.005 - .010</b>	1.109	.835	.010 - .020	1.116	.547	.050 - .075	1.120	.644	.100 - .125	<b>1.123</b>	<b>.853</b>	<b>.005 - .010</b>	1.125	.375	.125 - .156
<b>1.102</b>	<b>.237</b>	<b>.005 - .010</b>	1.109	.917	.040 - .050	<b>1.116</b>	<b>.688</b>	<b>.005 - .010</b>	1.120	.646	.030 - .050	1.123	.880	.030 - .050	1.125	.376	.125 - .156
<b>1.102</b>	<b>.239</b>	<b>.005 - .010</b>	<b>1.110</b>	<b>.094</b>	<b>.005 - .010</b>	1.116	.757	.010 - .020	1.120	.668	.090 - .120	1.123	.893	.020 - .030	<b>1.125</b>	<b>.378</b>	<b>.005 - .010</b>
1.102	.251	.025 - .040	1.110	.097	.045 - .060	1.116	.782	.010 - .015	1.120	.669	.015 - .025	<b>1.123</b>	<b>.908</b>	<b>.005 - .010</b>	1.125	.378	.075 - .090
<b>1.102</b>	<b>.305</b>	<b>.005 - .010</b>	1.110	.228	.030 - .042	<b>1.116</b>	<b>.786</b>	<b>.005 - .010</b>	1.120	.688	.048 - .062	1.123	.908	.010 - .030	1.125	.380	.050 - .075
<b>1.102</b>	<b>.394</b>	<b>.005 - .010</b>	1.110	.238	.018 - .038	1.116	.809	.030 - .060	1.120	.746	.005 - .015	1.123	.966	.015 - .025	1.125	.383	.005 - .012
1.102	.394	.010 - .020	1.110	.282	.015 - .030	1.116	.816	.005 - .016	1.120	.753	.030 - .050	1.123	.999	.040 - .060	<b>1.125</b>	<b>.390</b>	<b>.005 - .010</b>
1.102	.395	.015 - .025	1.110	.326	.050 - .070	1.116	.862	.015 - .030	1.120	.760	.015 - .032	<b>1.123</b>	<b>1.072</b>	<b>.005 - .010</b>	1.125	.390	.050 - .070
<b>1.102</b>	<b>.396</b>	<b>.005 - .010</b>	<b>1.110</b>	<b>.517</b>	<b>.005 - .010</b>	1.116	.868	.062 - .083	1.120	.765	.005 - .012	1.124	.188	.100 - .125	1.125	.391	.100 - .125
<b>1.102</b>	<b>.401</b>	<b>.005 - .010</b>	1.110	.607	.080 - .105	<b>1.116</b>	<b>.879</b>	<b>.005 - .010</b>	1.120	.779	.025 - .042	1.124	.199	.100 - .020	1.125	.406	.042 - .075
<b>1.102</b>	<b>.473</b>	<b>.005 - .010</b>	<b>1.110</b>	<b>.626</b>	<b>.005 - .010</b>	1.116	.883	.016 - .025	1.120	.780	.100 - .125	<b>1.124</b>	<b>.265</b>	<b>.005 - .010</b>	1.125	.407	.020 - .030
<b>1.102</b>	<b>.476</b>	<b>.005 - .010</b>	1.110	.684	.060 - .080	<b>1.116</b>	<b>1.002</b>	<b>.005 - .010</b>	1.120	.811	.030 - .050	1.124	.317	.050 - .070	1.125	.408	.100 - .125
1.102	.476	.010 - .020	1.110	.700	.100 - .120	1.117	.159	.105 - .125	1.120	.816	.060 - .080	1.124	.317	.070 - .090	1.125	.410	.100 - .125
<b>1.102</b>	<b>.477</b>	<b>.005 - .010</b>	<b>1.110</b>	<b>.710</b>	<b>.005 - .010</b>	1.117	.340	.005 - .015	1.120	.832	.015 - .030	1.124	.319	.020 - .040	1.125	.421	.008 - .015
1.102	.511	.160 - .190	1.110	.760	.005 - .008	1.117	.372	.050 - .075	1.120	.882	.060 - .083	1.124	.437	.060 - .080	1.125	.438	.100 - .125
1.102	.564	.100 - .120	1.110	.780	.020 - .035	1.117	.392	.050 - .070	1.120	.890	.060 - .080	1.124	.469	.015 - .030	1.125	.439	.070 - .090
1.102	.590	.090 - .105	1.110	.805	.015 - .030	1.117	.410	.156 - .187	1.120	.890	.075 - .090	<b>1.124</b>	<b>.501</b>	<b>.005 - .010</b>	1.125	.450	.025 - .042
1.102	.598	.030 - .050	1.110	.834	.080 - .105	1.117	.566	.025 - .040	1.120	.945	.015 - .030	<b>1.124</b>	<b>.502</b>	<b>.005 - .010</b>	1.125	.450	.042 - .062
<b>1.102</b>	<b>.632</b>	<b>.005 - .010</b>	<b>1.110</b>	<b>.835</b>	<b>.005 - .010</b>	1.117	.620	.100 - .125	<b>1.120</b>	<b>.997</b>	<b>.005 - .010</b>	1.124	.509	.100 - .125	1.125	.455	.090 - .125
1.102	.632	.010 - .020	<b>1.110</b>	<b>.868</b>	<b>.005 - .010</b>	1.117	.750	.100 - .125	1.121	.160	.010 - .020	<b>1.124</b>	<b>.519</b>	<b>.005 - .010</b>	1.125	.468	.105 - .125
1.102	.666	.040 - .060	1.110	.875	.050 - .075	1.117	.758	.135 - .156	<b>1.121</b>	<b>.260</b>	<b>.005 - .010</b>	1.124	.562	.105 - .135	1.125	.480	.040 - .060
1.102	.667	.040 - .060	1.110	.880	.042 - .062	1.117	.760	.020 - .040	<b>1.121</b>	<b>.344</b>	<b>.005 - .010</b>	1.124	.563	.010 - .020	1.125	.500	.032 - .042
1.102	.670	.030 - .050	1.110	.893	.083 - .105	1.117	.813	.062 - .083	1.121	.386	.050 - .070	<b>1.124</b>	<b>.592</b>	<b>.005 - .010</b>	<b>1.125</b>	<b>.503</b>	<b>.005 - .010</b>
1.102	.689	.050 - .070	1.110	.965	.042 - .062	1.117	.889	.010 - .020	1.121	.472	.030 - .040	1.124	.607	.100 - .120	1.125	.504	.015 - .025
<b>1.102</b>	<b>.766</b>	<b>.005 - .010</b>	1.110	1.006	.010 - .020	1.117	.929	.042 - .062	1.121	.511	.050 - .070	<b>1.124</b>	<b>.627</b>	<b>.005 - .010</b>	<b>1.125</b>	<b>.512</b>	<b>.005 - .010</b>
1.102	.771	.040 - .060	<b>1.110</b>	<b>1.011</b>	<b>.005 - .010</b>	1.117	.930	.050 - .075	1.121	.531	.105 - .125	1.124	.629	.080 - .100	1.125	.512	.042 - .062
1.102	.787	.060 - .080	1.111	.391	.050 - .070	1.117	.954	.060 - .080	1.121	.609	.134 - .156	1.124	.632	.060 - .080	1.125	.512	.090 - .125
1.102	.849	.070 - .090	1.111	.556	.040 - .060	1.117	1.010	.030 - .050	1.121	.628	.040 - .060	1.124	.634	.135 - .156	1.125	.512	.156 - .187
<b>1.102</b>	<b>.854</b>	<b>.005 - .010</b>	1.111	.567	.105 - .125	1.118	.138	.090 - .110	1.121	.644	.100 - .125	1.124	.639	.030 - .050	1.125	.515	.040 - .050
<b>1.102</b>	<b>.948</b>	<b>.005 - .010</b>	1.111	.711	.020 - .030	1.118	.506	.060 - .075	1.121	.664	.105 - .125	1.124	.663	.015 - .030	1.125	.530	.006 - .012
<b>1.103</b>	<b>.316</b>	<b>.005 - .010</b>	<b>1.111</b>	<b>.751</b>	<b>.005 - .010</b>	1.118	.679	.025 - .040	<b>1.121</b>	<b>.699</b>	<b>.005 - .010</b>	<b>1.124</b>	<b>.693</b>	<b>.005 - .010</b>	1.125	.532	.156 - .187
<b>1.103</b>	<b>.395</b>	<b>.005 - .010</b>	1.111	.775	.100 - .125	1.118	.754	.010 - .020	<b>1.121</b>	<b>.720</b>	<b>.005 - .010</b>	1.124	.704	.025 - .040	1.125	.546	.060 - .080
1.103	.395	.010 - .020	1.112</														

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.125	.687	.090 - .105	1.128	.314	.075 - .090	<b>1.140</b>	<b>.722</b>	<b>.005 - .010</b>	<b>1.150</b>	<b>.763</b>	<b>.005 - .010</b>	1.160	.655	.100 - .125	1.171	.853	.050 - .070
1.125	.702	.050 - .075	1.128	.347	.156 - .187	<b>1.140</b>	<b>.723</b>	<b>.005 - .010</b>	1.150	.803	.040 - .060	1.160	.710	.030 - .050	1.171	.965	.070 - .090
1.125	.711	.070 - .080	1.128	.358	.156 - .187	<b>1.140</b>	<b>.742</b>	<b>.005 - .010</b>	1.150	.814	.048 - .062	1.160	.750	.042 - .062	1.171	1.005	.060 - .080
1.125	.715	.025 - .040	1.128	.366	.048 - .062	1.140	.753	.010 - .020	1.150	.814	.100 - .125	1.160	.752	.030 - .048	<b>1.171</b>	<b>1.050</b>	<b>.005 - .010</b>
1.125	.718	.075 - .100	<b>1.128</b>	<b>.747</b>	<b>.005 - .010</b>	<b>1.140</b>	<b>.780</b>	<b>.005 - .010</b>	1.150	.830	.032 - .042	1.160	.759	.030 - .050	<b>1.171</b>	<b>1.105</b>	<b>.005 - .010</b>
1.125	.719	.040 - .060	1.128	.749	.025 - .040	<b>1.140</b>	<b>.809</b>	<b>.005 - .010</b>	1.150	.951	.025 - .040	1.160	.800	.050 - .062	1.172	.190	.040 - .060
1.125	.741	.020 - .040	<b>1.128</b>	<b>.751</b>	<b>.005 - .010</b>	1.140	.812	.031 - .042	<b>1.150</b>	<b>.986</b>	<b>.005 - .010</b>	1.160	.829	.060 - .080	1.172	.473	.120 - .135
1.125	.745	.100 - .125	1.128	.877	.010 - .020	1.140	.950	.005 - .015	1.150	.986	.010 - .020	1.160	.889	.025 - .040	<b>1.172</b>	<b>.523</b>	<b>.005 - .010</b>
1.125	.749	.105 - .135	1.128	.889	.050 - .070	1.140	.970	.025 - .050	1.150	.988	.010 - .020	1.160	.942	.050 - .075	1.172	.600	.050 - .070
1.125	.750	.015 - .030	1.129	.500	.080 - .105	1.140	.990	.015 - .030	1.150	.993	.005 - .012	1.160	.955	.030 - .060	1.172	.600	.156 - .187
1.125	.750	.031 - .042	1.129	.506	.050 - .070	<b>1.140</b>	<b>1.010</b>	<b>.005 - .010</b>	1.150	1.050	.030 - .040	1.160	.989	.032 - .050	1.172	.628	.040 - .060
1.125	.751	.010 - .020	1.129	.620	.100 - .125	<b>1.141</b>	<b>.394</b>	<b>.005 - .010</b>	1.151	.127	.020 - .040	<b>1.161</b>	<b>.408</b>	<b>.005 - .010</b>	1.172	.632	.030 - .040
1.125	.753	.015 - .030	1.129	.705	.105 - .135	1.141	.395	.005 - .015	1.151	.157	.035 - .050	1.161	.408	.015 - .030	1.172	.694	.050 - .075
<b>1.125</b>	<b>.754</b>	<b>.005 - .010</b>	1.129	.804	.060 - .080	1.141	.717	.015 - .025	1.151	.633	.010 - .020	1.161	.753	.060 - .080	1.172	.800	.010 - .020
<b>1.125</b>	<b>.755</b>	<b>.005 - .010</b>	<b>1.130</b>	<b>.163</b>	<b>.005 - .010</b>	1.141	.818	.105 - .125	<b>1.151</b>	<b>.700</b>	<b>.005 - .010</b>	1.161	.770	.010 - .020	1.172	.816	.050 - .075
1.125	.760	.050 - .070	1.130	.171	.050 - .070	1.142	.132	.010 - .020	<b>1.151</b>	<b>.729</b>	<b>.005 - .010</b>	1.161	.794	.080 - .100	1.172	.897	.030 - .050
1.125	.760	.070 - .090	1.130	.302	.020 - .040	<b>1.142</b>	<b>.472</b>	<b>.005 - .010</b>	1.151	.755	.062 - .090	1.161	.922	.040 - .060	1.172	.958	.050 - .062
1.125	.768	.048 - .062	<b>1.130</b>	<b>.376</b>	<b>.005 - .010</b>	1.142	.532	.080 - .100	1.151	.755	.090 - .120	1.162	.600	.075 - .100	1.172	1.000	.050 - .075
1.125	.781	.050 - .070	1.130	.410	.060 - .080	<b>1.142</b>	<b>.552</b>	<b>.005 - .010</b>	1.151	.900	.010 - .020	1.162	.906	.060 - .080	1.173	.063	.015 - .025
1.125	.795	.010 - .050	1.130	.500	.040 - .060	1.142	.638	.030 - .040	<b>1.151</b>	<b>1.046</b>	<b>.005 - .010</b>	1.162	.955	.040 - .060	1.173	.412	.130 - .150
1.125	.796	.050 - .062	1.130	.506	.100 - .125	<b>1.142</b>	<b>.751</b>	<b>.005 - .010</b>	<b>1.152</b>	<b>.380</b>	<b>.005 - .010</b>	1.163	.408	.010 - .020	1.173	.413	.156 - .190
1.125	.802	.134 - .156	1.130	.589	.030 - .050	1.142	.751	.010 - .020	1.152	.563	.040 - .060	1.163	.480	.040 - .060	<b>1.173</b>	<b>.710</b>	<b>.005 - .010</b>
1.125	.812	.080 - .100	1.130	.751	.080 - .105	1.142	.753	.090 - .110	1.152	.673	.120 - .135	1.163	.800	.030 - .042	<b>1.173</b>	<b>.722</b>	<b>.005 - .010</b>
<b>1.125</b>	<b>.815</b>	<b>.005 - .010</b>	<b>1.130</b>	<b>.759</b>	<b>.005 - .010</b>	1.142	.826	.080 - .104	1.153	.062	.025 - .042	1.163	.846	.040 - .060	1.173	.804	.030 - .050
<b>1.125</b>	<b>.823</b>	<b>.005 - .010</b>	1.130	.791	.050 - .070	1.142	.945	.040 - .060	1.153	.626	.010 - .020	1.163	1.010	.010 - .020	1.173	.851	.025 - .040
<b>1.125</b>	<b>.845</b>	<b>.005 - .010</b>	<b>1.130</b>	<b>.800</b>	<b>.005 - .010</b>	1.142	.945	.060 - .080	1.153	.626	.020 - .032	<b>1.164</b>	<b>.351</b>	<b>.005 - .010</b>	1.173	.891	.020 - .030
1.125	.845	.030 - .050	<b>1.130</b>	<b>.821</b>	<b>.005 - .010</b>	1.143	.187	.060 - .075	1.153	.731	.100 - .125	1.164	.787	.083 - .120	1.173	.998	.020 - .030
1.125	.848	.062 - .083	1.130	.855	.062 - .083	1.143	.206	.040 - .060	1.153	.843	.015 - .030	1.164	.801	.060 - .080	1.174	.207	.100 - .125
1.125	.872	.100 - .125	1.130	1.001	.030 - .050	1.143	.250	.060 - .075	1.154	.159	.030 - .060	1.164	.802	.040 - .060	1.174	.261	.125 - .156
1.125	.875	.032 - .060	1.131	.251	.050 - .070	1.143	.313	.060 - .075	1.154	.375	.100 - .125	1.164	.946	.031 - .048	1.174	.419	.090 - .105
<b>1.125</b>	<b>.878</b>	<b>.005 - .010</b>	1.131	.515	.040 - .060	1.143	.314	.062 - .080	1.154	.387	.005 - .008	1.165	.735	.010 - .020	1.174	.876	.030 - .050
1.125	.880	.010 - .020	<b>1.131</b>	<b>.664</b>	<b>.005 - .010</b>	1.143	.375	.060 - .075	1.154	.499	.050 - .075	1.165	.781	.070 - .090	1.174	.891	.060 - .080
1.125	.900	.040 - .060	1.131	.751	.015 - .025	1.143	.376	.020 - .035	1.154	.584	.030 - .060	1.165	1.010	.005 - .015	1.174	.921	.020 - .040
1.125	.908	.070 - .090	1.131	.855	.060 - .080	<b>1.143</b>	<b>.504</b>	<b>.005 - .010</b>	<b>1.154</b>	<b>.710</b>	<b>.005 - .010</b>	<b>1.165</b>	<b>1.065</b>	<b>.005 - .010</b>	1.175	.054	.020 - .040
1.125	.920	.050 - .075	1.131	.956	.025 - .042	1.143	.504	.010 - .020	1.154	.787	.090 - .100	<b>1.165</b>	<b>1.122</b>	<b>.005 - .010</b>	1.175	.063	.020 - .032
1.125	.935	.005 - .008	1.131	1.034	.025 - .042	1.143	.651	.140 - .160	1.154	.803	.030 - .050	1.166	.689	.010 - .020	1.175	.260	.090 - .125
1.125	.938	.015 - .030	1.132	.170	.060 - .075	<b>1.143</b>	<b>.739</b>	<b>.005 - .010</b>	1.154	.856	.025 - .040	1.166	.957	.025 - .035	1.175	.438	.015 - .030
1.125	.939	.050 - .070	1.132	.955	.025 - .050	1.143	.812	.100 - .120	1.154	.875	.010 - .020	1.168	.194	.020 - .030	1.175	.514	.020 - .035
<b>1.125</b>	<b>.940</b>	<b>.005 - .010</b>	1.133	.191	.030 - .050	1.143	.848	.015 - .025	<b>1.154</b>	<b>.877</b>	<b>.005 - .010</b>	1.168	.229	.020 - .040	1.175	.625	.010 - .020
1.125	.950	.040 - .060	1.133	.946	.030 - .050	1.143	.848	.025 - .040	<b>1.154</b>	<b>1.033</b>	<b>.005 - .010</b>	1.168	.697	.025 - .040	1.175	.715	.010 - .020
1.125	.958	.020 - .040	<b>1.133</b>	<b>.971</b>	<b>.005 - .010</b>	1.143	.952	.050 - .070	1.155	.250	.040 - .060	1.168	.704	.135 - .156	<b>1.175</b>	<b>.716</b>	<b>.005 - .010</b>
<b>1.125</b>	<b>.959</b>	<b>.005 - .010</b>	1.134	.545	.015 - .030	<b>1.145</b>	<b>.210</b>	<b>.005 - .010</b>	1.155	.266	.050 - .075	<b>1.168</b>	<b>.750</b>	<b>.005 - .010</b>	<b>1.175</b>	<b>.750</b>	<b>.005 - .010</b>
<b>1.125</b>	<b>.967</b>	<b>.005 - .010</b>	1.134	.555	.010 - .020	<b>1.145</b>	<b>.856</b>	<b>.005 - .010</b>	1.155	.437	.050 - .075	<b>1.168</b>	<b>.922</b>	<b>.005 - .010</b>	1.175	.814	.020 - .040
1.125	1.005	.010 - .025	1.134	.791	.050 - .070	1.145	.896	.030 - .060	1.155	.501	.075 - .090	<b>1.168</b>	<b>.985</b>	<b>.005 - .010</b>	<b>1.175</b>	<b>.868</b>	<b>.005 - .010</b>
1.126	.170	.050 - .075	1.134	.904	.040 - .060	<b>1.146</b>	<b>1.010</b>	<b>.005 - .010</b>	1.155	.510	.030 - .040	1.168	.985	.010 - .020	1.175	.905	.030 - .050
1.126	.270	.025 - .040	1.135	.375	.010 - .020	1.146	1.010	.010 - .020	1.155	.766	.020 - .030	1.168	.996	.005 - .015	1.175	.925	.020 - .030
1.126	.406	.100 - .130	<b>1.135</b>	<b>.483</b>	<b>.005 - .010</b>	1.146	1.035	.010 - .020	1.155	.775	.030 - .050	<b>1.168</b>	<b>1.000</b>	<b>.005 - .010</b>	1.175	.985	.080 - .100
1.126	.546	.060 - .080	1.135	.483	.030 - .050	1.147	.316	.050 - .070	1.155	.967	.025 - .042	1.169	.126	.010 - .025	1.175	.999	.015 - .020
1.126	.563	.015 - .030	1.135	.507	.090 - .120	1.147	.775	.070 - .090	<b>1.156</b>	<b>.125</b>	<b>.005 - .010</b>	1.169	.390	.060 - .083	<b>1.175</b>	<b>1.031</b>	<b>.005 - .010</b>
<b>1.126</b>	<b>.639</b>	<b>.005 - .010</b>	1.135	.770	.020 - .040	1.148	.221	.070 - .090	1.156	.188	.100 - .125	1.169	.410	.070 - .090	1.176	.127	.025 - .040
1.126	.677	.015 - .025	1.135	.775	.040 - .060	1.148	.251	.105 - .135	1.156	.379	.040 - .060	1.169	.419	.090 - .125	1.176	.371	.040 - .060
1.126	.728	.030 - .050	1.135	.812	.100 - .125	1.148	.630	.020 - .030	1.156	.532	.025 - .040	1.169	.691	.090 - .110	<b>1.176</b>	<b>.439</b>	<b>.005 - .010</b>
1.126	.755	.040 - .060	1.136	.946	.030 - .050	<b>1.148</b>	<b>.809</b>	<b>.005 - .010</b>	1.156	.562	.010 - .020	1.169	.698	.030 - .050	<b>1.176</b>	<b>.443</b>	<b>.005 - .010</b>
1.126	.781	.010 - .020	1.136	.961	.060 - .075	1.148	.941	.020 - .030	1.156	.5							

# BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.178	.395	.100 - .125	<b>1.181</b>	<b>.474</b>	<b>.005 - .010</b>	1.185	.908	.005 - .012	1.188	.563	.050 - .075	1.195	1.026	.010 - .030	1.200	.990	.010 - .020
1.178	.442	.060 - .080	<b>1.181</b>	<b>.477</b>	<b>.005 - .010</b>	1.185	.908	.010 - .020	1.188	.621	.080 - .100	1.195	1.116	.010 - .020	1.200	1.000	.040 - .060
<b>1.178</b>	<b>.631</b>	<b>.005 - .010</b>	1.181	.482	.030 - .050	1.185	.940	.030 - .062	1.188	.623	.040 - .060	1.195	1.120	.015 - .030	1.200	1.013	.015 - .030
1.178	.631	.010 - .020	1.181	.482	.050 - .060	<b>1.185</b>	<b>.973</b>	<b>.005 - .010</b>	1.188	.626	.105 - .125	1.196	.264	.025 - .042	<b>1.200</b>	<b>1.048</b>	<b>.005 - .010</b>
<b>1.178</b>	<b>.636</b>	<b>.005 - .010</b>	1.181	.518	.135 - .156	1.185	.990	.080 - .104	1.188	.656	.025 - .040	<b>1.196</b>	<b>.378</b>	<b>.005 - .010</b>	1.200	1.050	.025 - .040
1.178	.663	.090 - .110	1.181	.531	.010 - .020	1.185	1.024	.040 - .060	1.188	.688	.040 - .060	1.196	.859	.040 - .060	<b>1.201</b>	<b>.257</b>	<b>.005 - .010</b>
<b>1.178</b>	<b>.709</b>	<b>.005 - .010</b>	1.181	.560	.100 - .125	<b>1.185</b>	<b>1.048</b>	<b>.005 - .010</b>	1.188	.759	.156 - .187	<b>1.196</b>	<b>1.013</b>	<b>.005 - .010</b>	1.201	.314	.030 - .050
1.178	.753	.015 - .030	1.181	.577	.070 - .090	1.185	1.067	.015 - .030	<b>1.188</b>	<b>.763</b>	<b>.005 - .010</b>	1.196	1.020	.020 - .030	<b>1.201</b>	<b>.395</b>	<b>.005 - .010</b>
1.178	1.041	.020 - .040	1.181	.607	.005 - .015	1.186	.189	.105 - .125	1.188	.765	.070 - .090	<b>1.197</b>	<b>.362</b>	<b>.005 - .010</b>	1.201	.395	.015 - .030
1.179	.381	.170 - .190	1.181	.627	.020 - .040	1.186	.378	.156 - .190	1.188	.799	.050 - .070	<b>1.197</b>	<b>.376</b>	<b>.005 - .010</b>	1.201	.562	.020 - .030
1.179	.473	.010 - .020	1.181	.628	.025 - .035	1.186	.437	.010 - .015	<b>1.188</b>	<b>.880</b>	<b>.005 - .010</b>	1.197	.500	.030 - .050	1.201	.721	.050 - .070
<b>1.179</b>	<b>.502</b>	<b>.005 - .010</b>	1.181	.628	.060 - .083	1.186	.437	.080 - .100	1.188	.880	.140 - .160	<b>1.197</b>	<b>.637</b>	<b>.005 - .010</b>	<b>1.201</b>	<b>.755</b>	<b>.005 - .010</b>
1.179	.569	.030 - .060	1.181	.640	.090 - .125	1.186	.506	.060 - .090	1.188	.920	.010 - .020	<b>1.197</b>	<b>.880</b>	<b>.005 - .010</b>	1.201	.760	.050 - .070
1.179	.632	.010 - .020	1.181	.649	.160 - .190	1.186	.559	.090 - .125	<b>1.188</b>	<b>.940</b>	<b>.005 - .010</b>	1.197	1.120	.020 - .035	1.201	.763	.050 - .075
1.179	.641	.050 - .070	1.181	.669	.070 - .090	1.186	.740	.040 - .060	1.188	1.000	.062 - .089	1.198	.398	.105 - .125	1.201	.774	.025 - .040
1.179	.648	.015 - .030	1.181	.787	.135 - .160	<b>1.186</b>	<b>.781</b>	<b>.005 - .010</b>	<b>1.188</b>	<b>1.001</b>	<b>.005 - .010</b>	1.198	.441	.010 - .020	1.201	.800	.015 - .030
1.179	.687	.030 - .060	<b>1.181</b>	<b>.801</b>	<b>.005 - .010</b>	1.186	.783	.050 - .062	1.188	1.038	.025 - .040	<b>1.198</b>	<b>.500</b>	<b>.005 - .010</b>	1.201	1.003	.010 - .020
1.179	.721	.060 - .080	1.181	.802	.025 - .040	1.186	.826	.010 - .020	1.189	.140	.015 - .030	<b>1.198</b>	<b>.522</b>	<b>.005 - .010</b>	1.201	1.050	.050 - .062
1.179	.829	.030 - .060	1.181	.829	.025 - .040	1.186	1.015	.025 - .040	1.189	.309	.025 - .040	1.198	.552	.025 - .040	1.202	.439	.040 - .060
<b>1.179</b>	<b>.874</b>	<b>.005 - .010</b>	1.181	.877	.040 - .060	1.186	1.016	.030 - .050	1.189	.346	.030 - .050	1.198	.632	.020 - .050	1.202	.793	.015 - .030
<b>1.179</b>	<b>.875</b>	<b>.005 - .010</b>	1.181	.885	.040 - .050	1.186	1.063	.015 - .030	1.189	.380	.110 - .130	1.198	.640	.070 - .090	1.202	.937	.025 - .040
1.179	.911	.040 - .062	1.181	.943	.030 - .050	<b>1.187</b>	<b>.142</b>	<b>.005 - .010</b>	1.189	.627	.160 - .190	1.198	.875	.025 - .042	1.202	.996	.025 - .040
1.179	.914	.035 - .050	1.181	.943	.060 - .080	1.187	.142	.015 - .030	1.189	.751	.040 - .060	1.198	.890	.025 - .040	1.202	1.065	.010 - .020
1.179	.931	.040 - .060	1.181	.945	.010 - .025	1.187	.156	.050 - .062	<b>1.189</b>	<b>.798</b>	<b>.005 - .010</b>	1.198	1.053	.010 - .030	1.203	.353	.060 - .080
1.179	.936	.040 - .060	<b>1.181</b>	<b>.950</b>	<b>.005 - .010</b>	1.187	.212	.040 - .062	<b>1.189</b>	<b>.828</b>	<b>.005 - .010</b>	1.199	.187	.020 - .040	1.203	.439	.050 - .075
1.179	.996	.040 - .060	1.181	.965	.012 - .022	1.187	.283	.080 - .104	1.189	.999	.010 - .020	1.199	.379	.020 - .040	1.203	.502	.100 - .125
1.179	1.015	.025 - .040	1.181	.965	.025 - .040	1.187	.313	.010 - .025	<b>1.189</b>	<b>1.032</b>	<b>.005 - .010</b>	<b>1.199</b>	<b>.503</b>	<b>.005 - .010</b>	<b>1.203</b>	<b>.627</b>	<b>.005 - .010</b>
1.179	1.041	.020 - .040	1.181	1.000	.010 - .020	1.187	.374	.042 - .062	1.190	.128	.030 - .050	<b>1.199</b>	<b>.550</b>	<b>.005 - .010</b>	1.203	.793	.015 - .030
1.180	.140	.016 - .032	<b>1.181</b>	<b>1.020</b>	<b>.005 - .010</b>	<b>1.187</b>	<b>.378</b>	<b>.005 - .010</b>	1.190	.250	.100 - .125	1.199	.562	.015 - .030	1.203	.822	.015 - .025
1.180	.156	.060 - .080	<b>1.182</b>	<b>.317</b>	<b>.005 - .010</b>	1.187	.390	.134 - .187	1.190	.265	.062 - .090	1.199	.735	.050 - .070	1.203	1.004	.030 - .050
<b>1.180</b>	<b>.238</b>	<b>.005 - .010</b>	1.182	.317	.010 - .020	1.187	.404	.020 - .040	1.190	.317	.100 - .125	1.199	.737	.020 - .040	1.204	.757	.005 - .015
1.180	.239	.105 - .125	1.182	.395	.010 - .020	1.187	.477	.100 - .125	1.190	.392	.090 - .110	1.199	.830	.040 - .060	<b>1.204</b>	<b>1.030</b>	<b>.005 - .010</b>
1.180	.251	.156 - .187	<b>1.182</b>	<b>.398</b>	<b>.005 - .010</b>	1.187	.512	.060 - .080	1.190	.410	.010 - .020	1.199	1.012	.015 - .030	1.205	.870	.005 - .015
1.180	.315	.025 - .040	<b>1.182</b>	<b>.506</b>	<b>.005 - .010</b>	1.187	.516	.065 - .080	1.190	.500	.032 - .050	1.199	1.050	.040 - .060	1.205	.870	.062 - .090
1.180	.317	.090 - .110	1.182	.506	.010 - .020	1.187	.519	.010 - .020	1.190	.531	.050 - .070	<b>1.199</b>	<b>1.053</b>	<b>.005 - .010</b>	1.205	.922	.015 - .030
<b>1.180</b>	<b>.319</b>	<b>.005 - .010</b>	1.182	.550	.050 - .060	1.187	.550	.025 - .040	1.190	.543	.060 - .080	1.200	.138	.050 - .070	1.206	.920	.025 - .040
1.180	.331	.140 - .160	1.182	.561	.030 - .050	1.187	.594	.080 - .100	1.190	.564	.020 - .035	1.200	.168	.030 - .050	<b>1.206</b>	<b>1.072</b>	<b>.005 - .010</b>
1.180	.354	.010 - .020	1.182	.635	.100 - .125	1.187	.625	.030 - .050	1.190	.626	.025 - .035	1.200	.186	.020 - .040	1.207	.258	.050 - .070
1.180	.357	.150 - .170	1.182	.714	.048 - .062	1.187	.632	.006 - .012	1.190	.626	.050 - .070	1.200	.213	.040 - .060	1.207	.381	.160 - .190
1.180	.383	.048 - .075	1.182	.750	.090 - .120	1.187	.632	.010 - .020	1.190	.738	.050 - .070	<b>1.200</b>	<b>.220</b>	<b>.005 - .010</b>	<b>1.208</b>	<b>.259</b>	<b>.005 - .010</b>
1.180	.398	.005 - .020	1.182	.752	.100 - .125	1.187	.636	.115 - .135	1.190	.752	.042 - .060	1.200	.250	.080 - .100	1.208	.390	.010 - .020
<b>1.180</b>	<b>.409</b>	<b>.005 - .010</b>	<b>1.182</b>	<b>.753</b>	<b>.005 - .010</b>	1.187	.640	.040 - .060	1.190	.753	.015 - .030	<b>1.200</b>	<b>.314</b>	<b>.005 - .010</b>	1.208	.390	.030 - .050
1.180	.438	.050 - .070	1.182	.801	.010 - .020	1.187	.656	.048 - .062	1.190	.753	.030 - .040	1.200	.314	.010 - .020	1.209	.893	.020 - .030
<b>1.180</b>	<b>.475</b>	<b>.005 - .010</b>	1.182	.867	.010 - .020	1.187	.674	.090 - .120	1.190	.787	.080 - .104	1.200	.327	.010 - .020	1.210	.312	.015 - .030
1.180	.476	.025 - .040	<b>1.182</b>	<b>.960</b>	<b>.005 - .010</b>	1.187	.686	.060 - .075	1.190	.817	.048 - .062	<b>1.200</b>	<b>.350</b>	<b>.005 - .010</b>	1.210	.383	.050 - .075
1.180	.485	.010 - .020	<b>1.182</b>	<b>.993</b>	<b>.005 - .010</b>	1.187	.687	.050 - .083	1.190	.881	.025 - .040	<b>1.200</b>	<b>.376</b>	<b>.005 - .010</b>	1.210	.674	.050 - .062
1.180	.499	.015 - .025	1.183	.405	.010 - .020	1.187	.753	.050 - .060	1.190	.918	.010 - .020	1.200	.376	.010 - .020	<b>1.210</b>	<b>.878</b>	<b>.005 - .010</b>
1.180	.521	.070 - .090	1.183	.807	.006 - .015	1.187	.755	.020 - .040	<b>1.190</b>	<b>1.125</b>	<b>.005 - .010</b>	1.200	.377	.100 - .125	1.210	.878	.010 - .020
1.180	.540	.015 - .025	1.183	.933	.070 - .090	1.187	.757	.100 - .125	1.191	.460	.020 - .040	<b>1.200</b>	<b>.378</b>	<b>.005 - .010</b>	1.210	.958	.100 - .125
1.180	.563	.010 - .020	1.183	1.000	.040 - .060	1.187	.765	.025 - .040	1.191	.560	.170 - .190	1.200	.378	.100 - .125	1.210	1.038	.050 - .075
1.180	.635	.040 - .060	1.184	.127	.060 - .083	1.187	.765	.050 - .083	<b>1.191</b>	<b>.882</b>	<b>.005 - .010</b>	1.200	.383	.090 - .125	1.211	.201	.010 - .020
1.180	.671	.150 - .170	1.184	.585	.010 - .020	1.187	.812	.062 - .083	1.191	.900	.070 - .090	<b>1.200</b>	<b>.440</b>	<b>.005 - .010</b>	1.211	.403	.075 - .090
1.180	.694	.080 - .104	1.184	.635	.062 - .083	1.187	.823	.032 - .050	1.191	.934	.050 - .075	1.200	.440	.012 - .020	1.211	.751	.050 - .075
1.180	.714	.120 - .135	1.184	.730	.025 - .040	1.187	.823	.060 - .083	1.192	.739	.030 - .050	<b>1.200</b>	<b>.500</b>	<b>.005 - .010</b>	<b>1.211</b>	<b>1.005</b>	<b>.005 - .010</b>
1.180	.747	.030 - .050	<b>1.184</b>	<b>.753</b>	<b>.005 - .010</b>	1.187	.823	.090 - .120	1.192	.778	.040 - .060	1.200	.500	.010 - .020	1.211	1.035	.010 - .020
1.180	.773	.015 - .030	<b>1.184</b>	<b>.807</b>	<b>.005 - .010</b>	<b>1.187</b>	<b>.825</b>	<b>.005 - .010</b>	1.192	1.004	.015 - .025	<b>1.200</b>	<b>.501</b>	<b>.005 - .010</b>	1.212	.994	.030 - .050
1.180	.787	.010 - .020	<b>1.184</b>	<b>.995</b>	<b>.005 - .010</b>	1.187	.874	.010 - .020	1.192	1.014	.020 - .040	1.200	.501	.015 - .020	1.212	1.015	.020 - .040
1.180	.788	.090 - .105	<b>1.184</b>	<b>1.073</b>	<b>.005 - .010</b>	1.187	.880	.010 - .020	<b>1.193</b>	<b>.159</b>	<b>.005 - .010</b>	<b>1.200</b>	<b>.502</b>	<b>.005 - .010</b>	1.212	1.016	.020 - .040
1.180	.789	.010 - .020	1.185	.089	.060 - .090	<b>1.187</b>	<b>.881</b>	<b>.005 - .010</b>	1.								

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To		
1.218	.380	.040 - .060	<b>1.227</b>	<b>.812</b>	<b>.005 - .010</b>	1.240	.380	.030 - .048	<b>1.245</b>	<b>.773</b>	<b>.005 - .010</b>	<b>1.248</b>	<b>.510</b>	<b>.005 - .010</b>	<b>1.250</b>				
1.218	.439	.030 - .050	1.228	.661	.080 - .100	1.240	.451	.015 - .030	1.245	.788	.025 - .040	<b>1.248</b>	<b>.517</b>	<b>.005 - .010</b>					
<b>1.218</b>	<b>.474</b>	<b>.005 - .010</b>	1.228	.926	.010 - .020	1.240	.484	.070 - .090	1.245	.836	.030 - .050	1.248	.517	.100 - .125					
1.218	.565	.042 - .062	<b>1.228</b>	<b>1.012</b>	<b>.005 - .010</b>	1.240	.560	.075 - .105	1.245	.880	.015 - .030	<b>1.248</b>	<b>.532</b>	<b>.005 - .010</b>					
1.218	.758	.025 - .035	<b>1.229</b>	<b>.416</b>	<b>.005 - .010</b>	1.240	.697	.030 - .050	1.245	.887	.050 - .070	<b>1.248</b>	<b>.535</b>	<b>.005 - .010</b>					
1.218	.855	.060 - .075	1.229	.591	.040 - .060	1.240	.697	.050 - .072	1.245	.921	.030 - .050	1.248	.550	.050 - .070		1.250	.082	.025 - .040	
1.218	.856	.060 - .075	1.229	.753	.020 - .040	1.240	.710	.040 - .060	<b>1.245</b>	<b>.945</b>	<b>.005 - .010</b>	1.248	.627	.010 - .020		1.250	.125	.050 - .075	
1.218	.889	.050 - .062	1.229	.757	.025 - .040	1.240	.749	.010 - .020	1.245	.945	.010 - .020	1.248	.651	.090 - .105		1.250	.127	.031 - .048	
1.218	1.038	.060 - .080	1.229	.757	.050 - .070	1.240	.812	.025 - .040	1.245	.947	.080 - .104	<b>1.248</b>	<b>.656</b>	<b>.005 - .010</b>		1.250	.140	.020 - .030	
1.218	1.076	.025 - .040	1.229	.785	.032 - .050	<b>1.240</b>	<b>.814</b>	<b>.005 - .010</b>	1.245	.948	.070 - .090	1.248	.689	.050 - .070		1.250	.140	.100 - .125	
1.219	.268	.060 - .080	1.229	.861	.070 - .090	1.240	.875	.030 - .050	1.245	.990	.100 - .125	<b>1.248</b>	<b>.695</b>	<b>.005 - .010</b>	1.250	.148	.008 - .016		
<b>1.219</b>	<b>.270</b>	<b>.005 - .010</b>	1.229	.917	.025 - .042	1.240	.875	.100 - .125	1.245	1.010	.020 - .040	<b>1.248</b>	<b>.723</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.164</b>	<b>.005 - .010</b>		
1.219	.270	.010 - .025	<b>1.229</b>	<b>.919</b>	<b>.005 - .010</b>	1.240	.937	.090 - .105	1.245	1.010	.080 - .105	1.248	.742	.100 - .125	1.250	.165	.060 - .083		
1.219	.315	.035 - .050	1.229	.920	.010 - .020	1.240	.938	.020 - .040	1.245	1.107	.010 - .020	1.248	.749	.050 - .070	1.250	.170	.030 - .060		
<b>1.219</b>	<b>.473</b>	<b>.005 - .010</b>	1.230	.145	.050 - .070	1.240	.960	.025 - .040	<b>1.245</b>	<b>1.123</b>	<b>.005 - .010</b>	<b>1.248</b>	<b>.750</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.182</b>	<b>.005 - .010</b>		
1.219	.515	.050 - .075	1.230	.176	.040 - .060	1.240	1.015	.025 - .042	<b>1.245</b>	<b>1.126</b>	<b>.005 - .010</b>	1.248	.752	.008 - .015	1.250	.187	.040 - .060		
1.219	.534	.050 - .075	1.230	.201	.125 - .156	1.240	1.015	.040 - .060	1.245	1.143	.005 - .015	1.248	.780	.080 - .104	1.250	.187	.062 - .083		
<b>1.219</b>	<b>.552</b>	<b>.005 - .010</b>	1.230	.378	.060 - .080	1.240	1.036	.030 - .050	1.246	.252	.080 - .104	<b>1.248</b>	<b>.810</b>	<b>.005 - .010</b>	1.250	.192	.040 - .062		
1.219	.595	.025 - .042	1.230	.381	.042 - .062	<b>1.240</b>	<b>1.070</b>	<b>.005 - .010</b>	1.246	.254	.015 - .030	1.248	.811	.040 - .060	1.250	.193	.030 - .040		
<b>1.219</b>	<b>.801</b>	<b>.005 - .010</b>	1.230	.501	.050 - .070	1.240	1.075	.030 - .050	1.246	.261	.075 - .090	1.248	.811	.080 - .100	1.250	.193	.040 - .060		
1.219	.890	.020 - .040	1.230	.612	.050 - .070	1.240	1.120	.025 - .042	1.246	.384	.050 - .083	1.248	.813	.040 - .062	1.250	.203	.016 - .025		
1.219	.940	.040 - .060	<b>1.230</b>	<b>.761</b>	<b>.005 - .010</b>	<b>1.241</b>	<b>.279</b>	<b>.005 - .010</b>	<b>1.246</b>	<b>.566</b>	<b>.005 - .010</b>	<b>1.248</b>	<b>.877</b>	<b>.005 - .010</b>	1.250	.203	.100 - .125		
1.219	1.000	.020 - .030	1.230	.766	.050 - .070	1.241	.279	.020 - .030	1.246	.701	.110 - .130	<b>1.248</b>	<b>.878</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.208</b>	<b>.005 - .010</b>		
1.219	1.000	.050 - .075	1.230	.766	.104 - .134	1.241	.641	.050 - .075	1.246	.741	.015 - .030	1.248	.878	.010 - .025	1.250	.213	.010 - .020		
1.220	.125	.015 - .030	1.230	.890	.030 - .050	1.241	.750	.030 - .050	1.246	.750	.010 - .015	1.248	.909	.010 - .015	1.250	.217	.015 - .030		
1.220	.194	.075 - .100	1.230	.911	.015 - .025	1.241	.761	.105 - .125	1.246	.753	.050 - .070	<b>1.248</b>	<b>.932</b>	<b>.005 - .010</b>	1.250	.227	.005 - .015		
1.220	.283	.015 - .030	1.230	.921	.025 - .040	1.241	.782	.110 - .130	1.246	.754	.060 - .090	1.248	.950	.030 - .050	1.250	.250	.020 - .030		
<b>1.220</b>	<b>.394</b>	<b>.005 - .010</b>	1.230	.925	.010 - .030	1.241	.788	.010 - .020	1.246	.761	.070 - .090	1.248	.984	.010 - .020	1.250	.252	.012 - .025		
1.220	.394	.010 - .020	1.230	.981	.020 - .030	1.241	.937	.030 - .050	1.246	.768	.015 - .030	1.248	1.000	.062 - .083	1.250	.252	.060 - .090		
1.220	.455	.012 - .020	1.230	1.053	.020 - .030	1.241	.945	.020 - .040	1.246	.769	.040 - .060	<b>1.248</b>	<b>1.004</b>	<b>.062 - .083</b>	1.250	.254	.005 - .012		
<b>1.220</b>	<b>.476</b>	<b>.005 - .010</b>	1.230	1.053	.030 - .040	1.241	.994	.020 - .030	1.246	.781	.020 - .040	<b>1.248</b>	<b>1.020</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.255</b>	<b>.005 - .010</b>		
<b>1.220</b>	<b>.504</b>	<b>.005 - .010</b>	<b>1.230</b>	<b>1.080</b>	<b>.005 - .010</b>	1.241	1.063	.020 - .035	1.246	.783	.020 - .040	1.248	1.060	.005 - .015	<b>1.250</b>	<b>.259</b>	<b>.005 - .010</b>		
1.220	.504	.100 - .125	1.231	.915	.010 - .020	1.241	1.110	.050 - .070	1.246	.839	.060 - .080	1.248	1.145	.040 - .060	1.250	.260	.040 - .060		
1.220	.507	.110 - .134	<b>1.231</b>	<b>1.048</b>	<b>.005 - .010</b>	1.242	.452	.020 - .030	<b>1.246</b>	<b>.880</b>	<b>.005 - .010</b>	<b>1.249</b>	<b>.140</b>	<b>.005 - .010</b>	1.250	.262	.050 - .075		
1.220	.602	.090 - .120	1.232	.185	.015 - .030	1.242	.535	.090 - .100	1.246	.909	.050 - .075	1.249	.140	.010 - .020	1.250	.264	.010 - .020		
1.220	.640	.100 - .125	<b>1.232</b>	<b>.500</b>	<b>.005 - .010</b>	1.242	.641	.062 - .090	<b>1.246</b>	<b>.937</b>	<b>.005 - .010</b>	1.249	.140	.030 - .050	1.250	.266	.120 - .134		
1.220	.672	.025 - .042	1.232	.661	.040 - .060	1.242	.879	.042 - .062	1.246	1.035	.075 - .090	<b>1.249</b>	<b>.203</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.273</b>	<b>.005 - .010</b>		
1.220	.680	.030 - .050	1.233	1.027	.040 - .060	1.242	.944	.040 - .060	1.246	1.046	.020 - .040	1.249	.203	.090 - .105	1.250	.280	.062 - .083		
1.220	.699	.030 - .050	<b>1.233</b>	<b>1.065</b>	<b>.005 - .010</b>	1.243	.220	.035 - .060	1.246	1.060	.020 - .040	1.249	.250	.030 - .050	1.250	.283	.060 - .083		
1.220	.799	.010 - .020	1.233	1.131	.020 - .030	1.243	.405	.030 - .050	1.247	.064	.015 - .030	1.249	.318	.170 - .190	1.250	.286	.050 - .075		
1.220	.831	.060 - .083	1.234	.087	.015 - .030	1.243	.491	.125 - .156	1.247	.125	.040 - .060	1.249	.319	.036 - .060	1.250	.295	.025 - .042		
1.220	.844	.050 - .070	1.234	.392	.134 - .156	<b>1.243</b>	<b>.613</b>	<b>.005 - .010</b>	1.247	.254	.060 - .080	1.249	.327	.015 - .030	1.250	.311	.050 - .062		
1.220	.875	.062 - .090	1.234	.505	.070 - .090	<b>1.243</b>	<b>.614</b>	<b>.005 - .010</b>	1.247	.263	.050 - .075	1.249	.328	.090 - .125	<b>1.250</b>	<b>.312</b>	<b>.005 - .010</b>		
1.220	.960	.050 - .062	1.234	.849	.020 - .040	<b>1.243</b>	<b>.699</b>	<b>.005 - .010</b>	1.247	.354	.100 - .125	1.249	.380	.105 - .125	1.250	.314	.105 - .125		
1.220	.960	.062 - .083	1.234	.906	.105 - .120	1.243	.855	.070 - .090	<b>1.247</b>	<b>.378</b>	<b>.005 - .010</b>	1.249	.391	.042 - .060	<b>1.250</b>	<b>.320</b>	<b>.005 - .010</b>		
1.220	1.004	.010 - .020	1.234	.950	.090 - .110	1.243	.965	.090 - .105	<b>1.247</b>	<b>.392</b>	<b>.005 - .010</b>	1.249	.401	.100 - .125	1.250	.327	.020 - .030		
<b>1.220</b>	<b>1.083</b>	<b>.005 - .010</b>	1.234	1.015	.008 - .016	1.243	1.037	.015 - .030	1.247	.450	.020 - .030	1.249	.427	.020 - .040	1.250	.329	.070 - .090		
1.220	1.090	.042 - .062	1.234	1.025	.030 - .050	1.243	1.100	.042 - .060	1.247	.503	.030 - .050	1.249	.444	.036 - .060	1.250	.343	.080 - .100		
1.220	1.116	.040 - .050	1.234	1.080	.020 - .030	1.244	.150	.015 - .030	1.247	.572	.030 - .048	<b>1.249</b>	<b>.450</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.354</b>	<b>.005 - .010</b>		
1.221	.131	.015 - .030	1.235	.500	.010 - .020	1.244	.768	.060 - .080	<b>1.247</b>	<b>.699</b>	<b>.005 - .010</b>	<b>1.249</b>	<b>.495</b>	<b>.005 - .010</b>	1.250	.356	.015 - .030		
1.221	.194	.020 - .040	<b>1.235</b>	<b>.626</b>	<b>.005 - .010</b>	1.244	.768	.105 - .125	1.247	.754	.050 - .070	1.249	.510	.070 - .090	1.250	.359	.060 - .090		
1.221	.257	.040 - .060	1.235	.626	.010 - .020	1.244	.770	.020 - .040	<b>1.247</b>	<b>.816</b>	<b>.005 - .010</b>	1.249	.516	.030 - .050	1.250	.365	.020 - .040		
1.221	.867	.020 - .040	1.235	.628	.040 - .060	1.244	.770	.050 - .060	1.247	.816	.030 - .0								

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.250	.501	.070 - .090	1.250	.783	.050 - .075	<b>1.251</b>	<b>.500</b>	<b>.005 - .010</b>	<b>1.252</b>	<b>1.127</b>	<b>.005 - .010</b>	1.259	1.181	.030 - .050	1.270	.793	.100 - .125
<b>1.250</b>	<b>.503</b>	<b>.005 - .010</b>	1.250	.784	.050 - .070	1.251	.531	.156 - .187	1.253	.390	.100 - .120	<b>1.260</b>	<b>.237</b>	<b>.005 - .010</b>	1.270	.976	.040 - .060
1.250	.503	.010 - .020	1.250	.785	.040 - .060	1.251	.551	.015 - .030	1.253	.410	.060 - .080	1.260	.301	.100 - .125	<b>1.271</b>	<b>.886</b>	<b>.005 - .010</b>
1.250	.504	.006 - .015	1.250	.789	.105 - .135	1.251	.559	.105 - .125	1.253	.573	.030 - .050	<b>1.260</b>	<b>.319</b>	<b>.005 - .010</b>	1.271	.940	.006 - .012
<b>1.250</b>	<b>.505</b>	<b>.005 - .010</b>	1.250	.791	.010 - .020	1.251	.561	.060 - .080	1.253	.633	.060 - .080	<b>1.260</b>	<b>.398</b>	<b>.005 - .010</b>	1.271	1.005	.025 - .040
1.250	.505	.010 - .020	1.250	.795	.007 - .015	1.251	.561	.090 - .120	1.253	.656	.015 - .030	1.260	.398	.010 - .020	1.271	1.080	.020 - .035
<b>1.250</b>	<b>.507</b>	<b>.005 - .010</b>	1.250	.796	.110 - .125	1.251	.574	.010 - .020	1.253	.766	.156 - .187	<b>1.260</b>	<b>.440</b>	<b>.005 - .010</b>	1.272	.525	.050 - .070
1.250	.508	.015 - .030	1.250	.798	.015 - .030	1.251	.579	.100 - .125	1.253	.768	.030 - .050	1.260	.449	.010 - .020	1.272	.643	.090 - .120
1.250	.508	.048 - .062	1.250	.803	.080 - .100	<b>1.251</b>	<b>.640</b>	<b>.005 - .010</b>	1.253	.780	.156 - .187	<b>1.260</b>	<b>.474</b>	<b>.005 - .010</b>	1.272	.800	.040 - .060
1.250	.510	.090 - .120	1.250	.808	.010 - .020	1.251	.658	.040 - .062	1.253	.782	.008 - .020	<b>1.260</b>	<b>.475</b>	<b>.005 - .010</b>	1.273	.780	.080 - .105
1.250	.520	.020 - .040	1.250	.812	.010 - .020	1.251	.669	.050 - .070	1.253	.886	.050 - .070	<b>1.260</b>	<b>.477</b>	<b>.005 - .010</b>	1.273	.907	.030 - .050
1.250	.520	.040 - .060	1.250	.812	.080 - .104	1.251	.692	.090 - .110	1.253	.914	.020 - .030	<b>1.260</b>	<b>.501</b>	<b>.005 - .010</b>	1.273	.920	.020 - .030
1.250	.534	.036 - .050	1.250	.829	.090 - .120	1.251	.695	.025 - .040	1.253	1.000	.025 - .040	1.260	.503	.100 - .125	1.274	.711	.030 - .050
1.250	.534	.075 - .090	1.250	.839	.120 - .135	1.251	.725	.020 - .040	1.253	1.025	.030 - .050	<b>1.260</b>	<b>.505</b>	<b>.005 - .010</b>	1.274	.969	.080 - .105
<b>1.250</b>	<b>.540</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.843</b>	<b>.005 - .010</b>	1.251	.752	.020 - .030	1.253	1.110	.010 - .020	1.260	.505	.010 - .020	<b>1.274</b>	<b>1.125</b>	<b>.005 - .010</b>
1.250	.540	.100 - .125	1.250	.843	.015 - .030	1.251	.755	.015 - .030	<b>1.253</b>	<b>1.123</b>	<b>.005 - .010</b>	1.260	.553	.010 - .020	1.275	.255	.015 - .030
1.250	.562	.050 - .070	1.250	.845	.050 - .080	1.251	.759	.105 - .135	1.254	.516	.048 - .075	<b>1.260</b>	<b>.630</b>	<b>.005 - .010</b>	1.275	.297	.025 - .042
1.250	.562	.100 - .125	1.250	.855	.040 - .060	1.251	.814	.075 - .100	1.254	.542	.010 - .020	<b>1.260</b>	<b>.632</b>	<b>.005 - .010</b>	1.275	.313	.060 - .090
<b>1.250</b>	<b>.563</b>	<b>.005 - .010</b>	1.250	.875	.120 - .135	<b>1.251</b>	<b>.834</b>	<b>.005 - .010</b>	1.254	.630	.050 - .070	1.260	.682	.060 - .080	1.275	.409	.050 - .070
1.250	.563	.010 - .015	1.250	.876	.030 - .050	1.251	.874	.050 - .075	1.254	.748	.040 - .060	1.260	.683	.060 - .080	1.275	.410	.025 - .042
1.250	.563	.015 - .030	1.250	.878	.040 - .060	<b>1.251</b>	<b>.879</b>	<b>.005 - .010</b>	1.254	.765	.050 - .075	1.260	.750	.062 - .090	1.275	.411	.025 - .040
1.250	.564	.104 - .134	1.250	.879	.050 - .070	1.251	.907	.040 - .062	1.254	.766	.134 - .156	1.260	.750	.090 - .120	1.275	.500	.075 - .090
1.250	.571	.040 - .060	<b>1.250</b>	<b>.880</b>	<b>.005 - .010</b>	1.251	.928	.025 - .040	1.254	.840	.050 - .075	1.260	.827	.040 - .060	1.275	.672	.025 - .042
1.250	.572	.040 - .050	1.250	.880	.015 - .030	1.251	.942	.090 - .105	1.254	1.069	.020 - .040	1.260	.984	.025 - .040	1.275	.797	.025 - .042
1.250	.580	.135 - .156	1.250	.882	.090 - .125	1.251	.984	.010 - .020	1.254	1.083	.030 - .050	1.260	1.002	.080 - .100	1.275	.980	.020 - .040
1.250	.586	.015 - .030	<b>1.250</b>	<b>.887</b>	<b>.005 - .010</b>	<b>1.251</b>	<b>.999</b>	<b>.005 - .010</b>	1.254	1.130	.015 - .030	1.260	1.050	.015 - .025	1.275	1.009	.090 - .110
1.250	.595	.015 - .030	1.250	.888	.012 - .025	<b>1.251</b>	<b>1.003</b>	<b>.005 - .010</b>	1.255	.501	.060 - .080	1.260	1.055	.010 - .015	1.275	1.045	.025 - .042
1.250	.595	.042 - .062	1.250	.889	.060 - .090	1.251	1.005	.090 - .105	1.255	.656	.010 - .020	1.260	1.100	.040 - .060	1.275	1.060	.005 - .008
1.250	.595	.105 - .135	<b>1.250</b>	<b>.890</b>	<b>.005 - .010</b>	<b>1.251</b>	<b>1.050</b>	<b>.005 - .010</b>	1.255	.656	.090 - .120	1.260	1.130	.010 - .020	<b>1.275</b>	<b>1.092</b>	<b>.005 - .010</b>
1.250	.625	.020 - .030	1.250	.890	.062 - .090	1.251	1.081	.070 - .090	1.255	.664	.090 - .105	1.261	.126	.010 - .012	1.276	.105	.025 - .040
1.250	.625	.100 - .125	1.250	.893	.015 - .030	1.251	1.082	.020 - .040	1.255	.714	.110 - .125	<b>1.261</b>	<b>.195</b>	<b>.005 - .010</b>	1.276	.821	.050 - .070
1.250	.630	.050 - .070	1.250	.895	.025 - .040	1.251	1.099	.010 - .020	1.255	.843	.135 - .187	1.261	.217	.105 - .135	1.277	.657	.083 - .105
1.250	.630	.080 - .100	1.250	.895	.050 - .070	1.251	1.110	.020 - .030	<b>1.255</b>	<b>.845</b>	<b>.005 - .010</b>	1.261	.316	.090 - .125	1.277	.964	.020 - .030
<b>1.250</b>	<b>.636</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>.902</b>	<b>.005 - .010</b>	1.252	.268	.030 - .050	1.255	.872	.030 - .050	<b>1.261</b>	<b>.414</b>	<b>.005 - .010</b>	1.277	1.059	.050 - .070
<b>1.250</b>	<b>.637</b>	<b>.005 - .010</b>	1.250	.907	.040 - .060	1.252	.280	.105 - .135	1.255	.960	.040 - .060	1.261	.505	.070 - .090	1.278	.250	.005 - .015
1.250	.640	.030 - .040	1.250	.937	.100 - .125	1.252	.316	.025 - .040	1.255	1.031	.020 - .030	1.261	.509	.105 - .125	1.278	.500	.100 - .125
1.250	.640	.040 - .060	1.250	.939	.100 - .125	1.252	.316	.050 - .070	1.255	1.079	.020 - .030	<b>1.261</b>	<b>.632</b>	<b>.005 - .010</b>	1.278	.529	.100 - .125
1.250	.640	.060 - .080	1.250	.953	.015 - .030	1.252	.317	.135 - .156	1.256	.139	.050 - .083	1.261	1.004	.070 - .090	<b>1.278</b>	<b>.571</b>	<b>.005 - .010</b>
1.250	.641	.100 - .125	1.250	.953	.060 - .083	1.252	.319	.050 - .070	1.256	.329	.075 - .100	<b>1.261</b>	<b>1.016</b>	<b>.005 - .010</b>	1.278	.750	.015 - .030
1.250	.646	.005 - .015	1.250	.986	.090 - .105	1.252	.329	.048 - .062	1.256	.507	.050 - .070	1.261	1.063	.030 - .042	1.278	.821	.030 - .050
1.250	.647	.090 - .125	1.250	.990	.030 - .040	1.252	.343	.156 - .190	1.256	.519	.100 - .125	1.262	.187	.020 - .035	<b>1.278</b>	<b>.924</b>	<b>.005 - .010</b>
<b>1.250</b>	<b>.650</b>	<b>.005 - .010</b>	1.250	.995	.060 - .080	<b>1.252</b>	<b>.376</b>	<b>.005 - .010</b>	1.256	.613	.015 - .030	1.262	.295	.020 - .040	<b>1.279</b>	<b>.438</b>	<b>.005 - .010</b>
1.250	.656	.070 - .090	1.250	1.000	.093 - .125	1.252	.376	.010 - .020	1.256	.941	.125 - .156	<b>1.262</b>	<b>.535</b>	<b>.005 - .010</b>	1.279	.633	.050 - .060
1.250	.656	.090 - .120	1.250	1.007	.042 - .062	1.252	.396	.040 - .060	1.256	1.080	.062 - .080	1.262	.951	.030 - .050	1.280	.155	.005 - .015
1.250	.656	.156 - .187	1.250	1.010	.010 - .020	1.252	.407	.090 - .110	<b>1.257</b>	<b>.605</b>	<b>.005 - .010</b>	1.263	.882	.105 - .135	1.280	.170	.100 - .125
<b>1.250</b>	<b>.658</b>	<b>.005 - .010</b>	<b>1.250</b>	<b>1.011</b>	<b>.005 - .010</b>	1.252	.408	.025 - .042	1.257	.673	.020 - .030	1.263	1.075	.090 - .105	1.280	.221	.070 - .090
1.250	.660	.020 - .040	1.250	1.012	.050 - .070	1.252	.426	.100 - .125	1.257	.787	.120 - .135	1.263	1.085	.010 - .020	1.280	.318	.050 - .062
1.250	.662	.105 - .125	1.250	1.017	.060 - .083	1.252	.437	.060 - .075	1.257	.933	.030 - .048	1.263	1.089	.025 - .035	1.280	.518	.020 - .040
1.250	.665	.030 - .040	1.250	1.020	.100 - .120	1.252	.442	.125 - .156	1.257	.941	.125 - .156	1.264	.548	.030 - .050	1.280	.628	.040 - .060
<b>1.250</b>	<b>.669</b>	<b>.005 - .010</b>	1.250	1.035	.050 - .070	<b>1.252</b>	<b>.506</b>	<b>.005 - .010</b>	<b>1.257</b>	<b>.956</b>	<b>.005 - .010</b>	1.265	.354	.120 - .134	1.280	.668	.062 - .090
1.250	.675	.015 - .030	1.250	1.036	.080 - .105	1.252	.585	.030 - .050	<b>1.257</b>	<b>1.014</b>	<b>.005 - .010</b>	1.265	.376	.060 - .080	1.280	.668	.090 - .120
1.250	.680	.105 - .125	1.250	1.051	.010 - .020	<b>1.252</b>	<b>.625</b>	<b>.005 - .010</b>	1.257	1.100	.005 - .015	<b>1.265</b>	<b>.504</b>	<b>.005 - .010</b>	1.280	.677	.030 - .050
1.250	.683	.010 - .020	1.250	1.058	.072 - .093	1.252	.629	.020 - .030	1.257	1.166	.025 - .040	1.265	.533	.100 - .125	1.280	.760	.040 - .060
1.250	.688	.090 - .125	1.250	1.061	.025 - .040	1.252	.630	.105 - .125	<b>1.258</b>	<b>.380</b>	<b>.005 - .010</b>	1.265	.866	.080 - .100	1.280	.888	.070 - .090
1.250	.689	.010 - .020	1.250	1.115	.010 - .020	1.252	.633	.050 - .075	<b>1.258</b>	<b>.473</b>	<b>.005 - .010</b>	1.265	.875	.040 - .060	<b>1.280</b>	<b>.893</b>	<b>.005 - .010</b>
1.250	.689	.030 - .040	1.250	1.123	.025 - .040	1.252	.640	.008 - .016	<b>1.258</b>	<b>.474</b>	<b>.005 - .010</b>	1.265	.930	.010 - .020	1.280	.915	.007 - .012
<b>1.250</b>	<b>.690</b>	<b>.005 - .010</b>	1.250	1.140	.015 - .025	<b>1.252</b>	<b>.753</b>	<b>.005 - .010</b>	<b>1.258</b>	<b>.478</b>	<b>.005 - .010</b>	1.265	.990	.100 - .125	1.280	1.000	.060 - .090
1.250	.701	.015 - .025	1.250	1.145	.020 - .040	<b>1.252</b>	<b>.755</b>	<b>.005 - .010</b>	1.258	.538	.010 - .020	1.265	1.000	.060 - .075	1.280	1.017	.025 - .040
1.250	.701	.090 - .105	1.250	1.167	.010 - .025	<b>1.252</b>	<b>.765</b>	<b>.005 - .010</b>	1.258	.632	.015 - .030	<b>1.265</b>	<b>1.206</b>				

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.282	.310	.075 - .090	1.298	.220	.060 - .080	1.301	.504	.010 - .020	1.310	.878	.015 - .030	1.313	.687	.105 - .125	1.323	.666	.100 - .125
<b>1.282</b>	<b>.408</b>	<b>.005 - .010</b>	1.298	.275	.050 - .075	<b>1.301</b>	<b>.698</b>	<b>.005 - .010</b>	<b>1.310</b>	<b>.944</b>	<b>.005 - .010</b>	1.313	.751	.025 - .040	1.323	1.001	.015 - .030
<b>1.282</b>	<b>.409</b>	<b>.005 - .010</b>	1.298	.395	.010 - .020	1.301	.756	.018 - .025	<b>1.310</b>	<b>1.006</b>	<b>.005 - .010</b>	1.313	.759	.080 - .100	1.323	1.063	.050 - .070
1.282	.580	.010 - .020	1.298	.441	.010 - .020	1.301	.820	.040 - .060	<b>1.310</b>	<b>1.049</b>	<b>.005 - .010</b>	1.313	.874	.020 - .040	1.324	.320	.010 - .020
1.282	.942	.010 - .020	1.298	.479	.105 - .125	1.301	.901	.080 - .110	1.310	1.130	.005 - .015	1.313	.951	.070 - .090	1.324	.529	.105 - .135
<b>1.282</b>	<b>1.020</b>	<b>.005 - .010</b>	1.298	.496	.030 - .050	1.301	.945	.080 - .105	1.311	.189	.040 - .060	1.313	1.015	.060 - .083	<b>1.324</b>	<b>.687</b>	<b>.005 - .010</b>
1.282	1.043	.030 - .050	1.298	.504	.090 - .110	1.301	.962	.105 - .125	1.311	.202	.020 - .040	1.313	1.063	.040 - .060	1.324	.687	.015 - .030
1.282	1.066	.040 - .060	<b>1.298</b>	<b>.630</b>	<b>.005 - .010</b>	1.301	1.068	.030 - .050	1.311	.261	.020 - .036	1.313	1.118	.015 - .035	1.324	.808	.105 - .125
1.282	1.162	.010 - .020	<b>1.298</b>	<b>.640</b>	<b>.005 - .010</b>	1.302	.441	.100 - .125	1.311	.261	.025 - .040	1.313	1.148	.020 - .030	1.324	1.001	.020 - .040
1.282	1.164	.010 - .020	1.298	.880	.070 - .090	1.302	.477	.050 - .070	1.311	.335	.080 - .100	1.313	1.164	.025 - .040	1.325	.125	.010 - .020
<b>1.283</b>	<b>.104</b>	<b>.005 - .010</b>	1.298	.906	.015 - .025	1.302	.628	.100 - .125	1.311	.380	.030 - .050	1.314	.268	.030 - .060	1.325	.139	.040 - .060
1.283	.375	.020 - .035	1.299	.140	.020 - .040	1.302	.774	.060 - .090	1.311	.389	.025 - .040	1.314	.341	.060 - .080	1.325	.141	.010 - .020
1.283	.409	.010 - .020	<b>1.299</b>	<b>.245</b>	<b>.005 - .010</b>	1.302	.787	.100 - .125	1.311	.500	.025 - .040	1.314	.392	.040 - .060	1.325	.157	.010 - .020
1.283	.671	.015 - .025	1.299	.253	.030 - .040	1.302	1.007	.012 - .020	<b>1.311</b>	<b>.573</b>	<b>.005 - .010</b>	1.314	.439	.050 - .075	1.325	.171	.005 - .015
1.283	.890	.015 - .030	<b>1.299</b>	<b>.385</b>	<b>.005 - .010</b>	<b>1.302</b>	<b>1.200</b>	<b>.005 - .010</b>	1.311	.593	.075 - .090	1.314	.441	.105 - .135	1.325	.172	.010 - .020
1.283	1.126	.040 - .060	<b>1.299</b>	<b>.395</b>	<b>.005 - .010</b>	<b>1.303</b>	<b>.194</b>	<b>.005 - .010</b>	<b>1.311</b>	<b>.635</b>	<b>.005 - .010</b>	1.314	.522	.015 - .030	1.325	.204	.010 - .020
<b>1.283</b>	<b>1.167</b>	<b>.005 - .010</b>	1.299	.395	.010 - .020	<b>1.303</b>	<b>.504</b>	<b>.005 - .010</b>	1.311	.655	.090 - .110	1.314	.593	.015 - .030	1.325	.218	.010 - .020
1.284	.192	.050 - .070	<b>1.299</b>	<b>.396</b>	<b>.005 - .010</b>	1.303	.899	.040 - .060	<b>1.311</b>	<b>.676</b>	<b>.005 - .010</b>	1.314	.626	.100 - .125	1.325	.251	.010 - .020
1.284	.324	.080 - .104	1.299	.471	.030 - .050	1.304	.470	.075 - .104	<b>1.311</b>	<b>.858</b>	<b>.005 - .010</b>	1.314	.673	.015 - .025	1.325	.270	.010 - .020
1.284	.787	.050 - .070	<b>1.299</b>	<b>.473</b>	<b>.005 - .010</b>	1.304	.470	.100 - .125	1.311	.875	.020 - .040	1.314	.827	.010 - .020	1.325	.281	.040 - .060
1.284	1.019	.010 - .020	1.299	.553	.005 - .015	1.304	.504	.090 - .120	1.311	.884	.050 - .075	1.314	.969	.040 - .060	1.325	.295	.080 - .104
1.284	1.089	.015 - .030	1.299	.626	.010 - .020	<b>1.304</b>	<b>1.189</b>	<b>.005 - .010</b>	1.311	.884	.120 - .135	1.314	1.062	.006 - .016	1.325	.301	.012 - .025
<b>1.284</b>	<b>1.208</b>	<b>.005 - .010</b>	1.299	.812	.025 - .040	1.304	1.189	.008 - .016	1.311	.890	.030 - .050	1.314	1.090	.042 - .062	1.325	.350	.010 - .020
1.285	.409	.120 - .135	1.299	.922	.040 - .060	1.305	.080	.005 - .008	1.311	.947	.020 - .040	<b>1.315</b>	<b>.177</b>	<b>.005 - .010</b>	1.325	.381	.010 - .020
<b>1.285</b>	<b>1.136</b>	<b>.005 - .010</b>	1.299	.958	.050 - .070	1.305	.514	.100 - .120	1.311	.995	.030 - .050	1.315	.253	.080 - .104	1.325	.410	.010 - .015
1.286	.251	.060 - .090	<b>1.299</b>	<b>.960</b>	<b>.005 - .010</b>	1.305	.705	.062 - .090	<b>1.311</b>	<b>1.001</b>	<b>.005 - .010</b>	1.315	.522	.010 - .020	1.325	.440	.010 - .015
1.286	.509	.156 - .187	1.299	1.019	.016 - .042	1.305	.705	.090 - .120	1.311	1.005	.030 - .048	<b>1.315</b>	<b>.560</b>	<b>.005 - .010</b>	1.325	.440	.104 - .134
<b>1.286</b>	<b>.809</b>	<b>.005 - .010</b>	1.299	1.030	.015 - .025	1.305	.803	.040 - .060	1.311	1.009	.030 - .040	1.315	.626	.100 - .125	1.325	.500	.010 - .015
1.286	.811	.090 - .105	<b>1.299</b>	<b>1.068</b>	<b>.005 - .010</b>	1.305	.825	.040 - .060	<b>1.311</b>	<b>1.190</b>	<b>.005 - .010</b>	1.315	.923	.020 - .030	1.325	.600	.010 - .015
1.286	.918	.010 - .020	1.300	.147	.080 - .104	1.305	.826	.100 - .125	1.312	.197	.025 - .040	<b>1.315</b>	<b>1.177</b>	<b>.005 - .010</b>	1.325	.640	.010 - .015
1.287	.178	.050 - .083	1.300	.298	.020 - .030	1.305	.942	.020 - .040	1.312	.234	.050 - .075	<b>1.316</b>	<b>.655</b>	<b>.005 - .010</b>	1.325	.700	.010 - .015
1.287	.251	.060 - .090	<b>1.300</b>	<b>.312</b>	<b>.005 - .010</b>	1.305	1.006	.015 - .030	1.312	.251	.050 - .070	1.316	.745	.080 - .100	1.325	.750	.010 - .015
1.287	.254	.050 - .062	1.300	.316	.105 - .125	<b>1.305</b>	<b>1.011</b>	<b>.005 - .010</b>	1.312	.314	.075 - .090	1.316	.881	.020 - .040	1.325	.810	.010 - .020
1.287	.264	.010 - .020	<b>1.300</b>	<b>.318</b>	<b>.005 - .010</b>	1.306	.758	.040 - .060	1.312	.320	.030 - .050	1.316	.885	.025 - .050	1.325	.900	.050 - .075
<b>1.287</b>	<b>1.142</b>	<b>.005 - .010</b>	1.300	.368	.025 - .040	1.306	.970	.015 - .025	1.312	.374	.020 - .040	1.316	.940	.010 - .015	1.325	.920	.010 - .015
1.288	.614	.050 - .070	<b>1.300</b>	<b>.377</b>	<b>.005 - .010</b>	1.306	.996	.007 - .015	1.312	.377	.020 - .030	1.316	.978	.042 - .060	1.325	1.055	.080 - .104
1.288	.761	.030 - .050	1.300	.377	.010 - .020	1.306	1.007	.050 - .080	1.312	.392	.030 - .060	1.317	.502	.030 - .050	1.325	1.179	.080 - .100
1.288	.777	.100 - .120	<b>1.300</b>	<b>.378</b>	<b>.005 - .010</b>	1.306	1.007	.075 - .090	1.312	.505	.010 - .015	<b>1.317</b>	<b>.744</b>	<b>.005 - .010</b>	1.326	.314	.025 - .040
1.288	1.023	.015 - .030	1.300	.378	.010 - .020	1.306	1.070	.015 - .030	1.312	.507	.042 - .062	1.317	1.051	.010 - .020	1.326	.570	.015 - .030
1.288	1.111	.020 - .035	1.300	.382	.010 - .020	<b>1.306</b>	<b>1.167</b>	<b>.005 - .010</b>	<b>1.312</b>	<b>.553</b>	<b>.005 - .010</b>	1.317	1.115	.080 - .100	1.326	.570	.050 - .070
1.288	1.113	.075 - .090	1.300	.383	.020 - .030	<b>1.306</b>	<b>1.184</b>	<b>.005 - .010</b>	<b>1.312</b>	<b>.563</b>	<b>.005 - .010</b>	1.317	1.198	.020 - .035	1.326	.751	.010 - .020
1.288	1.128	.040 - .060	<b>1.300</b>	<b>.394</b>	<b>.005 - .010</b>	1.307	.502	.010 - .020	1.312	.564	.020 - .040	1.317	1.250	.020 - .032	<b>1.326</b>	<b>1.022</b>	<b>.005 - .010</b>
1.288	1.150	.015 - .030	1.300	.394	.010 - .020	<b>1.307</b>	<b>.655</b>	<b>.005 - .010</b>	1.312	.565	.090 - .110	<b>1.318</b>	<b>.180</b>	<b>.005 - .010</b>	1.327	.680	.030 - .050
1.289	1.113	.075 - .090	1.300	.397	.010 - .020	1.307	1.068	.075 - .090	<b>1.312</b>	<b>.566</b>	<b>.005 - .010</b>	1.318	.746	.050 - .075	1.328	.126	.016 - .025
1.290	.128	.020 - .030	<b>1.300</b>	<b>.437</b>	<b>.005 - .010</b>	1.308	.125	.040 - .062	1.312	.594	.075 - .090	1.318	1.005	.040 - .062	1.328	.415	.156 - .187
1.290	.231	.105 - .135	1.300	.438	.010 - .020	1.308	.220	.050 - .070	1.312	.625	.100 - .125	1.318	1.005	.090 - .125	1.328	1.020	.025 - .040
<b>1.290</b>	<b>.264</b>	<b>.005 - .010</b>	<b>1.300</b>	<b>.440</b>	<b>.005 - .010</b>	<b>1.308</b>	<b>.251</b>	<b>.005 - .010</b>	1.312	.634	.040 - .062	1.319	.387	.090 - .125	1.329	.175	.050 - .083
1.290	.377	.020 - .030	1.300	.440	.010 - .020	<b>1.308</b>	<b>.619</b>	<b>.005 - .010</b>	1.312	.655	.015 - .030	<b>1.319</b>	<b>.715</b>	<b>.005 - .010</b>	1.329	.791	.105 - .125
1.290	.627	.020 - .030	1.300	.511	.010 - .020	1.308	.751	.050 - .075	1.312	.687	.025 - .035	<b>1.319</b>	<b>.716</b>	<b>.005 - .010</b>	1.329	.900	.050 - .075
1.290	.760	.030 - .060	1.300	.518	.010 - .020	1.308	.762	.070 - .090	1.312	.703	.100 - .125	1.319	.851	.040 - .060	1.329	.990	.105 - .134
1.290	1.000	.050 - .070	1.300	.558	.010 - .020	1.309	.311	.105 - .125	1.312	.720	.050 - .070	1.319	1.070	.015 - .030	1.329	1.001	.080 - .100
1.290	1.146	.050 - .060	1.300	.628	.020 - .035	1.309	.377	.005 - .015	1.312	.748	.050 - .062	1.319	1.075	.050 - .070	1.329	1.174	.060 - .070
<b>1.290</b>	<b>1.204</b>	<b>.005 - .010</b>	<b>1.300</b>	<b>.629</b>	<b>.005 - .010</b>	1.309	.392	.030 - .048	1.312	.755	.105 - .125	<b>1.319</b>	<b>1.130</b>	<b>.005 - .010</b>	<b>1.329</b>	<b>1.180</b>	<b>.005 - .010</b>
1.291	.966	.020 - .040	1.300	.629	.010 - .020	1.309	.607	.025 - .040	1.312	.765	.090 - .120	<b>1.320</b>	<b>.183</b>	<b>.005 - .010</b>	1.329	1.190	.030 - .050
<b>1.291</b>	<b>1.180</b>	<b>.005 - .010</b>	1.300	.629	.020 - .030	1.309	.635	.010 - .020	1.312	.766	.050 - .075	<b>1.320</b>	<b>.210</b>	<b>.005 - .010</b>	<b>1.330</b>	<b>.328</b>	<b>.005 - .010</b>
<b>1.292</b>	<b>1.000</b>	<b>.005 - .010</b>	1.300	.630	.050 - .075	<b>1.309</b>	<b>.791</b>	<b>.005 - .010</b>	1.312	.781	.020 - .035	1.320	.318	.105 - .125	1.330	.391	.156 - .190
1.292	1.121	.010 - .020	1.300	.635	.010 - .020	1.309	.813	.020 - .035	1.312	.781	.075 - .090	1.320	.476	.010 - .020	1.330	.744	.030 - .060
1.292	1.132	.060 - .080	1.300	.650	.080 - .105	1.309	.816	.007 - .016	1.312	.781	.100 - .125	1.320	.495	.062 - .090	1.330	.851	.040 - .060
<b>1.293</b>	<b>.378</b>	<b>.005 - .010</b>	1.300	.677													

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.337	.475	.005 - .010	1.345	.408	.005 - .010	1.351	1.026	.060 - .080	1.364	.664	.005 - .010	1.369	.885	.005 - .015	1.372	1.135	.050 - .070
1.337	.500	.100 - .125	1.345	.818	.050 - .070	1.351	1.049	.010 - .020	1.364	.665	.070 - .090	1.369	.893	.125 - .156	1.372	1.145	.050 - .062
1.337	.502	.005 - .010	1.345	.836	.005 - .010	1.351	1.091	.025 - .040	1.364	.701	.040 - .060	1.369	1.001	.015 - .030	1.372	1.145	.080 - .105
1.337	.502	.010 - .020	1.345	.907	.060 - .090	1.351	1.164	.015 - .030	1.364	.780	.135 - .156	1.369	1.145	.090 - .105	1.372	1.153	.030 - .050
1.337	.747	.025 - .040	1.345	.967	.100 - .125	1.351	1.209	.010 - .020	1.364	.788	.070 - .090	1.369	1.188	.010 - .015	1.372	1.189	.030 - .050
1.337	.748	.010 - .020	1.345	1.001	.010 - .020	1.351	1.212	.010 - .020	1.364	.911	.070 - .090	1.370	.144	.030 - .050	1.372	1.191	.005 - .010
1.337	.856	.010 - .020	1.345	1.039	.025 - .040	1.351	1.253	.005 - .010	1.364	.912	.080 - .100	1.370	.192	.030 - .050	1.372	1.210	.010 - .020
1.337	.884	.005 - .010	1.345	1.040	.015 - .030	1.352	.776	.050 - .075	1.364	1.002	.008 - .016	1.370	.234	.100 - .125	1.372	1.213	.020 - .035
1.337	.945	.060 - .080	1.345	1.173	.015 - .030	1.353	.988	.075 - .090	1.364	1.011	.030 - .050	1.370	.282	.080 - .100	1.373	.218	.040 - .062
1.337	.984	.005 - .010	1.345	1.174	.015 - .025	1.353	1.070	.050 - .070	1.364	1.042	.080 - .100	1.370	.300	.075 - .104	1.373	.234	.105 - .125
1.337	.984	.025 - .040	1.346	.201	.060 - .080	1.354	.315	.020 - .040	1.364	1.182	.005 - .010	1.370	.300	.100 - .125	1.373	.250	.016 - .032
1.337	1.001	.070 - .090	1.346	.443	.005 - .010	1.354	.538	.005 - .010	1.364	1.191	.010 - .020	1.370	.316	.005 - .010	1.373	.255	.040 - .060
1.337	1.094	.005 - .010	1.346	.443	.015 - .025	1.355	.263	.090 - .120	1.364	1.193	.050 - .070	1.370	.333	.010 - .020	1.373	.380	.120 - .135
1.338	.320	.005 - .010	1.347	.441	.005 - .010	1.355	.501	.110 - .130	1.364	1.194	.030 - .060	1.370	.505	.100 - .125	1.373	.409	.005 - .010
1.338	.394	.010 - .020	1.347	.500	.005 - .010	1.355	.687	.015 - .025	1.364	1.237	.010 - .025	1.370	.538	.008 - .016	1.373	.410	.100 - .125
1.338	.396	.010 - .020	1.347	.502	.005 - .010	1.355	.746	.015 - .030	1.364	1.252	.005 - .010	1.370	.568	.005 - .010	1.373	.462	.020 - .040
1.338	.473	.005 - .010	1.347	1.075	.015 - .030	1.355	.795	.090 - .105	1.364	1.281	.005 - .010	1.370	.685	.075 - .104	1.373	.463	.015 - .030
1.338	.475	.010 - .020	1.347	1.140	.015 - .030	1.355	.899	.050 - .070	1.364	1.282	.005 - .012	1.370	.685	.100 - .125	1.373	.500	.105 - .135
1.338	.477	.005 - .010	1.348	.441	.005 - .010	1.355	1.010	.090 - .110	1.365	.354	.060 - .080	1.370	.696	.015 - .030	1.373	.563	.070 - .090
1.338	.505	.005 - .010	1.348	.500	.005 - .015	1.355	1.064	.015 - .030	1.365	.435	.050 - .083	1.370	.698	.050 - .075	1.373	.568	.170 - .190
1.338	.505	.010 - .020	1.348	.504	.006 - .012	1.355	1.073	.005 - .010	1.365	.562	.030 - .050	1.370	.751	.080 - .100	1.373	.570	.006 - .015
1.338	.552	.005 - .015	1.348	.566	.080 - .100	1.356	.444	.025 - .042	1.365	.584	.030 - .060	1.370	.793	.020 - .030	1.373	.575	.050 - .075
1.338	.582	.005 - .010	1.348	.677	.030 - .050	1.356	1.000	.015 - .030	1.365	.585	.025 - .042	1.370	.886	.070 - .090	1.373	.625	.020 - .032
1.338	.751	.100 - .134	1.348	.700	.005 - .010	1.356	1.030	.015 - .030	1.365	.595	.030 - .050	1.370	.890	.100 - .125	1.373	.625	.160 - .190
1.338	.867	.020 - .030	1.348	.717	.075 - .090	1.357	.190	.020 - .040	1.365	.808	.040 - .060	1.370	.900	.005 - .007	1.373	.627	.010 - .020
1.338	.937	.025 - .040	1.348	.818	.005 - .015	1.357	.350	.005 - .010	1.365	.940	.030 - .050	1.370	.940	.080 - .100	1.373	.639	.040 - .050
1.338	.983	.010 - .020	1.348	1.095	.010 - .025	1.357	.500	.100 - .125	1.365	1.131	.005 - .010	1.370	.948	.062 - .080	1.373	.641	.125 - .156
1.338	1.121	.020 - .030	1.348	1.145	.010 - .025	1.357	.666	.080 - .100	1.365	1.150	.050 - .075	1.370	.950	.005 - .015	1.373	.749	.005 - .010
1.339	.272	.015 - .030	1.349	.471	.040 - .060	1.357	.845	.032 - .060	1.365	1.187	.025 - .040	1.370	.960	.032 - .050	1.373	.765	.010 - .020
1.339	.316	.005 - .010	1.349	.501	.005 - .010	1.357	.890	.020 - .040	1.365	1.192	.005 - .010	1.370	1.000	.042 - .062	1.373	.785	.005 - .010
1.339	.474	.005 - .010	1.349	.503	.005 - .010	1.357	.968	.005 - .010	1.365	1.192	.010 - .020	1.370	1.056	.005 - .015	1.373	.890	.030 - .050
1.339	.640	.100 - .125	1.349	.503	.010 - .020	1.357	1.030	.015 - .025	1.365	1.194	.020 - .040	1.370	1.065	.005 - .015	1.373	.906	.005 - .020
1.339	.762	.005 - .010	1.349	.504	.005 - .010	1.357	1.030	.025 - .040	1.365	1.262	.020 - .030	1.370	1.126	.005 - .010	1.373	.912	.040 - .060
1.339	.828	.015 - .125	1.349	.593	.060 - .080	1.358	.125	.030 - .050	1.366	.191	.105 - .125	1.370	1.127	.040 - .060	1.373	.912	.060 - .090
1.339	.983	.005 - .010	1.349	.749	.050 - .070	1.358	.601	.040 - .060	1.366	.542	.025 - .050	1.370	1.130	.010 - .020	1.373	.996	.005 - .010
1.339	1.181	.005 - .010	1.349	.984	.050 - .070	1.358	.803	.005 - .010	1.366	.760	.020 - .030	1.370	1.163	.040 - .060	1.373	1.000	.008 - .015
1.339	1.202	.005 - .010	1.350	.089	.005 - .010	1.358	1.026	.050 - .075	1.366	.761	.005 - .010	1.370	1.199	.005 - .010	1.373	1.000	.040 - .060
1.339	1.205	.005 - .010	1.350	.090	.025 - .040	1.358	1.037	.008 - .015	1.366	.763	.005 - .010	1.370	1.255	.010 - .015	1.373	1.095	.042 - .062
1.340	.250	.062 - .090	1.350	.252	.015 - .030	1.358	1.130	.005 - .010	1.366	.883	.080 - .100	1.371	.148	.005 - .010	1.373	1.126	.020 - .040
1.340	.250	.090 - .120	1.350	.252	.075 - .090	1.359	.689	.005 - .010	1.366	.892	.005 - .020	1.371	.234	.090 - .125	1.373	1.207	.025 - .040
1.340	.260	.005 - .010	1.350	.252	.090 - .105	1.359	.860	.130 - .150	1.366	.997	.025 - .040	1.371	.281	.005 - .010	1.373	1.209	.030 - .060
1.340	.261	.005 - .010	1.350	.252	.105 - .125	1.359	.888	.005 - .010	1.366	1.028	.070 - .090	1.371	.525	.020 - .030	1.373	1.218	.040 - .060
1.340	.284	.015 - .030	1.350	.314	.005 - .010	1.359	1.025	.100 - .125	1.366	1.030	.050 - .075	1.371	.627	.050 - .075	1.373	1.236	.010 - .020
1.340	.288	.040 - .060	1.350	.314	.010 - .020	1.359	1.028	.100 - .125	1.366	1.070	.030 - .060	1.371	.641	.105 - .125	1.373	1.255	.005 - .010
1.340	.289	.005 - .010	1.350	.457	.005 - .010	1.359	1.126	.060 - .080	1.366	1.070	.070 - .105	1.371	.651	.030 - .050	1.373	1.255	.010 - .020
1.340	.630	.020 - .040	1.350	.500	.005 - .010	1.360	.204	.050 - .075	1.366	1.133	.050 - .070	1.371	.698	.040 - .062	1.374	1.155	.005 - .010
1.340	.632	.010 - .020	1.350	.500	.010 - .020	1.360	.338	.005 - .010	1.366	1.140	.020 - .030	1.371	.759	.100 - .125	1.374	.190	.060 - .080
1.340	.677	.042 - .072	1.350	.503	.005 - .010	1.360	.629	.010 - .020	1.366	1.144	.005 - .010	1.371	.760	.005 - .010	1.374	.245	.050 - .070
1.340	.751	.045 - .060	1.350	.503	.015 - .025	1.360	.639	.015 - .030	1.366	1.153	.010 - .020	1.371	.820	.008 - .020	1.374	.251	.160 - .180
1.340	.766	.042 - .062	1.350	.504	.006 - .015	1.360	.656	.100 - .125	1.367	.758	.070 - .090	1.371	.820	.020 - .040	1.374	.253	.083 - .104
1.340	1.004	.042 - .060	1.350	.504	.015 - .020	1.360	.878	.050 - .070	1.367	.760	.110 - .130	1.371	.886	.005 - .010	1.374	.318	.050 - .060
1.340	1.034	.005 - .010	1.350	.505	.006 - .015	1.360	.928	.080 - .105	1.367	.763	.110 - .130	1.371	.886	.015 - .025	1.374	.341	.090 - .110
1.340	1.104	.070 - .080	1.350	.508	.005 - .010	1.360	.986	.060 - .080	1.367	.884	.080 - .104	1.371	1.000	.120 - .135	1.374	.378	.050 - .070
1.340	1.118	.050 - .083	1.350	.562	.005 - .010	1.360	1.003	.005 - .010	1.367	.885	.040 - .060	1.371	1.073	.005 - .010	1.374	.389	.060 - .070
1.340	1.143	.005 - .020	1.350	.564	.010 - .020	1.360	1.026	.050 - .075	1.367	.911	.010 - .020	1.371	1.123	.020 - .040	1.374	.518	.134 - .187
1.341	.479	.005 - .010	1.350	.626	.005 - .010	1.360	1.146	.030 - .060	1.367	1.030	.060 - .080	1.371	1.138	.070 - .090	1.374	.562	.015 - .025
1.341	.537	.105 - .135	1.350	.626	.010 - .020	1.361	.219	.060 - .080	1.367	1.067	.040 - .060	1.371	1.178	.070 - .090	1.374	.563	.005 - .010
1.341	.871	.010 - .020	1.350	.634	.020 - .040	1.361	.875	.075 - .104	1.367	1.112	.025 - .040	1.371	1.200	.010 - .020	1.374	.568	.005 - .010
1.341	.893	.040 - .060	1.350	.669	.090 - .110	1.361	.875	.100 - .125	1.367	1.153	.020 - .030	1.371	1.212	.005 - .010	1.374	.575	.090 - .110
1.342	.380	.120 - .156	1.350	.675	.005 - .010	1.361	.884	.075 - .100	1.367	1.180	.005 - .015	1.371	1.212	.010 - .015	1.374	.577	.020 - .042
1.342	.457	.100 - .125	1.350	.700	.030 - .060	1.361	.890	.050 - .075	1.368	.510	.075 - .090	1.372	.141	.070 - .090	1.374	.641	.050 - .070
1.342	.876	.125 - .156	1.350	.750	.005 - .010	1.361	1.032	.005 - .010	1.368	.596	.030 - .050	1.372	.191	.070 - .090	1.374	.700	.156 - .187
1.342	.922	.040 - .060	1.350	.													

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.374	1.059	.030 - .050	1.375	.878	.090 - .120	<b>1.377</b>	<b>.985</b>	<b>.005 - .010</b>	1.385	1.010	.030 - .060	1.400	1.017	.090 - .105	<b>1.414</b>	<b>.794</b>	<b>.005 - .010</b>
1.374	1.078	.010 - .020	1.375	.883	.010 - .020	1.377	.997	.030 - .050	1.385	1.015	.075 - .090	1.400	1.076	.025 - .042	<b>1.415</b>	<b>.319</b>	<b>.005 - .010</b>
1.374	1.125	.050 - .075	1.375	.936	.020 - .032	1.377	1.001	.025 - .040	<b>1.385</b>	<b>1.269</b>	<b>.005 - .010</b>	<b>1.400</b>	<b>1.158</b>	<b>.005 - .010</b>	<b>1.415</b>	<b>.320</b>	<b>.005 - .010</b>
1.374	1.128	.010 - .020	1.375	.940	.060 - .090	1.377	1.001	.075 - .090	<b>1.385</b>	<b>1.339</b>	<b>.005 - .010</b>	1.400	1.200	.080 - .090	1.415	.320	.012 - .020
<b>1.374</b>	<b>1.145</b>	<b>.005 - .010</b>	<b>1.375</b>	<b>.953</b>	<b>.005 - .010</b>	1.377	1.018	.030 - .050	1.386	.474	.080 - .105	1.400	1.258	.020 - .030	1.415	.382	.040 - .062
1.374	1.209	.040 - .060	1.375	.962	.035 - .060	1.377	1.029	.040 - .060	1.386	.655	.170 - .190	1.400	1.260	.030 - .042	<b>1.415</b>	<b>.396</b>	<b>.005 - .010</b>
1.374	1.265	.030 - .050	1.375	.977	.062 - .083	<b>1.377</b>	<b>1.100</b>	<b>.005 - .010</b>	1.386	1.084	.060 - .080	<b>1.401</b>	<b>.195</b>	<b>.005 - .010</b>	1.415	.396	.010 - .020
1.375	.100	.025 - .045	1.375	1.000	.025 - .045	<b>1.377</b>	<b>1.241</b>	<b>.005 - .010</b>	<b>1.386</b>	<b>1.124</b>	<b>.005 - .010</b>	1.401	.986	.045 - .060	<b>1.415</b>	<b>.398</b>	<b>.005 - .010</b>
1.375	.125	.070 - .090	1.375	1.000	.100 - .125	1.378	.206	.050 - .075	1.386	1.187	.030 - .045	1.401	1.102	.010 - .020	<b>1.415</b>	<b>.477</b>	<b>.005 - .010</b>
1.375	.129	.015 - .030	1.375	1.005	.120 - .156	<b>1.378</b>	<b>.208</b>	<b>.005 - .010</b>	1.387	1.212	.020 - .040	1.401	1.169	.010 - .020	1.415	.567	.010 - .025
1.375	.144	.040 - .060	1.375	1.006	.100 - .125	1.378	.313	.020 - .032	1.388	.825	.020 - .040	1.401	1.186	.015 - .025	<b>1.415</b>	<b>1.000</b>	<b>.005 - .010</b>
1.375	.207	.040 - .062	1.375	1.008	.060 - .080	1.378	.315	.010 - .020	1.388	1.016	.090 - .110	<b>1.401</b>	<b>1.258</b>	<b>.005 - .010</b>	1.415	1.044	.015 - .030
1.375	.210	.100 - .125	<b>1.375</b>	<b>1.015</b>	<b>.005 - .010</b>	<b>1.378</b>	<b>.316</b>	<b>.005 - .010</b>	1.389	.474	.080 - .105	1.401	1.258	.015 - .030	1.415	1.100	.010 - .020
1.375	.250	.080 - .104	1.375	1.022	.016 - .032	<b>1.378</b>	<b>.324</b>	<b>.005 - .010</b>	1.389	1.052	.030 - .050	<b>1.401</b>	<b>1.295</b>	<b>.005 - .010</b>	1.415	1.122	.030 - .042
1.375	.252	.040 - .060	1.375	1.045	.025 - .040	1.378	.402	.156 - .187	<b>1.389</b>	<b>1.073</b>	<b>.005 - .010</b>	1.402	.295	.030 - .050	<b>1.415</b>	<b>1.126</b>	<b>.005 - .010</b>
1.375	.255	.040 - .060	1.375	1.065	.035 - .050	1.378	.500	.010 - .020	1.390	.368	.060 - .083	<b>1.402</b>	<b>.504</b>	<b>.005 - .010</b>	1.416	.169	.030 - .050
1.375	.260	.015 - .030	1.375	1.078	.040 - .060	1.378	.657	.060 - .080	1.390	1.430	.080 - .100	1.402	.505	.008 - .015	1.416	.324	.135 - .156
1.375	.281	.100 - .125	<b>1.375</b>	<b>1.110</b>	<b>.005 - .010</b>	1.378	.660	.105 - .135	1.390	.430	.100 - .134	1.402	.509	.105 - .135	<b>1.416</b>	<b>.473</b>	<b>.005 - .010</b>
1.375	.310	.062 - .080	<b>1.375</b>	<b>1.124</b>	<b>.005 - .010</b>	1.378	.736	.100 - .125	1.390	.552	.010 - .020	1.402	.518	.005 - .008	1.416	.474	.020 - .030
1.375	.312	.050 - .083	1.375	1.130	.015 - .030	1.378	.780	.025 - .050	<b>1.390</b>	<b>.780</b>	<b>.005 - .010</b>	1.402	.760	.005 - .015	<b>1.416</b>	<b>.502</b>	<b>.005 - .010</b>
1.375	.316	.050 - .075	<b>1.375</b>	<b>1.131</b>	<b>.015 - .010</b>	1.378	.783	.040 - .060	1.390	1.094	.005 - .008	1.402	1.224	.050 - .070	1.416	.502	.010 - .020
1.375	.316	.080 - .100	1.375	1.136	.050 - .070	1.378	.787	.100 - .120	1.390	1.187	.015 - .030	1.403	.250	.042 - .062	1.416	.502	.020 - .030
1.375	.318	.100 - .125	1.375	1.146	.025 - .040	1.378	.858	.032 - .050	1.391	.888	.010 - .020	1.403	.250	.060 - .075	<b>1.416</b>	<b>.505</b>	<b>.005 - .010</b>
1.375	.321	.060 - .080	<b>1.375</b>	<b>1.159</b>	<b>.005 - .010</b>	1.378	.861	.080 - .100	1.391	.888	.020 - .035	1.403	.430	.100 - .125	1.416	.505	.010 - .020
1.375	.328	.025 - .050	1.375	1.189	.030 - .050	1.378	.865	.100 - .125	1.391	.983	.040 - .060	1.403	.672	.110 - .130	1.416	.590	.160 - .190
1.375	.328	.050 - .070	<b>1.375</b>	<b>1.195</b>	<b>.005 - .010</b>	1.378	.876	.090 - .125	1.393	.611	.060 - .080	1.403	1.022	.010 - .020	<b>1.416</b>	<b>.629</b>	<b>.005 - .010</b>
1.375	.343	.100 - .125	1.375	1.195	.015 - .025	1.378	.878	.060 - .090	1.393	.719	.080 - .104	1.404	.508	.090 - .120	1.416	.635	.050 - .070
1.375	.355	.070 - .100	1.375	1.200	.020 - .032	1.378	.878	.090 - .120	<b>1.393</b>	<b>1.281</b>	<b>.005 - .010</b>	1.405	.610	.010 - .020	1.416	.709	.040 - .060
1.375	.373	.100 - .125	1.375	1.201	.025 - .040	1.378	.984	.010 - .020	<b>1.394</b>	<b>.654</b>	<b>.005 - .010</b>	<b>1.405</b>	<b>.630</b>	<b>.005 - .010</b>	1.416	1.030	.100 - .120
1.375	.375	.062 - .090	1.375	1.251	.010 - .020	<b>1.378</b>	<b>1.060</b>	<b>.005 - .010</b>	1.394	.724	.070 - .090	<b>1.405</b>	<b>1.265</b>	<b>.005 - .010</b>	<b>1.416</b>	<b>1.111</b>	<b>.005 - .010</b>
1.375	.375	.090 - .120	<b>1.375</b>	<b>1.253</b>	<b>.005 - .010</b>	1.378	1.061	.012 - .020	1.395	.132	.025 - .035	1.406	.139	.030 - .048	1.416	1.111	.015 - .030
1.375	.382	.050 - .075	1.375	1.253	.010 - .020	1.378	1.075	.030 - .050	1.395	.550	.050 - .083	<b>1.406</b>	<b>.390</b>	<b>.005 - .010</b>	1.416	1.141	.040 - .060
1.375	.395	.062 - .080	1.375	1.253	.015 - .030	1.378	1.186	.060 - .080	1.395	1.157	.040 - .060	1.406	1.091	.025 - .040	1.416	1.226	.025 - .040
1.375	.420	.048 - .062	<b>1.375</b>	<b>1.265</b>	<b>.005 - .010</b>	<b>1.378</b>	<b>1.201</b>	<b>.005 - .010</b>	1.396	.563	.060 - .080	1.406	1.249	.020 - .030	1.416	1.338	.010 - .020
1.375	.422	.060 - .070	<b>1.376</b>	<b>.258</b>	<b>.005 - .010</b>	1.379	.203	.020 - .040	1.396	.611	.105 - .125	1.407	.290	.025 - .040	1.417	.474	.010 - .020
1.375	.439	.170 - .190	1.376	.267	.134 - .187	1.379	.453	.010 - .020	1.396	1.190	.015 - .025	<b>1.407</b>	<b>.390</b>	<b>.005 - .010</b>	1.417	.519	.080 - .104
1.375	.440	.075 - .090	1.376	.383	.005 - .015	1.379	.453	.030 - .040	1.396	1.220	.010 - .020	1.407	.390	.015 - .030	1.417	.548	.050 - .070
1.375	.444	.050 - .070	1.376	.406	.050 - .075	<b>1.379</b>	<b>.564</b>	<b>.005 - .010</b>	1.397	.381	.115 - .130	<b>1.407</b>	<b>.624</b>	<b>.005 - .010</b>	1.417	.580	.075 - .090
1.375	.452	.156 - .187	1.376	.503	.090 - .125	1.379	.599	.015 - .030	1.397	.419	.060 - .125	1.407	.634	.060 - .090	<b>1.417</b>	<b>.632</b>	<b>.005 - .010</b>
1.375	.500	.100 - .125	<b>1.376</b>	<b>.513</b>	<b>.005 - .010</b>	<b>1.379</b>	<b>.812</b>	<b>.005 - .010</b>	<b>1.397</b>	<b>.545</b>	<b>.005 - .010</b>	<b>1.407</b>	<b>.705</b>	<b>.005 - .010</b>	1.417	.825	.050 - .070
<b>1.375</b>	<b>.502</b>	<b>.005 - .010</b>	1.376	.530	.156 - .187	<b>1.379</b>	<b>.835</b>	<b>.005 - .010</b>	1.397	.705	.060 - .090	1.407	1.112	.015 - .030	1.417	.912	.135 - .156
1.375	.502	.032 - .060	1.376	.534	.010 - .020	1.379	1.069	.090 - .120	1.397	.710	.050 - .075	<b>1.407</b>	<b>1.125</b>	<b>.005 - .010</b>	1.417	.912	.156 - .187
1.375	.505	.030 - .050	<b>1.376</b>	<b>.620</b>	<b>.005 - .010</b>	1.379	1.075	.015 - .025	1.397	.815	.005 - .012	1.407	1.188	.020 - .030	1.417	.983	.060 - .080
1.375	.515	.060 - .080	1.376	.650	.100 - .125	1.379	1.089	.030 - .050	1.397	.815	.010 - .020	1.408	.902	.032 - .050	1.417	.997	.050 - .070
1.375	.526	.070 - .090	<b>1.376</b>	<b>.657</b>	<b>.005 - .010</b>	1.380	.254	.040 - .060	1.397	.981	.015 - .030	<b>1.408</b>	<b>1.004</b>	<b>.005 - .010</b>	1.417	1.070	.020 - .040
<b>1.375</b>	<b>.530</b>	<b>.005 - .010</b>	<b>1.376</b>	<b>.657</b>	<b>.005 - .010</b>	1.380	.282	.062 - .083	1.397	1.068	.005 - .015	1.408	1.256	.040 - .060	1.418	.204	.040 - .060
1.375	.530	.050 - .075	1.376	.760	.060 - .080	1.380	.282	.156 - .190	1.397	1.068	.015 - .030	1.408	1.285	.030 - .050	1.418	.322	.010 - .020
<b>1.375</b>	<b>.556</b>	<b>.005 - .010</b>	1.376	.760	.120 - .140	1.380	.300	.005 - .008	<b>1.398</b>	<b>.505</b>	<b>.005 - .010</b>	<b>1.408</b>	<b>1.332</b>	<b>.005 - .010</b>	1.418	.375	.070 - .090
<b>1.375</b>	<b>.560</b>	<b>.005 - .010</b>	1.376	.761	.090 - .105	1.380	.346	.120 - .134	1.398	.505	.010 - .015	<b>1.409</b>	<b>.502</b>	<b>.005 - .010</b>	1.418	.474	.010 - .020
1.375	.564	.010 - .020	1.376	.765	.090 - .105	<b>1.380</b>	<b>.398</b>	<b>.005 - .010</b>	<b>1.398</b>	<b>.717</b>	<b>.005 - .010</b>	<b>1.409</b>	<b>.503</b>	<b>.005 - .010</b>	<b>1.418</b>	<b>.477</b>	<b>.005 - .010</b>
1.375	.590	.156 - .187	1.376	.780	.110 - .130	1.380	.405	.100 - .125	1.398	.872	.025 - .040	1.409	.766	.015 - .025	1.418	.478	.100 - .120
1.375	.619	.020 - .040	1.376	.815	.060 - .080	1.380	.596	.100 - .125	1.398	1.160	.010 - .020	1.409	.766	.050 - .070	1.418	.807	.080 - .104
1.375	.630	.005 - .007	<b>1.376</b>	<b>.847</b>	<b>.005 - .01</b>												

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.423	.157	.080 - .104	<b>1.435</b>	<b>.875</b>	<b>.005 - .010</b>	1.438	1.065	.036 - .050	1.450	.282	.040 - .060	1.467	.939	.075 - .090	1.480	.984	.070 - .090
1.423	.864	.020 - .040	1.435	1.082	.070 - .090	1.438	1.171	.025 - .040	<b>1.450</b>	<b>.441</b>	<b>.005 - .010</b>	1.467	1.038	.030 - .050	1.480	1.049	.120 - .156
1.423	.880	.010 - .020	1.435	1.107	.020 - .040	1.438	1.190	.015 - .030	1.450	.531	.080 - .100	1.467	1.126	.075 - .100	1.480	1.120	.010 - .020
1.423	1.000	.031 - .042	1.435	1.192	.040 - .060	1.439	.115	.020 - .040	1.450	.626	.010 - .020	1.468	.310	.010 - .020	1.480	1.154	.030 - .060
1.423	1.289	.010 - .020	1.435	1.315	.010 - .020	<b>1.439</b>	<b>.466</b>	<b>.005 - .010</b>	<b>1.450</b>	<b>.630</b>	<b>.005 - .010</b>	1.468	.384	.080 - .105	<b>1.480</b>	<b>1.232</b>	<b>.005 - .010</b>
1.423	1.289	.020 - .030	1.436	.125	.008 - .016	1.439	.636	.015 - .030	1.450	.650	.050 - .062	1.468	.391	.050 - .070	1.480	1.269	.080 - .105
1.424	.440	.060 - .070	1.436	.195	.025 - .050	1.439	.757	.040 - .060	1.450	.760	.030 - .060	1.468	.440	.010 - .020	1.481	.269	.042 - .062
<b>1.424</b>	<b>.505</b>	<b>.005 - .010</b>	1.436	.377	.010 - .020	1.439	.811	.040 - .060	1.450	.952	.040 - .060	1.468	.640	.050 - .075	1.481	.622	.010 - .020
1.425	.316	.015 - .030	1.436	.377	.025 - .040	<b>1.439</b>	<b>.812</b>	<b>.005 - .010</b>	1.450	1.019	.105 - .135	<b>1.468</b>	<b>.820</b>	<b>.005 - .010</b>	<b>1.481</b>	<b>.936</b>	<b>.005 - .010</b>
<b>1.425</b>	<b>.377</b>	<b>.005 - .010</b>	1.436	.383	.010 - .020	1.439	.812	.010 - .020	1.450	1.031	.083 - .120	<b>1.468</b>	<b>.988</b>	<b>.005 - .010</b>	1.481	1.108	.025 - .042
1.425	.377	.010 - .020	1.436	.383	.020 - .040	1.440	.235	.020 - .035	1.450	1.085	.050 - .075	1.468	1.235	.010 - .020	1.482	.250	.015 - .030
1.425	.438	.010 - .020	1.436	.504	.050 - .075	<b>1.440</b>	<b>.332</b>	<b>.005 - .010</b>	<b>1.450</b>	<b>1.140</b>	<b>.005 - .010</b>	1.468	1.310	.020 - .032	1.482	.774	.120 - .135
<b>1.425</b>	<b>.502</b>	<b>.005 - .010</b>	1.436	.563	.015 - .030	1.440	.375	.090 - .120	<b>1.451</b>	<b>.503</b>	<b>.005 - .010</b>	1.469	.665	.100 - .120	1.482	.882	.020 - .040
1.425	.502	.010 - .020	<b>1.436</b>	<b>.643</b>	<b>.005 - .010</b>	<b>1.440</b>	<b>.392</b>	<b>.005 - .010</b>	1.451	1.016	.050 - .070	<b>1.469</b>	<b>.808</b>	<b>.005 - .010</b>	1.482	.884	.020 - .040
1.425	.505	.010 - .020	1.436	.886	.008 - .012	<b>1.440</b>	<b>.395</b>	<b>.005 - .010</b>	1.451	1.140	.005 - .015	<b>1.470</b>	<b>.171</b>	<b>.005 - .010</b>	1.482	1.222	.050 - .070
<b>1.425</b>	<b>.515</b>	<b>.005 - .010</b>	<b>1.436</b>	<b>.940</b>	<b>.005 - .010</b>	1.440	.438	.040 - .060	1.451	1.196	.010 - .020	1.470	.610	.100 - .125	1.483	.755	.105 - .125
<b>1.425</b>	<b>.889</b>	<b>.005 - .010</b>	1.436	1.001	.050 - .075	1.440	.504	.005 - .020	1.451	1.271	.036 - .060	<b>1.470</b>	<b>.752</b>	<b>.005 - .010</b>	1.484	.132	.015 - .030
<b>1.425</b>	<b>1.155</b>	<b>.005 - .010</b>	1.436	1.134	.030 - .050	<b>1.440</b>	<b>.610</b>	<b>.005 - .010</b>	1.452	.266	.020 - .040	1.470	.782	.100 - .125	1.484	.252	.156 - .187
1.425	1.161	.040 - .050	1.436	1.154	.015 - .025	<b>1.440</b>	<b>.762</b>	<b>.005 - .010</b>	1.452	.441	.010 - .020	1.470	.833	.100 - .125	1.484	.882	.040 - .060
1.425	1.188	.010 - .020	1.436	1.195	.032 - .050	1.440	.891	.015 - .025	<b>1.453</b>	<b>.104</b>	<b>.005 - .010</b>	1.470	.833	.135 - .156	1.484	.889	.050 - .070
1.425	1.251	.060 - .075	<b>1.436</b>	<b>1.198</b>	<b>.005 - .010</b>	1.440	1.015	.020 - .040	1.453	.760	.030 - .050	1.470	1.062	.048 - .075	<b>1.484</b>	<b>1.070</b>	<b>.005 - .010</b>
<b>1.426</b>	<b>1.110</b>	<b>.005 - .010</b>	1.436	1.250	.040 - .060	1.440	1.070	.020 - .030	1.454	.568	.080 - .100	1.470	1.094	.015 - .030	1.484	1.382	.020 - .030
1.426	1.188	.025 - .040	<b>1.436</b>	<b>1.320</b>	<b>.005 - .010</b>	1.440	1.120	.050 - .075	1.454	.756	.020 - .030	1.470	1.111	.040 - .050	1.485	.472	.080 - .104
<b>1.426</b>	<b>1.261</b>	<b>.005 - .010</b>	1.437	.186	.010 - .020	<b>1.440</b>	<b>1.137</b>	<b>.005 - .010</b>	1.454	1.014	.015 - .030	1.470	1.150	.025 - .042	1.485	.520	.060 - .080
1.426	1.261	.010 - .020	1.437	.206	.025 - .042	1.441	.720	.050 - .083	<b>1.454</b>	<b>1.102</b>	<b>.005 - .010</b>	1.470	1.226	.040 - .060	1.485	.550	.100 - .125
1.426	1.291	.005 - .015	1.437	.206	.100 - .125	1.441	1.140	.050 - .075	1.454	1.282	.050 - .070	<b>1.470</b>	<b>1.375</b>	<b>.005 - .010</b>	1.485	.650	.100 - .125
1.427	.250	.050 - .075	1.437	.297	.070 - .090	1.441	1.142	.050 - .075	1.455	.637	.040 - .050	1.471	.688	.062 - .080	1.485	.674	.050 - .070
1.427	1.218	.020 - .040	<b>1.437</b>	<b>.376</b>	<b>.005 - .010</b>	<b>1.441</b>	<b>1.258</b>	<b>.005 - .010</b>	1.455	.638	.085 - .100	1.471	.758	.090 - .120	<b>1.485</b>	<b>.794</b>	<b>.005 - .010</b>
1.427	1.253	.075 - .093	1.437	.376	.010 - .025	1.442	.411	.062 - .080	<b>1.455</b>	<b>.754</b>	<b>.005 - .010</b>	1.471	.759	.100 - .125	<b>1.485</b>	<b>.846</b>	<b>.005 - .010</b>
1.427	1.257	.025 - .040	1.437	.378	.015 - .035	<b>1.442</b>	<b>.541</b>	<b>.005 - .010</b>	1.455	1.065	.040 - .060	1.471	.810	.050 - .070	1.485	.846	.010 - .020
1.428	1.014	.060 - .080	<b>1.437</b>	<b>.383</b>	<b>.005 - .010</b>	1.442	.881	.080 - .105	1.456	.315	.020 - .030	1.471	.821	.057 - .088	1.485	.901	.134 - .156
1.428	1.066	.015 - .032	1.437	.383	.040 - .060	1.442	1.002	.006 - .012	1.456	.826	.105 - .135	1.471	.877	.100 - .125	1.485	.970	.032 - .042
<b>1.428</b>	<b>1.249</b>	<b>.005 - .010</b>	1.437	.397	.020 - .040	1.442	1.130	.030 - .040	1.456	1.066	.030 - .050	1.471	.938	.105 - .125	1.485	1.108	.050 - .070
1.429	.783	.010 - .020	1.437	.420	.080 - .104	1.443	.626	.015 - .030	<b>1.457</b>	<b>.505</b>	<b>.005 - .010</b>	1.471	1.331	.005 - .015	1.485	1.223	.015 - .030
1.429	1.100	.020 - .030	1.437	.493	.156 - .187	1.443	.880	.070 - .090	1.457	.505	.010 - .020	1.471	1.331	.020 - .040	1.485	1.250	.005 - .012
1.429	1.126	.020 - .040	1.437	.500	.032 - .048	1.443	.948	.040 - .060	1.457	.675	.050 - .070	1.472	.438	.015 - .030	1.485	1.357	.015 - .025
1.429	1.194	.040 - .060	1.437	.504	.062 - .080	<b>1.444</b>	<b>.136</b>	<b>.005 - .010</b>	<b>1.457</b>	<b>1.022</b>	<b>.005 - .010</b>	<b>1.472</b>	<b>.501</b>	<b>.005 - .010</b>	1.486	.650	.100 - .125
1.430	.376	.015 - .030	1.437	.552	.005 - .015	1.444	1.006	.030 - .050	1.457	1.200	.015 - .025	1.472	.762	.010 - .020	<b>1.486</b>	<b>.803</b>	<b>.005 - .010</b>
<b>1.430</b>	<b>.519</b>	<b>.005 - .010</b>	1.437	.639	.015 - .025	<b>1.444</b>	<b>1.055</b>	<b>.005 - .010</b>	1.457	1.295	.020 - .030	1.472	.765	.080 - .100	1.486	.830	.040 - .062
1.430	.640	.100 - .125	1.437	.680	.100 - .125	1.445	.132	.040 - .062	1.458	.670	.100 - .120	1.472	.829	.010 - .020	<b>1.486</b>	<b>.893</b>	<b>.005 - .010</b>
<b>1.430</b>	<b>.698</b>	<b>.005 - .010</b>	1.437	.761	.105 - .125	1.445	.312	.010 - .020	1.458	.873	.030 - .050	1.472	1.001	.070 - .090	<b>1.486</b>	<b>.906</b>	<b>.005 - .010</b>
1.430	.716	.010 - .020	1.437	.764	.020 - .030	1.445	.322	.060 - .090	<b>1.458</b>	<b>.984</b>	<b>.005 - .010</b>	1.473	.130	.042 - .062	1.486	1.090	.050 - .075
1.430	.749	.010 - .020	1.437	.765	.050 - .075	1.445	.350	.032 - .060	1.458	1.124	.042 - .062	1.473	.609	.010 - .020	1.486	1.229	.070 - .090
1.430	.755	.015 - .030	1.437	.766	.015 - .025	1.445	.690	.090 - .120	<b>1.459</b>	<b>.630</b>	<b>.005 - .010</b>	1.473	.609	.020 - .030	1.486	1.330	.005 - .015
1.430	.827	.010 - .020	1.437	.792	.100 - .125	1.445	1.044	.045 - .060	1.459	.951	.030 - .050	1.474	.318	.010 - .020	1.487	.949	.080 - .104
<b>1.430</b>	<b>1.065</b>	<b>.005 - .010</b>	1.437	.795	.020 - .040	<b>1.446</b>	<b>.179</b>	<b>.005 - .010</b>	1.459	1.189	.015 - .030	1.474	1.010	.040 - .060	<b>1.487</b>	<b>1.128</b>	<b>.005 - .010</b>
1.430	1.128	.050 - .075	1.437	.850	.075 - .090	1.446	.240	.090 - .120	1.460	.180	.035 - .050	<b>1.474</b>	<b>1.180</b>	<b>.005 - .010</b>	1.487	1.233	.015 - .030
1.430	1.129	.050 - .070	1.437	.873	.156 - .190	1.446	.253	.105 - .135	1.460	.500	.025 - .040	<b>1.474</b>	<b>1.357</b>	<b>.005 - .010</b>	1.487	1.368	.020 - .030
1.430	1.148	.075 - .090	1.437	.879	.070 - .090	1.446	.254	.100 - .125	1.460	.569	.050 - .070	1.474	1.358	.015 - .025	1.488	.390	.020 - .030
<b>1.430</b>	<b>1.186</b>	<b>.005 - .010</b>	1.437	.886	.050 - .075	1.446	.315	.100 - .125	1.460	.761	.010 - .020	1.475	.500	.110 - .130	1.488	.550	.100 - .125
<b>1.431</b>	<b>.716</b>	<b>.005 - .010</b>	1.437	.950	.050 - .070	1.446	.318	.105 - .125	1.460	.950	.040 - .060	1.475	.504	.006 - .015	<b>1.488</b>	<b>.880</b>	<b>.005 - .010</b>
1.431	1.129	.010 - .020	1.437	1.000	.030 - .040	<b>1.446</b>	<b>1.062</b>	<b>.005 - .010</b>	1.460	1.189	.035 - .050	1.475	.526	.080 - .100	<b>1.488</b>	<b>1.043</b>	<b>.005 - .010</b>
1.431	1.253	.060 - .080	1.437	1.001	.156 - .187	1.446	1.062	.010 - .015	1.460	1.394	.020 - .025	<b>1.475</b>	<b>.626</b>	<b>.005 - .010</b>	1.488	1.217	.010 - .020
1.432	.936	.090 - .105	1.437	1.008	.075 - .104	1.447	.406	.100 - .125	1.461	.180	.070 - .080	1.475	.626	.010 - .020	1.488	1.313	.030 - .042
1.432	.995	.100 - .125	1.437	1.031	.050 - .070	<b>1.447</b>	<b>.596</b>	<b>.005 - .010</b>	1.461	.875	.030 - .050	1.475	.626	.010 - .020	1.488	1.330	.030 - .042
1.432	1.045	.030 - .050	1.437	1.093	.035 - .048	1.447	.837	.100 - .125	1.461	1.172	.050 - .070	<b>1.475</b>	<b>.751</b>	<b>.005 - .010</b>	<b>1.488</b>	<b>1.350</b>	<b>.005 - .010</b>
1.432	1.094	.050 - .060	1.437	1.103	.080 - .100	1.447	1.064	.080 - .100	1.461	1.362	.020 - .030	1.475	.828	.062 - .090	1.489	.383	.070 - .090
1.432	1.160	.050 - .062	1.437	1.123	.005 - .015	1.447	1.136	.105 - .125	1.462	.502	.080 - .100	1.475	1.169				

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To			
1.491	.875	.100 - .125	1.496	.620	.015 - .030	1.498	.625	.040 - .060	1.499	1.135	.040 - .060	1.500	.497	.105 - .125	1.500	.806	.080 - .104			
1.491	.994	.105 - .120	1.496	.620	.030 - .050	1.498	.687	.030 - .050	1.499	1.142	.005 - .012	<b>1.500</b>	<b>.500</b>	<b>.005 - .010</b>	1.500	.810	.025 - .040			
<b>1.491</b>	<b>1.001</b>	<b>.005 - .010</b>	1.496	.625	.050 - .075	1.498	.687	.100 - .125	1.499	1.202	.005 - .015	1.500	.500	.032 - .060	1.500	.812	.050 - .075			
1.491	1.063	.080 - .100	1.496	.625	.060 - .080	1.498	.690	.100 - .125	1.499	1.250	.050 - .075	<b>1.500</b>	<b>.505</b>	<b>.005 - .010</b>	1.500	.812	.072 - .100			
1.491	1.210	.010 - .020	<b>1.496</b>	<b>.630</b>	<b>.005 - .010</b>	1.498	.757	.040 - .060	1.499	1.256	.030 - .040	1.500	.505	.010 - .020	1.500	.813	.050 - .075			
<b>1.491</b>	<b>1.312</b>	<b>.005 - .010</b>	1.496	.630	.050 - .075	1.498	.771	.031 - .048	<b>1.500</b>			1.500	.505	.032 - .050	1.500	.813	.080 - .100			
<b>1.492</b>	<b>.394</b>	<b>.005 - .010</b>	1.496	.720	.010 - .020	<b>1.498</b>	<b>.819</b>	<b>.005 - .010</b>				<b>1.500</b>	<b>.506</b>	<b>.005 - .010</b>	<b>1.500</b>	<b>.817</b>	<b>.005 - .010</b>	1.500	.817	.105 - .135
1.492	.803	.016 - .025	<b>1.496</b>	<b>.762</b>	<b>.005 - .010</b>	1.498	.844	.100 - .125				1.500	.506	.083 - .104	1.500	.817	.105 - .135	1.500	.820	.020 - .040
1.492	.886	.020 - .032	1.496	.767	.010 - .020	<b>1.498</b>	<b>.867</b>	<b>.005 - .010</b>				1.500	.506	.100 - .125	1.500	.830	.015 - .030	1.500	.830	.120 - .135
1.492	1.011	.020 - .040	1.496	.783	.100 - .125	1.498	.902	.025 - .040				1.500	.512	.060 - .083	1.500	.841	.040 - .050	1.500	.853	.080 - .104
1.492	1.062	.100 - .125	<b>1.496</b>	<b>.946</b>	<b>.005 - .010</b>	1.498	.979	.050 - .070				1.500	.084	.020 - .035	1.500	.513	.100 - .125	1.500	.871	.010 - .020
<b>1.492</b>	<b>1.118</b>	<b>.005 - .010</b>	1.496	.994	.010 - .020	1.498	.997	.030 - .050	1.500	.126	.040 - .060	1.500	.513	.100 - .125	1.500	.873	.170 - .190			
1.493	.433	.105 - .125	1.496	1.003	.040 - .060	1.498	1.000	.060 - .080	1.500	.130	.020 - .032	1.500	.515	.100 - .125	1.500	.874	.020 - .040			
1.493	.748	.015 - .030	<b>1.496</b>	<b>1.007</b>	<b>.005 - .010</b>	1.498	1.014	.100 - .125	1.500	.135	.090 - .104	1.500	.519	.080 - .104	1.500	.877	.100 - .125			
1.493	.758	.032 - .060	1.496	1.014	.060 - .080	1.498	1.015	.005 - .015	1.500	.150	.040 - .062	1.500	.530	.015 - .025	1.500	.880	.010 - .020			
1.493	.776	.020 - .030	1.496	1.017	.050 - .075	<b>1.498</b>	<b>1.021</b>	<b>.005 - .010</b>	1.500	.156	.030 - .060	1.500	.536	.006 - .012	1.500	.882	.110 - .134			
<b>1.493</b>	<b>.810</b>	<b>.005 - .010</b>	<b>1.496</b>	<b>1.060</b>	<b>.050 - .010</b>	1.498	1.032	.020 - .040	1.500	.156	.100 - .125	1.500	.536	.030 - .050	1.500	.883	.040 - .060			
1.493	1.008	.050 - .070	<b>1.496</b>	<b>1.066</b>	<b>.005 - .010</b>	<b>1.498</b>	<b>1.033</b>	<b>.005 - .010</b>	1.500	.157	.030 - .050	1.500	.536	.030 - .050	1.500	.883	.105 - .125			
1.493	1.062	.030 - .050	1.496	1.114	.010 - .020	1.498	1.040	.105 - .135	1.500	.161	.100 - .125	1.500	.536	.050 - .075	1.500	.886	.156 - .187			
1.493	1.136	.010 - .025	<b>1.496</b>	<b>1.162</b>	<b>.005 - .010</b>	1.498	1.065	.005 - .012	1.500	.163	.010 - .020	1.500	.560	.005 - .012	1.500	.892	.105 - .120			
1.493	1.191	.030 - .050	<b>1.496</b>	<b>1.189</b>	<b>.005 - .010</b>	1.498	1.066	.030 - .050	1.500	.163	.020 - .030	1.500	.562	.050 - .070	1.500	.893	.062 - .090			
<b>1.493</b>	<b>1.229</b>	<b>.005 - .010</b>	1.496	1.255	.040 - .060	1.498	1.071	.015 - .030	1.500	.163	.030 - .040	1.500	.562	.050 - .070	1.500	.893	.062 - .090			
<b>1.493</b>	<b>1.242</b>	<b>.005 - .010</b>	<b>1.496</b>	<b>1.260</b>	<b>.005 - .010</b>	1.498	1.072	.110 - .130	1.500	.185	.050 - .083	1.500	.562	.050 - .070	1.500	.893	.062 - .090			
1.493	1.273	.060 - .070	1.496	1.260	.050 - .075	1.498	1.098	.030 - .060	<b>1.500</b>	<b>.188</b>	<b>.005 - .010</b>	1.500	.562	.050 - .070	1.500	.893	.062 - .090			
<b>1.493</b>	<b>1.299</b>	<b>.005 - .010</b>	1.496	1.311	.010 - .020	1.498	1.125	.090 - .120	1.500	.194	.025 - .042	1.500	.562	.050 - .070	1.500	.893	.062 - .090			
<b>1.493</b>	<b>1.314</b>	<b>.005 - .010</b>	1.497	.145	.020 - .040	1.498	1.130	.100 - .120	1.500	.195	.048 - .075	1.500	.562	.170 - .190	1.500	.908	.026 - .048			
1.494	.271	.015 - .030	1.497	.195	.025 - .042	1.498	1.169	.025 - .040	1.500	.200	.010 - .020	1.500	.563	.015 - .030	1.500	.910	.140 - .160			
1.494	.330	.005 - .020	1.497	.375	.050 - .083	1.498	1.178	.010 - .020	1.500	.200	.020 - .030	1.500	.564	.100 - .120	1.500	.934	.040 - .060			
<b>1.494</b>	<b>.474</b>	<b>.005 - .010</b>	1.497	.377	.105 - .125	1.498	1.268	.040 - .060	1.500	.209	.105 - .125	1.500	.571	.025 - .040	1.500	.935	.030 - .040			
<b>1.494</b>	<b>.477</b>	<b>.005 - .010</b>	1.497	.379	.042 - .062	1.498	1.305	.030 - .050	1.500	.219	.050 - .070	1.500	.577	.010 - .015	1.500	.937	.050 - .075			
<b>1.494</b>	<b>.637</b>	<b>.005 - .010</b>	1.497	.386	.062 - .080	1.498	1.321	.030 - .048	1.500	.245	.032 - .060	1.500	.579	.110 - .130	1.500	.938	.093 - .109			
1.494	.650	.007 - .020	1.497	.421	.156 - .187	<b>1.498</b>	<b>1.378</b>	<b>.005 - .010</b>	1.500	.250	.010 - .020	1.500	.605	.050 - .070	1.500	.942	.105 - .134			
1.494	.760	.060 - .080	<b>1.497</b>	<b>.477</b>	<b>.005 - .010</b>	1.498	1.396	.015 - .025	1.500	.259	.060 - .083	1.500	.625	.030 - .050	1.500	.970	.080 - .100			
1.494	.857	.080 - .104	1.497	.515	.100 - .125	1.499	.098	.050 - .075	1.500	.265	.100 - .125	1.500	.626	.100 - .125	1.500	.993	.025 - .040			
1.494	.937	.030 - .050	1.497	.559	.100 - .125	1.499	.127	.080 - .090	1.500	.266	.015 - .025	<b>1.500</b>	<b>.634</b>	<b>.005 - .010</b>	1.500	.996	.050 - .070			
1.494	1.024	.030 - .050	1.497	.612	.020 - .030	<b>1.499</b>	<b>.167</b>	<b>.005 - .010</b>	1.500	.267	.005 - .010	1.500	.636	.060 - .083	1.500	1.001	.005 - .015			
1.494	1.057	.080 - .104	1.497	.620	.010 - .020	1.499	.187	.020 - .040	1.500	.269	.030 - .048	1.500	.636	.160 - .180	1.500	1.002	.040 - .060			
1.494	1.060	.064 - .078	1.497	.620	.040 - .060	1.499	.197	.125 - .156	1.500	.281	.156 - .187	1.500	.638	.020 - .040	1.500	1.002	.070 - .090			
1.494	1.075	.050 - .060	1.497	.632	.010 - .020	<b>1.499</b>	<b>.213</b>	<b>.005 - .010</b>	1.500	.282	.008 - .015	1.500	.640	.110 - .130	<b>1.500</b>	<b>1.003</b>	<b>.005 - .010</b>			
1.494	1.092	.040 - .060	1.497	.655	.075 - .100	1.499	.268	.070 - .090	<b>1.500</b>	<b>.283</b>	<b>.005 - .010</b>	<b>1.500</b>	<b>.655</b>	<b>.005 - .010</b>	1.500	1.003	.050 - .075			
1.494	1.175	.015 - .025	1.497	.723	.060 - .083	1.499	.281	.100 - .125	<b>1.500</b>	<b>.303</b>	<b>.005 - .010</b>	1.500	.655	.010 - .020	1.500	1.003	.125 - .156			
1.494	1.201	.035 - .050	1.497	.753	.025 - .040	1.499	.303	.040 - .060	1.500	.311	.104 - .134	1.500	.656	.075 - .090	1.500	1.004	.015 - .030			
<b>1.494</b>	<b>1.265</b>	<b>.005 - .010</b>	1.497	.755	.025 - .042	1.499	.314	.010 - .020	1.500	.313	.062 - .080	1.500	.656	.110 - .130	1.500	1.004	.032 - .050			
1.494	1.270	.010 - .015	1.497	.757	.010 - .020	1.499	.374	.030 - .050	1.500	.315	.008 - .012	1.500	.660	.040 - .060	1.500	1.005	.050 - .075			
<b>1.494</b>	<b>1.305</b>	<b>.005 - .010</b>	1.497	.757	.020 - .030	1.499	.385	.135 - .156	1.500	.315	.090 - .110	<b>1.500</b>	<b>.665</b>	<b>.005 - .010</b>	1.500	1.009	.040 - .060			
1.494	1.338	.010 - .020	1.497	.763	.005 - .015	<b>1.499</b>	<b>.399</b>	<b>.005 - .010</b>	1.500	.325	.048 - .075	1.500	.687	.030 - .050	1.500	1.009	.120 - .140			
1.494	1.342	.008 - .015	1.497	.772	.030 - .048	<b>1.499</b>	<b>.420</b>	<b>.005 - .010</b>	<b>1.500</b>	<b>.327</b>	<b>.005 - .010</b>	1.500	.688	.050 - .070	<b>1.500</b>	<b>1.010</b>	<b>.005 - .010</b>			
1.494	1.414	.015 - .025	<b>1.497</b>	<b>.810</b>	<b>.005 - .010</b>	<b>1.499</b>	<b>.474</b>	<b>.005 - .010</b>	1.500	.330	.120 - .135	<b>1.500</b>	<b>.694</b>	<b>.005 - .010</b>	1.500	1.010	.010 - .020			
<b>1.495</b>	<b>.263</b>	<b>.005 - .010</b>	<b>1.497</b>	<b>.891</b>	<b>.005 - .010</b>	1.499	.485	.050 - .075	<b>1.500</b>	<b>.340</b>	<b>.005 - .010</b>	1.500	.700	.070 - .090	1.500	1.011	.010 - .020			
1.495	.294	.020 - .032	1.497	.906	.100 - .120	<b>1.499</b>	<b>.503</b>	<b>.005 - .010</b>	1.500	.345	.050 - .070	1.500	.701	.050 - .070	1.500	1.015	.040 - .060			
1.495	.295	.100 - .125	1.497	1.060	.100 - .125	1.499	.503	.012 - .020	1.500	.346	.105 - .135	<b>1.500</b>	<b>.703</b>	<b>.005 - .010</b>	1.500	1.015	.060 - .090			
1.495	.354	.105 - .135	1.497	1.119	.040 - .060	<b>1.499</b>	<b>.504</b>	<b>.005 - .010</b>	<b>1.500</b>	<b>.349</b>	<b>.005 - .010</b>	<b>1.500</b>	<b>.713</b>	<b>.005 - .010</b>	1.500	1.015	.100 - .125			
1.495	.375	.030 - .050	1.497	1.126	.135 - .156	1.499	.504	.010 - .020	1.500	.372	.040 - .060	<b>1.500</b>	<b>.715</b>	<b>.005 - .010</b>	1.500	1.018	.100 - .125			
1.495	.459	.156 - .187	<b>1.497</b>	<b>1.137</b>	<															

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.500	1.186	.105 - .135	<b>1.503</b>	<b>.509</b>	<b>.005 - .010</b>	1.528	.187	.025 - .040	1.540	1.102	.025 - .040	1.556	1.405	.010 - .020	1.562	.812	.062 - .080
1.500	1.187	.015 - .030	1.503	.701	.050 - .070	1.528	.195	.050 - .075	1.540	1.200	.020 - .030	1.556	1.437	.032 - .050	1.562	.864	.120 - .140
1.500	1.187	.100 - .125	1.503	.845	.025 - .040	1.528	.195	.075 - .100	1.540	1.290	.050 - .070	1.557	.396	.005 - .015	1.562	.874	.020 - .040
<b>1.500</b>	<b>1.190</b>	<b>.005 - .010</b>	<b>1.503</b>	<b>1.008</b>	<b>.005 - .010</b>	1.528	.250	.010 - .030	1.541	.318	.020 - .030	1.557	.407	.060 - .080	1.562	.875	.015 - .030
1.500	1.191	.105 - .125	1.503	1.016	.015 - .030	<b>1.528</b>	<b>.728</b>	<b>.005 - .010</b>	1.541	1.008	.025 - .040	1.557	.770	.110 - .130	1.562	.904	.040 - .050
<b>1.500</b>	<b>1.199</b>	<b>.005 - .010</b>	1.503	1.020	.050 - .075	1.528	1.009	.050 - .070	1.541	1.008	.050 - .070	1.557	1.002	.075 - .090	1.562	.906	.040 - .050
1.500	1.199	.025 - .040	1.504	.687	.010 - .020	1.528	1.276	.010 - .020	1.541	1.250	.050 - .070	1.557	1.038	.040 - .060	1.562	.925	.030 - .060
1.500	1.202	.031 - .048	1.504	.784	.042 - .062	1.528	1.285	.020 - .040	1.542	.833	.020 - .030	1.557	1.314	.105 - .125	1.562	.932	.050 - .075
1.500	1.204	.035 - .048	<b>1.504</b>	<b>.789</b>	<b>.005 - .010</b>	<b>1.529</b>	<b>.466</b>	<b>.005 - .010</b>	<b>1.542</b>	<b>.998</b>	<b>.005 - .010</b>	1.557	1.355	.025 - .040	1.562	.937	.100 - .125
1.500	1.212	.015 - .030	1.504	.811	.100 - .125	1.529	.791	.030 - .050	<b>1.542</b>	<b>1.193</b>	<b>.005 - .010</b>	<b>1.557</b>	<b>1.358</b>	<b>.005 - .010</b>	1.562	.938	.015 - .025
<b>1.500</b>	<b>1.215</b>	<b>.005 - .010</b>	1.504	1.036	.120 - .135	1.529	.984	.080 - .105	1.543	.431	.075 - .105	1.558	.256	.075 - .100	1.562	.939	.030 - .050
<b>1.500</b>	<b>1.249</b>	<b>.005 - .010</b>	1.504	1.230	.062 - .090	1.529	1.052	.080 - .100	1.543	1.255	.050 - .075	1.558	.375	.075 - .090	1.562	.996	.062 - .090
1.500	1.251	.025 - .040	1.504	1.287	.040 - .060	1.529	1.117	.100 - .110	1.543	1.257	.025 - .040	1.558	.378	.060 - .080	1.562	1.001	.120 - .134
1.500	1.264	.020 - .030	1.504	1.378	.010 - .020	1.529	1.259	.020 - .040	1.543	1.261	.030 - .050	1.558	.410	.090 - .105	1.562	1.002	.120 - .134
<b>1.500</b>	<b>1.265</b>	<b>.005 - .010</b>	1.505	.408	.015 - .030	1.529	1.360	.020 - .040	1.544	1.169	.030 - .050	1.558	.749	.020 - .040	1.562	1.008	.040 - .060
1.500	1.266	.010 - .020	1.505	.440	.156 - .187	1.529	1.416	.020 - .030	1.544	1.182	.025 - .040	1.558	.770	.100 - .125	1.562	1.032	.083 - .105
1.500	1.274	.010 - .020	1.505	.845	.025 - .035	<b>1.529</b>	<b>1.453</b>	<b>.005 - .010</b>	<b>1.544</b>	<b>1.191</b>	<b>.005 - .010</b>	1.558	1.004	.025 - .040	1.562	1.063	.015 - .025
1.500	1.275	.008 - .018	1.505	1.003	.015 - .030	1.530	.251	.015 - .030	1.544	1.481	.010 - .020	<b>1.558</b>	<b>1.433</b>	<b>.005 - .010</b>	1.562	1.128	.030 - .048
1.500	1.277	.090 - .125	1.505	1.109	.040 - .060	1.530	.282	.060 - .080	1.545	.264	.030 - .050	<b>1.559</b>	<b>.776</b>	<b>.005 - .010</b>	1.562	1.155	.015 - .032
1.500	1.282	.008 - .016	1.505	1.310	.015 - .025	1.530	.312	.030 - .050	1.545	.437	.020 - .040	1.559	.875	.110 - .130	<b>1.562</b>	<b>1.187</b>	<b>.005 - .010</b>
1.500	1.298	.010 - .025	1.506	1.249	.050 - .075	<b>1.530</b>	<b>.536</b>	<b>.005 - .010</b>	1.545	1.156	.020 - .030	<b>1.559</b>	<b>1.071</b>	<b>.005 - .010</b>	1.562	1.188	.020 - .040
1.500	1.300	.050 - .075	<b>1.507</b>	<b>1.324</b>	<b>.005 - .010</b>	<b>1.530</b>	<b>.548</b>	<b>.005 - .010</b>	<b>1.545</b>	<b>1.191</b>	<b>.005 - .010</b>	1.559	1.288	.010 - .020	1.562	1.203	.025 - .048
1.500	1.301	.050 - .070	1.508	.315	.105 - .125	1.530	.832	.020 - .030	1.545	1.457	.025 - .035	1.559	1.315	.006 - .010	<b>1.562</b>	<b>1.313</b>	<b>.005 - .010</b>
1.500	1.332	.025 - .040	1.508	.910	.080 - .105	1.530	1.031	.075 - .090	1.546	1.182	.025 - .040	1.559	1.315	.020 - .040	1.562	1.320	.060 - .080
1.500	1.376	.015 - .030	1.509	.301	.090 - .120	1.530	1.202	.010 - .030	1.546	1.184	.025 - .040	<b>1.559</b>	<b>1.439</b>	<b>.005 - .010</b>	1.562	1.323	.105 - .125
1.500	1.376	.030 - .060	1.509	.781	.090 - .105	<b>1.531</b>	<b>.333</b>	<b>.005 - .010</b>	1.547	1.007	.040 - .064	1.559	1.439	.010 - .020	1.562	1.346	.030 - .050
1.500	1.389	.030 - .050	1.510	.510	.060 - .080	1.531	.390	.100 - .125	1.548	.441	.010 - .020	1.560	.242	.015 - .030	1.562	1.347	.040 - .060
1.501	.125	.075 - .090	1.510	.900	.030 - .050	1.531	.516	.060 - .080	1.548	.951	.090 - .110	1.560	.381	.125 - .156	1.562	1.348	.062 - .075
<b>1.501</b>	<b>.190</b>	<b>.005 - .010</b>	<b>1.510</b>	<b>1.236</b>	<b>.005 - .010</b>	<b>1.531</b>	<b>.625</b>	<b>.005 - .010</b>	1.548	1.005	.010 - .020	1.560	.391	.080 - .105	<b>1.562</b>	<b>1.354</b>	<b>.005 - .010</b>
1.501	.200	.100 - .125	<b>1.510</b>	<b>1.258</b>	<b>.005 - .010</b>	1.531	.689	.060 - .080	1.548	1.038	.031 - .048	1.560	.392	.080 - .105	1.562	1.374	.025 - .040
1.501	.280	.060 - .090	1.511	.823	.170 - .190	1.531	.776	.025 - .040	1.549	.361	.050 - .070	1.560	.455	.100 - .125	1.562	1.375	.020 - .040
1.501	.336	.105 - .125	<b>1.511</b>	<b>1.015</b>	<b>.005 - .010</b>	1.531	.808	.030 - .050	1.549	.503	.015 - .030	1.560	.508	.100 - .125	<b>1.562</b>	<b>1.376</b>	<b>.005 - .010</b>
1.501	.372	.050 - .070	1.511	1.112	.050 - .075	1.531	1.000	.020 - .032	<b>1.549</b>	<b>.505</b>	<b>.005 - .010</b>	1.560	.563	.015 - .030	<b>1.563</b>	<b>.439</b>	<b>.005 - .010</b>
1.501	.382	.005 - .012	1.511	1.113	.040 - .060	1.531	1.015	.025 - .042	1.549	.505	.010 - .020	<b>1.560</b>	<b>.619</b>	<b>.005 - .010</b>	<b>1.563</b>	<b>.638</b>	<b>.005 - .010</b>
1.501	.385	.090 - .125	<b>1.511</b>	<b>1.351</b>	<b>.005 - .010</b>	1.531	1.223	.010 - .020	1.549	.754	.040 - .062	<b>1.560</b>	<b>.772</b>	<b>.005 - .010</b>	1.563	.690	.032 - .060
<b>1.501</b>	<b>.437</b>	<b>.005 - .010</b>	1.514	1.126	.062 - .080	1.532	.098	.030 - .050	1.549	1.003	.050 - .070	1.560	.839	.050 - .070	<b>1.563</b>	<b>.762</b>	<b>.005 - .010</b>
1.501	.508	.030 - .050	1.515	.583	.120 - .134	<b>1.532</b>	<b>.765</b>	<b>.005 - .010</b>	1.549	1.005	.040 - .060	1.560	.845	.025 - .048	1.563	.878	.025 - .040
<b>1.501</b>	<b>.514</b>	<b>.005 - .010</b>	1.515	.765	.050 - .070	1.532	1.047	.015 - .025	1.549	1.226	.030 - .050	1.560	1.063	.135 - .156	1.563	.892	.075 - .100
1.501	.626	.010 - .020	1.515	.892	.045 - .060	1.532	1.306	.070 - .090	1.550	.245	.042 - .075	<b>1.560</b>	<b>1.100</b>	<b>.005 - .010</b>	1.563	.999	.105 - .125
<b>1.501</b>	<b>.715</b>	<b>.005 - .010</b>	1.515	1.360	.040 - .060	1.533	1.003	.040 - .060	1.550	.368	.020 - .035	<b>1.560</b>	<b>1.140</b>	<b>.005 - .010</b>	1.563	1.005	.110 - .130
1.501	.755	.010 - .020	1.515	1.375	.020 - .040	1.533	1.379	.050 - .060	<b>1.550</b>	<b>.438</b>	<b>.005 - .010</b>	1.560	1.207	.010 - .020	<b>1.563</b>	<b>1.062</b>	<b>.005 - .010</b>
1.501	.773	.100 - .125	1.515	1.378	.010 - .020	1.534	.325	.080 - .104	1.550	.438	.015 - .030	1.560	1.315	.015 - .025	1.563	1.131	.050 - .070
1.501	.817	.100 - .125	1.516	.293	.050 - .075	<b>1.534</b>	<b>.505</b>	<b>.005 - .010</b>	<b>1.550</b>	<b>.440</b>	<b>.005 - .010</b>	<b>1.560</b>	<b>1.319</b>	<b>.005 - .010</b>	1.563	1.347	.040 - .062
1.501	.820	.040 - .060	1.516	.915	.050 - .070	1.534	.505	.010 - .020	1.550	.500	.050 - .070	1.560	1.320	.015 - .025	1.563	1.402	.020 - .040
1.501	.840	.010 - .020	<b>1.516</b>	<b>1.194</b>	<b>.005 - .010</b>	1.534	1.026	.105 - .125	<b>1.550</b>	<b>.502</b>	<b>.005 - .010</b>	1.560	1.331	.050 - .070	1.564	.375	.048 - .075
1.501	.876	.040 - .060	<b>1.516</b>	<b>1.199</b>	<b>.005 - .010</b>	1.534	1.046	.015 - .030	<b>1.550</b>	<b>.704</b>	<b>.005 - .010</b>	<b>1.560</b>	<b>1.353</b>	<b>.005 - .010</b>	1.564	.501	.025 - .040
1.501	.909	.050 - .070	<b>1.518</b>	<b>1.405</b>	<b>.005 - .010</b>	1.534	1.097	.020 - .040	1.550	.750	.020 - .040	1.560	1.376	.025 - .040	1.564	.511	.020 - .040
1.501	1.008	.080 - .100	<b>1.519</b>	<b>.623</b>	<b>.005 - .010</b>	1.534	1.397	.020 - .035	1.550	.752	.105 - .125	1.561	.161	.020 - .030	1.564	.767	.010 - .020
<b>1.501</b>	<b>1.009</b>	<b>.005 - .010</b>	1.520	.195	.035 - .050	1.535	.322	.050 - .075	<b>1.550</b>	<b>1.221</b>	<b>.005 - .010</b>	1.561	.251	.040 - .060	1.564	1.135	.050 - .075
<b>1.501</b>	<b>1.010</b>	<b>.005 - .010</b>	1.520	.328	.015 - .020	1.535	.330	.156 - .187	1.550	1.235	.050 - .075	1.561	.259	.083 - .125	<b>1.564</b>	<b>1.189</b>	<b>.005 - .010</b>
1.501	1.121	.020 - .030	1.520	.890	.050 - .070	1.535	.635	.025 - .040	1.550	1.255	.015 - .025	1.561	.629	.075 - .105	<b>1.564</b>	<b>1.309</b>	<b>.005 - .010</b>
1.501	1.132	.025 - .050	<b>1.520</b>	<b>1.015</b>	<b>.005 - .010</b>	1.535	.788	.050 - .070	<b>1.550</b>	<b>1.439</b>	<b>.005 - .010</b>	1.561	.766	.100 - .125	1.564	1.393	.015 - .030
1.501	1.133	.060 - .080	1.520	1.264	.020 - .030	1.535	.867	.105 - .125	1.551	.289	.050 - .070	1.561	.768	.025 - .040	<b>1.564</b>	<b>1.434</b>	<b>.005 - .010</b>
1.501	1.188	.050 - .070	1.520	1.264	.030 - .050	1.535	.904	.100 - .125	1.551	.438	.010 - .020	<b>1.561</b>	<b>.883</b>	<b>.005 - .010</b>	1.565	.122	.020 - .040
1.501	1.251	.020 - .030	<b>1.520</b>	<b>1.420</b>	<b>.005 - .010</b>	1.535	1.064	.080 - .104	1.551	.440	.010 - .020	1.561	.952	.030 - .050	1.565	.562	.030 - .048
<b>1.501</b>	<b>1.290</b>	<b>.005 - .010</b>	1.521	.326	.030 - .050	1.535	1.138	.005 - .020	1.551	1.026	.060 - .080	1.561	1.039	.030 - .050	1.565	1.192	.050 - .075
1.502	.185	.105 - .135	1.521	.390	.040 - .060	1.535	1.344	.012 - .025	1.551	1.140	.010 - .020	1.561	1.040	.010 - .015	1.565	1.228	.030 - .050
1.502	.220	.060 - .080	1.521	.889	.050 - .070												

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.569	.361	.040 - .060	1.575	.985	.010 - .020	1.597	.881	.090 - .125	1.608	1.444	.015 - .030	1.621	.319	.025 - .036	1.625	.465	.015 - .030
1.569	.504	.070 - .090	1.575	.985	.125 - .156	<b>1.598</b>	<b>.505</b>	<b>.005 - .010</b>	1.609	.810	.025 - .040	1.621	.758	.050 - .075	1.625	.475	.105 - .135
<b>1.569</b>	<b>.589</b>	<b>.005 - .010</b>	1.575	1.025	.030 - .050	1.598	.516	.050 - .070	1.609	.845	.012 - .020	<b>1.621</b>	<b>1.265</b>	<b>.005 - .010</b>	<b>1.625</b>	<b>.498</b>	<b>.005 - .010</b>
1.569	.589	.015 - .030	1.575	1.178	.156 - .187	1.598	.625	.030 - .050	1.609	1.015	.016 - .025	1.621	1.275	.020 - .040	1.625	.500	.025 - .042
1.569	.756	.105 - .125	1.575	1.200	.040 - .050	1.598	.630	.010 - .020	1.609	1.260	.050 - .075	1.621	1.317	.025 - .042	1.625	.500	.050 - .080
1.569	.807	.090 - .105	1.575	1.220	.005 - .015	<b>1.598</b>	<b>.720</b>	<b>.005 - .010</b>	1.609	1.275	.100 - .125	1.621	1.480	.025 - .035	<b>1.625</b>	<b>.504</b>	<b>.005 - .010</b>
1.569	.884	.105 - .125	<b>1.575</b>	<b>1.338</b>	<b>.005 - .010</b>	1.598	1.000	.080 - .125	1.609	1.400	.020 - .032	1.622	.341	.075 - .090	<b>1.625</b>	<b>.508</b>	<b>.005 - .010</b>
1.569	1.030	.025 - .040	1.575	1.389	.070 - .090	1.598	1.269	.050 - .070	1.609	1.468	.048 - .062	1.622	.407	.036 - .048	1.625	.508	.025 - .042
1.569	1.140	.070 - .090	<b>1.575</b>	<b>1.474</b>	<b>.005 - .010</b>	<b>1.599</b>	<b>.378</b>	<b>.005 - .010</b>	1.610	1.110	.015 - .030	1.622	.645	.100 - .125	<b>1.625</b>	<b>.514</b>	<b>.005 - .010</b>
1.569	1.187	.040 - .060	<b>1.575</b>	<b>1.747</b>	<b>.005 - .010</b>	1.599	.378	.010 - .020	1.610	1.148	.090 - .105	1.622	.767	.120 - .156	1.625	.531	.100 - .125
1.569	1.320	.015 - .030	1.576	.414	.160 - .190	1.599	.489	.090 - .110	<b>1.610</b>	<b>1.259</b>	<b>.005 - .010</b>	1.622	.894	.090 - .120	1.625	.535	.010 - .020
1.569	1.331	.040 - .060	1.576	.477	.010 - .020	<b>1.599</b>	<b>.503</b>	<b>.005 - .010</b>	1.610	1.275	.100 - .125	1.622	.992	.025 - .040	1.625	.535	.020 - .030
1.570	.168	.008 - .012	<b>1.576</b>	<b>.630</b>	<b>.005 - .010</b>	1.599	.504	.010 - .020	1.610	1.404	.070 - .090	1.622	1.161	.040 - .050	1.625	.540	.010 - .020
1.570	.256	.080 - .100	1.576	.670	.015 - .030	<b>1.599</b>	<b>.505</b>	<b>.005 - .010</b>	1.610	1.422	.020 - .035	1.622	1.188	.050 - .070	1.625	.540	.030 - .060
1.570	.526	.080 - .100	1.576	1.092	.050 - .070	1.599	.626	.015 - .025	<b>1.611</b>	<b>1.135</b>	<b>.005 - .010</b>	1.622	1.188	.080 - .100	1.625	.542	.090 - .120
<b>1.570</b>	<b>.720</b>	<b>.005 - .010</b>	1.576	1.245	.025 - .040	<b>1.599</b>	<b>.630</b>	<b>.005 - .010</b>	1.611	1.410	.010 - .020	1.622	1.250	.020 - .040	1.625	.563	.025 - .042
1.570	.813	.030 - .050	1.577	.632	.040 - .060	1.599	1.437	.010 - .020	<b>1.612</b>	<b>1.135</b>	<b>.005 - .010</b>	1.622	1.261	.050 - .070	1.625	.564	.050 - .075
<b>1.570</b>	<b>.870</b>	<b>.005 - .010</b>	1.577	.771	.030 - .060	1.600	.170	.050 - .062	1.612	1.135	.010 - .020	1.622	1.357	.015 - .030	1.625	.565	.010 - .020
1.570	.906	.100 - .125	1.577	.994	.015 - .030	1.600	.281	.050 - .075	1.612	1.316	.030 - .050	1.622	1.364	.020 - .040	1.625	.565	.100 - .125
1.570	1.003	.035 - .060	1.577	1.072	.090 - .110	1.600	.310	.030 - .050	1.613	.315	.025 - .040	1.623	.255	.080 - .104	1.625	.566	.100 - .125
1.570	1.031	.080 - .105	1.577	1.341	.070 - .090	1.600	.377	.005 - .015	1.613	1.312	.015 - .030	1.623	.511	.090 - .105	1.625	.571	.015 - .030
1.570	1.032	.100 - .125	1.578	.771	.025 - .040	1.600	.378	.005 - .015	1.614	.145	.070 - .090	1.623	.597	.080 - .104	1.625	.614	.015 - .030
1.570	1.190	.032 - .042	1.578	1.063	.030 - .050	1.600	.415	.075 - .100	<b>1.614</b>	<b>.329</b>	<b>.005 - .010</b>	1.623	.625	.010 - .020	1.625	.633	.060 - .090
1.570	1.191	.125 - .156	1.578	1.298	.010 - .015	1.600	.441	.100 - .125	1.614	.694	.020 - .030	<b>1.623</b>	<b>.775</b>	<b>.005 - .010</b>	1.625	.634	.100 - .125
1.570	1.220	.050 - .070	<b>1.579</b>	<b>.570</b>	<b>.005 - .010</b>	1.600	.478	.090 - .120	1.614	.884	.040 - .060	1.623	.782	.062 - .080	<b>1.625</b>	<b>.640</b>	<b>.005 - .010</b>
<b>1.570</b>	<b>1.250</b>	<b>.005 - .010</b>	1.579	1.232	.010 - .020	<b>1.600</b>	<b>.502</b>	<b>.005 - .010</b>	1.614	1.189	.025 - .040	<b>1.623</b>	<b>.891</b>	<b>.005 - .010</b>	1.625	.656	.010 - .020
1.571	.379	.080 - .100	1.579	1.378	.030 - .040	1.600	.503	.006 - .012	<b>1.614</b>	<b>1.251</b>	<b>.005 - .010</b>	1.623	1.000	.080 - .100	1.625	.657	.035 - .050
1.571	.870	.100 - .120	1.580	.795	.020 - .040	1.600	.625	.020 - .040	1.614	1.280	.020 - .040	1.623	1.032	.050 - .070	1.625	.688	.100 - .120
1.571	1.018	.100 - .125	1.580	1.081	.010 - .020	<b>1.600</b>	<b>.627</b>	<b>.005 - .010</b>	1.614	1.281	.010 - .020	1.623	1.063	.050 - .080	1.625	.754	.050 - .075
1.571	1.038	.005 - .015	<b>1.580</b>	<b>1.310</b>	<b>.005 - .010</b>	1.600	.627	.010 - .020	1.614	1.381	.010 - .020	1.623	1.064	.050 - .075	1.625	.755	.090 - .105
1.571	1.146	.070 - .090	<b>1.580</b>	<b>1.472</b>	<b>.005 - .010</b>	1.600	.630	.010 - .020	1.615	.316	.010 - .020	1.623	1.188	.060 - .090	1.625	.760	.100 - .125
<b>1.572</b>	<b>.476</b>	<b>.005 - .010</b>	<b>1.581</b>	<b>.119</b>	<b>.005 - .010</b>	1.600	.715	.105 - .120	1.615	.500	.050 - .070	1.623	1.208	.025 - .040	1.625	.765	.090 - .120
1.572	.625	.050 - .070	1.582	.405	.040 - .060	<b>1.600</b>	<b>.751</b>	<b>.005 - .010</b>	1.615	.629	.090 - .100	1.623	1.257	.110 - .125	1.625	.770	.050 - .075
<b>1.572</b>	<b>.754</b>	<b>.005 - .010</b>	1.582	.450	.010 - .020	<b>1.600</b>	<b>.800</b>	<b>.005 - .010</b>	1.615	.877	.050 - .075	1.623	1.375	.005 - .015	<b>1.625</b>	<b>.772</b>	<b>.005 - .010</b>
1.572	.761	.020 - .040	1.582	.530	.040 - .060	1.600	.874	.040 - .060	1.615	1.000	.050 - .075	1.623	1.410	.005 - .015	1.625	.781	.100 - .120
1.572	1.254	.030 - .050	1.582	.634	.010 - .020	1.600	.878	.025 - .040	1.615	1.407	.020 - .040	1.623	1.456	.025 - .040	1.625	.781	.120 - .135
1.572	1.255	.025 - .040	1.582	1.250	.083 - .105	1.600	.885	.030 - .040	1.615	1.417	.040 - .060	1.623	1.481	.025 - .040	1.625	.791	.030 - .050
1.572	1.258	.007 - .016	1.583	1.089	.020 - .040	1.600	.925	.080 - .100	<b>1.615</b>	<b>1.450</b>	<b>.005 - .010</b>	1.624	.311	.105 - .125	1.625	.797	.080 - .100
<b>1.572</b>	<b>1.452</b>	<b>.005 - .010</b>	<b>1.584</b>	<b>.834</b>	<b>.005 - .010</b>	<b>1.600</b>	<b>1.000</b>	<b>.005 - .010</b>	1.616	.752	.075 - .100	1.624	.440	.040 - .060	1.625	.816	.090 - .120
1.573	.504	.090 - .105	1.584	1.009	.040 - .060	1.600	1.070	.025 - .040	<b>1.616</b>	<b>1.382</b>	<b>.005 - .010</b>	1.624	.621	.050 - .070	1.625	.865	.100 - .125
1.573	.504	.105 - .135	1.585	.140	.042 - .060	1.600	1.070	.100 - .125	1.616	1.390	.100 - .120	1.624	.691	.050 - .075	1.625	.875	.090 - .125
1.573	.641	.060 - .083	1.585	.375	.070 - .090	1.600	1.125	.015 - .025	1.617	.498	.080 - .090	1.624	.695	.015 - .030	1.625	.932	.005 - .012
1.573	.648	.010 - .020	1.585	1.000	.032 - .050	1.600	1.128	.010 - .020	1.617	.498	.090 - .120	1.624	.875	.040 - .060	<b>1.625</b>	<b>.999</b>	<b>.005 - .010</b>
1.573	.731	.040 - .062	1.585	1.007	.010 - .030	1.600	1.175	.090 - .125	1.617	.500	.010 - .020	1.624	.906	.100 - .125	1.625	.999	.020 - .032
1.573	.812	.015 - .030	1.585	1.120	.005 - .015	1.600	1.205	.010 - .020	1.617	.626	.048 - .062	1.624	.917	.030 - .050	1.625	1.000	.040 - .060
<b>1.573</b>	<b>1.013</b>	<b>.005 - .010</b>	1.585	1.209	.025 - .040	1.600	1.260	.030 - .050	1.617	.751	.020 - .040	1.624	1.005	.040 - .060	1.625	1.009	.040 - .060
1.573	1.102	.060 - .080	1.585	1.256	.025 - .040	1.600	1.271	.110 - .130	1.617	.805	.040 - .060	1.624	1.015	.080 - .100	<b>1.625</b>	<b>1.010</b>	<b>.005 - .010</b>
1.573	1.221	.030 - .050	1.585	1.260	.015 - .030	1.600	1.300	.050 - .060	1.617	1.060	.050 - .070	1.624	1.021	.060 - .090	1.625	1.016	.020 - .036
1.573	1.224	.135 - .156	1.585	1.359	.050 - .062	1.600	1.310	.050 - .060	1.617	1.258	.025 - .042	1.624	1.032	.020 - .040	1.625	1.032	.100 - .125
<b>1.573</b>	<b>1.264</b>	<b>.005 - .010</b>	1.586	.141	.060 - .090	1.600	1.357	.005 - .015	1.617	1.390	.030 - .050	1.624	1.083	.100 - .120	1.625	1.062	.120 - .134
<b>1.573</b>	<b>1.374</b>	<b>.005 - .010</b>	<b>1.586</b>	<b>1.290</b>	<b>.005 - .010</b>	1.600	1.375	.010 - .020	1.618	.256	.100 - .125	1.624	1.100	.050 - .070	<b>1.625</b>	<b>1.125</b>	<b>.005 - .010</b>
1.574	.434	.150 - .170	1.587	.469	.010 - .020	<b>1.600</b>	<b>1.439</b>	<b>.005 - .010</b>	1.618	.651	.040 - .060	1.624	1.129	.062 - .080	1.625	1.125	.030 - .040
<b>1.574</b>	<b>.474</b>	<b>.005 - .010</b>	1.588	.700	.050 - .070	<b>1.601</b>	<b>.631</b>	<b>.005 - .010</b>	1.618	.690	.015 - .030	1.624	1.135	.015 - .030	1.625	1.125	.120 - .135
1.574	.475	.010 - .020	<b>1.588</b>	<b>1.006</b>	<b>.005 - .010</b>	<b>1.601</b>	<b>1.436</b>	<b>.005 - .010</b>	1.618	.899	.030 - .050	<b>1.624</b>	<b>1.141</b>	<b>.005 - .010</b>	<b>1.625</b>	<b>1.127</b>	<b>.005 - .010</b>
1.574	.502	.010 - .020	1.588	1.118	.105 - .120	<b>1.601</b>	<b>1.460</b>	<b>.005 - .010</b>	1.618	.963	.110 - .130	1.624	1.182	.020 - .040	1.625	1.130	.090 - .125
1.574	.631	.010 - .020	1.588	1.248	.020 - .035	1.602	.630	.100 - .125	1.618	1.010	.105 - .125	1.624	1.187	.100 - .125	1.625	1.134	.032 - .042
1.574	.984	.035 - .045	1.589	.505	.025 - .040	1.602	.973	.100 - .125	1.618	1.035	.060 - .090	1.624	1.205	.050 - .070	1.625	1.220	.050 - .075
1.574	1.071	.090 - .100	1.590	.490	.090 - .125	<b>1.602</b>	<b>1.432</b>	<b>.005 - .010</b>	<b>1.618</b>	<b>1.134</b>	<b>.005 - .010</b>	1.624	1.218	.020 - .035	1.625	1.250	.015 - .030
1.574	1.1																

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.626	.780	.010 - .020	1.640	1.442	.050 - .070	<b>1.652</b>	<b>.562</b>	<b>.005 - .010</b>	1.670	1.380	.030 - .050	<b>1.686</b>	<b>1.560</b>	<b>.005 - .010</b>	1.700	1.385	.040 - .060
1.626	1.007	.025 - .040	1.641	1.044	.036 - .060	1.652	.562	.010 - .020	<b>1.670</b>	<b>1.417</b>	<b>.005 - .010</b>	1.687	.255	.080 - .104	<b>1.700</b>	<b>1.389</b>	<b>.005 - .010</b>
1.626	1.125	.040 - .060	1.642	.682	.105 - .135	1.652	.786	.070 - .090	1.670	1.420	.020 - .040	1.687	.375	.030 - .050	<b>1.700</b>	<b>1.451</b>	<b>.005 - .010</b>
1.626	1.187	.005 - .012	<b>1.642</b>	<b>1.039</b>	<b>.005 - .010</b>	1.653	.474	.020 - .030	<b>1.671</b>	<b>.922</b>	<b>.005 - .010</b>	1.687	.406	.105 - .135	1.700	1.504	.030 - .050
1.626	1.187	.020 - .040	1.642	1.330	.050 - .080	<b>1.653</b>	<b>.475</b>	<b>.005 - .010</b>	1.671	1.152	.030 - .050	1.687	.484	.060 - .080	1.700	1.515	.012 - .020
1.626	1.321	.050 - .075	1.643	.678	.080 - .104	1.653	.492	.090 - .125	1.671	1.200	.075 - .105	<b>1.687</b>	<b>.562</b>	<b>.005 - .010</b>	1.700	1.542	.010 - .020
1.626	1.377	.025 - .040	1.643	.755	.050 - .080	<b>1.653</b>	<b>.502</b>	<b>.005 - .010</b>	1.672	.874	.105 - .125	1.687	.562	.010 - .020	1.701	1.266	.015 - .030
<b>1.626</b>	<b>1.402</b>	<b>.005 - .010</b>	1.644	.911	.025 - .040	<b>1.653</b>	<b>.631</b>	<b>.005 - .010</b>	<b>1.672</b>	<b>1.198</b>	<b>.005 - .010</b>	1.687	.634	.030 - .050	1.701	1.385	.030 - .050
1.627	.173	.010 - .020	1.644	.914	.030 - .050	1.653	.633	.020 - .040	<b>1.672</b>	<b>1.515</b>	<b>.005 - .010</b>	1.687	.756	.030 - .050	1.701	1.450	.040 - .060
1.627	.314	.015 - .030	1.644	.990	.040 - .060	1.653	1.274	.050 - .070	<b>1.673</b>	<b>.714</b>	<b>.005 - .010</b>	<b>1.687</b>	<b>.893</b>	<b>.005 - .010</b>	1.702	.208	.040 - .060
1.627	.380	.040 - .060	1.644	1.039	.015 - .030	1.653	1.326	.070 - .090	<b>1.675</b>	<b>.250</b>	<b>.005 - .010</b>	1.687	1.226	.030 - .050	1.702	.820	.080 - .100
1.627	.385	.090 - .105	1.644	1.328	.075 - .090	1.653	1.416	.070 - .090	1.675	.771	.060 - .075	1.687	1.312	.030 - .040	1.702	1.000	.010 - .020
1.627	.555	.156 - .187	1.644	1.388	.090 - .110	1.653	1.481	.040 - .060	1.675	.800	.042 - .075	1.687	1.520	.060 - .070	1.702	1.120	.050 - .070
1.627	.627	.062 - .080	1.644	1.405	.040 - .060	1.653	1.486	.030 - .050	<b>1.675</b>	<b>.855</b>	<b>.005 - .010</b>	1.688	.635	.015 - .030	1.703	.114	.005 - .015
1.627	.693	.105 - .135	1.644	1.458	.020 - .040	1.654	.475	.010 - .020	1.675	1.285	.060 - .080	1.688	.686	.100 - .125	1.703	1.320	.050 - .075
1.627	.816	.025 - .042	1.645	.625	.015 - .050	1.654	.632	.010 - .020	1.677	1.141	.030 - .050	1.688	1.090	.070 - .090	<b>1.703</b>	<b>1.386</b>	<b>.005 - .010</b>
1.627	.876	.015 - .030	1.645	.956	.105 - .125	1.654	.639	.090 - .105	<b>1.677</b>	<b>1.198</b>	<b>.005 - .010</b>	1.688	1.097	.030 - .050	<b>1.704</b>	<b>.114</b>	<b>.005 - .010</b>
1.627	1.006	.105 - .125	1.645	1.250	.140 - .160	<b>1.654</b>	<b>.691</b>	<b>.005 - .010</b>	1.677	1.499	.020 - .030	1.688	1.262	.050 - .075	1.704	.169	.010 - .025
1.627	1.125	.080 - .104	1.645	1.328	.060 - .080	<b>1.654</b>	<b>.820</b>	<b>.005 - .010</b>	1.678	.717	.020 - .030	1.688	1.432	.030 - .050	1.705	1.250	.005 - .012
<b>1.627</b>	<b>1.130</b>	<b>.005 - .010</b>	1.646	1.236	.030 - .050	1.654	1.050	.080 - .100	1.678	.756	.105 - .125	1.688	1.507	.040 - .060	1.705	1.418	.015 - .030
1.627	1.181	.080 - .100	1.646	1.411	.015 - .030	1.654	1.265	.050 - .070	1.678	.769	.025 - .040	1.689	.517	.075 - .105	1.706	.439	.040 - .060
<b>1.627</b>	<b>1.250</b>	<b>.005 - .010</b>	1.646	1.427	.015 - .030	1.654	1.272	.010 - .020	1.678	1.342	.080 - .100	1.689	.940	.090 - .125	1.706	.776	.070 - .090
1.627	1.302	.010 - .020	1.646	1.435	.070 - .090	1.654	1.419	.020 - .040	1.679	.897	.156 - .188	1.689	1.230	.100 - .125	<b>1.707</b>	<b>.780</b>	<b>.005 - .010</b>
1.627	1.320	.025 - .040	1.646	1.460	.015 - .025	<b>1.654</b>	<b>1.420</b>	<b>.005 - .010</b>	1.679	.951	.040 - .060	1.689	1.376	.020 - .030	1.707	1.002	.105 - .135
1.627	1.378	.050 - .070	1.647	.619	.010 - .020	1.655	.203	.050 - .075	<b>1.679</b>	<b>1.050</b>	<b>.005 - .010</b>	1.690	.125	.020 - .040	1.708	.381	.060 - .080
1.628	.129	.050 - .070	1.647	.621	.025 - .040	<b>1.655</b>	<b>.473</b>	<b>.005 - .010</b>	1.679	1.182	.040 - .060	1.690	.410	.105 - .125	<b>1.708</b>	<b>1.247</b>	<b>.005 - .010</b>
1.628	.323	.080 - .105	1.647	1.053	.010 - .020	<b>1.655</b>	<b>.629</b>	<b>.005 - .010</b>	1.679	1.365	.015 - .030	1.690	.711	.050 - .070	1.708	1.247	.010 - .020
1.628	.420	.156 - .187	1.647	1.310	.050 - .070	1.655	.633	.020 - .040	<b>1.679</b>	<b>1.375</b>	<b>.005 - .010</b>	1.690	.890	.080 - .104	1.708	1.311	.030 - .050
1.628	.508	.090 - .120	<b>1.647</b>	<b>1.426</b>	<b>.005 - .010</b>	1.655	.651	.080 - .105	1.679	1.389	.040 - .060	1.690	1.163	.040 - .050	1.708	1.312	.050 - .075
1.628	.810	.040 - .060	1.648	.408	.062 - .080	1.655	.771	.020 - .030	1.680	.250	.010 - .020	1.690	1.187	.020 - .040	1.709	.391	.005 - .015
<b>1.628</b>	<b>1.137</b>	<b>.005 - .010</b>	1.648	.543	.040 - .060	1.655	.905	.050 - .070	1.680	.250	.020 - .035	1.690	1.303	.030 - .050	1.709	.761	.156 - .187
1.628	1.358	.030 - .050	1.648	1.008	.010 - .020	1.655	1.063	.030 - .050	1.680	.500	.010 - .032	1.690	1.378	.030 - .060	1.710	.760	.100 - .125
1.628	1.387	.010 - .040	1.648	1.270	.020 - .030	1.655	1.125	.020 - .030	1.680	.500	.090 - .105	<b>1.690</b>	<b>1.559</b>	<b>.005 - .010</b>	<b>1.710</b>	<b>1.345</b>	<b>.005 - .010</b>
1.629	.240	.015 - .030	<b>1.648</b>	<b>1.403</b>	<b>.005 - .010</b>	<b>1.655</b>	<b>1.179</b>	<b>.005 - .010</b>	1.680	.712	.040 - .060	1.691	.772	.010 - .020	1.711	1.143	.156 - .187
1.629	.240	.015 - .030	1.648	1.515	.040 - .050	1.655	1.179	.010 - .020	1.680	.768	.040 - .060	<b>1.691</b>	<b>1.083</b>	<b>.005 - .010</b>	1.711	1.300	.050 - .070
1.629	.284	.015 - .030	<b>1.649</b>	<b>.055</b>	<b>.005 - .010</b>	1.655	1.440	.030 - .050	1.680	.797	.042 - .062	<b>1.691</b>	<b>1.477</b>	<b>.005 - .010</b>	1.712	.905	.025 - .040
1.629	.530	.100 - .125	<b>1.649</b>	<b>.505</b>	<b>.005 - .010</b>	<b>1.655</b>	<b>1.541</b>	<b>.005 - .010</b>	1.680	.813	.040 - .060	<b>1.691</b>	<b>1.563</b>	<b>.005 - .010</b>	<b>1.712</b>	<b>1.617</b>	<b>.005 - .010</b>
1.629	.592	.020 - .030	1.649	.562	.010 - .020	1.656	1.101	.120 - .156	1.680	.856	.040 - .060	1.692	.885	.080 - .100	1.714	1.408	.050 - .062
1.629	1.125	.015 - .025	1.649	.621	.030 - .050	1.656	1.223	.090 - .105	1.680	.895	.040 - .060	1.693	1.122	.010 - .020	1.714	1.409	.050 - .070
<b>1.629</b>	<b>1.319</b>	<b>.005 - .010</b>	<b>1.649</b>	<b>1.296</b>	<b>.005 - .010</b>	1.656	1.344	.050 - .070	1.680	.927	.040 - .060	<b>1.694</b>	<b>.723</b>	<b>.005 - .010</b>	1.714	1.513	.025 - .042
1.629	1.331	.025 - .040	1.649	1.366	.060 - .080	1.656	1.390	.030 - .050	1.680	.965	.040 - .060	<b>1.694</b>	<b>.984</b>	<b>.005 - .010</b>	1.714	1.541	.040 - .060
1.630	.231	.050 - .070	1.649	1.449	.050 - .070	1.656	1.437	.040 - .060	1.680	1.102	.030 - .050	1.694	1.260	.090 - .110	1.715	.185	.060 - .080
1.630	.243	.110 - .135	1.649	1.499	.050 - .070	<b>1.656</b>	<b>1.581</b>	<b>.005 - .010</b>	1.680	1.195	.090 - .120	1.694	1.499	.025 - .040	1.715	.188	.020 - .030
1.630	.320	.100 - .125	1.649	1.501	.010 - .020	<b>1.657</b>	<b>.345</b>	<b>.005 - .010</b>	1.680	1.249	.040 - .060	1.694	1.500	.005 - .015	1.715	.950	.050 - .080
1.630	.422	.140 - .160	1.650	.051	.015 - .030	<b>1.657</b>	<b>.352</b>	<b>.005 - .010</b>	1.680	1.372	.010 - .025	1.695	.203	.040 - .060	1.715	1.033	.060 - .080
1.630	.890	.025 - .042	1.650	.132	.010 - .020	<b>1.657</b>	<b>1.126</b>	<b>.005 - .010</b>	<b>1.680</b>	<b>1.430</b>	<b>.005 - .010</b>	1.695	.314	.040 - .060	1.715	1.513	.015 - .030
1.630	1.007	.083 - .120	1.650	.377	.030 - .050	1.657	1.135	.090 - .110	1.680	1.450	.032 - .060	<b>1.695</b>	<b>.998</b>	<b>.005 - .010</b>	<b>1.715</b>	<b>1.551</b>	<b>.005 - .010</b>
1.630	1.061	.042 - .062	1.650	.424	.100 - .125	1.657	1.212	.025 - .040	<b>1.681</b>	<b>.196</b>	<b>.005 - .010</b>	1.695	1.010	.100 - .125	1.716	.405	.090 - .120
1.630	1.153	.025 - .040	<b>1.650</b>	<b>.500</b>	<b>.005 - .010</b>	1.658	1.182	.010 - .015	1.681	.894	.050 - .070	1.696	1.002	.060 - .083	1.716	.720	.050 - .075
1.630	1.200	.125 - .156	<b>1.650</b>	<b>.503</b>	<b>.005 - .010</b>	1.659	.754	.025 - .040	1.681	1.193	.020 - .040	1.696	1.200	.020 - .040	1.716	.953	.050 - .070
1.630	1.200	.125 - .156	1.650	.503	.040 - .060	1.659	1.518	.050 - .062	1.681	1.300	.040 - .060	<b>1.696</b>	<b>1.397</b>	<b>.005 - .010</b>	1.716	1.312	.020 - .040
<b>1.630</b>	<b>1.274</b>	<b>.005 - .010</b>	1.650	.620	.015 - .025	1.660	.375	.050 - .070	<b>1.681</b>	<b>1.372</b>	<b>.005 - .010</b>	1.696	1.452	.080 - .105	1.717	.410	.075 - .090
1.630	1.283	.020 - .040	1.650	.620	.025 - .042	1.660	.873	.070 - .090	1.681	1.372	.010 - .020	1.697	.453	.100 - .125	1.717	1.186	.015 - .030
1.630	1.330	.040 - .060	1.650	.620	.060 - .090	1.660	.964	.010 - .020	<b>1.681</b>	<b>1.400</b>	<b>.005 - .010</b>	1.697	.861	.090 - .125	1.717	1.619	.015 - .030
1.630	1.489	.030 - .040	1.650	.620	.090 - .125	1.660	1.375	.090 - .120	1.682	1.016	.060 - .080	1.697	1.308	.105 - .125	1.718	.360	.050 - .070
1.630	1.503	.015 - .030	1.650	.626	.020 - .030	1.660	1.389	.090 - .105	1.683	.819	.010 - .020	<b>1.697</b>	<b>1.328</b>	<b>.005 - .010</b>	1.718	.630	.015 - .030
1.631	1.010	.010 - .020	1.650	.634	.020 - .040	1.660	1.390	.110 - .130	1.683	.918	.010 - .020	1.697	1.338	.010 - .020	1.718	.656	.100 - .125
<b>1.631</b>	<b>1.378</b>	<b>.005 - .010</b>	1.650	.686	.062 - .080	1.661	1.14										

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To				
1.721	1.514	.020 - .030	1.740	1.260	.010 - .020	1.747	.918	.070 - .090	1.749	1.187	.016 - .025	1.750	.655	.100 - .125	1.750	1.300	.040 - .060				
<b>1.722</b>	<b>.417</b>	<b>.005 - .010</b>	1.740	1.260	.020 - .030	1.747	1.006	.110 - .130	1.749	1.255	.040 - .060	1.750	.656	.010 - .020	1.750	1.316	.010 - .020				
1.722	.752	.045 - .060	1.740	1.260	.030 - .060	1.747	1.030	.020 - .040	<b>1.749</b>	<b>1.256</b>	<b>.005 - .010</b>	1.750	.656	.030 - .060	1.750	1.318	.005 - .008				
1.722	1.515	.060 - .080	1.740	1.261	.006 - .012	<b>1.747</b>	<b>1.253</b>	<b>.005 - .010</b>	1.749	1.293	.156 - .180	1.750	.657	.040 - .060	<b>1.750</b>	<b>1.319</b>	<b>.005 - .010</b>				
1.723	.265	.050 - .083	1.740	1.313	.062 - .093	1.747	1.255	.005 - .015	<b>1.749</b>	<b>1.494</b>	<b>.005 - .010</b>	1.750	.686	.050 - .075	1.750	1.324	.035 - .050				
1.723	.354	.060 - .080	<b>1.740</b>	<b>1.530</b>	<b>.005 - .010</b>	1.747	1.255	.015 - .025	<b>1.749</b>	<b>1.499</b>	<b>.005 - .010</b>	<b>1.750</b>	<b>.687</b>	<b>.005 - .015</b>	1.750	1.329	.030 - .050				
1.723	.686	.110 - .130	1.741	1.010	.025 - .040	1.747	1.309	.050 - .075	1.749	1.510	.010 - .020	1.750	.688	.100 - .125	1.750	1.351	.060 - .080				
1.723	1.415	.020 - .040	1.741	1.239	.030 - .050	<b>1.747</b>	<b>1.340</b>	<b>.005 - .010</b>	1.749	1.568	.025 - .040	1.750	.703	.010 - .020	1.750	1.353	.040 - .060				
1.723	1.513	.070 - .090	1.742	.198	.050 - .075	1.747	1.376	.020 - .030	1.750	.733	.015 - .025	<b>1.750</b>	<b>1.375</b>	<b>.005 - .010</b>	1.750	1.375	.010 - .020				
1.724	.375	.040 - .060	1.742	1.020	.020 - .032	1.747	1.394	.042 - .062	<h1>1.750</h1>				1.750	.749	.050 - .070	1.750	1.375	.010 - .020			
1.724	1.195	.060 - .080	1.742	1.020	.032 - .060	<b>1.747</b>	<b>1.395</b>	<b>.005 - .010</b>					1.750	.750	.100 - .125	<b>1.750</b>	<b>1.383</b>	<b>.005 - .010</b>	1.750	1.383	.010 - .025
1.725	1.350	.040 - .062	1.742	1.459	.010 - .020	<b>1.747</b>	<b>1.449</b>	<b>.005 - .010</b>					1.750	.751	.090 - .110	1.750	1.384	.015 - .025	1.750	1.385	.100 - .125
1.726	1.134	.050 - .070	1.742	1.555	.050 - .070	1.747	1.451	.015 - .025					1.750	.755	.060 - .090	1.750	1.385	.100 - .125	1.750	1.389	.060 - .080
1.726	1.385	.030 - .050	1.743	.315	.010 - .015	1.747	1.499	.015 - .030					1.750	.758	.005 - .010	1.750	1.389	.060 - .080	1.750	1.394	.090 - .120
1.727	1.623	.020 - .035	1.743	.315	.020 - .032	1.748	.116	.015 - .030					1.750	.780	.156 - .187	1.750	1.398	.032 - .050	<b>1.750</b>	<b>1.400</b>	<b>.005 - .010</b>
1.728	.878	.100 - .125	<b>1.743</b>	<b>.511</b>	<b>.005 - .010</b>	1.748	.266	.042 - .060					1.750	.812	.042 - .075	1.750	1.398	.032 - .050	1.750	1.400	.005 - .010
1.729	.870	.020 - .040	1.743	.532	.100 - .125	1.748	.267	.030 - .042					1.750	.812	.120 - .156	1.750	1.400	.005 - .010	1.750	1.400	.032 - .050
<b>1.730</b>	<b>.632</b>	<b>.005 - .010</b>	1.743	1.220	.020 - .030	<b>1.748</b>	<b>.278</b>	<b>.005 - .010</b>					1.750	.815	.005 - .010	1.750	1.400	.032 - .050	1.750	1.410	.010 - .020
<b>1.730</b>	<b>.748</b>	<b>.005 - .010</b>	1.743	1.225	.015 - .030	1.748	.281	.048 - .062					1.750	.815	.015 - .030	1.750	1.410	.010 - .020	1.750	1.411	.008 - .015
1.730	1.000	.080 - .105	1.743	1.339	.090 - .105	1.748	.315	.062 - .083	1.750	.820	.100 - .125	1.750	1.411	.008 - .015	1.750	1.435	.005 - .008				
1.730	1.300	.060 - .070	1.743	1.503	.020 - .030	1.748	.395	.010 - .025	1.750	.830	.005 - .010	1.750	1.435	.005 - .008	1.750	1.435	.025 - .040				
1.730	1.330	.010 - .020	1.743	1.536	.040 - .060	1.748	.495	.020 - .030	1.750	.832	.050 - .070	1.750	1.435	.025 - .040	1.750	1.436	.120 - .134				
1.730	1.330	.020 - .030	1.744	1.254	.020 - .040	1.748	.562	.100 - .125	1.750	.876	.030 - .048	1.750	1.436	.120 - .134	1.750	1.443	.090 - .105				
1.730	1.330	.030 - .050	1.744	1.398	.020 - .040	1.748	.627	.060 - .080	1.750	.876	.090 - .105	1.750	1.443	.090 - .105	1.750	1.471	.050 - .075				
1.730	1.541	.015 - .030	1.744	1.447	.030 - .050	<b>1.748</b>	<b>.752</b>	<b>.005 - .010</b>	1.750	.878	.006 - .016	1.750	1.471	.050 - .075	1.750	1.500	.025 - .040				
<b>1.731</b>	<b>.476</b>	<b>.005 - .010</b>	1.744	1.503	.020 - .040	1.748	.752	.020 - .030	1.750	.906	.100 - .125	1.750	1.500	.025 - .040	1.750	1.502	.005 - .010				
1.731	.748	.015 - .030	1.744	1.505	.030 - .060	<b>1.748</b>	<b>.756</b>	<b>.005 - .010</b>	1.750	.907	.110 - .130	1.750	1.502	.005 - .010	1.750	1.527	.020 - .040				
1.731	.828	.090 - .105	<b>1.744</b>	<b>1.567</b>	<b>.005 - .010</b>	1.748	.756	.030 - .050	1.750	.920	.030 - .050	1.750	1.527	.020 - .040	1.750	1.531	.030 - .050				
1.731	.854	.070 - .090	1.745	.125	.032 - .060	1.748	.759	.020 - .030	1.750	.920	.075 - .104	1.750	1.531	.030 - .050	1.750	1.531	.060 - .080				
1.731	.881	.040 - .060	1.745	.162	.015 - .030	1.748	.765	.050 - .070	1.750	.937	.100 - .125	1.750	1.531	.060 - .080	1.750	1.532	.025 - .045				
1.731	1.195	.025 - .040	1.745	.195	.005 - .012	1.748	.767	.100 - .125	1.750	.943	.060 - .080	1.750	1.532	.025 - .045	1.750	1.565	.005 - .010				
1.731	1.255	.040 - .050	1.745	.315	.060 - .080	1.748	.770	.010 - .020	1.750	.950	.105 - .135	1.750	1.565	.005 - .010	1.750	1.566	.005 - .010				
1.731	1.497	.030 - .050	1.745	.503	.100 - .125	1.748	.781	.050 - .075	1.750	.950	.135 - .160	1.750	1.566	.005 - .010	1.750	1.567	.010 - .020				
<b>1.732</b>	<b>.473</b>	<b>.005 - .010</b>	1.745	.505	.105 - .125	1.748	.785	.100 - .125	1.750	.954	.010 - .020	1.750	1.567	.010 - .020	1.750	1.571	.325				
<b>1.732</b>	<b>.630</b>	<b>.005 - .010</b>	1.745	.640	.020 - .030	1.748	.875	.020 - .040	1.750	1.000	.010 - .020	<b>1.751</b>	<b>.325</b>	<b>.005 - .010</b>	1.750	1.571	.060 - .080				
1.732	.695	.007 - .012	<b>1.745</b>	<b>.647</b>	<b>.005 - .010</b>	<b>1.748</b>	<b>.878</b>	<b>.005 - .010</b>	1.750	1.003	.050 - .070	1.751	.451	.105 - .125	1.750	1.571	.060 - .080				
1.732	1.257	.040 - .060	1.745	.695	.100 - .125	1.748	.906	.050 - .070	1.750	1.005	.100 - .125	1.751	.511	.005 - .010	1.750	1.571	.060 - .080				
1.732	1.387	.025 - .040	1.745	.885	.050 - .070	1.748	1.019	.060 - .083	1.750	1.005	.156 - .187	1.751	.560	.010 - .020	1.750	1.571	.060 - .080				
1.732	1.420	.020 - .040	1.745	1.073	.010 - .020	1.748	1.060	.010 - .020	1.750	1.009	.050 - .070	1.751	.560	.030 - .060	1.750	1.571	.060 - .080				
1.732	1.429	.010 - .020	<b>1.745</b>	<b>1.165</b>	<b>.005 - .010</b>	<b>1.748</b>	<b>1.072</b>	<b>.005 - .010</b>	1.750	1.015	.156 - .188	1.751	.626	.025 - .040	1.750	1.571	.060 - .080				
1.733	.634	.010 - .020	1.745	1.370	.025 - .040	1.748	1.136	.075 - .090	1.750	1.016	.050 - .070	1.751	.628	.100 - .125	1.750	1.571	.060 - .080				
1.733	1.257	.030 - .050	<b>1.745</b>	<b>1.375</b>	<b>.005 - .010</b>	1.748	1.161	.040 - .060	1.750	1.019	.005 - .010	1.751	.629	.030 - .050	1.750	1.571	.060 - .080				
1.733	1.357	.040 - .050	1.745	1.448	.020 - .030	1.748	1.264	.015 - .030	1.750	1.019	.010 - .020	1.751	.629	.030 - .050	1.750	1.571	.060 - .080				
1.733	1.506	.050 - .075	<b>1.745</b>	<b>1.511</b>	<b>.005 - .010</b>	1.748	1.293	.070 - .090	1.750	1.019	.010 - .020	1.751	.629	.030 - .050	1.750	1.571	.060 - .080				
1.734	.253	.105 - .125	1.745	1.560	.010 - .020	1.748	1.299	.005 - .010	1.750	1.020	.105 - .125	1.751	1.002	.105 - .125	1.750	1.571	.060 - .080				
<b>1.734</b>	<b>.924</b>	<b>.005 - .010</b>	1.745	1.561	.015 - .025	1.748	1.316	.070 - .090	1.750	1.020	.105 - .125	1.751	1.002	.105 - .125	1.750	1.571	.060 - .080				
1.734	1.382	.070 - .090	1.746	.373	.060 - .080	1.748	1.320	.040 - .060	1.750	1.025	.010 - .020	1.751	1.002	.105 - .125	1.750	1.571	.060 - .080				
<b>1.734</b>	<b>1.399</b>	<b>.005 - .010</b>	<b>1.746</b>	<b>.443</b>	<b>.005 - .010</b>	1.748	1.320	.040 - .060	1.750	1.031	.135 - .156	1.751	1.033	.050 - .075	1.750	1.571	.060 - .080				
<b>1.734</b>	<b>1.451</b>	<b>.005 - .010</b>	1.746	.497	.025 - .040	1.748	1.374	.100 - .125	1.750	1.033	.062 - .083	1.751	1.132	.050 - .075	1.750	1.571	.060 - .080				
1.734	1.536	.015 - .030	<b>1.746</b>	<b>.595</b>	<b>.005 - .010</b>	1.748	1.380	.020 - .040	<b>1.750</b>	<b>.505</b>	<b>.005 - .010</b>	1.751	1.132	.050 - .075	1.750	1.571	.060 - .080				
1.735	.378	.030 - .050	1.746	.781	.100 - .125	1.748	1.499	.015 - .030	1.750	1.033	.062 - .083	1.751	1.132	.050 - .075	1.750	1.571	.060 - .080				
1.735	.896	.080 - .105	1.746	.781	.100 - .125	1.748	1.511	.062 - .083	1.750	1.043	.050 - .070	1.751	1.198	.070 - .090	1.750	1.571	.060 - .080				
1.735	1.265	.015 - .030	1.746	.906	.100 - .125	1.748	1.650	.005 - .010	1.750	1.049	.005 - .010	1.751	1.260	.050 - .070	1.750	1.571	.060 - .080				
<b>1.735</b>	<b>1.399</b>	<b>.005 - .010</b>	1.746	1.001	.040 - .062	1.749</															

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.753	.752	.105 - .125	1.775	1.275	.100 - .130	1.800	.147	.080 - .104	1.812	.456	.060 - .080	<b>1.835</b>	<b>1.501</b>	<b>.005 - .010</b>	1.850	1.438	.100 - .120
<b>1.753</b>	<b>1.067</b>	<b>.005 - .010</b>	1.775	1.511	.025 - .040	1.800	.154	.050 - .060	1.812	.751	.156 - .187	1.835	1.620	.010 - .020	1.850	1.570	.020 - .030
<b>1.753</b>	<b>1.268</b>	<b>.005 - .010</b>	1.775	1.517	.030 - .040	<b>1.800</b>	<b>.195</b>	<b>.005 - .010</b>	1.812	.792	.035 - .048	<b>1.836</b>	<b>1.646</b>	<b>.005 - .010</b>	1.850	1.570	.030 - .050
1.753	1.313	.080 - .100	1.775	1.520	.025 - .040	1.800	.473	.025 - .040	1.812	1.062	.075 - .100	<b>1.837</b>	<b>1.343</b>	<b>.005 - .010</b>	1.850	1.685	.015 - .025
1.753	1.385	.005 - .008	<b>1.776</b>	<b>.685</b>	<b>.005 - .010</b>	<b>1.800</b>	<b>.505</b>	<b>.005 - .010</b>	1.812	1.124	.050 - .075	1.837	1.345	.005 - .015	1.851	1.505	.025 - .040
1.753	1.564	.050 - .070	1.776	.752	.100 - .134	1.800	.505	.010 - .020	1.812	1.130	.090 - .125	1.838	.126	.030 - .050	1.851	1.590	.005 - .012
1.754	.894	.100 - .125	1.776	1.235	.060 - .080	<b>1.800</b>	<b>.754</b>	<b>.005 - .010</b>	1.812	1.156	.080 - .104	<b>1.838</b>	<b>.419</b>	<b>.005 - .010</b>	<b>1.851</b>	<b>1.630</b>	<b>.005 - .010</b>
1.754	1.254	.062 - .083	1.776	1.262	.060 - .080	1.800	.880	.010 - .020	1.812	1.188	.050 - .080	1.838	1.371	.040 - .060	1.851	1.630	.015 - .025
1.754	1.387	.020 - .030	1.776	1.452	.030 - .050	1.800	.892	.062 - .083	1.812	1.312	.010 - .015	1.838	1.571	.030 - .050	1.852	.290	.020 - .030
1.755	.281	.080 - .100	1.776	1.576	.015 - .025	<b>1.800</b>	<b>.906</b>	<b>.005 - .010</b>	1.812	1.381	.050 - .075	1.839	1.251	.025 - .030	1.852	.560	.070 - .090
1.755	.322	.050 - .070	1.777	.998	.010 - .020	1.800	.992	.060 - .080	1.812	1.410	.030 - .050	<b>1.839</b>	<b>1.382</b>	<b>.005 - .010</b>	1.852	1.165	.035 - .045
1.755	.906	.040 - .062	1.777	1.110	.015 - .030	1.800	1.010	.120 - .134	1.812	1.436	.040 - .060	1.840	.249	.060 - .075	1.852	1.590	.008 - .015
1.755	1.285	.060 - .080	1.778	.199	.020 - .040	1.800	1.172	.080 - .100	1.812	1.444	.040 - .060	1.840	.509	.050 - .070	1.854	1.658	.020 - .030
1.755	1.536	.050 - .070	1.779	.999	.050 - .070	1.800	1.173	.083 - .120	1.812	1.445	.020 - .040	1.840	.679	.050 - .070	1.857	.586	.020 - .030
1.757	.252	.080 - .104	<b>1.779</b>	<b>1.057</b>	<b>.005 - .010</b>	<b>1.800</b>	<b>1.380</b>	<b>.005 - .010</b>	1.812	1.480	.050 - .075	<b>1.840</b>	<b>1.005</b>	<b>.005 - .010</b>	1.857	.710	.090 - .125
1.757	.629	.100 - .125	1.780	.250	.020 - .032	1.800	1.430	.040 - .060	1.812	1.498	.010 - .020	1.840	1.008	.090 - .105	1.857	1.435	.005 - .012
<b>1.757</b>	<b>1.437</b>	<b>.005 - .010</b>	1.780	.509	.020 - .040	<b>1.800</b>	<b>1.500</b>	<b>.005 - .010</b>	<b>1.812</b>	<b>1.510</b>	<b>.005 - .010</b>	1.840	1.336	.050 - .075	1.858	1.360	.025 - .040
<b>1.758</b>	<b>.562</b>	<b>.005 - .010</b>	<b>1.780</b>	<b>.720</b>	<b>.005 - .010</b>	1.800	1.500	.010 - .020	1.812	1.522	.020 - .040	1.840	1.343	.010 - .020	1.859	.389	.050 - .075
1.758	1.476	.050 - .070	1.780	.754	.030 - .048	<b>1.800</b>	<b>1.548</b>	<b>.005 - .010</b>	1.812	1.523	.030 - .050	1.840	1.424	.050 - .075	<b>1.859</b>	<b>.818</b>	<b>.005 - .010</b>
1.760	.631	.010 - .020	1.780	.953	.120 - .135	<b>1.800</b>	<b>1.562</b>	<b>.005 - .010</b>	1.812	1.524	.015 - .030	1.840	1.425	.065 - .080	<b>1.859</b>	<b>1.435</b>	<b>.005 - .010</b>
1.760	.767	.007 - .016	1.780	1.250	.015 - .030	1.800	1.569	.025 - .040	1.812	1.563	.015 - .030	1.840	1.479	.040 - .060	1.859	1.642	.060 - .080
1.760	1.140	.007 - .016	1.780	1.612	.030 - .050	1.801	.505	.010 - .020	1.813	.251	.083 - .104	1.840	1.519	.040 - .060	1.860	.201	.050 - .075
<b>1.760</b>	<b>1.286</b>	<b>.005 - .010</b>	1.780	1.691	.020 - .030	<b>1.801</b>	<b>.751</b>	<b>.005 - .010</b>	1.813	.751	.025 - .040	1.841	.377	.110 - .130	1.860	1.268	.025 - .050
1.761	.408	.015 - .030	1.781	.936	.080 - .105	1.801	1.501	.050 - .070	1.813	.906	.025 - .040	1.841	.402	.040 - .060	1.860	1.345	.030 - .040
1.762	.408	.015 - .030	1.781	1.157	.020 - .040	1.801	1.610	.020 - .030	1.813	1.140	.156 - .187	1.841	1.189	.015 - .030	1.860	1.445	.050 - .075
1.762	.950	.140 - .160	1.781	1.517	.015 - .030	1.801	1.611	.010 - .020	1.813	1.266	.090 - .105	1.841	1.189	.030 - .040	<b>1.861</b>	<b>1.446</b>	<b>.005 - .010</b>
1.762	1.388	.060 - .080	<b>1.782</b>	<b>.396</b>	<b>.005 - .010</b>	1.802	.425	.040 - .060	1.813	1.323	.010 - .020	<b>1.841</b>	<b>1.404</b>	<b>.005 - .010</b>	1.862	1.510	.012 - .025
1.763	1.126	.135 - .160	<b>1.782</b>	<b>1.645</b>	<b>.005 - .010</b>	<b>1.802</b>	<b>1.257</b>	<b>.005 - .010</b>	1.813	1.394	.040 - .060	<b>1.841</b>	<b>1.407</b>	<b>.005 - .010</b>	<b>1.863</b>	<b>.650</b>	<b>.005 - .010</b>
1.764	.453	.010 - .020	1.783	.880	.010 - .020	1.803	.906	.020 - .032	1.813	1.585	.010 - .020	<b>1.841</b>	<b>1.569</b>	<b>.005 - .010</b>	1.863	1.361	.110 - .130
1.764	.453	.030 - .040	1.783	.880	.020 - .030	1.803	1.362	.040 - .060	1.814	1.000	.100 - .125	1.842	.378	.100 - .125	1.863	1.375	.090 - .110
1.764	.504	.090 - .125	1.784	1.136	.020 - .040	1.804	1.270	.010 - .020	1.814	1.300	.025 - .050	1.842	.640	.025 - .040	1.865	.354	.070 - .090
1.764	.514	.105 - .134	1.784	1.330	.010 - .020	<b>1.804</b>	<b>1.366</b>	<b>.005 - .010</b>	1.815	.323	.005 - .016	<b>1.842</b>	<b>.828</b>	<b>.005 - .010</b>	1.865	.888	.050 - .062
1.764	.950	.110 - .130	1.784	1.616	.060 - .080	<b>1.805</b>	<b>.338</b>	<b>.005 - .010</b>	1.815	.410	.070 - .090	1.842	1.098	.080 - .100	1.865	1.023	.100 - .125
1.764	1.268	.060 - .090	1.785	.881	.050 - .070	1.805	.375	.090 - .105	1.815	.410	.090 - .110	1.842	1.251	.090 - .125	1.865	1.123	.100 - .125
1.764	1.475	.080 - .104	1.785	1.084	.032 - .048	1.805	.550	.025 - .040	1.815	.523	.010 - .020	1.842	1.531	.040 - .060	1.865	1.134	.075 - .100
1.765	.297	.042 - .060	1.785	1.264	.105 - .125	1.805	1.117	.020 - .040	1.815	.772	.100 - .125	1.842	1.643	.025 - .040	1.865	1.390	.040 - .060
1.765	.308	.042 - .062	1.788	.698	.050 - .075	1.805	1.375	.030 - .040	1.815	.775	.125 - .135	1.843	.316	.015 - .030	1.865	1.502	.025 - .040
1.765	.504	.100 - .125	1.788	1.124	.010 - .015	1.805	1.375	.040 - .060	1.815	1.192	.080 - .100	1.843	.816	.025 - .035	1.867	1.387	.040 - .060
1.765	.630	.008 - .016	1.788	1.425	.075 - .100	<b>1.805</b>	<b>1.398</b>	<b>.005 - .010</b>	1.815	1.523	.015 - .030	<b>1.843</b>	<b>.880</b>	<b>.005 - .010</b>	1.867	1.438	.100 - .125
1.765	.993	.100 - .125	1.788	1.586	.090 - .105	1.805	1.584	.015 - .030	1.818	.631	.020 - .030	1.843	1.188	.020 - .030	1.868	1.063	.040 - .060
1.765	1.005	.010 - .020	1.788	1.587	.050 - .065	1.805	1.591	.070 - .090	1.818	1.065	.015 - .030	1.843	1.188	.030 - .050	1.869	.380	.040 - .060
1.765	1.024	.036 - .060	1.788	1.605	.020 - .040	<b>1.805</b>	<b>1.718</b>	<b>.005 - .010</b>	1.818	1.404	.025 - .040	<b>1.843</b>	<b>1.381</b>	<b>.005 - .010</b>	1.869	.405	.020 - .040
1.765	1.044	.090 - .105	1.789	.761	.080 - .105	1.806	.206	.040 - .050	1.818	1.498	.040 - .060	1.843	1.455	.038 - .060	1.869	.501	.110 - .135
1.765	1.350	.030 - .050	1.789	.761	.105 - .125	<b>1.806</b>	<b>.350</b>	<b>.005 - .010</b>	1.819	.450	.010 - .020	1.843	1.456	.030 - .050	<b>1.869</b>	<b>1.136</b>	<b>.005 - .010</b>
1.765	1.361	.050 - .070	1.790	.620	.015 - .042	1.806	1.344	.015 - .030	1.819	1.580	.005 - .008	1.844	1.098	.050 - .075	1.869	1.277	.050 - .070
1.765	1.382	.062 - .083	1.790	.620	.060 - .090	1.806	1.655	.030 - .050	1.820	.630	.010 - .020	1.844	1.100	.030 - .050	1.869	1.277	.090 - .105
1.766	1.382	.060 - .080	1.790	.620	.090 - .125	1.806	1.690	.030 - .050	<b>1.820</b>	<b>1.013</b>	<b>.005 - .010</b>	<b>1.844</b>	<b>1.624</b>	<b>.005 - .010</b>	1.869	1.283	.090 - .105
<b>1.768</b>	<b>1.232</b>	<b>.005 - .010</b>	1.790	.820	.015 - .025	1.807	.166	.035 - .050	1.820	1.450	.075 - .090	1.845	.140	.040 - .060	1.869	1.438	.050 - .062
1.768	1.380	.030 - .050	1.790	.820	.025 - .042	1.807	.461	.050 - .075	<b>1.820</b>	<b>1.515</b>	<b>.005 - .010</b>	1.845	.391	.050 - .070	1.869	1.567	.025 - .040
<b>1.768</b>	<b>1.382</b>	<b>.005 - .010</b>	1.790	.820	.060 - .090	<b>1.807</b>	<b>1.223</b>	<b>.005 - .010</b>	1.821	1.006	.050 - .075	1.845	.661	.105 - .125	1.870	.080	.020 - .040
1.769	.406	.080 - .104	1.790	.820	.090 - .125	1.807	1.438	.040 - .060	1.822	1.586	.030 - .050	1.845	1.250	.040 - .060	1.870	.500	.100 - .125
1.769	.641	.090 - .120	<b>1.790</b>	<b>1.063</b>	<b>.005 - .010</b>	1.807	1.518	.030 - .040	1.823	.434	.050 - .070	1.845	1.312	.048 - .075	1.870	.505	.100 - .125
1.769	.838	.040 - .060	1.791	1.605	.030 - .050	1.807	1.518	.040 - .060	1.823	1.066	.020 - .040	1.845	1.568	.025 - .035	<b>1.870</b>	<b>.642</b>	<b>.005 - .010</b>
1.769	1.301	.040 - .060	1.792	1.605	.010 - .020	1.808	.690	.030 - .050	1.823	1.135	.010 - .025	<b>1.845</b>	<b>1.569</b>	<b>.005 - .010</b>	1.870	.661	.105 - .125
1.769	1.391	.025 - .040	<b>1.793</b>	<b>.638</b>	<b>.005 - .010</b>	1.808	1.534	.010 - .020	1.823	1.135	.030 - .060	1.846	.792	.080 - .120	1.870	.696	.060 - .080
1.770	.789	.040 - .060	1.793	.999	.010 - .020	1.809	.096	.040 - .060	1.823	1.135	.080 - .100	1.846	1.312	.020 - .030	1.870	.698	.050 - .075
1.770	.810	.030 - .040	1.793	1.499	.020 - .030	1.809	.463	.025 - .040	1.823	1.205	.020 - .030	1.846	1.401	.050 - .070	1.870	.795	.040 - .060
1.770	.827	.030 - .048	1.794	.387	.010 - .020	1.809	1.063	.093 - .113	1.823	1.250	.035 - .050	1.846	1.441	.125 - .156	1.870	.880	.04

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.873	.177	.050 - .070	1.875	1.061	.050 - .070	1.878	.812	.105 - .125	<b>1.898</b>	<b>.754</b>	<b>.005 - .010</b>	1.916	.966	.050 - .070	1.933	1.565	.030 - .050
1.873	.252	.005 - .015	1.875	1.072	.070 - .090	<b>1.878</b>	<b>1.053</b>	<b>.005 - .010</b>	1.898	.910	.050 - .075	1.917	1.258	.125 - .156	1.934	1.002	.030 - .050
1.873	.386	.090 - .125	1.875	1.093	.025 - .040	1.878	1.500	.060 - .080	<b>1.899</b>	<b>.194</b>	<b>.005 - .010</b>	1.918	1.385	.015 - .025	1.934	1.562	.050 - .062
1.873	.625	.100 - .125	1.875	1.113	.080 - .104	1.878	1.505	.010 - .020	1.899	.340	.156 - .190	1.918	1.410	.062 - .083	1.935	.473	.060 - .083
1.873	.750	.100 - .125	1.875	1.135	.050 - .070	<b>1.879</b>	<b>.523</b>	<b>.005 - .010</b>	1.899	.380	.030 - .050	<b>1.918</b>	<b>1.632</b>	<b>.005 - .010</b>	1.935	.473	.060 - .085
1.873	.844	.105 - .135	1.875	1.140	.010 - .025	1.879	1.029	.120 - .135	1.899	.437	.156 - .190	1.919	1.390	.060 - .080	1.935	.500	.060 - .083
1.873	.882	.015 - .030	1.875	1.140	.025 - .042	<b>1.879</b>	<b>1.130</b>	<b>.005 - .010</b>	1.899	.629	.015 - .030	1.919	1.501	.010 - .020	1.935	1.032	.156 - .187
1.873	1.140	.100 - .125	1.875	1.142	.007 - .016	<b>1.879</b>	<b>1.140</b>	<b>.005 - .010</b>	<b>1.899</b>	<b>.630</b>	<b>.005 - .010</b>	1.919	1.595	.060 - .080	<b>1.935</b>	<b>1.190</b>	<b>.005 - .010</b>
1.873	1.260	.065 - .080	<b>1.875</b>	<b>1.152</b>	<b>.005 - .010</b>	1.879	1.255	.070 - .090	1.899	1.015	.040 - .060	1.919	1.754	.015 - .030	1.935	1.309	.105 - .125
1.873	1.349	.030 - .050	1.875	1.156	.032 - .050	1.879	1.431	.060 - .070	1.900	.378	.030 - .050	1.920	.859	.080 - .104	1.935	1.555	.060 - .083
1.873	1.381	.090 - .125	1.875	1.156	.100 - .125	1.879	1.463	.015 - .030	1.900	.378	.050 - .075	1.920	1.000	.070 - .090	1.935	1.656	.010 - .020
1.873	1.386	.100 - .134	1.875	1.171	.100 - .125	1.879	1.501	.015 - .030	<b>1.900</b>	<b>.626</b>	<b>.005 - .010</b>	1.920	1.263	.062 - .083	1.935	1.661	.032 - .048
1.873	1.437	.100 - .125	1.875	1.188	.015 - .030	1.879	1.563	.025 - .040	1.900	.626	.010 - .020	1.920	1.410	.060 - .090	1.935	1.687	.090 - .105
1.873	1.444	.062 - .075	1.875	1.188	.050 - .070	1.879	1.605	.025 - .040	<b>1.900</b>	<b>.630</b>	<b>.005 - .010</b>	1.920	1.411	.090 - .105	1.936	.688	.025 - .040
1.873	1.508	.005 - .012	1.875	1.244	.040 - .062	1.879	1.687	.010 - .020	<b>1.900</b>	<b>.855</b>	<b>.005 - .010</b>	1.920	1.471	.080 - .100	1.936	.780	.060 - .080
1.873	1.508	.010 - .020	1.875	1.250	.020 - .040	1.880	.585	.156 - .187	1.900	.870	.060 - .080	1.920	1.826	.010 - .020	1.936	.818	.005 - .015
<b>1.873</b>	<b>1.533</b>	<b>.005 - .010</b>	<b>1.875</b>	<b>1.254</b>	<b>.005 - .010</b>	1.880	1.131	.025 - .040	1.900	.881	.090 - .125	1.921	.438	.090 - .110	1.936	.818	.020 - .040
<b>1.873</b>	<b>1.639</b>	<b>.005 - .010</b>	1.875	1.258	.030 - .050	1.880	1.193	.015 - .030	1.900	1.002	.075 - .105	1.921	.566	.015 - .030	1.936	.818	.040 - .060
1.873	1.671	.005 - .015	1.875	1.260	.060 - .090	<b>1.880</b>	<b>1.465</b>	<b>.005 - .010</b>	1.900	1.006	.040 - .060	1.921	1.500	.010 - .020	1.936	1.186	.050 - .075
1.873	1.734	.010 - .020	1.875	1.310	.040 - .062	<b>1.880</b>	<b>1.759</b>	<b>.005 - .010</b>	1.900	1.095	.040 - .060	1.921	1.671	.062 - .083	1.936	1.564	.060 - .080
1.874	.219	.100 - .134	1.875	1.310	.040 - .062	1.881	.786	.010 - .025	1.900	1.256	.080 - .104	1.922	.317	.015 - .030	1.936	1.579	.015 - .025
<b>1.874</b>	<b>.252</b>	<b>.005 - .010</b>	1.875	1.355	.070 - .090	1.881	1.204	.015 - .030	1.900	1.320	.040 - .060	1.922	.565	.150 - .170	1.936	1.579	.025 - .042
1.874	.281	.020 - .032	1.875	1.370	.060 - .083	1.881	1.281	.040 - .060	1.900	1.321	.040 - .060	1.922	.972	.080 - .104	1.936	1.656	.050 - .070
1.874	.281	.032 - .050	1.875	1.375	.006 - .013	<b>1.881</b>	<b>1.424</b>	<b>.005 - .010</b>	1.900	1.375	.050 - .075	1.922	1.079	.080 - .104	<b>1.936</b>	<b>1.719</b>	<b>.005 - .010</b>
1.874	.282	.015 - .030	1.875	1.375	.015 - .030	1.882	.887	.060 - .080	1.900	1.500	.006 - .015	1.922	1.176	.080 - .104	<b>1.936</b>	<b>1.740</b>	<b>.005 - .010</b>
1.874	.282	.040 - .060	<b>1.875</b>	<b>1.379</b>	<b>.005 - .010</b>	1.882	.887	.080 - .100	1.900	1.500	.040 - .060	1.922	1.341	.080 - .104	1.937	.651	.105 - .125
1.874	.375	.100 - .125	1.875	1.379	.040 - .050	1.883	1.035	.060 - .080	1.900	1.501	.090 - .105	1.922	1.410	.080 - .104	1.937	1.015	.075 - .090
1.874	.376	.070 - .090	1.875	1.379	.050 - .075	1.883	1.585	.040 - .060	1.900	1.530	.010 - .020	1.923	.390	.015 - .030	1.937	1.021	.156 - .187
1.874	.376	.090 - .105	1.875	1.384	.042 - .062	1.884	1.010	.015 - .030	1.900	1.600	.030 - .050	1.923	.881	.105 - .135	<b>1.937</b>	<b>1.079</b>	<b>.005 - .010</b>
1.874	.376	.105 - .125	1.875	1.386	.030 - .050	1.884	1.010	.030 - .040	1.900	1.628	.030 - .050	1.923	1.181	.025 - .040	1.937	1.157	.020 - .040
1.874	.409	.100 - .120	1.875	1.453	.040 - .060	1.884	1.494	.050 - .075	1.900	1.650	.025 - .040	1.923	1.262	.080 - .104	1.937	1.260	.040 - .062
1.874	.440	.170 - .190	1.875	1.502	.105 - .125	1.884	1.577	.040 - .050	1.900	1.650	.040 - .060	1.923	1.533	.050 - .070	<b>1.937</b>	<b>1.283</b>	<b>.005 - .010</b>
1.874	.625	.015 - .030	1.875	1.503	.015 - .032	1.884	1.585	.030 - .060	1.900	1.651	.080 - .100	1.923	1.714	.010 - .020	1.937	1.284	.015 - .030
1.874	.628	.040 - .060	1.875	1.505	.040 - .062	1.885	.327	.025 - .035	<b>1.900</b>	<b>1.660</b>	<b>.005 - .010</b>	1.924	.315	.015 - .030	1.937	1.399	.030 - .050
1.874	.631	.105 - .125	1.875	1.505	.062 - .083	1.885	.376	.060 - .080	1.901	.626	.025 - .040	1.924	.691	.050 - .070	1.937	1.436	.030 - .050
1.874	.713	.005 - .012	1.875	1.550	.020 - .032	1.885	.956	.062 - .090	1.901	.726	.105 - .125	1.924	.860	.062 - .083	1.937	1.498	.025 - .040
1.874	.822	.050 - .062	1.875	1.550	.032 - .050	1.885	1.060	.042 - .062	1.901	.726	.105 - .125	1.924	.973	.062 - .083	<b>1.937</b>	<b>1.527</b>	<b>.005 - .010</b>
1.874	.875	.110 - .130	1.875	1.568	.060 - .090	1.885	1.136	.060 - .080	1.901	.760	.120 - .140	1.924	1.068	.025 - .040	1.937	1.528	.050 - .075
1.874	.879	.005 - .020	1.875	1.585	.010 - .020	1.885	1.157	.062 - .090	1.901	.781	.105 - .125	1.924	1.080	.062 - .083	1.937	1.657	.010 - .020
<b>1.874</b>	<b>.883</b>	<b>.005 - .010</b>	1.875	1.640	.050 - .070	1.885	1.380	.062 - .090	1.901	1.501	.010 - .020	1.924	1.177	.062 - .083	1.937	1.665	.050 - .070
1.874	.907	.080 - .105	1.875	1.681	.050 - .070	1.886	.985	.100 - .125	<b>1.902</b>	<b>.631</b>	<b>.005 - .010</b>	1.924	1.180	.062 - .083	1.937	1.733	.040 - .060
1.874	.951	.050 - .070	1.875	1.688	.005 - .015	<b>1.886</b>	<b>1.188</b>	<b>.005 - .010</b>	1.902	1.101	.040 - .062	1.924	1.263	.062 - .083	<b>1.937</b>	<b>1.809</b>	<b>.005 - .010</b>
1.874	1.045	.025 - .040	1.875	1.707	.025 - .040	1.886	1.382	.060 - .080	1.902	1.139	.090 - .125	1.924	1.341	.062 - .083	1.938	.319	.015 - .030
1.874	1.180	.030 - .050	1.876	.533	.105 - .125	<b>1.886</b>	<b>1.397</b>	<b>.005 - .010</b>	1.902	1.256	.083 - .104	1.924	1.410	.062 - .083	<b>1.938</b>	<b>1.395</b>	<b>.005 - .010</b>
1.874	1.202	.015 - .025	1.876	.659	.080 - .100	<b>1.886</b>	<b>1.398</b>	<b>.005 - .010</b>	<b>1.902</b>	<b>1.570</b>	<b>.005 - .010</b>	1.925	.328	.030 - .040	1.938	1.468	.030 - .050
1.874	1.257	.070 - .090	1.876	.669	.100 - .125	1.886	1.446	.050 - .075	1.903	.485	.025 - .040	1.925	.564	.010 - .020	1.938	1.502	.025 - .040
1.874	1.282	.010 - .020	1.876	.754	.062 - .083	1.887	1.186	.010 - .020	1.903	.719	.010 - .020	1.925	.573	.015 - .030	<b>1.938</b>	<b>1.758</b>	<b>.005 - .010</b>
1.874	1.282	.050 - .070	1.876	.765	.125 - .156	<b>1.888</b>	<b>.755</b>	<b>.005 - .010</b>	1.903	.719	.105 - .125	1.925	.754	.060 - .080	<b>1.938</b>	<b>1.809</b>	<b>.005 - .010</b>
<b>1.874</b>	<b>1.331</b>	<b>.005 - .010</b>	1.876	1.007	.015 - .032	1.888	.788	.050 - .070	1.903	1.031	.050 - .070	1.925	1.317	.020 - .040	1.939	.126	.030 - .050
1.874	1.450	.150 - .170	1.876	1.129	.015 - .030	1.889	.760	.015 - .030	1.903	1.404	.015 - .025	1.925	1.391	.025 - .040	1.939	1.380	.110 - .130
1.874	1.479	.020 - .030	1.876	1.156	.105 - .135	1.890	.380	.105 - .135	1.904	1.510	.025 - .040	1.925	1.510	.010 - .020	1.940	.880	.065 - .080
1.874	1.595	.030 - .045	1.876	1.257	.105 - .135	<b>1.890</b>	<b>.512</b>	<b>.005 - .010</b>	<b>1.905</b>	<b>1.160</b>	<b>.005 - .010</b>	1.925	1.554	.050 - .075	1.940	1.155	.080 - .100
1.874	1.625	.015 - .030	<b>1.876</b>	<b>1.260</b>	<b>.005 - .010</b>	1.890	1.023	.010 - .025	<b>1.905</b>	<b>1.510</b>	<b>.005 - .010</b>	1.925	1.715	.062 - .083	1.940	1.410	.040 - .060
1.874	1.627	.025 - .040	1.876	1.260	.010 - .025	1.890	1.220	.040 - .062	1.905	1.590	.010 - .030	1.926	1.554	.020 - .040	<b>1.940</b>	<b>1.769</b>	<b>.005 - .010</b>
1.874	1.752	.010 - .020	1.876	1.260	.025 - .040	1.890	1.220	.060 - .090	1.905	1.627	.025 - .040	1.926	1.684	.032 - .060	1.941	1.627	.065 - .080
1.875	.159	.010 - .020	1.876	1.260	.025 - .040	1.890	1.378	.030 - .050	1.905	1.640	.080 - .100	1.926	1.691	.030 - .042	1.941	1.629	.075 - .090
1.875	.204	.100 - .125	1.876	1.380	.010 - .020	<b>1.890</b>	<b>1.384</b>	<b>.005 - .010</b>	1.906	.194	.070 - .090	1.928	.533	.008 - .020	1.942	1.157	.080 - .100
1.875	.250	.050 - .075	1.876	1.381	.015 - .030	1.890	1.389	.010 - .020	1.906	.316	.060 - .080	1.928	1.265	.025 - .040	1.942	1.746	.015 - .030
1.875	.250	.075 - .090	1.876														

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
1.950	1.600	.030 - .050	1.969	1.380	.070 - .090	1.991	.998	.015 - .030	1.998	1.501	.050 - .060	2.000	.619	.015 - .030	2.000	1.380	.135 - .156
1.950	1.820	.025 - .035	1.969	1.440	.010 - .020	1.991	.998	.030 - .050	1.998	1.506	.020 - .030	2.000	.620	.040 - .060	2.000	1.386	.030 - .060
1.951	.504	.110 - .130	1.969	1.468	.010 - .020	1.991	1.325	.020 - .040	1.998	1.635	.010 - .020	2.000	.625	.100 - .125	2.000	1.389	.015 - .030
1.951	1.000	.105 - .135	1.969	1.469	.030 - .050	<b>1.992</b>	<b>.419</b>	<b>.005 - .010</b>	1.998	1.664	.030 - .050	2.000	.626	.015 - .030	2.000	1.389	.060 - .080
1.951	1.201	.030 - .050	1.969	1.469	.050 - .070	1.992	.560	.010 - .020	1.998	1.734	.050 - .070	2.000	.627	.040 - .060	2.000	1.402	.105 - .125
1.952	.812	.040 - .060	1.969	1.470	.105 - .125	1.992	.999	.020 - .030	1.998	1.748	.080 - .100	2.000	.628	.020 - .040	<b>2.000</b>	<b>1.450</b>	<b>.005 - .010</b>
1.952	1.592	.030 - .050	1.969	1.628	.015 - .030	1.992	1.313	.040 - .060	1.998	1.750	.050 - .070	2.000	.632	.010 - .020	<b>2.000</b>	<b>1.499</b>	<b>.005 - .010</b>
1.953	1.375	.040 - .060	1.969	1.657	.050 - .070	1.993	.406	.030 - .040	<b>1.998</b>	<b>1.789</b>	<b>.005 - .010</b>	<b>2.000</b>	<b>.636</b>	<b>.005 - .010</b>	<b>2.000</b>	<b>1.500</b>	<b>.005 - .010</b>
<b>1.953</b>	<b>1.421</b>	<b>.005 - .010</b>	1.970	.413	.105 - .125	1.993	.410	.010 - .015	1.999	.238	.005 - .015	2.000	.644	.090 - .105	2.000	1.500	.100 - .125
1.954	.377	.050 - .075	1.970	.556	.030 - .050	1.993	.474	.030 - .050	1.999	.280	.120 - .135	2.000	.657	.100 - .125	2.000	1.502	.010 - .020
1.954	.421	.050 - .070	1.970	.938	.090 - .110	1.993	.499	.090 - .110	<b>1.999</b>	<b>.310</b>	<b>.005 - .010</b>	2.000	.670	.090 - .125	2.000	1.511	.090 - .125
1.954	1.108	.125 - .156	<b>1.970</b>	<b>1.630</b>	<b>.005 - .010</b>	<b>1.993</b>	<b>.520</b>	<b>.005 - .010</b>	1.999	.313	.050 - .070	2.000	.685	.080 - .105	2.000	1.513	.015 - .030
<b>1.954</b>	<b>1.627</b>	<b>.005 - .010</b>	1.971	1.268	.093 - .125	<b>1.993</b>	<b>1.017</b>	<b>.005 - .010</b>	1.999	.388	.105 - .135	2.000	.692	.090 - .120	2.000	1.515	.030 - .060
1.955	.421	.050 - .070	1.971	1.541	.005 - .015	<b>1.993</b>	<b>1.664</b>	<b>.005 - .010</b>	1.999	.406	.160 - .190	2.000	.752	.010 - .020	<b>2.000</b>	<b>1.536</b>	<b>.005 - .010</b>
1.955	1.004	.140 - .160	1.971	1.541	.015 - .030	<b>1.993</b>	<b>1.933</b>	<b>.005 - .010</b>	1.999	.407	.100 - .125	<b>2.000</b>	<b>.753</b>	<b>.005 - .010</b>	<b>2.000</b>	<b>1.589</b>	<b>.005 - .010</b>
1.955	1.513	.020 - .042	1.972	.379	.015 - .030	<b>1.994</b>	<b>.412</b>	<b>.005 - .010</b>	1.999	.452	.100 - .125	<b>2.000</b>	<b>.758</b>	<b>.005 - .010</b>	2.000	1.626	.105 - .125
1.955	1.519	.080 - .104	1.972	.505	.015 - .030	1.994	.885	.110 - .135	1.999	.484	.070 - .090	2.000	.761	.090 - .110	2.000	1.635	.005 - .015
<b>1.955</b>	<b>1.780</b>	<b>.005 - .010</b>	1.972	.875	.105 - .125	1.994	1.629	.010 - .020	1.999	.515	.156 - .187	<b>2.000</b>	<b>.779</b>	<b>.005 - .010</b>	<b>2.000</b>	<b>1.649</b>	<b>.005 - .010</b>
1.956	.995	.050 - .090	1.972	1.130	.015 - .030	1.994	1.662	.010 - .020	1.999	.562	.100 - .125	2.000	.780	.015 - .030	2.000	1.649	.010 - .020
<b>1.956</b>	<b>1.520</b>	<b>.005 - .010</b>	1.972	1.250	.093 - .125	<b>1.994</b>	<b>1.789</b>	<b>.005 - .010</b>	1.999	.687	.156 - .187	2.000	.781	.005 - .015	<b>2.000</b>	<b>1.654</b>	<b>.005 - .010</b>
1.956	1.564	.010 - .015	1.974	.408	.015 - .030	1.994	1.885	.020 - .040	1.999	.691	.120 - .140	2.000	.781	.040 - .060	2.000	1.654	.080 - .105
1.957	1.415	.030 - .050	<b>1.974</b>	<b>1.170</b>	<b>.005 - .010</b>	<b>1.994</b>	<b>1.933</b>	<b>.005 - .010</b>	1.999	.749	.025 - .040	<b>2.000</b>	<b>.786</b>	<b>.005 - .010</b>	2.000	1.670	.025 - .040
1.960	.754	.120 - .134	<b>1.974</b>	<b>1.284</b>	<b>.005 - .010</b>	<b>1.995</b>	<b>.395</b>	<b>.005 - .010</b>	1.999	.750	.156 - .187	2.000	.797	.020 - .040	<b>2.000</b>	<b>1.695</b>	<b>.005 - .010</b>
1.960	.870	.150 - .170	<b>1.974</b>	<b>1.503</b>	<b>.005 - .010</b>	<b>1.995</b>	<b>.404</b>	<b>.005 - .010</b>	1.999	.753	.020 - .030	2.000	.812	.080 - .105	2.000	1.749	.010 - .020
1.960	1.011	.105 - .120	1.975	.755	.025 - .040	1.995	.453	.060 - .080	1.999	.797	.020 - .040	2.000	.876	.105 - .125	2.000	1.749	.042 - .060
1.960	1.065	.070 - .090	1.975	1.879	.010 - .020	<b>1.995</b>	<b>.634</b>	<b>.005 - .010</b>	1.999	.813	.135 - .156	2.000	.880	.010 - .020	2.000	1.755	.080 - .100
1.960	1.500	.020 - .040	1.976	.759	.030 - .050	1.995	.750	.105 - .125	1.999	.937	.075 - .090	2.000	.906	.015 - .030	2.000	1.780	.015 - .020
1.960	1.584	.010 - .020	1.976	1.289	.040 - .060	1.995	.886	.090 - .120	1.999	.977	.015 - .030	2.000	.906	.030 - .060	2.000	1.780	.025 - .040
1.960	1.619	.020 - .040	1.976	1.673	.030 - .050	1.995	1.000	.030 - .050	1.999	1.000	.030 - .040	2.000	.977	.025 - .040	<b>2.000</b>	<b>1.810</b>	<b>.005 - .010</b>
<b>1.960</b>	<b>1.642</b>	<b>.005 - .010</b>	<b>1.977</b>	<b>1.775</b>	<b>.005 - .010</b>	1.995	1.128	.120 - .135	<b>1.999</b>	<b>1.015</b>	<b>.005 - .010</b>	2.000	.979	.020 - .040	2.000	1.810	.010 - .020
1.961	1.188	.010 - .020	1.977	1.798	.010 - .020	1.995	1.500	.048 - .060	1.999	1.033	.160 - .190	2.000	1.000	.055 - .070	2.000	1.843	.010 - .025
1.961	1.300	.020 - .030	1.978	1.550	.015 - .030	1.995	1.636	.015 - .030	<b>1.999</b>	<b>1.034</b>	<b>.005 - .010</b>	<b>2.000</b>	<b>1.005</b>	<b>.005 - .010</b>	2.001	.198	.010 - .020
1.961	1.312	.050 - .083	1.978	1.694	.020 - .030	1.995	1.663	.020 - .040	1.999	1.289	.025 - .040	2.000	1.006	.083 - .105	2.001	.250	.100 - .125
1.961	1.584	.090 - .125	<b>1.979</b>	<b>1.660</b>	<b>.005 - .010</b>	1.995	1.818	.015 - .030	1.999	1.308	.005 - .020	2.000	1.014	.035 - .060	2.001	.315	.105 - .120
1.962	1.735	.008 - .020	1.979	1.775	.020 - .030	<b>1.996</b>	<b>.381</b>	<b>.005 - .010</b>	1.999	1.504	.025 - .040	2.000	1.015	.050 - .075	2.001	.345	.125 - .135
<b>1.963</b>	<b>.281</b>	<b>.005 - .010</b>	1.980	1.060	.010 - .020	<b>1.996</b>	<b>.647</b>	<b>.005 - .010</b>	<b>1.999</b>	<b>1.560</b>	<b>.005 - .010</b>	2.000	1.020	.015 - .030	2.001	.375	.105 - .125
<b>1.963</b>	<b>.481</b>	<b>.005 - .010</b>	1.980	1.478	.050 - .070	<b>1.996</b>	<b>.768</b>	<b>.005 - .010</b>	1.999	1.685	.020 - .030	2.000	1.030	.010 - .025	<b>2.001</b>	<b>.447</b>	<b>.005 - .010</b>
1.963	1.565	.025 - .040	1.980	1.500	.050 - .070	<b>1.996</b>	<b>.821</b>	<b>.005 - .010</b>	1.999	1.692	.030 - .040	2.000	1.030	.100 - .125	2.001	.499	.170 - .190
1.964	.281	.015 - .030	<b>1.980</b>	<b>1.546</b>	<b>.005 - .010</b>	1.996	1.120	.135 - .156	2.000	1.031	.050 - .070	2.000	1.031	.050 - .070	2.001	.501	.015 - .030
1.964	1.576	.015 - .025	<b>1.980</b>	<b>1.778</b>	<b>.005 - .010</b>	<b>1.996</b>	<b>1.404</b>	<b>.005 - .010</b>	2.000	1.062	.100 - .125	2.000	1.062	.100 - .125	2.001	.592	.120 - .135
<b>1.964</b>	<b>1.579</b>	<b>.005 - .010</b>	1.981	.831	.156 - .187	1.996	1.504	.010 - .020	2.000	1.064	.100 - .125	<b>2.001</b>	<b>.750</b>	<b>.005 - .010</b>	<b>2.001</b>	<b>.755</b>	<b>.005 - .010</b>
1.964	1.579	.020 - .040	1.981	1.519	.040 - .060	<b>1.996</b>	<b>1.666</b>	<b>.005 - .010</b>	2.000	1.075	.015 - .030	<b>2.001</b>	<b>1.090</b>	<b>.005 - .010</b>	<b>2.001</b>	<b>.813</b>	<b>.005 - .010</b>
1.964	1.756	.020 - .030	<b>1.981</b>	<b>1.736</b>	<b>.005 - .010</b>	1.996	1.751	.050 - .070	2.000	1.108	.040 - .060	2.000	1.108	.040 - .060	2.001	.814	.060 - .080
1.964	1.790	.012 - .020	1.982	1.609	.083 - .104	1.996	1.850	.010 - .020	2.000	1.125	.015 - .030	2.000	1.125	.015 - .030	2.001	.942	.105 - .135
<b>1.965</b>	<b>.281</b>	<b>.005 - .010</b>	1.983	.515	.030 - .050	1.997	.407	.050 - .070	2.000	.160	.005 - .015	2.000	1.125	.048 - .062	2.001	1.020	.015 - .030
1.965	.815	.060 - .080	1.983	1.628	.020 - .040	1.997	.500	.105 - .125	2.000	.165	.050 - .070	2.000	1.131	.030 - .062	2.001	1.105	.080 - .104
1.965	1.427	.030 - .050	<b>1.984</b>	<b>.229</b>	<b>.005 - .010</b>	<b>1.997</b>	<b>.561</b>	<b>.005 - .010</b>	<b>2.000</b>	<b>.180</b>	<b>.005 - .010</b>	2.000	1.158	.025 - .042	2.001	1.155	.105 - .125
1.965	1.491	.015 - .030	<b>1.984</b>	<b>.395</b>	<b>.005 - .010</b>	<b>1.997</b>	<b>.700</b>	<b>.005 - .010</b>	2.000	.194	.036 - .050	2.000	1.165	.020 - .040	2.001	1.282	.105 - .125
1.965	1.498	.048 - .062	1.984	.395	.160 - .190	1.997	.720	.020 - .035	2.000	.205	.093 - .125	<b>2.000</b>	<b>1.166</b>	<b>.005 - .010</b>	2.001	1.312	.050 - .070
<b>1.965</b>	<b>1.503</b>	<b>.005 - .010</b>	1.984	1.544	.005 - .015	1.997	.766	.010 - .020	2.000	.210	.105 - .135	2.000	1.190	.080 - .104	2.001	1.397	.015 - .025
1.965	1.860	.007 - .015	1.985	1.398	.010 - .030	<b>1.997</b>	<b>.913</b>	<b>.005 - .010</b>	2.000	.250	.025 - .040	2.000	1.190	.160 - .187	<b>2.001</b>	<b>1.505</b>	<b>.005 - .010</b>
1.965	1.860	.015 - .030	1.985	1.590	.010 - .020	1.997	1.021	.030 - .050	2.000	.250	.090 - .125	<b>2.000</b>	<b>1.199</b>	<b>.005 - .010</b>	2.001	1.583	.025 - .040
<b>1.966</b>	<b>1.006</b>	<b>.005 - .010</b>	1.985	1.695	.040 - .060	1.997	1.061	.050 - .075	2.000	.255	.030 - .060	2.000	1.208	.050 - .075	2.001	1.602	.030 - .050
1.967	.394	.080 - .100	<b>1.986</b>	<b>.540</b>	<b>.005 - .010</b>	<b>1.997</b>	<b>1.071</b>	<b>.005 - .010</b>	2.000	.261	.060 - .080	<b>2.000</b>	<b>1.217</b>	<b>.005 - .010</b>	<b>2.002</b>	<b>.101</b>	<b>.005 - .010</b>
1.967	.502	.010 - .020	1.987	.671	.100 - .120	<b>1.997</b>	<b>1.254</b>	<b>.005 - .010</b>	2.000	.266	.040 - .060	2.000	1.220	.035 - .060	2.002	.380	.090 - .134
1.967	1.113	.025 - .040	1.987	.888	.050 - .070	<b>1.997</b>	<b>1.414</b>	<b>.005 - .010</b>	2.000	.270	.080 - .100	2.000	1.248	.156 - .187	2.002	.437	.050 - .075
<b>1.967</b>	<b>1.519</b>	<b>.005 - .010</b>	1.988	.880	.050 - .070	1.997	1.503	.080 - .									

**NO TOOLING CHARGE FOR ANY OF THE SIZES LISTED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
2.004	1.131	.010 - .020	2.045	.724	.020 - .030	2.066	1.718	.030 - .050	2.119	1.061	.075 - .090	2.127	1.673	.040 - .060	2.156	.877	.110 - .130
2.005	.204	.080 - .104	2.045	.724	.030 - .050	2.070	1.180	.080 - .104	<b>2.119</b>	<b>1.503</b>	<b>.005 - .010</b>	2.128	1.122	.050 - .075	2.156	2.006	.015 - .030
2.005	1.260	.025 - .040	2.045	1.344	.040 - .060	2.070	1.530	.020 - .030	<b>2.119</b>	<b>1.512</b>	<b>.005 - .010</b>	2.128	1.374	.060 - .080	2.157	.344	.050 - .075
2.005	1.515	.010 - .020	<b>2.045</b>	<b>1.703</b>	<b>.005 - .010</b>	2.071	1.749	.010 - .020	2.119	1.587	.050 - .070	2.128	1.505	.050 - .070	<b>2.157</b>	<b>.350</b>	<b>.005 - .010</b>
2.006	1.280	.105 - .125	2.045	1.730	.010 - .020	2.072	1.277	.015 - .030	2.120	.628	.050 - .075	<b>2.128</b>	<b>1.626</b>	<b>.005 - .010</b>	2.157	.629	.120 - .135
<b>2.006</b>	<b>1.775</b>	<b>.005 - .010</b>	<b>2.045</b>	<b>1.881</b>	<b>.005 - .010</b>	2.075	1.969	.030 - .050	2.120	.810	.015 - .030	<b>2.128</b>	<b>1.668</b>	<b>.005 - .010</b>	<b>2.157</b>	<b>1.253</b>	<b>.005 - .010</b>
2.007	1.533	.040 - .060	2.046	1.611	.070 - .090	2.076	1.629	.050 - .070	2.120	.875	.040 - .062	2.129	.251	.050 - .070	2.157	1.344	.050 - .075
2.008	.765	.105 - .125	2.047	.551	.060 - .080	2.077	1.155	.080 - .104	2.120	.927	.156 - .187	2.129	.533	.105 - .135	2.157	1.427	.040 - .050
<b>2.008</b>	<b>1.319</b>	<b>.005 - .010</b>	2.047	.747	.015 - .030	2.077	1.380	.080 - .104	2.120	1.014	.015 - .030	2.129	.735	.020 - .040	2.157	2.006	.010 - .020
2.008	1.392	.005 - .012	2.047	.807	.070 - .090	2.077	1.639	.030 - .050	2.120	1.187	.015 - .025	2.129	1.282	.050 - .070	2.158	1.060	.075 - .090
2.008	1.676	.070 - .090	2.047	.828	.025 - .040	2.077	1.719	.030 - .050	2.120	1.305	.030 - .050	2.129	1.500	.010 - .020	2.158	1.063	.080 - .120
2.009	.239	.040 - .060	2.047	.965	.025 - .040	2.078	1.691	.050 - .060	2.120	1.506	.050 - .070	2.129	1.524	.100 - .125	<b>2.158</b>	<b>1.469</b>	<b>.005 - .010</b>
2.009	1.783	.070 - .090	<b>2.047</b>	<b>1.274</b>	<b>.005 - .010</b>	2.079	1.750	.060 - .080	2.120	1.615	.050 - .075	2.130	.293	.050 - .070	2.158	1.564	.080 - .120
2.009	1.804	.030 - .050	2.047	1.773	.015 - .030	2.080	.834	.070 - .090	2.120	1.785	.050 - .075	2.130	.532	.134 - .156	2.158	1.727	.030 - .050
2.013	1.003	.015 - .030	2.047	1.811	.025 - .040	2.080	1.600	.005 - .015	2.120	1.811	.080 - .105	2.130	.549	.040 - .060	2.159	.386	.010 - .020
2.013	1.502	.020 - .040	<b>2.048</b>	<b>.296</b>	<b>.005 - .010</b>	2.080	1.600	.020 - .040	2.120	1.819	.025 - .040	2.130	.860	.100 - .125	2.159	1.690	.025 - .040
<b>2.013</b>	<b>1.658</b>	<b>.005 - .010</b>	<b>2.048</b>	<b>.626</b>	<b>.005 - .010</b>	2.080	1.719	.030 - .040	2.121	1.903	.010 - .020	2.130	1.030	.015 - .030	2.160	1.127	.020 - .030
<b>2.016</b>	<b>1.687</b>	<b>.005 - .010</b>	2.048	1.378	.030 - .050	2.081	.820	.042 - .060	2.122	1.507	.020 - .030	<b>2.130</b>	<b>1.057</b>	<b>.005 - .010</b>	2.160	1.400	.040 - .060
2.018	1.510	.030 - .050	2.048	1.393	.070 - .090	2.081	1.060	.010 - .020	<b>2.122</b>	<b>1.877</b>	<b>.005 - .010</b>	<b>2.130</b>	<b>1.762</b>	<b>.005 - .010</b>	2.160	1.400	.105 - .125
2.019	.502	.030 - .050	2.048	1.748	.020 - .040	<b>2.082</b>	<b>1.883</b>	<b>.005 - .010</b>	2.122	1.878	.020 - .040	2.130	1.869	.025 - .040	2.162	.668	.020 - .030
2.019	.508	.050 - .070	<b>2.049</b>	<b>1.854</b>	<b>.005 - .010</b>	2.082	1.942	.020 - .030	2.123	.906	.090 - .125	2.130	1.871	.010 - .020	2.162	.756	.025 - .040
2.019	1.623	.015 - .030	2.050	.140	.060 - .080	<b>2.083</b>	<b>1.440</b>	<b>.005 - .010</b>	2.123	1.008	.050 - .070	2.131	1.658	.015 - .030	2.162	.857	.020 - .030
2.020	.280	.100 - .125	<b>2.050</b>	<b>.506</b>	<b>.005 - .010</b>	2.085	1.429	.040 - .060	2.123	1.645	.105 - .125	2.131	1.878	.080 - .105	2.162	1.512	.080 - .105
2.020	1.551	.080 - .100	2.050	.626	.010 - .020	2.085	1.801	.025 - .040	2.123	1.659	.105 - .125	2.131	2.031	.030 - .050	2.162	1.724	.134 - .160
<b>2.021</b>	<b>1.014</b>	<b>.005 - .010</b>	2.050	.627	.010 - .020	2.086	.787	.020 - .035	<b>2.123</b>	<b>1.811</b>	<b>.005 - .010</b>	2.132	.250	.090 - .110	2.162	1.760	.032 - .050
2.022	1.184	.010 - .020	<b>2.050</b>	<b>.630</b>	<b>.005 - .010</b>	2.089	1.508	.050 - .070	2.124	.312	.080 - .100	2.132	1.190	.060 - .080	2.163	.252	.030 - .050
2.024	.810	.030 - .050	2.050	.630	.010 - .020	2.090	.815	.070 - .090	2.124	1.127	.015 - .030	2.134	1.729	.060 - .080	<b>2.163</b>	<b>.678</b>	<b>.005 - .010</b>
<b>2.029</b>	<b>1.222</b>	<b>.005 - .010</b>	2.050	1.425	.030 - .050	2.090	.941	.110 - .135	2.124	1.250	.010 - .020	2.134	1.752	.005 - .012	2.163	1.929	.060 - .080
2.029	1.626	.050 - .070	2.050	1.660	.075 - .090	2.093	.223	.100 - .125	2.124	1.580	.040 - .060	2.134	1.898	.020 - .040	<b>2.163</b>	<b>2.028</b>	<b>.005 - .010</b>
<b>2.029</b>	<b>1.755</b>	<b>.005 - .010</b>	2.050	1.708	.040 - .060	2.093	1.001	.060 - .080	2.124	1.815	.070 - .090	2.135	1.120	.100 - .120	2.164	1.801	.025 - .040
2.030	.936	.050 - .070	2.052	.626	.025 - .040	2.095	.473	.080 - .100	2.125	.346	.050 - .075	2.136	1.578	.060 - .080	2.164	1.898	.070 - .090
2.030	1.060	.050 - .070	2.054	1.274	.010 - .020	2.095	.688	.105 - .135	2.125	.380	.100 - .125	<b>2.137</b>	<b>1.969</b>	<b>.005 - .010</b>	2.164	1.908	.050 - .070
2.030	1.184	.050 - .070	2.054	1.384	.025 - .040	2.095	.875	.105 - .135	2.125	.500	.080 - .100	<b>2.138</b>	<b>1.897</b>	<b>.005 - .010</b>	<b>2.165</b>	<b>.254</b>	<b>.005 - .010</b>
2.030	1.310	.050 - .070	2.054	1.632	.015 - .030	<b>2.095</b>	<b>1.890</b>	<b>.005 - .010</b>	<b>2.125</b>	<b>.507</b>	<b>.005 - .010</b>	2.138	1.968	.025 - .040	2.165	.323	.030 - .050
2.030	1.434	.050 - .070	<b>2.055</b>	<b>1.570</b>	<b>.005 - .010</b>	<b>2.095</b>	<b>1.946</b>	<b>.005 - .010</b>	2.125	.562	.100 - .125	2.139	1.417	.080 - .104	2.165	.670	.105 - .135
<b>2.030</b>	<b>1.500</b>	<b>.005 - .010</b>	2.056	.528	.048 - .062	2.096	1.186	.015 - .030	2.125	.565	.010 - .020	<b>2.139</b>	<b>1.454</b>	<b>.005 - .010</b>	2.165	1.506	.050 - .070
2.030	1.715	.016 - .030	2.057	.390	.040 - .060	2.097	1.013	.110 - .125	2.125	.626	.015 - .030	<b>2.139</b>	<b>1.818</b>	<b>.005 - .010</b>	2.165	1.660	.080 - .100
<b>2.031</b>	<b>.936</b>	<b>.005 - .010</b>	2.058	.482	.048 - .062	2.098	.253	.025 - .040	2.125	.655	.075 - .100	2.139	1.821	.025 - .040	2.165	1.701	.030 - .050
<b>2.031</b>	<b>1.755</b>	<b>.005 - .010</b>	2.058	.630	.105 - .135	2.098	.760	.015 - .030	2.125	.695	.090 - .105	2.140	1.730	.025 - .040	<b>2.165</b>	<b>1.800</b>	<b>.005 - .010</b>
2.031	1.755	.015 - .030	2.058	1.010	.010 - .020	2.098	1.635	.010 - .020	<b>2.125</b>	<b>.705</b>	<b>.005 - .010</b>	2.140	2.012	.040 - .060	2.166	1.216	.050 - .070
<b>2.031</b>	<b>2.090</b>	<b>.005 - .010</b>	2.058	1.196	.050 - .070	<b>2.099</b>	<b>1.638</b>	<b>.005 - .010</b>	2.125	.761	.060 - .090	2.142	1.545	.030 - .050	2.166	1.594	.060 - .090
<b>2.032</b>	<b>.489</b>	<b>.005 - .010</b>	2.058	1.515	.020 - .040	2.100	.753	.025 - .040	2.125	.813	.110 - .135	<b>2.142</b>	<b>1.941</b>	<b>.005 - .010</b>	2.167	1.408	.070 - .090
<b>2.032</b>	<b>.880</b>	<b>.005 - .010</b>	2.059	.402	.030 - .060	2.100	.794	.010 - .020	<b>2.125</b>	<b>.895</b>	<b>.005 - .010</b>	<b>2.142</b>	<b>2.003</b>	<b>.005 - .010</b>	<b>2.167</b>	<b>1.718</b>	<b>.005 - .010</b>
2.033	.877	.025 - .040	2.059	1.671	.030 - .060	2.100	1.406	.050 - .070	2.125	.907	.020 - .030	<b>2.143</b>	<b>1.621</b>	<b>.005 - .010</b>	2.167	1.772	.070 - .090
2.033	1.525	.010 - .030	2.059	1.750	.050 - .075	2.100	1.640	.005 - .015	2.125	1.075	.010 - .020	2.143	1.730	.020 - .040	2.169	.720	.020 - .030
2.033	1.562	.020 - .030	<b>2.059</b>	<b>1.759</b>	<b>.005 - .010</b>	2.100	1.656	.105 - .125	2.125	1.123	.060 - .080	2.143	1.791	.010 - .020	2.170	1.520	.015 - .030
2.033	1.745	.010 - .020	2.060	.221	.050 - .075	2.100	1.900	.050 - .075	2.125	1.251	.050 - .075	<b>2.144</b>	<b>1.890</b>	<b>.005 - .010</b>	<b>2.170</b>	<b>1.556</b>	<b>.005 - .010</b>
2.033	1.845	.040 - .060	<b>2.060</b>	<b>.254</b>	<b>.005 - .010</b>	<b>2.100</b>	<b>1.933</b>	<b>.005 - .010</b>	2.125	1.260	.075 - .090	<b>2.145</b>	<b>.845</b>	<b>.005 - .010</b>	2.171	1.900	.010 - .020
2.034	1.574	.020 - .040	2.060	.254	.110 - .130	2.101	.564	.010 - .020	2.125	1.308	.025 - .050	<b>2.145</b>	<b>1.730</b>	<b>.005 - .010</b>	<b>2.171</b>	<b>1.969</b>	<b>.005 - .010</b>
2.035	.423	.030 - .050	<b>2.060</b>	<b>.312</b>	<b>.010 - .010</b>	2.101	1.731	.025 - .040	2.125	1.339	.080 - .105	<b>2.145</b>	<b>1.967</b>	<b>.005 - .010</b>	2.172	1.760	.020 - .030
2.035	.788	.105 - .125	<b>2.060</b>	<b>.390</b>	<b>.005 - .010</b>	2.102	.792	.030 - .040	2.125	1.376	.015 - .030	2.146	1.645	.070 - .090	<b>2.173</b>	<b>1.393</b>	<b>.005 - .010</b>
2.035	1.002	.090 - .110	<b>2.060</b>	<b>.443</b>	<b>.005 - .010</b>	2.103	1.781	.010 - .020	2.125	1.408	.030 - .050	2.146	1.654	.075 - .090	<b>2.173</b>	<b>1.709</b>	<b>.005 - .010</b>
2.035	1.690	.040 - .060	2.060	.530	.050 - .075	2.104	1.680	.040 - .060	2.125	1.439	.015 - .030	<b>2.146</b>	<b>1.743</b>	<b>.005 - .010</b>	2.176	.942	.050 - .070
2.035	1.750	.050 - .075	2.060	.800	.025 - .036	2.106	1.808	.015 - .030	2.125	1.500	.015 - .032	2.146	1.743	.010 - .020	2.176	2.068	.010 - .020
2.035	1.834	.025 - .042	2.060	.890	.080 - .104	2.106	1.814	.050 - .075	2.125	1.500	.080 - .104	2.147	1.671	.030 - .050	2.177	2.051	.040 - .060
2.036	1.557	.040 - .062	2.060	1.141	.040 - .060	2.108	1.801	.075 - .090	<b>2.125</b>	<b>1.507</b>	<b>.005 - .010</b>	2.148	.626	.015 - .030	2.178	.362	.050 - .070
<b>2.037</b>	<b>1.588</b>	<b>.005 - .010</b>	2.060	1.438	.030 - .050	2.109	1.726	.025 - .040	2.125	1.507	.040 - .060	2.148					

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
2.191	1.892	.060 - .080	2.232	1.764	.010 - .030	2.248	2.002	.080 - .100	2.250	1.563	.050 - .075	2.273	1.910	.010 - .020	<b>2.321</b>	<b>2.053</b>	<b>.005 - .010</b>
2.191	2.005	.015 - .030	2.233	1.845	.010 - .020	2.249	.316	.050 - .070	2.250	1.563	.080 - .104	2.273	1.968	.005 - .012	2.322	.192	.015 - .030
2.192	1.636	.040 - .062	2.234	1.250	.015 - .025	2.249	.438	.156 - .187	2.250	1.598	.030 - .050	2.273	1.968	.012 - .020	2.322	2.000	.015 - .030
2.192	1.754	.030 - .040	<b>2.235</b>	<b>1.034</b>	<b>.005 - .010</b>	2.249	.439	.104 - .120	2.250	1.615	.015 - .030	2.275	.881	.025 - .040	2.323	.311	.015 - .030
2.193	.972	.025 - .042	2.235	1.499	.050 - .070	2.249	.540	.015 - .030	2.250	1.620	.040 - .060	2.277	1.184	.060 - .080	2.323	1.948	.070 - .090
2.193	2.006	.010 - .020	2.235	1.950	.040 - .060	2.249	.542	.150 - .170	2.250	1.628	.110 - .130	2.278	1.674	.105 - .135	2.323	2.165	.050 - .070
2.196	1.698	.010 - .020	2.236	1.562	.070 - .090	<b>2.249</b>	<b>.752</b>	<b>.005 - .010</b>	2.250	1.631	.005 - .020	2.278	1.868	.050 - .070	2.324	1.253	.025 - .040
<b>2.196</b>	<b>1.702</b>	<b>.005 - .010</b>	2.238	1.427	.025 - .040	<b>2.249</b>	<b>.756</b>	<b>.005 - .010</b>	2.250	1.668	.020 - .040	2.278	1.919	.040 - .060	2.325	1.851	.050 - .070
<b>2.196</b>	<b>1.982</b>	<b>.005 - .010</b>	2.239	.875	.100 - .125	2.249	.800	.080 - .100	2.250	1.668	.050 - .075	2.278	1.990	.050 - .070	2.325	2.008	.015 - .030
2.197	1.650	.040 - .060	2.239	1.020	.156 - .188	<b>2.249</b>	<b>1.217</b>	<b>.005 - .010</b>	2.250	1.687	.025 - .040	2.279	.313	.030 - .050	2.325	2.008	.040 - .060
2.198	1.047	.040 - .060	2.239	1.260	.050 - .060	2.249	1.640	.005 - .020	2.250	1.751	.005 - .020	2.279	1.746	.020 - .030	<b>2.325</b>	<b>2.062</b>	<b>.005 - .010</b>
2.198	1.126	.040 - .060	2.239	1.773	.050 - .070	2.249	1.711	.040 - .060	2.250	1.768	.050 - .075	2.280	1.070	.040 - .060	2.328	.500	.120 - .135
<b>2.198</b>	<b>2.047</b>	<b>.005 - .010</b>	2.240	.782	.156 - .188				2.250	1.781	.050 - .070	2.280	1.150	.025 - .040	2.328	1.199	.030 - .050
<b>2.199</b>	<b>.250</b>	<b>.005 - .010</b>	2.240	1.200	.016 - .032				2.250	1.801	.100 - .134	2.280	2.032	.050 - .070	<b>2.328</b>	<b>2.006</b>	<b>.005 - .010</b>
2.199	.629	.015 - .030	2.240	1.384	.080 - .105				2.250	1.844	.040 - .075	2.282	1.771	.050 - .070	<b>2.330</b>	<b>1.200</b>	<b>.005 - .010</b>
2.199	.706	.050 - .070	2.240	1.440	.105 - .135				2.250	1.875	.050 - .075	2.283	.334	.060 - .080	2.331	1.627	.090 - .110
<b>2.199</b>	<b>.840</b>	<b>.005 - .010</b>	2.240	1.631	.015 - .030	<b>2.250</b>	<b>2.250</b>	<b>.005 - .010</b>	2.250	1.912	.070 - .090	2.284	2.043	.040 - .060	2.334	2.164	.025 - .040
2.200	.360	.050 - .070	2.240	1.762	.040 - .060				2.250	1.969	.010 - .015	2.284	2.070	.030 - .040	2.335	1.968	.050 - .070
<b>2.200</b>	<b>1.010</b>	<b>.005 - .010</b>	<b>2.240</b>	<b>2.010</b>	<b>.005 - .010</b>				2.250	2.025	.020 - .040	2.285	.768	.075 - .090	2.335	1.995	.020 - .030
2.200	1.010	.040 - .060	2.240	2.010	.010 - .020				<b>2.251</b>	<b>.266</b>	<b>.005 - .010</b>	<b>2.285</b>	<b>2.070</b>	<b>.005 - .010</b>	2.338	1.636	.020 - .040
2.200	1.378	.105 - .125	2.240	2.010	.025 - .040	2.250	.125	.050 - .070	2.251	.378	.025 - .040	2.287	.770	.080 - .104	2.339	.430	.060 - .080
2.200	1.519	.030 - .050	<b>2.240</b>	<b>2.025</b>	<b>.005 - .010</b>	2.250	.136	.015 - .025	2.251	.540	.134 - .156	2.290	1.125	.105 - .134	2.342	1.770	.075 - .090
2.200	1.599	.048 - .075	2.241	.880	.030 - .050	2.250	.164	.010 - .020	2.251	.579	.090 - .105	2.290	2.160	.020 - .040	2.342	2.001	.050 - .070
2.200	1.700	.048 - .075	2.241	1.578	.100 - .125	2.250	.216	.060 - .080	<b>2.251</b>	<b>.812</b>	<b>.005 - .010</b>	2.291	1.630	.030 - .050	<b>2.343</b>	<b>1.773</b>	<b>.005 - .010</b>
2.200	1.800	.105 - .120	<b>2.242</b>	<b>1.565</b>	<b>.005 - .010</b>	2.250	.325	.075 - .104	2.251	.905	.030 - .050	2.295	1.857	.030 - .050	2.345	.718	.090 - .105
2.200	1.884	.030 - .050	2.242	1.726	.080 - .105	2.250	.370	.050 - .070	2.251	1.083	.120 - .140	2.295	2.052	.025 - .040	2.346	2.074	.030 - .050
<b>2.201</b>	<b>.505</b>	<b>.005 - .010</b>	2.242	1.761	.050 - .070	2.250	.378	.050 - .070	2.251	1.377	.040 - .060	2.296	.187	.025 - .040	2.347	1.437	.050 - .070
2.201	.505	.010 - .020	2.242	1.844	.080 - .105	2.250	.394	.030 - .050	2.251	1.501	.030 - .050	2.296	.501	.015 - .025	<b>2.347</b>	<b>2.110</b>	<b>.005 - .010</b>
<b>2.201</b>	<b>.755</b>	<b>.005 - .010</b>	2.243	.762	.030 - .050	2.250	.400	.100 - .125	2.251	1.519	.025 - .040	2.296	2.068	.025 - .040	2.348	.747	.050 - .070
2.201	1.520	.040 - .060	2.243	1.009	.060 - .080	2.250	.439	.100 - .125	<b>2.251</b>	<b>1.538</b>	<b>.005 - .010</b>	<b>2.297</b>	<b>1.960</b>	<b>.005 - .010</b>	2.348	.783	.075 - .090
2.201	2.010	.010 - .020	2.243	1.551	.010 - .020	2.250	.478	.030 - .050	2.251	1.563	.030 - .040	2.298	.402	.105 - .125	2.348	1.380	.060 - .080
<b>2.201</b>	<b>2.039</b>	<b>.005 - .010</b>	2.244	1.857	.015 - .030	2.250	.500	.105 - .120	2.251	2.025	.105 - .135	<b>2.300</b>	<b>.196</b>	<b>.005 - .010</b>	2.348	2.000	.042 - .062
2.202	.752	.015 - .030	<b>2.245</b>	<b>.330</b>	<b>.005 - .010</b>	2.250	.507	.030 - .050	2.252	.377	.025 - .040	<b>2.300</b>	<b>.628</b>	<b>.005 - .010</b>	2.348	2.067	.015 - .030
<b>2.202</b>	<b>1.887</b>	<b>.005 - .010</b>	<b>2.245</b>	<b>.633</b>	<b>.005 - .010</b>	<b>2.250</b>	<b>.517</b>	<b>.005 - .010</b>	2.252	.758	.040 - .060	2.300	1.314	.105 - .135	2.349	.502	.100 - .120
2.203	.255	.100 - .125	2.245	.886	.105 - .125	2.250	.517	.090 - .110	2.252	.781	.090 - .120	2.300	1.654	.050 - .070	2.349	1.494	.025 - .040
2.203	1.026	.010 - .020	<b>2.245</b>	<b>1.192</b>	<b>.005 - .010</b>	2.250	.519	.170 - .190	2.252	1.000	.040 - .060	<b>2.301</b>	<b>.625</b>	<b>.005 - .010</b>	2.349	2.005	.060 - .090
2.203	1.582	.050 - .075	2.245	1.259	.090 - .105	2.250	.562	.135 - .156	<b>2.252</b>	<b>1.032</b>	<b>.005 - .010</b>	2.301	1.480	.050 - .075	2.350	1.267	.050 - .070
2.203	1.884	.030 - .050	2.245	1.319	.025 - .040	2.250	.620	.030 - .050	2.252	1.253	.050 - .070	2.302	1.620	.050 - .070	<b>2.350</b>	<b>1.815</b>	<b>.005 - .010</b>
2.205	1.122	.050 - .070	2.245	1.343	.025 - .042	2.250	.626	.015 - .030	2.252	1.511	.050 - .075	<b>2.303</b>	<b>2.000</b>	<b>.005 - .010</b>	2.351	.270	.080 - .100
2.205	1.912	.070 - .090	2.245	1.375	.080 - .105	2.250	.629	.040 - .060	<b>2.252</b>	<b>1.656</b>	<b>.005 - .010</b>	2.304	1.905	.100 - .120	2.351	1.659	.010 - .020
<b>2.206</b>	<b>1.791</b>	<b>.005 - .010</b>	2.245	1.380	.030 - .050	2.250	.639	.015 - .030	<b>2.252</b>	<b>1.887</b>	<b>.005 - .010</b>	2.305	1.498	.008 - .016	<b>2.352</b>	<b>1.660</b>	<b>.005 - .010</b>
2.206	1.980	.050 - .100	2.245	1.395	.010 - .020	2.250	.641	.125 - .156	2.252	1.979	.080 - .105	2.305	1.681	.050 - .075	2.354	2.100	.010 - .020
2.210	1.015	.050 - .060	2.245	1.417	.080 - .104	2.250	.643	.135 - .156	2.253	.188	.025 - .040	2.306	1.899	.048 - .062	2.355	2.217	.010 - .020
2.210	1.215	.090 - .125	2.245	1.417	.105 - .125	2.250	.662	.140 - .160	2.253	.252	.025 - .040	2.307	1.199	.030 - .050	2.356	.815	.080 - .105
2.210	1.625	.040 - .070	2.245	1.738	.110 - .130	2.250	.688	.104 - .125	2.253	.517	.105 - .125	2.307	1.893	.110 - .130	2.358	1.095	.025 - .040
2.210	1.625	.090 - .125	2.245	2.007	.010 - .015	2.250	.750	.075 - .104	2.253	.642	.120 - .135	2.308	2.208	.005 - .015	2.358	1.542	.030 - .050
2.211	.127	.040 - .060	2.246	.378	.080 - .100	2.250	.771	.060 - .080	<b>2.253</b>	<b>.780</b>	<b>.005 - .010</b>	2.310	.890	.030 - .050	2.358	1.932	.135 - .156
2.211	1.933	.010 - .020	2.246	.627	.025 - .040	2.250	.781	.100 - .134	2.253	1.011	.030 - .050	2.310	1.136	.080 - .105	2.358	2.130	.010 - .020
2.215	.880	.050 - .075	2.246	.631	.156 - .179	2.250	.790	.040 - .060	2.253	1.063	.120 - .156	<b>2.310</b>	<b>1.636</b>	<b>.005 - .010</b>	2.360	.438	.070 - .090
<b>2.215</b>	<b>.916</b>	<b>.005 - .010</b>	2.246	1.048	.050 - .070	2.250	.795	.050 - .070	2.253	1.145	.120 - .134	<b>2.310</b>	<b>1.693</b>	<b>.005 - .010</b>	2.360	.728	.050 - .070
2.215	.933	.040 - .060	2.246	1.058	.050 - .070	2.250	.874	.060 - .080	2.253	1.751	.105 - .135	2.310	1.873	.070 - .090	2.360	1.133	.160 - .190
2.215	1.153	.060 - .090	2.246	1.064	.025 - .040	2.250	.877	.070 - .090	2.253	1.752	.050 - .070	2.310	1.997	.010 - .025	<b>2.360</b>	<b>1.262</b>	<b>.005 - .010</b>
2.215	1.434	.075 - .100	2.246	1.813	.050 - .075	<b>2.250</b>	<b>.880</b>	<b>.005 - .010</b>	2.253	1.973	.050 - .070	2.311	.312	.030 - .050	2.360	1.375	.015 - .030
2.215	1.976	.010 - .020	2.247	.538	.010 - .0												

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
2.368	2.069	.005 - .010	2.376	1.875	.040 - .060	2.405	.993	.080 - .104	2.448	2.089	.005 - .010	2.497	.813	.045 - .060	2.500	.951	.040 - .060
2.369	.245	.010 - .020	2.377	.502	.005 - .010	2.405	2.125	.010 - .025	2.449	1.970	.015 - .035	2.497	1.314	.040 - .060	2.500	.984	.070 - .090
2.369	.816	.015 - .030	2.377	1.512	.050 - .075	2.405	2.217	.040 - .060	2.450	1.192	.040 - .060	2.497	1.318	.080 - .105	<b>2.500</b>	<b>1.000</b>	<b>.005 - .010</b>
2.369	<b>1.701</b>	<b>.005 - .010</b>	2.378	.689	.040 - .060	2.407	.658	.100 - .120	2.450	2.133	.015 - .032	2.497	1.506	.020 - .040	2.500	1.000	.025 - .040
2.369	1.875	.050 - .070	2.378	<b>1.255</b>	<b>.005 - .010</b>	2.408	1.875	.020 - .040	2.450	<b>2.135</b>	<b>.005 - .010</b>	2.497	1.518	.030 - .050	2.500	1.014	.110 - .130
<b>2.370</b>	<b>.135</b>	<b>.005 - .010</b>	2.378	1.785	.025 - .035	2.410	1.908	.007 - .016	2.450	2.135	.020 - .030	2.497	<b>2.029</b>	<b>.005 - .010</b>	<b>2.500</b>	<b>1.020</b>	<b>.005 - .010</b>
<b>2.370</b>	<b>.246</b>	<b>.005 - .010</b>	2.378	1.800	.090 - .125	2.410	1.908	.020 - .035	2.450	2.140	.012 - .020	2.498	.188	.025 - .040	2.500	1.034	.036 - .050
<b>2.370</b>	<b>.510</b>	<b>.005 - .010</b>	2.378	1.997	.090 - .115	2.414	1.935	.025 - .040	2.451	.629	.010 - .020	2.498	.283	.025 - .040	<b>2.500</b>	<b>1.038</b>	<b>.005 - .010</b>
2.370	1.254	.110 - .130	2.378	2.000	.040 - .060	2.416	1.519	.040 - .060	2.451	<b>.814</b>	<b>.005 - .010</b>	2.498	.379	.005 - .008	2.500	1.062	.120 - .156
2.370	1.588	.090 - .105	2.379	.876	.060 - .080	2.416	1.911	.030 - .040	2.452	1.630	.060 - .080	2.498	.385	.020 - .040	2.500	1.130	.010 - .020
<b>2.370</b>	<b>1.681</b>	<b>.005 - .010</b>	2.379	1.505	.040 - .060	2.417	1.465	.050 - .070	2.453	1.565	.060 - .075	<b>2.498</b>	<b>.752</b>	<b>.005 - .010</b>	2.500	1.130	.040 - .060
2.370	2.001	.080 - .105	2.379	1.630	.010 - .030	2.418	1.873	.020 - .040	2.453	1.791	.075 - .095	<b>2.498</b>	<b>.755</b>	<b>.005 - .010</b>	2.500	1.150	.093 - .125
2.371	1.515	.050 - .070	2.380	.551	.080 - .105	2.420	1.873	.020 - .030	2.453	1.820	.060 - .080	2.498	1.062	.090 - .105	2.500	1.185	.110 - .125
2.371	1.865	.015 - .030	2.380	.670	.050 - .075	2.420	2.100	.020 - .030	2.453	1.828	.134 - .156	2.498	1.126	.090 - .120	2.500	1.192	.040 - .060
2.372	.418	.015 - .030	2.380	.870	.060 - .090	2.420	2.180	.020 - .035	2.453	2.050	.120 - .135	2.498	1.261	.060 - .080	2.500	1.262	.010 - .020
2.372	.866	.025 - .040	2.380	1.000	.040 - .060	2.421	2.125	.020 - .040	2.454	1.020	.015 - .030	2.498	1.359	.015 - .030	2.500	1.268	.050 - .070
2.372	.866	.040 - .060	2.380	1.250	.030 - .040	2.422	1.522	.110 - .130	2.454	1.827	.105 - .125	2.498	1.449	.070 - .090	2.500	1.272	.015 - .025
2.372	1.000	.025 - .040	2.380	1.632	.010 - .020	2.422	2.040	.100 - .125	2.460	1.726	.050 - .060	2.498	1.532	.110 - .135	2.500	1.279	.100 - .125
2.372	1.015	.100 - .125	2.380	1.649	.030 - .050	<b>2.422</b>	<b>2.215</b>	<b>.005 - .010</b>	2.462	1.727	.050 - .070	2.498	1.568	.020 - .050	2.500	1.295	.010 - .020
2.372	1.512	.050 - .075	2.380	1.997	.015 - .030	2.423	1.422	.005 - .008	2.462	1.940	.020 - .040	2.498	1.625	.010 - .020	2.500	1.311	.040 - .060
2.372	1.654	.040 - .060	2.380	2.020	.090 - .105	2.423	1.623	.030 - .050	2.468	.381	.105 - .135	<b>2.498</b>	<b>1.687</b>	<b>.005 - .010</b>	<b>2.500</b>	<b>1.346</b>	<b>.005 - .010</b>
2.372	1.990	.015 - .030	2.381	.328	.050 - .070	2.425	1.520	.040 - .060	2.469	1.270	.010 - .020	2.498	1.881	.020 - .030	2.500	1.392	.040 - .060
2.373	.193	.060 - .080	2.381	1.437	.025 - .040	2.425	1.552	.020 - .030	2.469	2.123	.010 - .020	2.498	1.910	.060 - .070	2.500	1.394	.040 - .060
2.373	.210	.030 - .050	2.381	1.552	.020 - .040	2.425	1.899	.010 - .020	<b>2.469</b>	<b>2.264</b>	<b>.005 - .010</b>	2.498	2.002	.005 - .015	2.500	1.500	.105 - .125
2.373	.630	.015 - .030	2.382	2.014	.105 - .125	2.427	1.187	.010 - .020	2.470	.502	.040 - .060	2.498	2.015	.050 - .070	<b>2.500</b>	<b>1.517</b>	<b>.005 - .010</b>
2.373	.642	.080 - .100	2.383	.881	.060 - .080	2.427	1.191	.050 - .070	<b>2.470</b>	<b>2.362</b>	<b>.005 - .010</b>	2.498	2.119	.060 - .080	2.500	1.523	.050 - .070
2.373	.876	.050 - .070	2.385	.254	.080 - .100	2.428	1.510	.050 - .070	2.472	.814	.125 - .135	2.499	.325	.060 - .080	2.500	1.529	.070 - .090
2.373	1.125	.025 - .040	2.387	1.366	.050 - .075	2.428	2.001	.020 - .030	2.473	2.000	.010 - .020	2.499	1.061	.050 - .070	2.500	1.561	.050 - .075
2.373	1.281	.030 - .045	2.388	1.701	.050 - .070	2.428	2.020	.042 - .060	2.475	1.351	.070 - .080	<b>2.499</b>	<b>1.270</b>	<b>.005 - .010</b>	2.500	1.606	.025 - .042
2.373	1.300	.040 - .060	2.390	1.120	.015 - .030	2.430	1.651	.010 - .020	<b>2.475</b>	<b>1.770</b>	<b>.005 - .010</b>	2.499	1.313	.105 - .135	2.500	1.624	.040 - .060
2.373	1.500	.050 - .070	2.390	1.188	.050 - .070	2.430	1.938	.010 - .020	2.477	1.968	.030 - .050	2.499	1.379	.060 - .070	<b>2.500</b>	<b>1.625</b>	<b>.005 - .010</b>
2.373	1.739	.015 - .025	2.390	1.328	.010 - .020	2.430	2.000	.020 - .040	2.477	1.968	.060 - .080	2.499	1.387	.060 - .080	2.500	1.625	.030 - .060
<b>2.373</b>	<b>1.912</b>	<b>.005 - .010</b>	2.390	1.328	.032 - .050	2.430	2.118	.015 - .025	2.478	1.230	.075 - .090	2.499	1.498	.025 - .040	2.500	1.635	.090 - .125
2.373	1.937	.030 - .050	2.390	1.850	.020 - .040	<b>2.430</b>	<b>2.121</b>	<b>.005 - .010</b>	2.478	1.230	.080 - .105	<b>2.499</b>	<b>1.749</b>	<b>.005 - .010</b>	2.500	1.750	.040 - .060
2.373	2.166	.040 - .060	<b>2.391</b>	<b>2.070</b>	<b>.005 - .010</b>	<b>2.431</b>	<b>2.090</b>	<b>.005 - .010</b>	<b>2.478</b>	<b>1.598</b>	<b>.005 - .010</b>	2.499	1.749	.010 - .020	<b>2.500</b>	<b>1.755</b>	<b>.005 - .010</b>
2.374	.346	.105 - .125	2.391	2.078	.040 - .060	2.431	2.091	.020 - .030	2.478	1.889	.020 - .040	2.499	1.757	.040 - .060	2.500	1.756	.105 - .125
2.374	.560	.040 - .060	2.393	1.100	.010 - .020	2.432	1.005	.015 - .025	2.479	2.100	.015 - .030	2.499	1.889	.010 - .020	2.500	1.759	.090 - .105
2.374	.625	.050 - .075	2.393	1.100	.030 - .050	2.432	1.267	.025 - .040	2.480	.750	.060 - .075	<b>2.499</b>	<b>1.952</b>	<b>.005 - .010</b>	2.500	1.770	.040 - .060
2.374	.900	.020 - .040	2.395	.813	.040 - .060	2.432	1.679	.040 - .050	<b>2.480</b>	<b>2.255</b>	<b>.005 - .010</b>	2.499	2.061	.015 - .020	2.500	1.777	.015 - .035
<b>2.374</b>	<b>1.066</b>	<b>.005 - .010</b>	2.395	1.435	.050 - .070	2.432	2.000	.005 - .015	2.481	1.673	.105 - .135	2.500	1.777	.035 - .062	2.500	1.777	.035 - .062
2.374	1.170	.030 - .060	2.395	2.000	.020 - .030	2.432	2.140	.020 - .030	<b>2.481</b>	<b>2.185</b>	<b>.005 - .010</b>	2.500	1.787	.040 - .060	2.500	1.787	.040 - .060
2.374	1.170	.090 - .134	2.396	2.099	.010 - .020	2.433	2.188	.010 - .020	2.482	2.142	.025 - .040	2.500	1.796	.070 - .090	2.500	1.796	.070 - .090
2.374	1.170	.134 - .187	2.396	2.099	.040 - .060	2.434	1.483	.030 - .050	2.482	2.150	.050 - .070	2.500	1.796	.120 - .156	2.500	1.796	.120 - .156
2.374	1.374	.050 - .070	2.396	2.151	.030 - .050	2.434	1.501	.050 - .075	2.485	1.055	.135 - .156	2.500	1.814	.010 - .020	2.500	1.814	.010 - .020
2.374	1.535	.040 - .060	2.397	2.024	.030 - .050	2.434	1.531	.030 - .050	2.487	1.015	.134 - .187	2.500	1.814	.020 - .031	2.500	1.814	.020 - .031
<b>2.374</b>	<b>1.811</b>	<b>.005 - .010</b>	<b>2.398</b>	<b>2.170</b>	<b>.005 - .010</b>	2.435	1.255	.125 - .156	2.487	1.425	.030 - .050	2.500	.100	.015 - .030	<b>2.500</b>	<b>1.820</b>	<b>.005 - .010</b>
2.374	1.811	.020 - .030	2.399	1.393	.080 - .105	2.435	1.900	.050 - .075	<b>2.487</b>	<b>1.635</b>	<b>.005 - .010</b>	<b>2.500</b>	<b>.144</b>	<b>.005 - .010</b>	2.500	1.889	.030 - .050
2.374	1.811	.030 - .050	2.399	1.560	.025 - .040	2.435	2.255	.010 - .015	2.489	1.748	.050 - .070	2.500	.144	.010 - .020	2.500	1.890	.020 - .030
2.374	1.990	.100 - .120	2.399	1.681	.025 - .040	2.435	2.263	.015 - .030	2.489	1.776	.015 - .020	2.500	.149	.080 - .090	2.500	1.900	.010 - .025
2.375	.139	.040 - .062	<b>2.399</b>	<b>1.713</b>	<b>.005 - .010</b>	2.436	1.750	.090 - .105	<b>2.489</b>	<b>2.002</b>	<b>.005 - .010</b>	2.500	.188	.090 - .105	2.500	1.945	.010 - .020
2.375	.165	.030 - .050	2.399	1.720	.035 - .050	<b>2.436</b>	<b>1.877</b>	<b>.005 - .010</b>	<b>2.490</b>	<b>1.436</b>	<b>.005 - .010</b>	2.500	.198	.010 - .020	2.500	1.945	.042 - .060
2.375	.280	.025 - .040	2.399	2.133	.050 - .075	2.437	1.257	.050 - .070	<b>2.490</b>	<b>1.853</b>	<b>.005 - .010</b>	2.500	.261	.100 - .135	2.500	1.954	.025 - .040
2.375	.375	.104 - .134	2.400	.505	.010 - .020	2.437	1.313	.040 - .060	2.490	1.980	.0						

**BOKER'S METAL WASHERS ARE FLAT AND TUMBLE DEBURRED**

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
2.501	2.137	.020 - .040	<b>2.565</b>	<b>2.434</b>	<b>.005 - .010</b>	2.624	1.781	.030 - .050	<b>2.640</b>	<b>1.630</b>	<b>.005 - .010</b>	2.840	2.540	.010 - .020	3.037	.820	.020 - .035
<b>2.502</b>	<b>.314</b>	<b>.005 - .010</b>	2.565	2.434	.010 - .020	2.624	1.791	.015 - .030	2.640	2.410	.030 - .050	2.843	.781	.010 - .015	3.047	1.795	.040 - .050
<b>2.502</b>	<b>.637</b>	<b>.005 - .010</b>	2.566	2.320	.040 - .060	2.624	1.958	.090 - .120	2.645	2.175	.030 - .040	2.843	2.538	.010 - .015	3.060	2.180	.040 - .050
<b>2.502</b>	<b>.771</b>	<b>.005 - .010</b>	2.571	.710	.080 - .100	<b>2.624</b>	<b>1.996</b>	<b>.005 - .010</b>	2.647	2.174	.020 - .040	<b>2.845</b>	<b>2.540</b>	<b>.005 - .010</b>	3.062	2.798	.025 - .035
2.502	1.500	.020 - .030	2.574	2.250	.010 - .020	2.625	.281	.080 - .104	2.655	1.137	.050 - .060	2.845	2.540	.020 - .040	3.063	2.372	.048 - .062
2.502	1.501	.080 - .100	2.575	.711	.040 - .060	2.625	.347	.100 - .125	2.657	2.219	.040 - .050	<b>2.850</b>	<b>2.370</b>	<b>.005 - .010</b>	3.065	1.560	.090 - .105
2.502	1.796	.070 - .090	2.578	1.025	.030 - .060	<b>2.625</b>	<b>.362</b>	<b>.005 - .010</b>	2.662	2.050	.040 - .060	2.850	2.650	.020 - .040	3.065	2.800	.040 - .050
2.502	1.999	.125 - .156	<b>2.578</b>	<b>2.076</b>	<b>.005 - .010</b>	2.625	.376	.050 - .075	2.665	2.055	.040 - .060	2.854	1.583	.010 - .020	3.066	2.550	.040 - .050
<b>2.502</b>	<b>2.273</b>	<b>.005 - .010</b>	2.579	2.060	.090 - .120	2.625	.383	.100 - .125	2.666	1.715	.040 - .060	<b>2.869</b>	<b>1.765</b>	<b>.005 - .010</b>	3.067	.901	.040 - .050
2.502	2.282	.025 - .040	2.580	1.381	.120 - .135	2.625	.385	.048 - .062	2.675	1.440	.040 - .060	2.869	1.900	.030 - .050	3.070	1.930	.020 - .040
2.503	.509	.010 - .020	2.580	2.137	.020 - .040	2.625	.469	.105 - .135	2.677	2.362	.030 - .050	2.870	1.780	.048 - .062	3.080	2.190	.040 - .050
2.503	.625	.040 - .060	2.580	2.196	.015 - .025	<b>2.625</b>	<b>.502</b>	<b>.005 - .010</b>	2.677	2.382	.060 - .080	2.871	1.316	.020 - .030	3.085	2.458	.060 - .080
2.503	1.578	.020 - .030	2.580	2.338	.020 - .040	2.625	.503	.015 - .030	2.677	2.440	.020 - .035	2.872	1.700	.010 - .020	3.090	1.650	.048 - .062
2.503	2.076	.070 - .090	2.583	.880	.040 - .060	2.625	.627	.090 - .120	2.687	1.635	.090 - .105	2.875	.755	.040 - .060	3.093	2.628	.020 - .040
2.504	.875	.100 - .120	2.585	.536	.110 - .130	2.625	.874	.050 - .075	2.694	2.081	.080 - .093	<b>2.875</b>	<b>1.500</b>	<b>.005 - .010</b>	3.094	2.000	.010 - .020
2.504	1.501	.050 - .070	2.586	2.031	.020 - .040	2.625	1.000	.060 - .070	<b>2.700</b>	<b>2.540</b>	<b>.005 - .010</b>	2.875	2.255	.020 - .040	3.099	2.757	.040 - .050
2.505	.145	.025 - .040	2.588	.391	.060 - .080	<b>2.625</b>	<b>1.020</b>	<b>.005 - .010</b>	2.713	2.380	.020 - .035	2.875	2.275	.030 - .050	<b>3.100</b>	<b>2.500</b>	<b>.005 - .010</b>
2.505	.195	.060 - .080	2.589	2.100	.040 - .060	<b>2.625</b>	<b>1.075</b>	<b>.005 - .010</b>	2.720	1.125	.020 - .040	2.880	2.263	.050 - .060	3.100	2.501	.030 - .050
2.505	.929	.050 - .070	2.590	.345	.105 - .125	2.625	1.315	.080 - .100	2.725	2.010	.035 - .050	2.883	2.000	.008 - .016	3.100	2.750	.030 - .050
2.505	1.413	.120 - .135	2.590	2.253	.050 - .070	2.625	1.413	.080 - .104	2.730	2.007	.020 - .035	<b>2.890</b>	<b>2.390</b>	<b>.005 - .010</b>	3.120	2.747	.040 - .060
2.505	1.416	.100 - .134	2.591	2.373	.020 - .030	2.625	1.516	.100 - .125	2.734	2.323	.020 - .030	2.895	2.420	.020 - .030	3.120	2.750	.010 - .020
<b>2.505</b>	<b>1.989</b>	<b>.005 - .010</b>	2.591	2.376	.015 - .030	2.625	1.531	.104 - .134	2.735	1.985	.030 - .040	2.900	2.010	.060 - .080	3.121	1.641	.048 - .062
2.507	.562	.050 - .070	2.595	1.580	.020 - .030	2.625	1.640	.010 - .025	2.735	2.000	.050 - .060	2.900	2.400	.010 - .020	3.123	2.151	.015 - .025
2.507	.562	.070 - .105	2.595	1.580	.060 - .080	2.625	1.640	.040 - .060	2.736	2.253	.010 - .020	2.900	2.400	.030 - .040	3.123	2.153	.010 - .020
2.507	.562	.105 - .125	<b>2.598</b>	<b>2.392</b>	<b>.005 - .010</b>	2.625	1.701	.025 - .040	2.740	2.200	.020 - .030	2.911	1.656	.040 - .060	3.125	.906	.080 - .090
2.507	2.310	.015 - .025	2.599	1.378	.010 - .020	2.625	1.781	.015 - .030	2.740	2.250	.010 - .020	2.915	2.643	.020 - .030	3.125	1.900	.048 - .062
2.511	.781	.040 - .060	2.599	1.387	.060 - .080	2.625	1.926	.050 - .075	2.742	1.728	.030 - .040	2.916	1.965	.040 - .060	3.125	1.902	.040 - .060
2.511	1.980	.030 - .060	2.600	.629	.010 - .020	2.625	1.998	.105 - .125	2.743	2.520	.030 - .040	2.919	1.257	.050 - .060	3.125	2.000	.020 - .040
2.515	.145	.015 - .030	2.600	.752	.015 - .030	<b>2.625</b>	<b>2.002</b>	<b>.005 - .010</b>	<b>2.745</b>	<b>.888</b>	<b>.005 - .010</b>	2.920	2.030	.050 - .060	3.130	.315	.105 - .125
2.515	2.218	.080 - .100	2.600	.753	.008 - .015	2.625	2.367	.040 - .060	2.745	2.345	.020 - .030	2.925	1.690	.040 - .060	3.138	1.566	.020 - .030
2.516	1.581	.070 - .090	2.600	.812	.005 - .020	<b>2.626</b>	<b>.440</b>	<b>.005 - .010</b>	2.747	1.400	.025 - .040	2.931	1.310	.040 - .060	3.149	.722	.090 - .125
2.516	1.683	.030 - .050	2.600	1.782	.020 - .030	2.626	.500	.104 - .134	2.749	1.376	.040 - .050	2.932	2.596	.010 - .020	3.175	2.700	.010 - .020
2.518	1.918	.040 - .060	2.600	2.120	.060 - .080	2.626	.895	.105 - .135				2.934	2.597	.060 - .070	3.181	2.230	.040 - .050
2.520	.354	.060 - .080	2.600	2.176	.018 - .031	2.626	1.516	.100 - .125				2.935	2.520	.020 - .030	<b>3.185</b>	<b>1.023</b>	<b>.005 - .010</b>
<b>2.520</b>	<b>.368</b>	<b>.005 - .010</b>	2.600	2.180	.018 - .030	2.626	1.532	.006 - .015				2.937	1.375	.040 - .060	3.191	1.955	.040 - .060
2.520	1.921	.020 - .030	2.600	2.300	.040 - .060	2.626	1.562	.015 - .025				2.937	1.500	.040 - .050	<b>3.195</b>	<b>1.260</b>	<b>.005 - .010</b>
2.520	2.121	.015 - .030	2.601	1.391	.070 - .090	2.626	1.577	.030 - .050				2.937	1.500	.050 - .060	3.195	1.355	.020 - .035
2.520	2.194	.050 - .070	2.602	1.378	.010 - .020	2.626	1.658	.060 - .090				2.937	2.640	.025 - .040	3.200	2.500	.010 - .020
<b>2.520</b>	<b>2.255</b>	<b>.005 - .010</b>	2.602	2.402	.030 - .050	2.626	1.745	.060 - .090				2.940	1.325	.048 - .062	3.200	2.500	.020 - .040
<b>2.522</b>	<b>1.921</b>	<b>.005 - .010</b>	2.603	1.250	.020 - .040	2.626	1.807	.025 - .040				2.945	1.994	.040 - .060	3.200	2.500	.030 - .040
2.523	2.040	.035 - .062	2.603	1.932	.050 - .070	2.626	1.825	.060 - .090	2.750	.505	.010 - .020	2.949	1.511	.040 - .060	3.200	2.500	.060 - .075
2.528	2.328	.020 - .030	2.603	2.180	.020 - .031	2.626	1.836	.060 - .080	2.750	.563	.090 - .125	2.950	2.229	.040 - .050	3.220	3.024	.020 - .030
2.530	1.251	.060 - .070	2.604	1.559	.050 - .070	<b>2.626</b>	<b>1.849</b>	<b>.005 - .010</b>	2.750	.628	.010 - .020	2.950	2.260	.020 - .040	<b>3.244</b>	<b>1.425</b>	<b>.005 - .010</b>
2.530	1.875	.060 - .080	2.605	1.685	.050 - .070	2.626	1.871	.010 - .020	2.750	.628	.020 - .030	2.955	1.719	.040 - .050	3.248	2.776	.010 - .015
<b>2.530</b>	<b>2.192</b>	<b>.005 - .010</b>	2.605	1.810	.050 - .070	2.626	1.933	.060 - .090	2.750	.760	.020 - .040	2.958	2.469	.040 - .060	<b>3.249</b>	<b>1.001</b>	<b>.005 - .010</b>
<b>2.530</b>	<b>2.316</b>	<b>.005 - .010</b>	2.607	2.015	.010 - .030	2.626	2.000	.015 - .030	2.750	1.200	.020 - .030	2.965	2.485	.020 - .040	3.250	.190	.010 - .020
2.531	2.331	.015 - .025	2.607	2.063	.050 - .070	2.626	2.000	.030 - .050	2.750	1.250	.010 - .020	2.967	.786	.040 - .060	3.250	.750	.010 - .015
<b>2.533</b>	<b>2.365</b>	<b>.005 - .010</b>	2.608	2.063	.025 - .040	2.626	2.074	.060 - .080	2.750	1.300	.020 - .035	2.977	2.330	.020 - .040	<b>3.250</b>	<b>1.013</b>	<b>.005 - .010</b>
2.534	2.087	.050 - .060	2.608	2.200	.035 - .050	2.627	.394	.010 - .020	2.750	1.635	.020 - .030	2.980	2.450	.010 - .020	<b>3.250</b>	<b>1.338</b>	<b>.005 - .010</b>
2.539	.301	.040 - .060	2.610	.513	.090 - .120	<b>2.627</b>	<b>.395</b>	<b>.005 - .010</b>	2.750	1.880	.020 - .040	2.986	2.230	.060 - .080	3.250	2.375	.030 - .050
2.540	1.528	.030 - .050	2.610	.513	.105 - .135	2.627	.500	.135 - .187	2.755	1.260	.035 - .045	2.997	2.187	.010 - .020	3.250	2.510	.020 - .030
2.541	1.939	.025 - .040	<b>2.610</b>	<b>2.262</b>	<b>.005 - .010</b>	2.627	1.266	.025 - .040	2.755	2.346	.025 - .035	2.998	2.380	.050 - .060	3.250	2.563	.010 - .020
<b>2.542</b>	<b>1.897</b>	<b>.005 - .010</b>	2.611	2.303	.030 - .050	2.627	1.296	.060 - .075	2.755	2.401	.010 - .020				3.259	2.694	.010 - .015
<b>2.548</b>	<b>2.213</b>	<b>.005 - .010</b>	2.612	2.300	.050 - .070	2.627	1.317	.060 - .080	2.755</								

O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To	O.D.	I.D.	Choose Any Thickness* From To
3.470	.705	.090 - .105	3.543	3.150	.015 - .025	3.889	2.315	.020 - .030	4.025	3.060	.040 - .060	4.380	3.375	.006 - .012	<b>5.000</b>		
3.481	2.415	.010 - .020	3.557	2.782	.010 - .020	3.900	2.700	.050 - .060	4.026	3.309	.050 - .060	4.402	2.778	.010 - .020			
3.482	2.703	.032 - .042	3.570	.259	.030 - .050	3.900	3.360	.020 - .040	4.055	1.299	.050 - .060	4.420	3.890	.020 - .030			
3.484	2.880	.035 - .048	3.575	1.020	.036 - .050	3.908	2.352	.020 - .040	4.065	3.275	.020 - .030	4.432	3.810	.020 - .035			
3.491	2.000	.010 - .015	3.586	3.275	.020 - .032	3.937	2.008	.015 - .025	4.095	3.858	.010 - .020	4.434	3.153	.010 - .015			
3.494	.636	.090 - .125	3.609	2.250	.025 - .040	3.937	2.362	.020 - .032	4.096	3.267	.010 - .020	4.435	.756	.050 - .070			
3.497	2.670	.060 - .080	3.609	2.500	.025 - .040	3.940	3.150	.050 - .060	4.120	2.549	.020 - .030	4.490	4.223	.030 - .050			
			3.625	2.030	.062 - .080	3.960	3.612	.030 - .050	4.120	3.150	.035 - .050	4.500	.504	.040 - .060			
			3.625	3.196	.020 - .030	3.987	1.891	.010 - .015	4.125	1.781	.040 - .050	4.500	2.500	.048 - .062			
			3.640	2.072	.020 - .040				4.125	3.750	.020 - .035	4.550	.243	.040 - .060			
<b>3.500</b>			3.647	2.346	.015 - .025	<b>4.000</b>			4.125	3.750	.020 - .040	4.570	3.870	.020 - .030	<b>For outside diameters up to 12" contact BOKER's at (800) 927-4377.</b>		
			3.647	2.346	.025 - .036				4.127	3.214	.048 - .062	4.623	4.328	.010 - .015			
			3.663	2.427	.040 - .060				4.130	.660	.020 - .030	<b>4.688</b>	<b>3.560</b>	<b>.005 - .010</b>			
			3.700	2.899	.040 - .060				4.150	3.576	.020 - .030	<b>4.688</b>	<b>3.879</b>	<b>.005 - .010</b>			
			3.733	3.332	.020 - .035				4.195	2.136	.010 - .020	4.700	3.865	.010 - .020			
3.500	.135	.015 - .025	3.750	.656	.090 - .105	4.000	.504	.040 - .060	4.200	3.505	.020 - .032	4.706	3.140	.020 - .030			
3.500	.504	.040 - .060	3.750	.875	.020 - .035	4.000	.690	.040 - .060	4.218	1.618	.020 - .040	4.710	3.873	.010 - .020			
3.500	2.030	.040 - .050	<b>3.750</b>	<b>3.015</b>	<b>.005 - .010</b>	4.000	1.010	.050 - .070	4.224	1.520	.020 - .032	4.720	3.884	.020 - .035			
3.500	2.250	.020 - .035	3.750	3.250	.035 - .045	4.000	2.000	.008 - .015	4.240	2.525	.020 - .032	4.730	4.083	.030 - .050			
3.500	2.500	.010 - .020	3.761	1.870	.030 - .050	4.000	2.281	.008 - .015	4.250	.780	.010 - .020	4.860	.390	.090 - .125			
3.500	3.060	.010 - .015	3.780	3.049	.020 - .040	4.000	2.530	.030 - .050	4.250	3.550	.050 - .060	4.860	4.350	.020 - .036			
3.500	3.125	.020 - .030	3.781	1.435	.030 - .050	4.000	2.562	.048 - .062	4.250	3.660	.015 - .025	4.860	4.600	.015 - .030			
3.500	3.158	.020 - .030	3.800	3.300	.020 - .035	4.000	2.577	.020 - .040	4.254	3.018	.040 - .050	4.875	3.018	.020 - .030			
3.500	3.158	.020 - .030	3.800	3.350	.020 - .040	4.000	2.780	.040 - .060	4.270	3.935	.020 - .040	4.935	4.763	.015 - .025			
3.500	3.250	.010 - .020	3.819	3.415	.040 - .060	4.000	3.000	.008 - .015	4.300	3.200	.020 - .040	4.950	4.393	.010 - .020			
3.503	2.702	.040 - .060	3.823	3.332	.030 - .040	4.000	3.000	.015 - .025	4.308	2.746	.020 - .040	4.960	4.260	.020 - .030			
3.511	3.207	.040 - .050	3.870	1.370	.020 - .032	4.000	3.410	.020 - .030	4.358	.485	.048 - .062	4.975	3.165	.025 - .040			
3.515	3.050	.050 - .060	3.874	1.642	.050 - .062	4.000	3.426	.020 - .030	4.368	3.273	.020 - .035	4.994	4.904	.020 - .040			
3.537	2.186	.020 - .040	3.875	1.150	.040 - .060	4.000	3.544	.015 - .025	4.375	4.083	.030 - .040						
3.537	2.280	.030 - .050	3.881	2.396	.050 - .060	4.015	3.572	.040 - .060	4.376	3.258	.025 - .040						

\*With BOKER'S precision metal washers, you can choose the exact thickness you want from the tool range listed. Tools indicated in **BOLD** can also be used for non-metallic materials – see page 3 for details.

**Call BOKER'S for precision stamping, assembly, and secondary operations.**

**New Tools Continually Added!**  
 For the most up-to-date list of washer sizes,  
 please visit [bokers.com](http://bokers.com)

# Your Source for Quality Stampings Too!

When your needs go beyond washers and spacers, Boker's is there to help you with full stamping capabilities. Backed by 94 years of experience in the stamping business, Boker's has developed the expertise necessary to produce the more complicated stampings with the same precision that goes into every one of your washers and spacers.



Draws up to 3" deep and 8" in diameter



Complex metal forming from .005" to .134" thick



Flat blanking and piercings up to 12" by 12"

Boker's has specialized in producing high quality metal stampings for over nine decades. Our precision manufacturing covers a complete range of sizes up to 12" x 12" (flat) with thicknesses from .005" to .134" and draws of up to 3" deep and 8" in diameter.

At Boker's, we utilize the latest stamping technologies and manufacturing concepts to continually provide you with stampings of the highest quality. This diligent effort to achieve and retain the highest quality possible in our metal stamping processes goes back to 1919.

Our process begins with our in-house tool department, where wire EDM-produced tooling provides the dimensional tolerances you require. Complete Statistical Process Control (S.P.C.) is available upon request to further assure accuracy throughout the manufacturing process. Our "Dock-to-Stock" capability saves you inspection time and is another example of our commitment to customer service. Boker's World Class Manufacturing also means we can meet your delivery requirements with flexible Just-In-Time (J.I.T.) programs.

## BOKER'S Web Site Makes Your Job Easier



### Boker's Bulletin

Your FREE online source for the latest news and offerings from Boker's. This electronic newsletter is sent out on a quarterly basis. To subscribe, go to [www.bokersbulletin.com](http://www.bokersbulletin.com)

### Credit Cards Accepted



### [www.bokers.com](http://www.bokers.com)

This complete catalog of washers and spacers is also available by accessing our Internet Site at [www.bokers.com](http://www.bokers.com). This electronic format makes finding the right size washer or spacer faster and easier than ever. You simply key in the desired size range by OD or ID and you get an immediate display of all available sizes in inch or millimeter measurements. There's nothing easier! Access our Web Site today!

Call Toll Free: 1-800-927-4377



3104 Snelling Avenue • Minneapolis, MN 55406-1937  
 Phone (612) 729-9365 • Fax (612) 729-8910  
 Call 1-800-WASHERS (1-800-927-4377)  
 Toll Free Fax 1-800-321-3462  
[www.bokers.com](http://www.bokers.com) • [sales@bokers.com](mailto:sales@bokers.com)



**BOKER'S Delivers Worldwide**

 **BOKER'S<sup>®</sup>, INC.**

3104 Snelling Avenue • Minneapolis, MN 55406-1937  
Phone (612) 729-9365 • Fax (612) 729-8910

Call 1-800-WASHERS (1-800-927-4377) • Toll Free Fax 1-800-321-3462

[www.bokers.com](http://www.bokers.com) • [sales@bokers.com](mailto:sales@bokers.com)